

Integrated Coordinate Geometry and CAD for Professional Engineers and Land Surveyors

Reference Manual



Tech Support: (218) 773-7966 • Fax: (218) 773-3849 • support@simsystems.com

PUBLISHED BY

Simplicity Systems, Inc. 1621 Second Avenue NE, P.O. Box 556 East Grand Forks, Minnesota 56721-0556

Printed and bound in the United States of America

Sales Telephone	(218) 773-8917
Fax	(218) 773-3849
E-mail	sales@simsystems.com
Internet	www.simsystems.com
Technical Support	(218) 773-7966
E-mail	support@simsystems.com

COPYRIGHTS

Software:

© 1995-2000 by Simplicity Systems, Inc., All Rights Reserved. Portions © 1994 by Crescent Software, Inc., All Rights Reserved. Portions © 1994 by Microsoft Corporation, All Rights Reserved. Portions © 1995 by Choice Computing, All Rights Reserved. Portions © 1995 by Pinnacle Publishing Inc., All Rights Reserved. Portions © 1995 by Apex Software Corp., All Rights Reserved. Portions © 1995 by VideoSoft, Inc., All Rights Reserved.

Documentation:

© 1995-2000 by Simplicity Systems, Inc., All Rights Reserved. Portions © 1995-98 by Choice Computing, All Rights Reserved.

ACKNOWLEDGMENTS

Programming Team: Stacy Hoggarth, Mark Floan, Shirl Vonasek, and Scott Hoggarth. Documentation by Mark Floan, Shirl Vonasek, and Choice Computing. Online Documentation by Stacy Hoggarth and Mark Floan. Surveying Consultant: Donald L. Floan, PE, RLS.

TRADEMARKS

"Sight Survey" TM, Survey 4.0 TM, Simplicity Systems TM, LegalEase TM, Collector Connector TM, Contour It! TM, and the Simplicity Systems logo are trademarks of Simplicity Systems, Inc. TrueCAD TM is a trademark of Choice Computing.

IBM ®, *PC/XT* ®, and *AT* ® are registered trademarks of International Business Machines Corp. *MS-DOS* ®, *Microsoft* ®, *Windows* TM, *Windows* 95 TM, *Windows* 98 TM, and *Windows* NT TM are trademarks of Microsoft Corporation.

All other products are trademarks or registered trademarks of their respective companies.

This software and documentation are subject to change without notice.

COPYRIGHT AND LICENSE AGREEMENT

This software is protected by both United States copyright law and by international treaty provisions. Therefore, you must treat this software just like a book.

By saying"just like a book", Simplicity Systems, Inc. means that this software may be used by any number of people and may be freely moved from any one computer location to another, as long as there is no possibility of the software being used at one location while it is being used at another. Just as a book cannot be read by two or more people in two different places at the same time, neither can this software be used by two or more people in two different places at the same time. To do so is a violation of copyright law.

This software may not be installed on any multi-user or LAN system without obtaining written permission and a site license from Simplicity Systems, Inc.

A site license may be purchased for each additional computer at the same location, including a multi-user network. Contact Simplicity Systems, Inc. for additional information.

LIMITED WARRANTY

This program, instruction manual and reference materials are sold"as is,"without any warranty as to their performance, merchantability, or fitness for any particular purpose. The entire risk as to the results and performance of this software is assumed by the purchaser.

However, to the original purchaser only, Simplicity Systems, Inc. warrants the magnetic media on which the program is recorded to be free from defects in materials and workmanship under normal use for a period of 90 days from the date of purchase. If within this period of 90 days the diskette should become defective, it may be returned to Simplicity Systems, Inc. for replacement, provided the purchaser has previously filed a warranty registration form.

Your sole and exclusive remedy in the event of a defect is expressly limited to replacement of the diskette as provided above. If the failure of the diskette has resulted from accident or abuse, Simplicity Systems, Inc. shall have no responsibility to replace the diskette under this limited warranty.

Any implied warranties relating to the diskette, including any implied warranties of merchantability and fitness for a particular purpose, are limited to a period of 90 days from the date of purchase. Neither the author nor the publisher of this software shall be liable for indirect, special, or consequential damages resulting from the use of this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

SUPPORT

Simplicity Systems, Inc. will provide support free of charge to registered users for a period of 90 days from the date of purchase, provided the user has returned a signed software registration form acknowledging his or her acceptance of the terms of the Copyright and License Agreement, Limited Warranty, and Support Agreement as previously stated herein. Furthermore, initial support will be provided without return of the registration form for a period of 10 days from the date of receipt of the software by the original purchaser.

Support for hardware related questions and problems, for software produced by manufacturers other than Simplicity Systems, Inc., and all support provided after the initial 90 day period will be billed to the caller at the rate of \$35.00 per incident. This rate is subject to change without notice.

Technical Support: (218) 773-7966 (8am-5pm Central) Fax: (218) 773-3849 • Email: <u>support@simsystems.com</u>

THE COPYRIGHT - English Translation You are guilty of theft if you...

- 1. Use a single copy of this software on more than a single machine at a time without first obtaining a site license agreement.
- 2. Use a site licensed copy of this software at any location other than the location for which a site license is granted.
- 3. Modify this software without first obtaining written permission from Simplicity Systems, Inc.
- 4. Attempt to unlock a demo version of this software without the permission of Simplicity Systems, Inc.
- 5. Copy any or all of this program manual without first obtaining written permission or a site license from Simplicity Systems, Inc.
- 6. Install this software on any multi-user or LAN system without obtaining a site license from Simplicity Systems, Inc.
- 7. Sell this software license to a third party without first destroying all archival copies of the disk and/or manual, and erasing all portions of this software from any storage device.

Any violation of the above constitutes copyright infringement and theft, and all violators will be prosecuted to the fullest extent of the law.

Technical Support

Phone: (218) 773-7966 (8:00am - 5:00pm Central Time)

Fax: (218) 773-3849

Email: support@simsystems.com

Table of Contents

Quick Start Manual

Section 1 - "Sight" Survey Basics

1.01	Introduction	19
1.02	"Site or "Sight"	19
1.03	Program Structure	20
1.04	What Version Do You Have?	20
1.05	The Reference Manual	21
1.06	Response Terminology	23
1.07	Message Icons	26
1.08	Routine Codes & Keyboard Shortcuts	26
1.09	Toolbars	27
1.10	Read Me Files	28
1.11	Changes from "Sight" Survey 2.0	28

Section 2 - Setup

Minimum System Configuration	
Do You Need a Site License?	33
Installation	35
Starting "Sight" Survey	36
Product Registration	38
Un-Installing "Sight" Survey	39
	Do You Need a Site License? Installation Starting "Sight" Survey Product Registration

Section 3 - Examples

3.01	Closed Traverse	42
3.02	Open Traverse	59
3.03	Subdivision Layout	69
3.04	Draw Building Location	
3.05	Least Squares Adjustment	137
3.06	Routine Index	153

COGO Reference Manual

Section 4 - Data Entry Basics

4.01	General Data Entry Procedures	155
4.02	Point Identifiers	155
4.03	Searching for a Point by Name	160
4.04	Point Ranges	162
4.05	Directional Entries	
4.06	The Reference Bearing	168
4.07	Horizontal Distance Entry	
4.08	The In-Line Calculator	
4.09	Vertical and Zenith Angles	173
4.10	Slope Entries & Slope Types	
4.11	Entering Coordinates	
4.12	Correcting Your Entered (Raw) Data	
4.13	Rounding Errors	

Section 5 - Windows Everywhere

5.01	"Sight" Survey's Main Screen	185
5.02	The Data Entry Window	186
5.03	The Text Output Window	188
5.04	The Drawing & Properties Windows	196

Section 6 - File Menu

197	6.01
198	6.02
199	6.03
201	6.04
201	6.05
202	6.06
203	6.07
209	6.08
209	6.09
210	6.10
214	6.11
214	6.12
20 20 21 21 21	6.08 6.09 6.10 6.11

6.13	Export PCoordinates	217
6.14	Export ∛Text	220
6.15	Copy Job	220
6.16	Delete Job	221
6.17	Last Used Job List	222
6.18	E <u>x</u> it (SY)	222

Section 7 - Edit Menu

	223
	224
	224
Paste CmV	
Edit Coordinates (EC) F12	. 225
Clear Text Output (CW)	227
Edit <u>O</u> riginal Raw Data (ER)	
	Cut_CutX Copy CutC Paste CutV Edit Coordinates (EC) F12 Clear Text Output (CW)

Section 8 - Points Menu

8.01	Enter and Assign (EA)	. 231
8.02	Enter Elevation (EZ)	232
8.03	Identify Point (ID)	233
8.04	Enter Station (ES)	234
8.05	Start At (ST)	235
8.06	<u>G</u> o To (GT) [´]	236
8.07	Enter Backsight Point (EP)	
8.08	Enter Backsight <u>B</u> earing (EB)	238
8.09	Point Plot (PP)	239
8.10	List Coordinates (LC)	. 242
8.11	Blan <u>k</u> Point Scan (BP)	. 243
8.12	Renumber Points (RP)	. 243
8.13	Copy Block of Points (CB)	. 245
8.14	Clear Coordinates (CC)	246
8.15	Clear Point Names (CN)	. 247
8.16	Clear Point Stations (CS)	
8.17	Define Figures (DF)	249
8.18	Edit Default Descriptions (AP)	

Section 9 - Lines Menu

9.01	Inverse (IN)	255
9.02	Field Data Inverse (FI)	256
9.03	Radial Inverse (RI)	
9.04	Deflection Inverse (DI)	259
9.05	Radial Stake Out (RS)	261
9.06	Side Shots (SS)	262
9.07	Offset (OS)	
9.08	Traverse (TR)	265
9.09	Traverse with Offsets (TO)	267
9.10	Traverse <u>C</u> lose (TC)	268
9.11		
9.12	Traverse Adjustment - Compass Rule	270
9.13	Traverse Adjustment - Crandall Rule	270
9.14		270
9.15	Traverse Adjustment - Least Squares Adjustment	271
9.16	Enter Diagonal (ED)	272
9.17	Inverse with Stations (IS)	281
9.18	Traverse with Stations (TS)	283
9.19	Traverse Right of Way (RW)	285
9.20	Best Fit Line (BF)	287

Section 10 - Curves Menu

10.01	Inverse <u>C</u> urve (IC)	289
10.02	Obtuse Curve (OC)	291
10.03	Three Point Curve (TP)	292
10.04	Inscribe Arc [®] Tangent from the PC	294
10.05	Inscribe Arc [®] Tangent from the PI	296
10.06	Inscribe Arc [®] Non-Tangent from the PC	297
10.07	Inscribe Arc [₽] Tangent from the PC with Offsets	298
10.08	Inscribe Arc [®] Tangent from the PI with Offsets	300
10.09	Inscribe Arc ₹Non-Tangent from the PC with Offsets	301
10.10	Traverse Arc (TA)	303
10.11	Traverse Arc with Offsets (AO)	305
10.12	Curve Offset (CO)	306
10.13	Best Fit Curve (BC)	308

Section 11 - Misc Menu

11.01	Intersections [®] Arc-Arc Intersection (AA)	309
11.02	Intersections To Arc-Bearing Intersection (AB)	311
11.03	Intersections There-Distance Intersection (AD)	313
11.04	Intersections Pagearing-Arc Intersection (BA)	316
11.05	Intersections To Bearing-Bearing Intersection (BB)	
11.06	Intersections >Bearing-Distance Intersection (BD)	319
11.07	Intersections PDistance-Arc Intersection (DA)	321
11.08	Intersections PDistance-Bearing Intersection (DB)	324
11.09	Intersections PDistance-Distance Intersection (DD)	326
11.10	Intersections Perpendicular Offset (PO)	
11.11	Intersections PDffset Intersection (OI)	329
11.12	Intersections PLine Station and Offset (LS)	331
11.13	Intersections The Arc Station and Offset (AS)	332
11.14	<u>A</u> rea [≥] y <u>A</u> rea Print Out (AR)	
11.15	<u>A</u> rea [®] <u>P</u> oint to Point Area (PA)	
11.16	Pre-determined Area (PD) [®] 2 Sides Parallel	339
11.17	Pre-determined Area (PD) ³ Line Through a Point	340
11.18	P <u>r</u> e-determined Area (PD) [®] <u>R</u> adial Sides	342
11.19	Pre-determined Area (PD) [®] 2 Lines <u>T</u> hrough a Point	344
11.20	Measure a Distance (MD)	346
11.21	Measure an Angle (MA)	
11.22	<u>C</u> oordinate Transformation (CT) [®] <u>R</u> otation Point and Angle Known	349
11.23	<u>C</u> oordinate Transformation (CT) [¬] > <u>T</u> wo Points in Each System Known	
11.24	<u>C</u> oordinate Transformation (CT) [®] <u>U</u> S Survey Feet to Meters	354
11.25	<u>C</u> oordinate Transformation (CT) [¬] >US Survey Feet to Int'l Feet	355
11.26	<u>C</u> oordinate Transformation (CT) [®] <u>M</u> eters to US Survey Feet	
11.27	<u>C</u> oordinate Transformation (CT) [¬] →Meters to International Feet	357
11.28	<u>C</u> oordinate Transformation (CT) [®] International Feet to Meters	358
11.29	Coordinate Transformation (CT) Plnternational Feet to US Survey Feet	359
11.30	Pop-up Calculator (PC)	360

Section 12 - Draw Menu

12.01	Snap Modes	368
12.02	Select Point (SP)	368
12.03	Select Distance (SD)	369
12.04	Select Bearing (SB)	370
12.05	CAD to COGO Get an Arc (GA)	371
	CAD to COGO NGet a Line (GL)	
12.07	CAD to COGO ♣Get a Point (GP)	375
12.08	CAD to COGO [®] →Get a Point Series (GS)	376
	CAD to COGO ₹Quick Pick CAD->COGO (QP)	

12.10	Draw Supplemental [®] Short Line Table (SL)	379
12.11	Draw Supplemental [®] Curve Table (CL)	379
12.12	Draw Supplemental Scale Bar	380
12.13	Draw Supplemental North Arrow	381
12.14	Draw Supplemental Coordinate List	381
12.15	Draw Supplemental Tocomponent Table	382
12.16	Label an Angle (AL)	383
12.17	Layer Override (LV)	382
12.18	CAD Paper in Landscape Orientation	385
12.19	Show Paper Border	385

Section 13 - Config Menu

13.01	Config Menu Basics	387
13.02	Text Output Configuration Menu	388
13.03	Slope Entry Configuration Menu	390
13.04	CAD Configuration Menu (CM)	392
13.05	COGO Configuration Menu	401
13.06	Angle Setup Configuration Menu	408
13.07	File Paths Configuration Menu	409
13.08	Customize Side Tool Bar	411
13.09	Adjust Screen Colors	414
13.10	Show Status Bar	416
13.11	Sho <u>w</u> Tool Bar	417
13.12	Check Registration	420

Section 14 - Utilities Menu

14.01	<u>C</u> ircular Curves (UA)	421
	Curve by Deflections (UB)	
	Curve by Tangent Offsets (UC)	
14.04	Curve by Chord Offsets (UD)	429
14.05	EDM Slope Reduction (UE)	431
14.06	Stadia Reduction (UF)	434
14.07	Spiral Curve Solution (UG)	436
14.08	Vertical Alignment (UH)	439
14.09	Universal Triangle (UI)	446

Section 15 - Add Ins Menu

15.01	Contour It! (CI)	449
15.02	Collector Connector	451
15.03	LegalEase (LE)	453

Section 16 - Windows Menu

16.01	User Arrangement #1 & #2	455
	Set User Arrangement #1 & #2	
	Cascade	
16.04	Tile	456
16.05	<u>1</u> Text Output, <u>2</u> Drawing, <u>3</u> Traverse, or <u>4</u> COGO Drawing Properties	457

Section 17 - Help Menu

17.01	Contents	459
	Current Topic	
17.03 17.04	Current <u>T</u> opic <u>S</u> earch for Help On <u>H</u> ow to Use Help System <u>I</u> nformation (SI)	460 460

Section 18 - Getting Support

18.01	Help!	463
18.02	Support Plans	464
18.03	Updates & Upgrades	466

Section 19 - Troubleshooting

19.01	Startup & Loading Problems	467
19.02	Helpful LegalEase Information	471
	Drawing, Printing & Plotting Problems	

Drawing Window Reference Manual

Section 20 - The Drawing Window

20.01 The Drawing Window	475
20.02 The Command Line	476
20.03 Scroll Bars & Sliders	476
20.04 The Status Bar	476
20.05 The Scale Bar	477
20.06 The Drawing Window Toolbar	477
20.07 The Start Menu Button	480
20.08 The Properties Menu Button	481
20.09 The Right Click Draw Menu	496

Section 21 - Accurate Placement

21.01	Jumps & Snaps	497
21.02	Precise Cursor Movements	502
21.03	Ortho Snaps	506
	Grids	
	Calculations	

Section 22 - File

22.01	New Drawing	509
22.02	Open Drawing	510
22.03		
22.04	Save Drawing	515
22.05	Save Drawing As	515
22.06	Save Settings	523
22.07	Load Symbol File	
22.08	Import ASCII Text	527
22.09	Import Bitmap	528
22.10	Export ASCII Text	530
22.11	Print	531
22.12	Zoom Print	536
22.13	Print Setup	540
22.14	Repair Drawing File (FD)	541
22.15	Purge Redundant Elements	544
22.16		545
22.17	Load Title Block	545

Section 23 - Edit

23.01	Undo (OO)	547
23.02		
23.03	Cut	548
23.04	Сору	549
23.05		550
23.06	Delete (DS)	551
23.07	Select	
23.08	Select by Polygon	558
23.09	Selection Filters (SF)	560
23.10		
23.11		
23.12		
23.13	Move to Front	569
23.14	Move to Back	570

Section 24 - View

24.01	Zoom Window (ZW)	571
24.02	Zoom Last (ZL)	
24.03		573
24.04	Zoom All (ZA)	
24.05	Zoom Sheet (ZP) (ZS)	
24.06	Zoom Scaled	
24.07	Zoom Selected	
24.08	Zoom View (Z# 0-9)	576
24.09	Define Zoom View (DZ)	
24.10	Magnify (MG)	
24.11	Demagnify (DM)	580
24.12	Pan (PN)	581
24.13	Long Pan (LP)	
24.14	Redraw (RD)	
24.15	Split Window	
24.16	Join Window	584
24.17	Clear Drawing Window (DX)	584

Section 25 - Draw

25.01	Line (Chained) (LI)	585
25.02	Lines (Pt to Pt)	586
25.03	Point	
25.04	Rectangle (DR)	
25.05	Arc 3 Point (AC)	589
25.06	Arc Radius	590
25.07	Circle (DC)	591
25.08	Circle Diameter	
25.09	Circle 2 Point	593
25.10	Line Arc Line	595
25.11	Parallel Line (DP)	
25.12	1 Parallel Element	
25.13	Around a Perimeter (PU)	
25.14	Ellipse	603
25.15	Part Ellipse	604
25.16	Circular Spline	
25.17	Cubic Spline (RC)	608
25.18	Polyline	
25.19	Polygon	
25.20	Symbol	
25.21	Sketch	615
25.22	Draw a Building Location	
25.23	Draw Perpendiculars	622

Section 26 - Modify

26.01	Stretch	623
26.02	<u>M</u> ove	625
26.03	Move Point	626
26.04	Mirror Image	627
26.05		
26.06	Repeat	631
26.07	<u>D</u> rop	634
26.08	Rotate	636
26.09	<u>T</u> rim	638
26.10	Fillet	
26.11	Chamfer	645
26.12		647
26.13	Join Lines	648
26.14	Cut and Rub	650
26.15		653
26.16	Move Selected to New Layer	655

26.17	Copy Selected to New Layer	657
26.18	Ellipse2Arcs	658

Section 27 - Annotate

27.01	Text Line Entry (TL)	659
27.02	Arc Text	663
27.03	Edit Text	664
27.04	Move Text	665
27.05	Scale Text	666
27.06	Change Text Parameters	
27.07	Set Alignment	668
27.08	Align	
27.09	Horizontal Dimension	672
27.10	Vertical Dimension	679
27.11	Slope Dimension	679
27.12	Angular Dimension	685
27.13	Radial Dimension	694
27.14	Survey Dimensions	697
27.15	Ordinate Dimension	698
27.16	Dimension Arc	701
27.17	Dimension Perpendicular	703
27.18	Edit Dimension Properties	705
27.19	Cut Dimension Line	707
27.20	Alter Dimension	708
27.21	Add Arrow	712
27.22	Add Balloon	
27.23	Add/Rem Text Bubble	715
27.24	Enter Hatch/Solid Fill	716
27.25	Adjust Existing Hatch	719
27.26	Draw All Hatch	721
27.27	Draw Selected Hatch	721
27.28	Hatch -> Lines	722
27.29	Label Coordinates	723

Section 28 - Tools

28.01	Jump to Grab All Cursor	727
28.02	Jump Grid	728
28.03		729
28.04	Jump Point	730
28.05	Jump Circle Center	730
28.06	Jump Near Element	731
28.07	Last Fixed	732
28.08	Mid Point Jump	733
28.09	Ratio Jump	733
28.10	Move to Coordinates	735
28.11	Polar Move	736
28.12	Show Nodes	737
28.13	Dump Data	738
28.14	Grid	747
28.15	Measure	748
28.16	Polygon Area	749
28.17	Query Entity (QE)	751
28.18	Tidy Polygons	754
28.19		760

Section 29 - Objects

29.01	Begin New Object	765
29.02	Group into Object	767
29.03	Explode Object	770
29.04	Show Objects	
29.05	List Objects	773
29.06	Make Symbol	774
29.07	Change Name	
29.08	Change Parent	783
29.09	Change Hook Point	784
29.10	Update Objects	785
29.11	Select Current Object	787
29.12	Blink Current Object	

Section 30 - Settings

30.01	Drawing Settings	789
30.02	Unit Settings	
30.03	View Settings	799
30.04	Re-Center Paper	803
30.05	Snap Mode	804
30.06	Change Magnify Factor	810
30.07	Line Defaults (XL)	810
30.08	Polyline Defaults	812
30.09	Parallel Defaults	814
30.10	Set Text Defaults (XT)	820
30.11	Dimension Defaults	826
30.12		
30.13	Set Arrow Defaults (XA)	832
30.14	Set Balloon Defaults	834
30.15	DXF/DWG Conversion Settings (XG)	835
30.16	Virtual Memory Settings	838
30.17	Layer Control (EL)	839
30.18	Set Current Layer (LV)	849
30.19	Set Visible Layers	850
30.20	Delete Layer	852
30.21	Working Layers	

Section 31 - Title Blocks

Drawing the Lines	855
Adding Text	860
Using Your New Title Block	
	Adding Text Grouping the Title Block Saving the Title Block

Section 32 - Hatches

Hatch Pattern Definitions		865
---------------------------	--	-----

Section 33 - Line Types

Line Type Definitions	7	7	
-----------------------	---	---	--

Index	8	381
-------	---	-----

This page intentionally left blank.

Pg. # < 155 – Quick Start Pg. 155-474 – COGO Reference Manual

Pg. # > 474 – Drawing Window Reference Manual

Section 1 "Sigi The Basics

1.01

ī

Previous Users of "Sight" Survey

Menu and toolbar

changes from "Sight"

Survey 2.0 are listed in

Section 1.11 on page 28.

Introduction

"Sight" Survey is a Windows based coordinate geometry program designed to provide you with simplified methods for solving any commonly encountered coordinate geometry and construction surveying problem.

"Sight" Survey contains several menus and provides numerous monitor prompts and help screens to guide you. You will be capable of running the routines contained in this package without the aid of the manual in a very short time. As each routine runs, all data inputs will be requested by screen prompts. As you enter data, the computer checks the responses for obvious errors, refusing most improper entries. This results in a collection of routines which actually guides you from beginning to end.

1.02

"Site" or "Sight"

We've already been chided about misspelling "Site" as "Sight", but rest assured it's intentional. Why? Because "Sight" Survey is a visual feedback program. Not content to show you a "connect-thedots" or "not-to-scale" view screen, "Sight" Survey's CAD engine actually presents your work graphically while you calculate your data!

However "Sight" Survey's CAD features are much more than a simple routine to show your computations graphically. The entire package is more like a well-orchestrated harmony of two different programs: COGO and CAD.

Using "Sight" Survey's CAD routines, you may:

- Draw and annotate lines, points, and arcs; ٠
- Set points;

- Select bearings and distances to be used as COGO data entries;
- Set line types, colors, and weights;
- Move, cut, copy and paste graphic elements;
- Place symbols and text;
- Select text fonts and colors;
- Import bitmaps or scanned images such as aerial photos or USGS quadrangles and overlay your computations on them;
- Import and export TrueCAD and AutoCAD drawings, and DXF files;
- Scale your drawing;
- Plot or print your drawing on any Windows compatible device.

1.03

Program Structure

"Sight" Survey is structured into two parts: The actual "Sight" Survey (COGO/CAD) section, which contains the routines most commonly used in field traverse programs; and the Utility section, which contains routines for the solution of curves, triangles, and slope reductions.

While the program runs in the Coordinate Geometry mode, you are allowed to access the Utility routines without any coordinate data loss.

What Version Do You Have?

Your "Sight" Survey program may have arrived as a **Demo**, or as a **Fully Functional** version. How can you tell? Well, if you ordered the program directly from Simplicity, and it's been less than 60 days since you received it, it's probably a full version.

It's Instantly Upgradable! But if it's a demo... The "Sight" Survey program disks are designed to allow you to copy and distribute them to anyone who might be interested in this program. Each and every disk copied, no matter what copy method is used, will be a **Demo** disk. If the user decides to purchase the program, they need only call the Sim-

1.04

	plicity Sales office at (800) 777-7978 or (218) 773-8917 and we can upgrade their disk to a full working version over the telephone. <i>Instant software, with no delay for shipping!</i>
How to Upgrade	To upgrade "Sight" Survey , you must first install it. Actual upgrading instructions may be found in Section 2.03.
"Sight" Survey Demo	The "Sight" Survey Demo allows access to the entire program. You will be limited to 25 data points and you will not be able to save coordinate files, import drawings, export data or drawings, or use your printer. Other restrictions may apply to the Utility pro- grams.
"Sight" Survey Full	The "Sight" Survey program allows access of the entire program with a point capacity of over <i>3.5 trillion</i> data points! You will also be able to save coordinate files, use your printer, and import and export data and drawings.

The Reference Manual

1.05

This "Sight" Survey manuals are designed to provide information in a clear, convenient format. As you page through the manual sections you will notice that the program's monitor prompts and the names of the routines are shown in **Bold Style Helvetica** letters. All prompts are followed by detailed instructions for each needed response. In cases where the manual indicates a specific response, the response is printed in **Bold Style Courier** letters.

The three **Reference Manuals** are organized by sections and include:

Quick Start Manual Section 1 - "Sight" Survey Basics	This section, which includes a general introduction, reference manual conventions, information regarding entering and leaving routines, terminology, jumping between windows, and using the pull-down menus.
Section 2 - Setup	Contains installation and setup information for this program.

	Section 3 - Examples	Contains keystroke by keystroke example solutions for: balancing a closed traverse; balancing an open traverse; and the development of a small subdivision. These examples illustrate the use of the majority of "Sight" Survey's COGO routines.
co	GO Reference Manual	
	Section 4 - Data Entry Basics	Contains information regarding basic and advanced types of data entry, including formats, angular entry, bearing and distance recalls, station entry, point number entry, setting points graphi- cally, and picking data from the drawing for use in data entry.
	Section 5 - Windows Everywhere	Contains information on "Sight" Survey's main screen and the three main program windows.
	Section 6 - Section 17 COGO Menu Functions	Contains information on "Sight" Survey's COGO commands, as well as information regarding "Sight" Survey's configuration options, and also the Utility programs.
	Section 18 - Getting Support	Contains the information you need in the event that you find it necessary to call Simplicity Systems for technical support. Our support hours are listed in this section, as are the numbers for contacting us by phone, fax, or Email.
	Section 19 - Troubleshooting	Contains information you may find helpful in the event that you encounter any unexpected problems while running "Sight" Survey.
Dra	wing Window Reference Manual	
Dia	Section 20 - The Drawing Window	Contains information regarding the elements of the Drawing window, including snaps, jumps, drawing properties, and the Drawing window toolbar buttons.
	Section 21 - Accurate Placement	Contains information on how to position the cursor accurately in the Drawing window, including polar moves, and moves to specific points or coordinates.
	Section 22 - Section 30 CAD Menu Functions	Contains information on "Sight" Survey's CAD functions, accessed through the toolbar or <u>Start (SM)</u> button menus.
	Section 31 - Title Blocks	Contains information on constructing, saving, and loading title blocks into "Sight" Survey.

Section 32 - Hatches	Contains information on "Sight" Survey's hatching patterns, and how you may construct your own hatch patterns.
Section 33 - Line Types	Contains information on "Sight" Survey's line types, and how you may program your own custom line types.
	The display illustrations shown throughout this manual may differ slightly from your actual displays. Screen captures for the manual were made while running Windows 95 and Windows 98. Also, "Sight" Survey was installed to drive E.
Three Manuals	As previously stated, the Reference Manuals consist of three volumes. The first book, Quick Start , contains Sections 1-3. The second book, the COGO Reference Manual , contains Sections 4-19. The third book, the Drawing Window Reference Manual , contains Sections 20-33.
	Each manual contains a Table of Contents , and an Index encompassing all three volumes.
1.06	Response Terminology
	Throughout this manual, you will see a variety of instructions for answering all of the various types of prompts. Some prompts will require a YES or NO answer, while others will be accompanied by instructions to ENTER your response. Still others will contain instructions for you to PRESS a key (either on the keyboard or with your mouse) in response to a given prompt. In an effort to simplify your operation of this program, the following guidelines apply to all the prompt responses for all "Sight" Survey routines.
ENTER vs. PRESS	When you encounter an instruction which requires you to ENTER data, the program expects you to press refier after the data has been entered. When you encounter the word PRESS, the program is indicating that it is expecting a single key press, or a series of key

response.

presses, in response. In these cases, do not press Finer after your

Mouse Clicks	Since "Sight" Survey is a Windows program, you can expect to see a number of references to your mouse. It used to be possible to say "click" or "right-click" your mouse button and everyone knew that "click" meant the main mouse button, located directly under your index finger on your right hand. Now that a mouse may come with left hand configurations or software for configuring a right-hand mouse as left handed, "click" takes on a slightly altered meaning, no longer referring to the left button, but simply the main mouse button, still located under your index finger. (Unless you are using a right handed mouse configuration with your left hand.)
	When you are asked to click your mouse, click once on the main mouse button, located under your index finger. Right- click means to click once on the secondary mouse button. "Double-click" simply means two clicks in rapid succession.
YES or NO	This type of prompt requires only that you press \mathbf{Y} to answer in the affirmative, or \mathbf{N} to answer in the negative.
	You may also use your mouse to answer "Yes or No" questions. To answer Yes, click on the Yes button. To answer No, click on the No button.
Keyboard Responses	In this manual you will occasionally see KEYCAP responses which indicate that you should press the key or keys shown. When you see keycaps shown in combination (but not with an end key) such as Atten, press the first key and hold it down while pressing the second key.
	In most cases, pull-down menu items may also be selected from the keyboard. This type of selection will be depicted in some form of this manner: $Att E, \bigcirc$ or $Att E, \bigcirc$. To respond to this type of entry, press the first key and hold it down while pressing the second key, then release the keys and press the next key (or keys) in succession. <i>DO NOT press the</i> \neg <i>key</i> .
	When a combination includes an <i>venter</i> key, such as <i>eventer</i> , press

and release the keys shown in succession.

	Even though the key presses and responses within this manual may be shown in capital letters, lower case data entry is acceptable.
Button Responses	You will also see graphic representations of Windows response buttons, such as <u>Accept</u> . Activate a response button in one of two ways: either by clicking your mouse on the button, or (in this example) by pressing <u>Alt</u> A, <u>"Enter</u> , where the letter following the <u>Alt</u> key corresponds to the underlined letter on the button.
Accessing Menus	Menus are accessed using the keyboard or your mouse. To access any of the menus, either click on the menu name or press (for ex- ample) ARE , where the letter following the AR key corresponds to the underlined letter on the menu name. In this case, the File menu would have been opened.
	Once a menu has been opened and you are presented with a list of routines, simply click on a routine or press the letter corresponding to the underlined letter in the routine name.
	If you see a menu item with a right arrow $(_{e})$ on the right end of the line, selecting that item or simply using your mouse to move the highlight bar over the item will result in the opening of a submenu. Select items from any sub-menu in the same manner as you would select an item from a main menu.
Depicting Menus in the Manual	In this manual, menus and sub-menus are depicted in the following manner: Menu ³ →Sub-menu 1 ³ →Sub-menu 2.
	The manual uses the symbol \textcircled to indicate items in a menu structure. For example, the function Get an Arc is on the CAD to COGO sub-menu of the Draw menu. To get to this function you select the Draw menu (with your mouse or by pressing Alt D), then the CAD to COGO item (with your mouse or by pressing G). Finally you would select the Get an Arc function (with your mouse or by pressing A). In the manual, the location of the function is shown as: Draw \textcircled CAD to COGO \textcircled Get an Arc .

Message Icons

Throughout the manual, you will see various messages preceded by a message icon. The icons are:

¥ WARNING	¥
	(i
HINT	and
REFER TO	()
3 <i>IMPORTANT NOTE</i>	3
SHORTCUT	$\boldsymbol{\times}$

1.08


Routine Codes & Keyboard Shortcuts

If you've ever used a Simplicity Systems COGO program before, you're probably very familiar with our two letter routine codes. While most all of the routine codes we've used in the past have been retained, a few have been altered, and more have been added. In addition, the Windows menu system adds a considerable number of keyboard shortcuts. Of course you may always use your mouse , but if you can rember the keyboard shortcuts and routine codes you will be able to operate "Sight" Survey faster than navigating with the mouse alone.

Where routine codes are available for a particular function, the codes are indicated next to the menu item for that function. Routine codes are also listed in the manual discussion for each individual function.

Toolbars

Throughout this manual, you will see instructions to click on toolbar icons. It is important that you know where to find the referenced toolbar. "Sight Survey" has three toolbars: the Main toolbar, a horizontal bar running along the top of the screen; the Drawing window toolbar, a vertical bar on the left side of the Drawing window; and the User Customizable toolbar, in the Data Entry window. The toolbar locations are shown below:



Depending upon your screen resolution setting, the **Drawing** window toolbar may be formatted in one, two, or three columns.

1.09

1.11

Read Me Files

Quite often, software manufacturers will place a file on their disk(s) which contains information regarding software version updates and features not described in the manual. These files are typically named ReadMe.Txt, ReadMe.Doc or just Read.Me. It's a good idea to always directory your software to determine if the disk contains a "Read Me" file.

The easiest way to read a "Read Me" file is to load the file into the Notepad or Write program in Windows 3.1, or into the Wordpad program in Windows 95/98. From any of these programs, you can scroll through "Read Me" files or print them to have a paper copy.

Changes from "Sight" Survey 2.0

"Now where did that go?"	As we incorporated new buttons and menus into "Sight" Survey, it became inevitable that we had to move some things around. We tried to keep changes to a minimum, and we tried to make only changes that seemed logical. For example, a number of drawing related items were moved from the pull-down menus to the new CAD menus. Makes sense, right? But it still may be aggravating when you can't find what you are looking for.
	If you didn't use the menus, instead relying on keyboard shortcuts and routine codes, you're in luck! We didn't change the shortcuts.
	As for menu items and toolbar buttons well, that's a different story. Here is your guide to "Sight" Survey's changes:
The File menu:	New becomes New Job
	Open becomes Open Job
	Save becomes Save Job
	Save As becomes Save Job As
	Save Settings has moved to Start ♣ File ♣ Save Settings

	Import [™] Drawing has moved to Start [™] File [™] Load Drawing This routine will import an AutoCAD .dwg or .dxf file.
	Export Drawing has moved to Start File Save Drawing As This routine will export a drawing to the AutoCAD .dwg or .dxf format. To save a drawing as a .dwg or .dxf format, you must select the appropriate file type from the Save file as type selection box in the lower left of the Save dialog box, and then type in filename with the desired filename extension.
	Import ⅔Bitmap has moved to Start ⅔File ⅔Import Bitmap
	Import ऄTitle Block has moved to Start ऄFile ऄLoad Title Block
	Export ♣ Title Block is replaced by Start ♣ File ♣ Save Drawing
	Repair Drawing has moved to Start To File To Repair Drawing File
The Edit menu:	The Edit menu items are unchanged.
The Points menu:	The Points menu items are unchanged.
The Lines menu:	The Lines menu items are unchanged.
The Curves menu:	The Curves menu items are unchanged.
The Misc menu:	The Balance Traverse sub-menu, along with sub-items: Traverse Closure (TC) ; Adjust Traverse (AT) ; and Re-Run Adjusted Traverse has been deleted since balancing is a part of Traverse Closure . The two-letter commands still work.
	Label an Arc (AL) has been renamed Label an Angle and has moved to the Draw menu. The two-letter command is still AL.
	LegalEase has been moved to the Add Ins menu.
The Draw menu:	Edit Selection Filter has moved to Start Selection Filters
	Edit To Cut has moved to Start To Edit To Cut
	Edit To Copy has moved to Start To Edit To Copy
	Edit Paste has moved to Start PEdit Paste

Edit > Delete has moved to Start > Edit > Delete

- Edit The Change Text Properties (XT) has moved to Start The Settings The Set Text Defaults
- Edit The Change Line Properties (XL) has moved to Start The Settings The Line Defaults
- Edit Nove Objects to New Layer (XY) has moved to Start Nodify Nove Selected to New Layer
- Edit The Edit Layers (EL) has moved to Start The Settings The Layer Control

Point/Symbol (PS) has moved to Start > Draw > Symbol

Line (LI) has moved to Start ⇒ Draw ⇒ Line (Chained)

Circle (DC) has moved to Start ⇒Draw ⇒Circle

Arc (AC) has moved to Start → Draw → Arc 3 Point

Rectangle (DR) has moved to Start → Draw → Rectangle

Random Curve (RC) has moved to Start > Draw > Cubic Spline

Text (TL) has moved to Start > Annotate > Text Line Entry

Break Line (BL) has moved to Start > Modify > Divide/Extend

Leader Line & Arrow Create (AW) has moved to Start The Annotate The Add Arrow

Leader Line & Arrow Setup (XA) has moved to Start >> Settings >> Set Arrow Defaults

Parallel Lines Parallel to Selection (DP) has moved to Start ⅔ Draw ⅔ Parallel Line

Parallel Lines Around a Perimeter (PU) has moved to Start ⅔ Draw ⅔ Around a Perimeter

Query Entity has moved to Start Tools Tools A Query Entity

Zooms [¬]→Zoom All (ZA) has moved to Start [¬]→View [¬]→Zoom All

Zooms > Zoom Last (ZL) has moved to Start > View > Zoom Last

Zooms [¬]>Zoom Window (ZW) has moved to Start [¬]>View [¬]>Zoom Window

Zooms [™]→Zoom Page (ZP) has changed to Start [™]→View [™]→Zoom Sheet (ZS) (Note: ZP still works)

	Zooms The Magnify (MG) has moved to Start The View The Magnify
	Zooms ➡ Demagnify (DM) has moved to Start ➡ View ➡ Demagnify
	Center Paper has moved to Start >> Settings >> Re-Center Paper
	Redraw (RD) has moved to Start ⅔ View ⅔ Redraw
	Cancel/Done has been eliminated
The Config menu:	Drawing Configuration Menu has changed to CAD Configuration Menu
	Properties has moved to the <u>Properties (PR)</u> button at the top of the Drawing window
	Conversion Settings (XG) have moved to Start ✤ Settings ✤ DXF/DWG Conversion
	CAD Paper in Landscape Orientation has moved to the Draw menu
The Utilities menu:	The Utilities menu items are unchanged.
The Add Ins menu:	Make Contour Lines has been renamed Contour It!
	LegalEase has been moved here from the Misc menu
	Transfer Record (Landmark) has been deleted due to a change in their program format.
The Window menu:	Default Arrangement #1 has been replaced by User Arrangement #1
	Default Arrangement #2 has been replaced by User Arrangement #2
Main Toolbar Buttons	Many of the Main toolbar buttons have been enhanced to include right-click functions. The new button functions are described in Section 13.11 .
	The following buttons have been moved to the Drawing window toolbar: Delete ; Undo ; Redo (right-click the Undo button); Zoom Page (right-click the Redraw button); Zoom All (right-click the Zoom Menu button); Zoom Window ; and Redraw . Additionally, the Properties toolbar button has been replaced by the Properties (PR) button at the top of the Drawing window.

32 "Sight" Survey Basics

This page intentionally left blank.

"Sight" 3.0 Section 2 Survey 3.0 Setup

Minimum System Configuration

To function effectively, "Sight" Survey must run on a computer capable of running Windows 95/98 or NT.

Required Items:

- 1. Windows 95/98/NT;
- 2. 64 Mb of RAM;
- 3. One 3¹/₂" high-density floppy drive (or CD-ROM drive);
- 4. A hard drive with at least 10 Mb of free space;
- 5. A VGA (or higher resolution) display adapter;
- 6. A mouse, or compatible pointing device.

Optional Hardware:

- 7. A dot matrix or laser printer;
- 8. A plotter.

Do You Need A Site License?

Your purchase of "Sight" Survey is nothing more than a license to run the "Sight" Survey program on a single computer. You may need an additional site license if you plan to:

- □ Install "Sight" Survey on more than one computer at your place of business;
- □ Install "Sight" Survey on a home computer;
- □ Install "Sight" Survey on a field computer;
- □ Install "Sight" Survey on a network computer or server;
- □ Have "Sight" Survey available at temporary field office sites within your company.

2.02

2.01

	The best rule to follow is: <i>If there is any probability that a single copy of "Sight" Survey will be running on more than one computer at a time, an additional site license is required!</i>
The "Transportable" License	Realizing that you may not always perform your job entirely in the office, the "Sight" Survey license is a "Transportable" license which allows you to copy the "Sight" Survey program to your home computer and use it there for no additional fee, provided that "Sight" Survey is used in accordance with the copyright. In other words, you may use "Sight" Survey under the "Transportable" license only when you are certain that no other licensed copies of "Sight" Survey are running at the same time.
	If the "Sight" Survey license was originally purchased by a Com- pany, and the Company has multiple owners, the license extends to one owner only. The Company must purchase site licenses in or- der for additional owners and/or their employees to have a legal copy of "Sight" Survey on their home computers. The purchasing Company retains ownership of ALL licenses of the programs.
	The "Transportable" license may also be used to allow "Sight" Survey to be loaded on a portable field computer instead of, <i>or in</i> <i>addition to</i> , a single home computer, <i>if the user can guarantee that</i> <i>only a single copy of "Sight" Survey is running at a time.</i>
Multiple Office Installations	The "Sight" Survey license covers only a single site, i.e. building or address. <i>If you have multiple locations, each location is ex-</i> <i>pected to purchase their first license at full cost,</i> with subsequent purchases for each location in accordance with the established site licensing fees.
Network Installations	If "Sight" Survey is loaded on a <i>network</i> computer, either a server or a node, a site license may be needed. If the network administra- tor limits access to "Sight" Survey to a single user at any one time, a site license is not needed. However, if "Sight" Survey is avail- able to more than one networked computer at a time, at least one additional site license is required. The number of site licenses re- quired is based on the number of computers likely to be using "Sight" Survey <i>concurrently</i> , not necessarily the total number of computers on the network.

Site Licensing Fees

A site license granting you permission to make an additional copy of this software and manual is available at a cost of approximately **50% of the full version price**, **per computer licensed**. An extra manual and disks may be purchased at an additional cost. Prices are subject to change without notice. Call for verification.

2.03

Installation

"Sight" Survey may only be installed to a hard disk containing at least 10Mb of free space. To install "Sight" Survey, you must begin by loading Microsoft Windows. To simplify the installation instructions, we will assume that you are logged to drive $C:\gg$ and your floppy disk is drive $A:\gg$.

Place the "Sight" Survey Disk 1 into your floppy drive.

For Windows 95/98/NT users, use your mouse to select <u>Start</u> [™] <u>Run</u> (or press <u>Att</u> <u>S</u>, <u>R</u>) and type <u>A:SETUP</u> <u>-Enter</u>.

USING THE MICROSOFT INTELLIMOUSE

If you are installing "Sight" Survey on a computer equipped with the Microsoft Intellimouse (the mouse with a wheel) you may have to disable the mouse driver during the installation. The mouse driver may conflict with the installation program and may cause the program to hang. Once installed, "Sight" Survey will run just fine with the Intellimouse.

To disable the Intellimouse, press Ctrl Alt Delete In the Close Program window that appears, click on MSWheel and then click the End Task button.

Reboot your computer after installing "Sight" Survey and your Intellimouse will once again be running normally.

Step 1.



2.04

Į	If you are installing "Sight" Survey from a CD-ROM, simply insert the CD into the drive, and the startup program will run automatically.
Step 2.	Follow the installation instructions that appear on your display. We strongly recommend that you accept the default directory structure, (but not necessarily the disk drive), presented in the in- stallation program.
Step 3.	After the installation is complete, store the original "Sight" Survey disks in a safe place.
Step 4.	After you've finished the installation procedure, your computer will automatically create a Simplicity Systems program group containing the "Sight" Survey program and the Utility programs.
Step 5.	View the original <i>"Sight" Survey Last Minute Changes</i> file by clicking on the icon in the Simplicity Systems group.

Starting "Sight" Survey

You may start "Sight" Survey in a wide variety of ways, just as you may for any Windows program. This manual will touch on the most common start-up methods for both Windows 3.1 and Windows 95/98/NT.

Windows 95/98/NTAtter a moment, the Program List appears.
Point to Simplicity Systems. After a moment, the Simplicity Systems Program Group List appears.
Point to "Sight" Survey 3 and click your mouse once.

Shortcut Method: First you must create a shortcut for "Sight" Survey.

If you wish to create a shortcut on your **Desktop** for *"Sight" Survey* we recommend that you do it immediately after installing the program, while the **Simplicity Systems Program Folder** is displayed on the screen. Click and hold the right mouse botton on the "*Sight*" *Survey* 3.0 icon while you drag it to the **Desktop**. Release the mouse button when the icon is over the **Desktop**, and select **Create Shortcut(s) Here**. You may now use the mouse to drag shortcut to a convenient location on the **Desktop**. If you would like to create icon later please use the following instructions.

3

If you are not familiar with the Windows Desktop and the Windows Explorer, please consult your Windows documentation for instructions before attempting this procedure.

- 1. Click on the Windows **Start** button. Point to **Programs**. After a moment, the **Program List** appears. Point to **Windows Explorer** and click your mouse once.
- Use the Explorer to move to the folder containing the "Sight" Survey program. This folder will usually be named SightSrv, unless you change it during "Sight" Survey's installation.
- To create a shortcut to "Sight" Survey, simply click and hold your right mouse button on the file SightSrv.Exe and drag the item from the Explorer to the Desktop.
- When you release the mouse button, the shortcut to "Sight" Survey will be located on the Desktop. Close the Explorer. You may now use your mouse to drag the shortcut icon to a convenient location on the Desktop.
- 5. To launch "Sight" Survey from the shortcut icon, double-click your mouse on the icon.


Keyboard Method: Press Att S, P to open the <u>Start Run</u> dialog window. Type C:\SightSrv\SightSrv into the filename box and press Fire. (If necessary, change the drive letter and directory name to match your installation.)

Product Registration

If "Sight" Survey has been installed as a demo, you'll need to go through the upgrade procedure to realize the full potential of "Sight" Survey. Upgrading is a fast, easy procedure that begins by selecting the <u>Check Registration</u> item under the <u>Config</u> menu. To select this item, use your mouse or press <u>Att</u>[G], C], C], <u>Ener</u>. If you access the <u>Config</u> menu and you don't see a <u>Check Registration</u> item, it simply means that your copy of "Sight" Survey has already been registered.

You will be asked to provide or verify your name, company name, address and telephone number. This information, or at least portions of it, must be provided or the registration program will fail. The information provided is used in two places. Your name and/or company name will automatically appear on your job printouts, but more importantly, the information entered is used to prepare your product registration form for you. Once you have entered and/or verified your data, click on **Accept**, or press Alt A. You will be asked if your data is correct. If it is, click **Yes**, otherwise click **No**.

If your copy of "Sight" Survey is a demo version, you will see the **Activation Number** screen.



Call Simplicity Systems at (800) 777-7978 or (218) 773-8917 and report your upgrade code number which is shown in the dialog box. If you have not yet paid for your purchase, you will also be asked for a credit card number. You will then be given an Activation Number to enter in the data field at the bottom of the dialog

2.05

box. Once you have typed the number, click on \underline{Accept} , or press $\overline{Alt}[A]$, or just press $\overline{-Enter}$.

If your upgrade attempt is successful, you will see the screen shown below.

Congrat	ulations 🛛
٩	Your new registration file has been written. Your copy of "Sight" Survey is now fully functional but you should print and return the registration form. Would you like to print the registration form now?
	Yes No

At this point, we strongly suggest that you print the registration form, sign it, fold it, stamp it and mail it in. It's a quick and simple task that you are strongly urged to complete.

Product registration is important for many reasons. It provides us with updated information so that we may contact you with upgrade information, etc. *But perhaps most important is that we will not provide support for unregistered software*.

Un-Installing "Sight" Survey

"Sight" Survey may be easily uninstalled from your computer by running the "*Sight" Survey Setup* program from the Simplicity Systems menu. Run the setup program and select the Un-Install "Sight" Survey option.

When you uninstall "Sight" Survey, your registration is written to a floppy disk for reinstallation at a later time. You will be prompted to insert a "Sight" Survey program disk at the appropriate time.

If you need to move "Sight" Survey from one computer to another, uninstall the program to the original disk set, and then re-install it on the new computer. If "Sight" Survey was properly removed, it will re-install as a full working copy. You should not have to call Simplicity for a new unlocking number. 40 Setup

This page intentionally left blank.

"Sight" 3.0 Section 3 Survey 3.0 Examples

The following examples will acquaint you with "Sight" Survey features that are shared among most procedures. They serve only to demonstrate certain procedures, and are not intended to demonstrate the most efficient means of using "Sight" Survey. The knowledge you gain by working through these examples should enable you to easily manipulate all of the "Sight" Survey routines. All routines used herein have been listed in the Routine Index at the end of this section. Each example is accompanied by an illustration indicating the point numbering and known data used in the problem. Example 1..... Pg. 42 This example illustrates the closure and balancing of a closed traverse, including: error correction; angle balancing; Compass Rule adjustment; Crandall Rule adjustment; and comparing adjustments. Example 2 Pg. 59 This example illustrates the closure and balancing of an open traverse, including angle balancing and Compass Rule adjustment. Example 3 Pg. 69 This example involves fitting an actual subdivision into an area bounded by three known points. The example is a small seven lot subdivision called Oakwoods Subdivision. Example 4..... Pg. 123 This example illustrates the Draw Building Location command used to locate a building from ties to two lot corners. Example 5..... Pg. 137 This example illustrates the closure and balancing of a closed traverse using Least Squares. Routine Index Pg. 153 Contains an index to the routines used in these examples. Only the first usage of any particular routine is indexed. **Operational Note:** Throughout the examples, the instructions tell you to click on the Properties (PR) button to open and close the Properties window. The **Properties** window doesn't actually get closed, it simply gets moved to the background behind any other displayed windows. If the

Properties window is located on the screen such that another window does not overlap it, then when you click the <u>Properties (PR)</u> button, the window will not disappear, it will simply no longer be the "active" window.

Example 1: Closed Traverse

This example sets traverse points using the Enter & Assign (EA) and Traverse (TR) routines. All distances used for the purpose of corner establishment are horizontal.

Begin by loading the "Sight" Survey program.

PROMPT

RESPONSE / NOTES / ETC.

Traverse: From Point

When the "Sight" Survey program appears, press AtG, T to access the <u>Text Output Configuration Menu</u>. In order for your prompts and printed output to follow this manual, you must set your configuration options to match the following menu screens before running the rest of this example.

Configuration Screen		×
Printed Precision Prin Prec Area: Prn. Prec Bras:	CAD COGO Angle Setup File Path Printing Options Fire Think Input Data	21
Prn. Prgo. Crds: Prg. Prec Dist Prn. Prec Ejev:	5 IF Print Point Descriptions 3 IF	
<u></u> K	Cancel Help	

After setting your <u>Text Output</u> configuration, press <u>Att</u> to access the <u>Slope Entry Configuration Menu</u>.

3.01

Configuration Screen	×
Iext Output Slope Entry CAD	COGO Angle Setup File Paths
Slope Type Prompt for slope input Stadja Stadja Stadja C Single Slope Angles C Leveling C Total Stations EDM (Mining Option) C Assigned Elevations EDM Options Difference in H.I.'s of the EDM and EDM -H.I. of Theod.) Difference in H.I.'s of the prism and H.I. of Prism - H.I. of Target)	
<u>D</u> K	<u>C</u> ancel <u>H</u> elp

After setting your <u>Slope Entry</u> configuration, press At to access the CAD Configuration Menu.

Configuration Screen		×
Iext Output Slope Entry	CAD COGO Angle Setup File Paths	
Paper Size / Scale 1 foot = 6000 feet A 8.5x11" Cad Background Color	CAD Units Page Center C Ecet North 10700 C Inches East 10700 White	
Printed Prec Bng: 1 CIds: 5	C Shrink text to fit along line C Create a short line table	
Dist: 2 -	Padding Option Pad with space Label Offset 6.0 Beset DS Lavers	
<u></u>	6.0 Reset <u>D</u> S Layers	

After setting your CAD configuration, press At G to access the COGO Configuration Menu.

Configuration Screen	×
Text Output Slope Entry CAD CO	<u>G</u> O <u>A</u> ngle Setup File <u>P</u> aths
Automatic Point Numbering Show Department Overwrite Protection	Stations Format © 0±00.00 Offsets (0D) Constant Factor (CF) Defined Figures (DF) Change Cogo Font Restore All Defaults Did Style Cogo Window Tool Tips e Backup File on Save
<u> </u>	<u>H</u> elp

After setting your $CO\underline{GO}$ configuration, press $\underline{Alt} \underline{A}$ to access the <u>Angle Setup Configuration Menu</u>.

Configuration Screen					×
Iext Output Slope Entry	CA <u>D</u>	co <u>g</u> o)	Angle Setup	File <u>P</u> aths	
Default Angle Angle Right	•				
Angular Units © Degrees © Grads		Azimuth © <u>N</u> orth ©So <u>u</u> th			
Angle Output © <u>B</u> earings		⊙ SS <u>I</u> A	Code Set		
C Azimuths		<u>O H</u> PA	ingle Codes		
<u>0</u> K	<u>C</u> ano	el	Help		

When all of the items have been set to match the screens shown, press <u>Finer</u> or click on <u>OK</u> to accept the changes and return to the main "Sight" Survey program screen. (On the Angle Setup screen, your Default Angle <u>must</u> be set to Angle Right.)

PROMPT

RESPONSE / NOTES / ETC.

Traverse: From Point

Properties

When the main "Sight" Survey program screen appears, click the **Drawing** window **Properties** (PR) button to display the **Properties**.


Many drawing **Properties** may be set however you wish, however, if you will be sending your drawing to a **plotter**, the **Text Font** that you choose should be a **plotter** font such as **Roman**. In addition, please set the following items as specified below.

Line TypeCoLabel TypePoEnd Point SymbolDoText PlacementDoText Size10

Continuous Point Number Dot Dist / Bng 10

COGO Drawing Pr	operties 📝
Object Color	14 - Black
LineType	Continuous
Line Width	01
Label Type	Point Number
Label Place	Quad #1
Label Angle	+0* - Horizontal
End Pt. Sym	Dot
Text Place	Dist / Bng
Text Font	Arial
Text Size	10
Text Color	08 - Blue
Text Bold	No
Text Italic	No
Text Underline	No
Text Strikeout	No
Symbols Lyr	SYMBOLS
Coords. Lyr	COORDINATES
Coord. List Lyr	COORDLIST
Elevations Lyr	ELEVATIONS
ASCII File Lyr	ASCIITEXT
Line Lyr	LINES
Pt. Name Lyr	PTNAMES
Pt. Number Lyr	PTNUMBERS
Points Lyr	POINTS
Sup. Table Lyr	SUPTABLES
Line Annot Lyr	LINETEXT
Station Lyr	STATIONS


4 A	3 Known Point Northing Easting 1 10000.00000 10000.00000 5 8000.00000 9997.57399
5	2 Occ.Pt BS FS Angle Right Distance 1 5 2 253° 00' 00" 2359.24 2 1 3 95° 47' 57" 2559.01 3 2 4 87° 09' 09" 2078.42 4 3 1 98° 35' 36" 2707.94 1 4 2 78° 27' 06" 2359.24
PROMPT	RESPONSE / NOTES / ETC.
Traverse: From Point	Click Properties (PR) to deselect the Properties window. Click on the Text Output Window to bring it back into view. Now, press so to activate the Traverse entry window, and then type EA to select the Enter & Assign routine.
Enter & Assign: Point # Northing Easting Elevation Description	Type 5 Finer to set the point number. Type 8000 Finer. Type 9997.57399 Finer. Press Finer. Type Initial Backsight Finer.
Enter & Assign: Point # Northing Easting Elevation Description	Type 1 Finer to set the point number. Type 10000 Finter. Type 10000 Finter. Press Finter. Type SW Corner Finter.
Enter & Assign: Point #	Type IN to select the Inverse routine.




PROMPT	RESPONSE / NOTES / ETC.
Distance	Type 2559.01 [-Enter] to enter the horizontal distance.
Description for Pt. 3	Press Home Delete N Enter to edit the default (last used) description to read NE Corner Enter. (If you wish, just type NE Corn
Traverse:	
From Point	3 (By default).
To Point	Type 4 <i>Enter</i> to set the point number.
Bearing	Type 87.0909 $\overline{\text{-Enter}}$ to enter an angle right of 87° 09' 09".
Distance	Type 2078.42 - to enter the horizontal distance.
Description for Pt. 4	Press Home - Delete W - Enter to edit the default (last used) description to read NW Corner - Enter].
Traverse:	
From Point	4 (By default).
To Point	Type TC to select the Traverse Closure routine.
raverse Close:	
From Point	4 (By default).
Close to	Type 1 <i>Etter</i> to set the closing point of the closed traverse.
Bearing	Type 88.3536 Ito enter an angle right of 88° 35' 36". Note
	We are entering an erroneous angle on purpose, in order to illustrate the traverse editing feature.
Distance	Type 2707.94 Entry to enter the horizontal distance.

Enter closing ANGLE RIGHT at Pt. 1 backsighting Pt. 4 foresighting Pt. 2 Press <Enter> if unknown

Type **78.2706** — to enter an angle right of 78° 27' 06".





Prec	atus sision Ratic oth Travers		1 : 9704.6		or in Latitude: or In Departure:		84.941 464.530	Add Leg
	ath To Clos		472.2		or in Elevation:		0.000	<u>D</u> el Leg
Area		i92.0085 Sq. Feet or	118.1954		al Angular Error:	1	0*00'12.0"	Сору
	Acres			Erro	or per station:		2°30'03.0''	Help
Bal	Angl C	Compass Crandal	I <u>T</u> rans	it Lsi	tSgr Re-Ry	n Prjnt	Accept	Cancel
<u>B</u> al/ Leg			I <u>I</u> rans Distance				<u>A</u> ccept Description	Cancel
	Action	Bearing	Distance		Northing	Easting	Description	Cancel
Leg		Bearing	Distance		Northing	Easting 10000.00000	Description SW	
Leg	Action	Bearing 0.0410200117 SW	Distance 2000.001	FS Pt 1	Northing 10000.00000 10000.00000	Easting 10000.00000 10000.00000	Description SW SW	/ Corner
Leg BS 1	Action EB ST	Bearing 0.0410200117 SW N/A	Distance 2000.001 N/A	FS Pt 1 1 2	Northing 10000.00000 10000.00000 10687.03779	Easting 10000.00000 10000.00000 12256.98747	Description SW SW	/ Corner / Corner
Leg BS 1 2	Action EB ST TR	Bearing 0.0410200117 SW N/A 253AR	Distance 2000.001 N/A 2359.240	FS Pt 1 1 2	Northing 10000.00000 10000.00000 10687.03779 13197.90573	Easting 10000.00000 10000.00000 12256.98747 11762.94864	Description SW SW SE	/ Corner / Corner E Corner
Leg BS 1 2 3	Action EB ST TR TR	Bearing 0.0410200117 SW N/A 253AR 95.4757AR 87.0909AR	Distance 2000.001 N/A 2359.240 2559.010	FS Pt 1 2 3 4	Northing 10000.00000 10000.00000 10687.03779 13197.90573 12695.83548	Easting 10000.00000 10000.00000 12256.98747 11762.94864 9746.08098	Description SW SW SE NE	/ Corner / Corner E Corner Corner / Corner

PROMPT RESPONSE / NOTES / ETC.

The **Unbalanced Traverse** window allows you to easily review and edit your traverse data. Scanning the data, we see a problem in the **Bearing** column for **LEG 5**. The angle you entered as **88.3536** should have been **98.3536**. Double-click your mouse on the bad angle entry which reads **88.3536** AR.

"Sight" Survey will present a pop-up editing box for you to make the changes.


Modify a Value	×
Enter the new value	OK
	Cancel
88.3536AR	

Press Home, then Delete, and then 9 to change the line to read 98.3536 AR, then press <u>rener</u> or click <u>OK</u>. Select <u>Re-Run</u> with your mouse or press <u>Alt</u> U to accept the change and re-run the traverse using the corrected angle entry.

After computing the new coordinates based on the traverse changes, "Sight" Survey will display the **Modified Traverse** window showing the new traverse statistics and raw traverse data.

Modified Traverse

When "Sight" Survey displays the **Modified Traverse** window, all data will be identical to the previous window, except for the portion of the data that changed as a result of the modifications you made. In this example, the backsight and the first four legs are identical to the **Unbalanced Traverse** window. However, since we modified the **Bearing** value in leg five, the data from that point on has appropriately been recalculated using the modified angle.



	atus ision Ratio		1:343	92 Erro	or in Latitude:		0.151	Add Leg
Lend	th Traver:	sed:	9704.6	10 Erro	or In Departure:		0.238	Add Ecg
Lend	ath To Clo:		0.2	82 Erro	or in Elevation:		0.000	<u>D</u> el Leg
Area		22.5650 Sq. Feet or	132.8104		al Angular Error:		0°00'12.0''	Сору
	Acres			Erro	or per station:		0°00'03.0''	
								Help
Bal.	and C	Compass Cranda	. 1			1		
201	angi	Compass Cranda	II <u>T</u> rans	it Lsi	tSgr Re-R <u>u</u>	n Print	Accept	<u>C</u> ancel
_		<u>ompass</u> <u>ur</u> anda Bearing				n Print Easting	<u>A</u> ccept Description	Cancel
– Leg		Bearing	Distance			Easting	Description	Cancel
 Leg	Action	Bearing	Distance		Northing	Easting 10000.00000	Description SW	
– Leg	Action	Bearing 0.0410200117 SW	Distance / 2000.001	FS Pt 1	Northing 10000.00000 10000.00000	Easting 10000.00000 10000.00000	Description SW SW	/ Corner
Leg BS 1	Action EB ST	Bearing 0.0410200117 SW N/A	Distance / 2000.001 N/A	FS Pt 1 1 2	Northing 10000.00000 10000.00000 10687.03779	Easting 10000.00000 10000.00000 12256.98747	Description SW SW	/ Corner / Corner
Leg BS 1 2	Action EB ST TR	Bearing 0.0410200117 SW N/A 253AR	Distance / 2000.001 N/A 2359.240	FS Pt 1 2 3	Northing 10000.00000 10000.00000 10687.03779	Easting 10000.00000 10000.00000 12256.98747 11762.94864	Description SW SW SE	/ Corner / Corner Corner
Leg BS 1 2 3	Action EB ST TR TR	Bearing 0.0410200117 SW N/A 253AR 95.4757AR	Distance / 2000.001 N/A 2359.240 2559.010	FS Pt 1 2 3 4	Northing 10000.00000 10000.00000 10687.03779 13197.90573	Easting 10000.00000 10000.00000 12256.98747 11762.94864	Description SW SW SE	/ Corner / Corner E Corner Corner / Corner

Select an Adjustment Option

Press Alt B or click Bal Angl to choose the Balance Angles option. Before proceeding with the adjustment, "Sight" Survey will present a Raw Data Exists prompt.



Press Y or click Yes to update the raw data file with the data shown in the Modified Traverse window, which contains the corrected angle entry. "Sight" Survey will save the revised raw data,

PROMPT

Angles Balanced

RESPONSE / NOTES / ETC.


balance the angles, and display the **Traverse with Angles Balanced** window showing the new traverse statistics and adjusted data.

When "Sight" Survey displays the **Traverse with Angles Balanced** window, the angles have been balanced and the **Bearing** column now shows the appropriate bearing between the points instead of the raw field angles. (You may have to expand the width of the **Bearing** column to see entire entries.) The coordinates in the **Northing** and **Easting** columns have also changed accordingly.


		ith Angles Balanc	ed					
Preci: Lengl Lengl	Status Other Operation 1:55397 Error in Latitude: 0.095 Add Leg Lendth Traversed: 9704.610 Error in Levation: 0.103 Add Leg Lendth To Close: 0.172 Error in Elevation: 0.000 Del Leg Area: 5785413.3365 Sq. Feet or 132.8148 Total Angular Error: 0*0000.0* Copy Acres Error per station: 0*0000.0* Help							
BalA	ingl C	Compass Crandall	<u> </u>	t Lst	Sgr Re-Ry	n Print	Accept	<u>C</u> ancel
Leg	Action	Bearing	Distance	FS Pt	Northing	Easting	Description	
BS	EB	0.0410200117 SW	2000.001	1	10000.00000	10000.00000	SW	Corner
1	ST	N/A	N/A	1	10000.00000	10000.00000	SW	Corner
2	TB	73.0413200118 NE	2359.240	2	10687.00496	12256.99746	SE	Corner
3	TB	11.0746799881 NW	2559.010	3	13197.88728	11763.03168	NE	Corner
4	TB	76.0125200118 SW	2078.420	4	12695.90503	9746.14211	NW	Corner
5	TC	5.2255799881 SE	2707.940	1	9999.90377	10000.14266	Temporary	Closing
6	CA	73.0413200118 NE	N/A	2	10687.00496	12256.99746	SE	Corner

Select an Adjustment Option

Press Att O or click Compass to choose the Compass Rule Adjustment option. Before proceeding with the adjustment, "Sight" Survey will present a Raw Data Exists prompt.



Press N or click No to indicate that you do not want to update your raw data file with balanced data that was created by the **Bal**ance Angles routine. ("Sight" Survey's <u>raw</u> data file may be edited using the Edit Original Raw Data routine. If you overwrite your raw data file at this point, you will no longer have a data file with your <u>original</u> raw data.)



"Sight" Survey will continue by displaying the **Traverse Adjusted by Compass Rule** window showing the new traverse statistics and adjusted data

— Sta	atus							
	ision Ratio	D:	1:9.70E+3	23 Erro	r in Latitude:		0.000	Add Leg
	ath Traver:		9704.6		r In Departure:		0.000	
	th To Clo		0.0		r in Elevation:		0.000	<u>D</u> el Leg
Area:	: 57857 Acres	731.5553 Sq. Feet or 1	32.8221		al Angular Error:		0*00'00.0''	Сору
	Acres			FILO	r per station:		0*00'00.0''	
								<u>H</u> elp
<u>B</u> al A	Angl C	Compass Crandal	Iransi	t Lst	Sgr Re-Ryr	n Print	Accept	Cancel
Bal A						n Print Easting	<u>Accept</u> Description	<u>C</u> ancel
2		Bearing				Easting	Description	Cancel
Leg	Action	Bearing	Distance		Northing	Easting	Description SW	
Leg	Action	Bearing 0.0410200117 SW	Distance 2000.001	FS Pt 1	Northing 10000.00000	Easting 10000.00000 10000.00000	Description SW SW	Corner
Leg BS 1	Action EB ST	Bearing 0.0410200117 SW N/A 73.0410360524 NE	Distance 2000.001 N/A	FS Pt 1 1 2	Northing 10000.00000 10000.00000	Easting 10000.00000 10000.00000	Description SW SW	/ Corner / Corner
Leg BS 1 2	Action EB ST IN	Bearing 0.0410200117 SW N/A 73.0410360524 NE	Distance 2000.001 N/A 2359.214	FS Pt 1 2 3	Northing 10000.00000 10000.00000 10687.02836	Easting 10000.00000 10000.00000 12256.96278 11762.95938	Description SW SW SE NE	/ Corner / Corner : Corner
Leg BS 1 2 3	Action EB ST IN IN	Bearing 0.0410200117 SW N/A 73.0410360524 NE 11.0749380071 NW	Distance 2000.001 N/A 2359.214 2559.042	FS Pt 1 2 3 4	Northing 10000.00000 10000.00000 10687.02836 13197.93604	Easting 10000.00000 10000.00000 12256.96278 11762.95938	Description SW SW SE NE NW	Corner Corner Corner

Selecting a different

Compass Rule Adjustment

Adjustment Option

After performing an adjustment, you may either accept the results or try another adjustment option for comparison. For this example, we will now try the **Crandall Rule Adjustment**.

Regardless of which additional adjustment you use, you should start with the data window which is closest to the final adjustment step. For this example, we will start from the window created from the **Balance Angles** routine, since this data is the same regardless of which adjustment option we use. To start with that data, we need to establish the **Traverse with Angles Balanced** window as the active window.

PROMPT RESPONSE / NOTES / ETC.

To activate the **Traverse with Angles Balanced** window, click your mouse anywhere on that window, or select <u>7</u> **Traverse with Angles Balanced** from the <u>Window</u> pull-down menu (Att W, Z). Once the **Traverse with Angles Balanced** window is the active window, simply press Att R or click <u>Crandall</u> to choose the **Crandall Rule Adjustment** option. Before proceeding with the adjustment, "Sight" Survey will again present the **Raw Data Exists** prompt. (Prompt is not shown here.)

Press N or click No to indicate that you again do not want to update your raw data file. "Sight" Survey will continue by displaying the Traverse Adjusted by Crandall Rule window showing the new traverse statistics and adjusted data.


Crandall Rule Adjustment

		djusted by Crandal	l Rule					_ 🗆 ×
Precis Lengt Lengt	Status 0.000 Add Leg Precision Ratio: 1: 9.70E+23 Error in Latitude: 0.000 Add Leg Lendth Traversed: 9704.610 Error in Depature: 0.000 Add Leg Lendth To Close: 0.000 Error in Elevation: 0.000 Def Leg Area: 5785739.1238 Sq. Feet or 132.8223 Total Angular Error: 0*0000.0** Cogy Acres Error per station: 0*0000.0** Error Help					Сору		
Bal A	ngi (igmpass Crandal	Iransi	t Lst	Sgr Re-By	n Print	Accept	<u>C</u> ancel
Leg	Action	Bearing	Distance	FS Pt	Northing	Easting	Description	
BS	EB	0.0410200117 SW	2000.001	1	10000.00000	10000.00000	SW	/ Corner
1	ST	N/A	N/A	1	10000.00000	10000.00000	SW	/ Corner
2	IN	73.0413200118 NE	2359.174	2	10686.98560	12256.93385	SE	Corner
3	IN	11.0746799881 NW	2559.078	3	13197.93505	11762.95485	NE	Corner
4	IN	76.0125200118 SW	2078.482	4	12695.93791	9746.00542	NW	/ Corner
5	IN	5.2255799880 SE	2707.876	1	10000.00000	10000.00000	SW	/ Corner
6	EA	73.0413200118 NE	N/A	2	10686.98560	12256.93385	SE	Corner

Comparing Adjustments

If you wish to compare the different results obtained by the **Com**pass and **Crandall Rule Adjustments** on-screen, it is best to arrange the two windows so you may see both at the same time.

Although we won't do it in this example, you could send a copy of the adjustment data to the **Text Output** window by selecting the <u>Print</u> buttons in both adjustment windows. You may wish to do this as an audit trail, or to print the adjustment data (later) to your printer. Once the data has been copied to the **Text Output** window, you may print the text by activating the **Text Output** window, highlighting the desired text and using the **Print Text** routine's **Selection: Print Range** option.



l 🚮 l ra								_ 🗆 🗡
- Sta Preci	tus ision Ratio	D:	1:9.70E+23	Error i	n Latitude:		0.000	Add Leg
	th Traver		9704.610		n Departure:		0.000	Add Leg
Leng	th To Clo		0.000	Error i	n Elevation:		0.000	<u>D</u> el Leg
Area:	Area: 5785731.5553 Sq. Feet or 132.8221 Total Angular Error: 0*00'00.0** Copy					Copy		
	Acres Error per station: 0*00'00.0"					Copy		
								<u>H</u> elp
BalA	ingi (Compass Crandal	l <u>I</u> ransit	Lst S	gr Re-Ryr	n Print	Accept	<u>C</u> ancel
Leg	Action	Bearing	Distance FS	Pt IN	lorthing	Easting	Description	
BS	EB			1	10000.00000	10000.00000		/ Corner
1	ST	N/A	N/A	1	10000.00000	10000.00000		/ Corner
2	IN	73.0410360524 NE		2	10687.02836	12256.96278		Corner
3	IN	11.0749380071 NW	2559.042	3	13197,93604	11762.95938	NE	Corner
4	IN	76.0127917114 SW	2078.445	4	12695.97440	9746.03926	NW	/ Corner
5	IN	5.2252973014 SE	2707.910	1	10000.00000	10000.00000	SW	/ Corner
6	EA	73.0413200118 NE	N/A	2	10687.02836	12256.96278	SE	Corner
·								
		djusted by Cranda	ll Rule					
- Sta	tus ——			-	1.00.1		0.000	
- Sta Preci	itus ision Ratio	D:	1:9.70E+23		n Latitude:		0.000	Add Leg
Sta Preci Leng	itus ision Ratio th Traver	o: sed:	1 : 9.70E+23 9704.610	Error	n Departure:		0.000	Add Leg
Sta Preci Leng	tus ision Ratio th Traver th To Clo	o: sed:	1 : 9.70E+23 9704.610 0.000	Error I Error i				Add Leg Del Leg
Freci Preci Leng	tus ision Ratio th Traver th To Clo	o: sed: se: 739.1238 Sq. Feet or	1 : 9.70E+23 9704.610 0.000	Error I Error i Total	n Departure: n Elevation:		0.000	Add Leg
Freci Preci Leng	tus ision Ratio th Traver th To Clo 57857	o: sed: se: 739.1238 Sq. Feet or	1 : 9.70E+23 9704.610 0.000	Error I Error i Total	n Departure: n Elevation: Angular Error:		0.000 0.000 0°00'00.0''	Add Leg Del Leg
Freci Preci Leng	tus ision Ratio th Traver th To Clo 57857 Acres	o: sed: se: 739.1238 Sq. Feet or	1 : 9.70E+23 9704.610 0.000 132.8223	Error I Error i Total	n Departure: n Elevation: Angular Error: per station:	7 Print	0.000 0.000 0°00'00.0''	Add Leg Del Leg Copy
Sta Preci Leng Leng Area:	tus ision Ratio th Traver th To Clo 57857 Acres	o: sed: se: 739.1238 Sq. Feet or Compass Crendal Bearing	1 : 9.70E+23 9704.610 0.000 132.8223	Error I Error i Total Error p Lst S	n Departure: n Elevation: Angular Error: ber station: igr Re:Ryr	1 Print Easting	0.000 0.000 0*00'00.0'' 0*00'00.0''	Add Leg Del Leg Copy Help
Sta Preci Leng Leng Area:	tus ision Ratio th Traver th To Clo 57857 Acres	o: sed: se: 739.1238 Sq. Feet or Compose Crendal Bearing	1 : 9.70E+23 9704.610 0.000 132.8223	Error I Error i Total Error p Lst S	n Departure: n Elevation: Angular Error: ber station: igr Re:Ryr		0.000 0.000 0*00'00.0'' 0*00'00.0'' <u>Accept</u> Description	Add Leg Del Leg Copy Help
Sta Preci Leng Area: <u>Ball</u> Leg BS 1	tus ision Ratio th Traver th To Clo 57857 Acres	x sed: sec: 239.1238 Sq. Feet or Crendel Bearing 0.0410200117 SW N/A	1 : 9.70E +23 9704.610 0.000 132.8223	Error I Error i Total. Error i Lst S Pt N 1	n Departure: n Elevation: Anqular Error: ber station: igr Reflur lothing 10000.00000 10000.00000	Easting 10000.00000 10000.00000	0.000 0.000 0*00'00.0'' 0*00'00.0'' <u>Accept</u> Description SW SW	Add Leg Del Leg Copy Help Cancel
Sta Preci Leng Area: Ball/ Leg BS 1 2	tus ision Ratio th Traver th To Clo 57857 Acres	2: sed: se: Crandel Bearing 0.0410200117 SW N/A 73.0413200118 NE	1: 9,70E+23 9704.610 0,000 132.8223 Distance FS 2000.001 N/A 2359.174	Error I Error i Total Error r Lst S Pt N 1 1 2	n Departure: n Elevation: Angular Error: ser station: gr Reffur lothing 10000.00000 10086.98560	Easting 10000.00000 10000.00000 12256.93385	0.000 0.000 0*00'00.0'' 0*00'00.0'' <u>Accept</u> Description SW SV SV	Add Leg Del Leg Copy Help Cancel
Sta Preci Leng Area: <u>Ball</u> Leg BS 1	tus ision Ratio th Traver th To Clo 57857 Acres Acres Action EB ST	2: 3: 3: 3: 3: 3: 3: 3: 3: 3: 3	1: 9.70E+23 9704.610 0.000 132.8223	Error I Error i Total. Error i Lst S Pt N 1	n Departure: n Elevation: Angular Error: oer station: Iorthing 10000.00000 10000.00000 10686.98560 13197.93505	Easting 10000.00000 10000.00000 12256.93385 11762.95485	0.000 0.000 0*00*00.0* 0*00*00.0* Description SV SV SV SE NE	Add Leg Del Leg Copy Help Cancel
Sta Preci Leng Area: Bal / BS 1 2 3 4	tus ision Ratic th To Clo 57857 Acres Acres Action EB ST IN IN	2: sect: sec: 33.1238 Sq. Feet or Crandal Bearing 0.0410200117 SW N/A 73.0413200118 NE 11.0746793881 NW	1: 9.70E+23 9704.610 0.000 132.8223 Distance FS 2000.001 N/A 2359.174 2559.078 2078.482	Error I Error i Total. Error r Lst S Pt N 1 1 2 3 4	n Departure: n Elevation: Angular Error: ber station: Iorthing 10000.00000 10086.98560 13197.93505 12695.93791	Easting 10000.00000 10000.00000 12256.93385 11762.95485 9746.00542	0.000 0.000 0*00*00.0* 0*00*00.0* Description SW SW SW NM	Add Leg Del Leg Copy Help Cancel
Sta Preci Leng Area: Ball/ Eg BS 1 2 3 4 5	tus ision Ratid th Traver th To Clo 57857 Acres Acres Action EB ST IN IN IN	2 2 2 2 2 2 2 2 2 2 2 2 2 2	1: 9.70E+23 9704.610 0.000 132.8223 Distance FS 2000.001 N/A 2359.174 2259.078 2078.482 2707.876	Error I Error i Total. Error r Lst S Pt N 1 1 2 3 4 1	n Departure: n Elevation: Angular Error: ber station: Iotthing 10000.00000 10686.98560 13197.93505 12695.93791 10000.00000	Easting 10000.00000 10000.00000 12256.93385 11762.95485 9746.00542 10000.00000	0.000 0.000 0'00'00.0'' 0'00'00.0'' Description SW SW SE NW SW SW SW	Add Leg Del Leg Copy Help Cancel
Sta Preci Leng Area: Bal / BS 1 2 3 4	tus ision Ratic th To Clo 57857 Acres Acres Action EB ST IN IN	2: sect: sec: 33.1238 Sq. Feet or Crandal Bearing 0.0410200117 SW N/A 73.0413200118 NE 11.0746793881 NW	1: 9.70E+23 9704.610 0.000 132.8223 Distance FS 2000.001 N/A 2359.174 2259.078 2078.482 2707.876	Error I Error i Total. Error r Lst S Pt N 1 1 2 3 4	n Departure: n Elevation: Angular Error: ber station: Iorthing 10000.00000 10086.98560 13197.93505 12695.93791	Easting 10000.00000 10000.00000 12256.93385 11762.95485 9746.00542	0.000 0.000 0'00'00.0'' 0'00'00.0'' Description SW SW SE NW SW SW SW	Add Leg Del Leg Copy Help Cancel

Accepting the Adjustment

For this example, we will be saving the results of the Crandall Rule adjustment. Activate the **Traverse Adjusted by Crandall Rule** window by clicking on its title bar. Now click the **Accept** button, or press **AttA**. The adjustment windows will be closed and the chosen traverse adjustment data will automatically re-run. As the

PROMPT	RESPONSE / NOTES / ETC.
	traverse data is re-run, the Drawing and Text Output windows will be updated accordingly.
Saving the Data	Now would be a really good time to save your work. To save all data associated with this job, click the <u>Save Job</u> icon (\square) on the Main (top) toolbar (or type SC to Save Coordinates).
Printing or Plotting the Drawing	To send the drawing to your printer or plotter, select File $Plot$ Drawing $Plot$ to Scale.
Printing the Text	To obtain a hard copy printout of the information in the Text Output window, select <u>File Print Text</u> , or <u>Alt</u> [F], P. After verifying your print options, click on OK or press <u>Print</u> . A copy of the final printout is presented here for your convenience.

PRINTOUT	Poin	t #	Bearing	Distance	Northing	Easting
	Assign					
	Assign	ned points				
		5	Initial Backsight		8000.00000	9997.57399
		1	SW Corner		10000.00000	10000.00000
	Go to					
		5	Initial Backsight		8000.00000	9997.57399
	IN		N 0°04'10.2" Ĕ	2000.001		
		1	SW Corner		10000.00000	10000.00000
	Start					
	otart	1	SW Corner		10000.00000	10000.00000
	D	1		0050.04	10000.00000	10000.00000
	Raw:		253 AR	2359.24		
	TR		N 73°04'10.2" E	2359.240		
		2	SE Corner		10687.03779	12256.98747
	Raw:		95.4757 AR	2559.01		
	TR		N 11°07'52.8" W	2559.010		
		3	NE Corner		13197.90573	11762.94864
	Raw:	•	87.0909 AR	2078.42		
	TR		S 76°01'16.2" W	2078.420		
	IK			2070.420	40005 00540	0740 00000
	_	4	NW Corner		12695.83548	9746.08098
	Raw:		88.3536 AR	2707.94		
	ТС		S 15°23'07.8" E	2707.940		
		1	Calculated Closing Pt		10084.94107	10464.53029

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	тс	S 79°38'15.8" W	472.232		
	1	SW Corner		10000.00000	10000.00000
	Angle righ	t at Pt. 1 from 4 to 2 = Al (RAW: 78.2706)			
	Database \$	Saved: Tuesday, Noverr	mber 02, 1999 1:3	6 pm.	
	Entering T	raverse Adjustment mod	de		
	Precision		1 : 21		
	Length Tra		4.610		
	Length To	Close = 472	2.232		
	Error in La	titude = 84	4.941		
	Error in De	eparture = 464	4.530		
	Error in Ele	evation =	0.000		
	Area = 51	48592.0085 Sq. Feet or	118.1954 Acres		
	Total Angu	ılar Error = 10°00'	12.0"		
	Error Per S	Station = 2°30'	03.0"		
	Traverse N	Nodified			
	Traverse A	Angles Balanced			
		djusted by Compass Ru	lle		
		djusted by Crandall Rul			
	Rerunning	Traverse Adjusted by C	randall Rule		
	Inversing /	Adjusted Points			
	Start				
	5	Initial Backsight	t	8000.0000	9997.57399
	IN	N 0°04'10.2" Ĕ	2000.001		
	1	SW Corner		10000.00000	10000.00000
	EB	S 0°04'10.2" W		New Backsight	Bng.
	Start	014/0			
	1	SW Corner	0050 474	10000.00000	10000.00000
	IN 2	N 73°04'13.2" E SE Corner	2359.174	10686.98560	12256.93385
	IN Z	SE Corner N 11°07'46.8" W	2559.078	10000.90000	12230.93303
		14 11 07 4 0.0 W	2009.010		

3	NE Corner		13197.93505	11762.95485
IN	S 76°01'25.2" W	2078.482		
4	NW Corner		12695.93791	9746.00542
IN	S 5°22'55.8" E	2707.876		
1	SW Corner		10000.00000	10000.00000
Area = 5785739.4	1238 Sq. Feet or 132.8	223 Acres		
Precision Ratio	= 1:9.70E+23			
Length Traversed	= 9704.610			
Length To Close	= 0.000			
Error in Latitude	= 0.000			
Error in Departure	e = 0.000			
Error in Elevation	= 0.000			
Area = 5785739.4	1238 Sq. Feet or 132.8	223 Acres		
Total Angular Erro	or = 0°00'00.0"			
Error Per Station	= 0°00'00.0"			

END of Example 1


3.02	Example 2: Open Traverse
	This example sets traverse points using the Enter & Assign (EA) and Traverse (TR) routines. All distances used for the purpose of corner establishment are horizontal.
	Begin by loading the "Sight" Survey program.
PROMPT	RESPONSE / NOTES / ETC.
Traverse: From Point	When the "Sight" Survey program appears, type CM to access the "Sight" Survey Configuration Menu . In order for your prompts and printed output to follow this manual, you must set your Configuration Menu options to match the screens shown at the beginning of <i>Example 1</i> .
	When all of the items have been set to match the screens shown, press for click on OK to accept the changes and return to the main "Sight" Survey program screen. (On the Angle Setup screen, your Default Angle <u>must</u> be set to Angle Right.)
Traverse: From Point	When the main "Sight" Survey program screen appears, click the Drawing window Properties (PR) button to display the Properties window.
Properties	Many of the drawing Properties may be set to whatever you wish, however, if you will be sending your drawing to a plotter , the Text Font that you choose should be a plotter font such as Roman . In addition, please set the following items as specified below.
	Line TypeContinuousLabel TypePoint NumberEnd Point SymbolDotText PlacementDist / BngText Size10

When you have finished setting properties, click **Properties (PR)** to deselect the **Properties** window.

	6 4 1	2	Known 1 5 6 Occ.Pt 1 2 3		10 12 8 13		" 2359.24 " 2559.01 " 2078.42	
	5		4	3	ь	323° 53' 22	." 397.56	
PROMPT		RESPON	SE / NO	TES	5 / E'	TC.		
Traverse: From Point		click on the select Win	ne Text O dow � <u>1</u> entry wind	utpu Text	t Wir Out	ndow to bri put). Now	ng it back in	o activate the
Enter & Assign: Point # Northing Easting Elevation Description		Type 1 I I Type 100 Type 100 Press I Internet Type SW	00 - <u>- Enter</u> . 00 - <u>- Enter</u> .	_		t number.		
Enter & Assign: Point # Northing Easting Elevation Description		Type 4 Type 126 Type 974 Press Edit the de	95 - <u>Enter</u> . 5 - <u>Enter</u> .	-			to read NW (Corner <u>Enter</u> .


	/ ⁶ 3	Known	Point		Northing	Easting	
	4 A	1 4 5 6		12) 81	000.00000 695.00000 000.00000 000.00000	10000.00000 9745.00000 9997.57399 10000.00000	
	٨	2 Occ.Pt	BS	FS	Angle Righ	t Distance	
	5	1 2 3 4	5 1 2 3	2 3 4 6	253° 00' 00" 95° 47' 57" 87° 09' 09" 323° 53' 22"	2559.01 2078.42	
PROMPT	F	RESPONSE / NO	TES	/ E	ГС.		
Enter & Assign:							
Point #	1	Type 5 Enter to set	the p	ooint	number.		
Northing	Т	ype 8000 - Enter.					
Easting	Т	ype 9997.573 9	9 🖳	nter			
Elevation	P	ress -Enter .					
Description	1	ype Initial E	Back	sig	ght <mark>. Enter</mark> .		
Enter & Assign:							
Point #		Type 6 FILTER to set	-	ooint	number.		
Northing		ype 13000 - Enter.					
Easting		Type 10000 - Enter.					
Elevation		Press -Enter .					
Description	1	ype Closing E	ack	sig	gnt [<u>⊣Enter</u>].		
Enter & Assign: Point #	Т	Type ST to select t	he <mark>S</mark>	TAR	T AT routine	2 .	
Start At Point: Point #		Type 1 — Enter to set o clear the Area S				·	• •

PROMPT	RESPONSE / NOTES / ETC.
Traverse:	
From Point	1 (By default).
To Point	Type EP to select the Enter Backsight Point routine.
Enter Backsight Point:	
Point #	Type 5 Find to set the backsight point number. "Sight" Survey will calculate the correct backsight bearing.
Traverse: From Point	1 (By default).
To Point	Type 2 <i>Enter</i> to set the point number.
Bearing	Type 253 Fire to enter an angle right of 253° 00' 00".
Distance	Type 2359.24
Description for Pt. 2	Type SE Corner -Enter.
Traverse:	
From Point	2 (By default).
To Point	Type 3 <i>reterner</i> to set the point number.
Bearing	Type 95.4757 Termine to enter an angle right of 95° 47' 57".
Distance	Type 2559.01 <i>Enter</i> to enter the horizontal distance.
Description for Pt. 3	Press Home Delete N - Enter to edit the default (last used) description to NE Corner - Enter. (If you prefer, just type NE Corner - Enter.)
Traverse:	
From Point	3 (By default).
To Point	Type TC to select the Traverse Closure routine.
Traverse Close:	
From Point	3 (By default).
Close to	Type 4 <i>Enter</i> to set the closing point of the open traverse.
Bearing	Type 87.0909 $\overrightarrow{\text{Letter}}$ to enter an angle right of 87° 09' 09".
Distance	Type 2078.42 <i>Enter</i> to enter the horizontal distance.
Enter the number of the Closing Foresight Pt.	
Press <enter> if unknown</enter>	Type 6 <i>Enter</i> to set the closing foresight point number.



Enter closing ANGLE RIGHT at Pt.4 backsighting Pt. 3 foresighting Pt. 6 Press <Enter> if unknown

Type **323.5322** when the fixed foresight point 6.



Press \heartsuit or click Yes to save this job before proceeding with the traverse adjustment. (Up to this point, your data has been saved in a temporary file called COGO.ZAK. The COGO.ZAK file is used to store COGO data until the job is saved to a different file name, or until a new or different job is opened.)

Type **OpenTrav** Fine. "Sight" Survey will save your file and display the **Unbalanced Traverse** window showing the current traverse statistics and your raw traverse data. The *calculated closing* point's Northing and Easting, and the closure bearing and distance have also been printed in the **Text Output** window.

Save Job As File Name:

PROMPT

RESPONSE / NOTES / ETC.

Unbalanced Traverse

Calculated Closing Point TC S 52°18'00.0"

12695.83548 9746.08098 1.366

		l Traverse						_ 🗆 ×
- Status Precision Ratio: Lendth Traversed: Lendth To Close: Area: Open Traverse - No Area			1 : 51: 6996.6 1.3	70 Erro 56 Erro Tota	r in Latitude: r In Departure: r in Elevation: al Angular Error: r per station:		0.835 1.081 0.000 0*00'46.0'' 0*00'11.5''	Add Leg Del Leg Copy Help
<u>B</u> al A	Angl C	ompass Crandal	<u>I</u> ransi	t Lst	Sgr Re-Ry	n Print	Accept	<u>C</u> ancel
Leg	Action	Bearing	Distance	FS Pt	Northing	Easting	Description	
BS	EB	0.0410200117 SW	2000.001	1	10000.00000	10000.00000	SW	Corner
1	ST	N/A	N/A	1	10000.00000	10000.00000	SW	Corner
2	TB	253AR	2359.240	2	10687.03779	12256.98747	SE	Corner
3	TB	95.4757AR	2559.010	3	13197.90573	11762.94864	NE	Corner
4	TC	87.0909AR	2078.420	4	12695.83548	9746.08098	Temporary	Closing
5	CA	323.5322AR	N/A	6	13000.00000	10000.00000	Closing Ba	acksight
6	EA	N/A	N/A	N/A	0.00000	0.00000		


The **Unbalanced Traverse** window allows you to easily review and edit your traverse data, if necessary. Depending upon your screen resolution, all the traverse data may or may not fit onto your display. If scroll bars are present either at the bottom or right side of the window, you may use them to view and/or edit the traverse data that is not shown on the immediate screen.

Press Alt B or click Bal Angl to choose the Balance Angles option. "Sight" Survey will balance the angles and display the Traverse with Angles Balanced window showing the new traverse statistics and adjusted data.

— Sta	atus —							
	ision Ratio		1 : 68		r in Latitude:		0.569	Add Leg
		6996.6		r In Departure:		0.847		
	ath To Clo		1.03		r in Elevation:		0.000	<u>D</u> el Leg
Area	: Upen	Traverse - No Area			il Angular Error: r per station:		0°00'00.0''	Сору
				Eno	per station.		0 00 00.0	Help
Bal Angl Compass Crandall Transit Lst Sgr Re-Ryn Print Accept Cancel								
Bali	Angi C	Compass Crandall	<u> </u>	t Lst	Sgr Re-Ru	n Print	Accept	<u>C</u> ancel
								<u>C</u> ancel
Leg	Action	Bearing	Distance		Northing	Easting	Description	
						Easting	Description	<u>Cancel</u>
Leg	Action	Bearing	Distance		Northing	Easting 10000.00000	Description SW	
Leg	Action	Bearing 0.0410200117 SW	Distance 2000.001		Northing 10000.00000	Easting 10000.00000	Description SW SW	/ Corner
Leg	Action EB ST	Bearing 0.0410200117 SW N/A	Distance 2000.001 N/A	FS Pt 1	Northing 10000.00000 10000.00000	Easting 10000.00000 10000.00000 12256.94917	Description SW SW	/ Corner / Corner
Leg BS 1 2	Action EB ST TR	Bearing 0.0410200117 SW N/A 73.0358701361 NE 11.0815797394 NW	Distance 2000.001 N/A 2359.240	FS Pt 1 1 2	Northing 10000.00000 10000.00000 10687.16361	Easting 10000.00000 10000.00000 12256.94917	Description SW SW SE NE	/ Corner / Corner E Corner E Corner
Leg BS 1 2	Action EB ST TR TR	Bearing 0.0410200117 SW N/A 73.0358701361 NE 11.0815797394 NW	Distance 2000.001 N/A 2359.240 2559.010	FS Pt 1 1 2 3	Northing 10000.00000 10000.00000 10687.16361 13197.97645	Easting 10000.00000 10000.00000 12256.94917 11762.63039	Description SW SW SE NE Temporary	/ Corner / Corner E Corner E Corner Closing

Angles Balanced

Select an Adjustment Option



Select an Adjustment Option

Press Alt O or click **Compass** to choose the **Compass Rule Adjustment** option. Before proceeding with the adjustment, "Sight" Survey will present a **Raw Data Exists** prompt.

Raw Da	ta Exists 🛛 🕅
?	Do you want to replace the existing raw data file with the data in this window?
	Yes <u>N</u> o

Press N or click No to indicate that you do not want to update your raw data file with balanced data that was created by the Balance Angles routine. ("Sight" Survey's raw data file may be edited using the Edit Original Raw Data routine. If you overwrite your raw data file at this point, you will no longer have a data file with your <u>original</u> raw data.)

"Sight" Survey will continue by displaying the **Traverse Adjusted by Compass Rule** window showing the new traverse statistics and adjusted data.

PROMPT **RESPONSE / NOTES / ETC. Compass Rule Adjustment** a Traverse Adjusted by Compass Rule _ 🗆 × Traves Status Precision Ratio: Length Traversed: Length To Close: Area: Open Traverse - No Area 1 : 7.00E+23 6996.482 0.000 Error in Latitude: Error In Departure: Error in Elevation: Total Angular Error: 0.000 Add <u>L</u>eg 0.000 <u>D</u>el Leg 0.000 0°00'00.0" 0°00'00.0" Сору Error per station <u>H</u>elp Compass Crandal Iransit Lst Sgr Re-F yn Print <u>A</u>ccept <u>C</u>ancel Leg Action Bearing 3S EB 0.0410200117 SW 1 ST N/A 2 IN 73.0407476368 NE Distance FS Pt V 2000.001 Northing Easting 1 10000.00000 10000.00000 Description SW Corner N/A 10000.00000 10000.00000 SW Corner IN 73.0407476368 NE IN 11.0843530487 NW IN 76.0031465069 SW 2358.911 2558.866 SE Corner NE Corner NW Corner 10686.97178 13197.57655 12256.66366 11762.03519 2078.705 12695.00000 9745.00000 ΕA 39.5352205091 NE N/A 13000.00000 10000.00000 Closing Backsight EΛ N/A NZA 0.0000 0.0000 Accepting the Adjustment Select the Accept button with your mouse, or press Alt A. The traverse adjustment windows will be closed and the traverse adjustment data will automatically re-run. As the traverse data is rerunning, the Drawing and Text Output windows will be updated accordingly. Saving the Data Now would be a really good time to save your work. To save all data associated with this job, click the Save Job icon (Main (top) toolbar (or type SC to Save Coordinates). Printing or Plotting To send the drawing to your printer or plotter, select File >Plot the Drawing Drawing [™]→ <u>P</u>lot to Scale. **Printing the Text** To obtain a hard copy printout of the information in the Text Output window, select File Print Text, or Att F, P. After verifying your print options, click on **OK** or press **Ener**. A

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	Assigned points				
	1	SW Corner		10000.00000	10000.00000
	4	NW Corner		12695.00000	9745.00000
	5	Initial Backsight		8000.0000	9997.57399
	6	Closing Backsight		13000.00000	10000.00000

copy of the final printout is presented here for your convenience.

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	Start				
	1	SW Corner		10000.00000	10000.00000
	EP	S 0°04'10.2" W	2000.001	New BS Bng.	(B.S. is 5)
	Raw:	253 AR	2359.24		
	TR	N 73°04'10.2" E	2359.240		
	2	SE Corner		10687.03779	12256.98747
	Raw:	95.4757 AR	2559.01		
	TR	N 11°07'52.8" W	2559.010		
	3	NE Corner		13197.90573	11762.94864
	Raw:	87.0909 AR	2078.42		
	TC	S 76°01'16.2" W	2078.420		
	4	Calc. Closing Point		12695.83548	9746.08098
	тс	S 52°18'00.0" W	1.366		
	4	NW Corner		12695.00000	9745.00000
	Closing Foresigh				
		4 from 3 To fixed fore			RAW: 323.5322)
		Thursday, October 12	, 1995 9:45 a	ım.	
		e Adjustment mode			
	Precision Ratio	= 1 : 5121			
	Length Traversed	d = 6996.670			
	Length To Close	= 1.366	5		
	Error in Latitude	- 0.026			
	Error in Latitude	= 0.835			
	Error in Departur				
	Error in Elevatior	n = 0.000			
	Open Traverse - I	No Area			
	Total Angular Err	or = 0°00'46.0'	•		
	Error Per Station				
	Traverse Angles				
		d by Compass Rule rse Adjusted by Comp ed Points	ass Rule		
	1 SW Cor	ner	10000.00	1000 10000	.00000
	EP		00.001		ight Bng. (B.S. is 5)
	Start			How Buoks	.g Diigi (Dioi io 0)
	1	SW Corner		10000.00000	10000.00000

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	IN	N 73°04'07.5" E	2358.911		
	2	SE Corner		10686.97178	12256.66366
	IN	N 11°08'43.5" W	2558.866		
	3	NE Corner		13197.57655	11762.03519
	IN	S 76°00'31.5" W	2078.705	40005 00000	0745 00000
	4 Onen Traverse A	NW Corner		12695.00000	9745.00000
	Open Traverse - N	IO Alea			
	Precision Ratio	= 1:7.00E+23	1		
	Length Traversed	= 6996.482			
	Length To Close	= 0.000	l		
	Error in Latitude	= 0.000	l.		
	Error in Departure	e = 0.000	l.		
	Error in Elevation	= 0.000	l		
	Area = Open Tra	verse - No Area			
	Total Angular Erro	or = 0°00'00.0'	I.		
	Error Per Station	= 0°00'00.0'			

END of Example 2

Example 3: Subdivision Layout

Since this is strictly a coordinate geometry problem, all distances used for the purpose of corner establishment are horizontal. Again, this example is intended only to demonstrate many different procedures performed in "Sight" Survey, and is not intended to demonstrate the most efficient means for solving this particular surveying situation.

While computing the subdivision coordinates, we will annotate all drawing lines with distance on top of the line and bearing below. Once we have designed the subdivision, we will modify the annotation and embellish the drawing with symbols and tables.

Begin by loading the "Sight" Survey program.

When the "Sight" Survey program appears, press AtG, T to access the <u>Text Output Configuration Menu</u>. In order for your prompts and printed output to follow this manual, you must set your configuration options to match the following menu screens before running the rest of this example.

Configuration Screen					X
Text Output Slope Entry	CA <u>D</u>)	CO <u>G</u> O	<u>} A</u> ngle Setup }	File <u>P</u> aths	
Printed Precision Prn. Prec Agea: Prn. Prec Bings: Prn. Prgo Crds: Prg. Prec Dist: Prn. Prec Ejev:	4 × 1 × 5 × 3 × 3 ×	Print I	Options nput Data Elevations Point Descriptions		
<u>0</u> K	<u></u> a	ncel	<u>H</u> elp		

After setting your <u>Text Output</u> configuration, press <u>Atts</u> to access the <u>Slope Entry Configuration Menu</u>.

Traverse: From Point

Configuration Screen	×
Iext Output) Slope Entry CAD Slope Type Prompt for slope input	COGO Angle Setup File Paths
© EDM C Stadja C Simple Slope Angles C Leveling C Total Stations C EDM (Mining Option) C Assigned Elevations	Horizontal Distance © Use Horiz. Dist @ EDM Elev. © @ EDM/Target Avg. Elev. © @ Target Elevation © @ Sea Level Elevation © Use Slope Distance
EDM Options Difference in H.I.'s of the EDM and EDM - H.I. of Theod.) Difference in H.I.'s of the prism and H.I. of Prism - H.I. of Target)	
<u></u>	<u>C</u> ancel <u>H</u> elp

After setting your <u>Slope Entry</u> configuration, press At to access the CAD Configuration Menu.

Configuration Screen	×
Iext Output Slope Entry	CAD COGO Angle Setup File Paths
Paper Size / Scale	t CAD Units Page Center © Eeet North 10000 © Meters East 20000
Printed Prec Bng: 0 V C <u>r</u> ds: 5 V	Dimensioning of Short Lines C Shrink tegt to fit along line C Create a short line table
Dist: 2 Elev: 2 Dist. Smbl. Text Offset	Padding Option No Pad Custom Lines Label Offset
<u> </u>	Beset QS Lavers Cancel Help

After setting your CAD configuration, press $\mbox{Att}\mbox{G}$ to access the COGO Configuration Menu.

<u>Setup 71</u>

Configuration Screen	×
Iext Output Slope Entry CAD CO	<u>G</u> O <u>Angle Setup</u> File <u>P</u> aths
Automatic Point Numbering Show Departure Protection	Stations Format © <u>0</u> +00.00 © <u>0</u> ±000.00 Constant Factor (CF) Defined Figures (DF) Change Cogo Font Restore All Defaults Did Style Cogo Window v Tool Tips e Backup File on Save
<u> </u>	

After setting your $CO\underline{GO}$ configuration, press $\underline{Alt} \underline{A}$ to access the <u>Angle Setup Configuration Menu</u>.

onfiguration Screen				
Iext Output	CA <u>D</u>) CO <u>G</u> O	Angle Setup	File <u>P</u> aths
Default Angle None]		
Angular Units —— © D <u>eg</u> rees © Grads		Azim © <u>N</u> o © So		
Angle Dutput © <u>B</u> earings © Azimuths		• SS	le Code Set 1 Angle Codes 9 Angle Codes	
<u>K</u>	<u>[</u>	ancel	<u>H</u> elp	

When all of the items have been set to match the screens shown, press -Enter or click on \mathbf{OK} to accept the changes and return to the main "Sight" Survey program screen. (On the Angle Setup screen, your Default Angle <u>must</u> be set to None.)

PROMPT


RESPONSE / NOTES / ETC.

Traverse: When the main "Sight" Survey screen appears, click the Drawing **From Point** window Properties (PR) button to display the Properties window. **Properties** Many of the drawing **Properties** may be set to whatever you wish, however, if you will be sending your drawing to a plotter, the Text Font that you choose should be a plotter font such as Roman. In addition, please set the following items as specified below. Line Type Continuous Label Type Point Number Label Place Quad #1 End Point Symbol Dot **Text Placement** Dist/Bng

Text Size

COGO Drawing Pi	roperties 🛛 📈
Object Color	14 - Black
LineType	Continuous
Line Width	01
Label Type	Point Number
Label Place	Quad #1
Label Angle	+0* - Horizontal
End Pt. Sym	Dot
Text Place	Dist / Bng
Text Font	Arial
Text Size	10
Text Color	08 - Blue
Text Bold	No
Text Italic	No
Text Underline	No
Text Strikeout	No
Symbols Lyr	SYMBOLS
Coords. Lyr	COORDINATES
Coord. List Lyr	COORDLIST
Elevations Lyr	ELEVATIONS
ASCII File Lyr	ASCIITEXT
Line Lyr	LINES
Pt. Name Lyr	PTNAMES
Pt. Number Lyr	PTNUMBERS
Points Lyr	POINTS
Sup. Table Lyr	SUPTABLES
Line Annot Lyr	LINETEXT
Station Lyr	STATIONS

10



To Point


Bearing

PROMPT **RESPONSE / NOTES / ETC.** Enter & Assign: Point # Type **12** - Enter to set the point number. Type 10126.2344 -Enter. Northing Easting Type 20186.4565 -Enter. Elevation Press -Enter. **Description** Edit the description to read **NE** Corner Lot 7 and press *Enter*, or if you prefer, just type NE Corner Lot 7 - Enter. Enter & Assign: Type ST to select the Start At routine. Point # **Start At Point:** Point # Type **3 . Enter** to set the starting point. Traverse: From Point 3 (By default). **To Point** Type **EB** to select the **Enter Backsight Bearing** routine. **Enter Backsight Bearing: BS Bng** Type ***3-12** - to recall the bearing from point 3 to point 12 and set it as the reference/backsight bearing. Traverse: **From Point** 3 (By default). **To Point** Type 2 *Letter* to set the point number. Bearing Type 0 **F6** to enter an angle right of zero degrees. Distance Type **135.5** -Enter. **Description for Pt. 2** Type NE Corner Lot 1 -Enter. Traverse: **From Point** 2 (By default). To Point Type **SS** to select the **Side Shot** routine. Side Shots: **From Point** 2 (By default).

2 (By default).
Type 13 *weighted* to set the point number.
Type 0DR *weighted* to enter a deflect right of zero degrees.

	1 20 22 3 2 LOT 1 13 12 4 1 14 11 LOT 2 18 19 LOT 6 15 15 15 15 N
	<u>6 7/8 9</u>
PROMPT	RESPONSE / NOTES / ETC.
Distance Description for Pt. 13	Type 80 Fine to enter the horizontal distance. Edit the description to read NW Corner Lot 7 and press Fine.
Side Shots: From Point To Point	2 (By default).Type TR to select the Traverse routine.
Traverse: From Point To Point Bearing Distance Description for Pt. 1	 2 (By default). Type 1 Fine to set the point number. Press F9 to enter an angle left of 90 degrees. Type 75 Fine to enter the horizontal distance. Edit the description to read SE Corner Lot 1 and then press
Traverse: From Point To Point	 I (By default). Type SS to select the Side Shot routine.
Side Shots: From Point PROMPT	1 (By default). RESPONSE / NOTES / ETC.

To Point	Type 14 to set the point number.
Bearing	Type 90AR we to enter a 90° angle right.
Distance	Type 80
Description for Pt. 14	Edit the description to read SW Corner Lot 7 and press .
Side Shots:	We will now set the center point of the cul-de-sac and we don't particularly want lines or annotation to that point. On the Main (top) toolbar, click the Dimension Lines icon ($\boxed{\texttt{MS}}$) and also the Draw Lines Between Points icon ($\boxed{\texttt{MS}}$) to deactivate them. (They are deactivated when a red X appears over the icon.)
From Point	1 (By default).
To Point	Type DD to select the Distance-Distance routin1
PROMPT	RESPONSE / NOTES / ETC.
Distance-Distance Intersection: From Point	1 (By default).
Distance	Type 65 Find to set the radius length.
To Point	Type 19 Enter to set the intersection point number.
Close Distance	Type 65 Find to set the radius length.
Close Point	Type 14 Find to set the point number of the closing point.
Choose Intersection Point:	
B or <u>1</u> (CW) A or <u>0</u> (CCW) Cancel / Esc or <u>2</u>	Press (A) or (0) to accept point, the counter-clockwise solution.
Description for Pt. 19 Traverse:	Type Center of Cul-de-Sac -Enter.
From Point	14 (By default).
To Point `	Type GT to select the Go To Point routine.
Go To Point #	Type 1 - Enter to set the new occupied point.
	We will now set the Southwest corner of lot 1, and we <i>do</i> want lines and annotation to that point. On the Main (top) toolbar, click the Dimension Lines icon ($\frac{1445}{1000}$) and also the Draw Lines Between




Points icon (\searrow) to reactivate them. (They are reactivated when the red X no longer appears over the icon.)

Traverse:	
From Point	1 (By default).
To Point	Type BB to select the Bearing-Bearing routine.
Bearing-Bearing Intersection:	
From Point	1 (By default).
Bearing	Type 90 F4 to enter a bearing of 90° Northwest.
To Point	Type 4 -Enter to set the intersection point number.
Close Bearing	Type ONW we to enter a bearing of zero degrees Northwest.
Close Point	Type 3 -Enter to set the point number of the closing point.
Description for Pt. 4	Type SW Corner Lot 1 -Enter.
Traverse:	
From Point	3 (By default).
To Point	Type NO to toggle Point Names Output to OFF . "Sight" Survey will display the message, Prompting for point descriptions is now turned off . Press Fine to clear this message.

PROMPT	RESPONSE / NOTES / ETC.
Traverse:	
From Point	3 (By default).
To Point	Type GT to select the Go To Point routine.
Go To Point #	Type 1 -Enter to set the new occupied point.
Traverse:	
From Point	1 (By default).
To Point	Type TA to select the Traverse Arc routine.
Traverse Arc:	
From Point	1 (By default).
Center Point	Type 19 Fire to set the known center point.
To Point	Type 18 <i>Etter</i> to set the point number for the end of arc.
Value A / C / T / D	Type - 80 [refiter] to enter a counterclockwise 80 foot arc. Type A [refiter] to designate the value as the arc length.
Traverse Arc:	
From Point	18 (By default).
Center Point	19 (By default).
To Point	Type BB to select the Bearing-Bearing routine.
Bearing-Bearing Intersection:	
From Point	18 (By default).
Bearing	Type *19-18 - Enter to recall bearing from point 19 to point 18.
Inter. Point	Type 5
Close Bearing	Type OAZ renter a North Azimuth of zero degrees.
Close Point	Type 4 <i>Enter</i> to set the point number of the closing point.
	At this point the Bearing-Bearing routine has computed a distance of 109.95 feet from point 5 to point 4. For some reason however, we decide that we need at least 115 feet between those points. We can reset point 5 using the Traverse routine, but first we need to erase the parts of our drawing that we will not be using.

We can erase the drawing data using several methods, however we will use the easiest (or perhaps, laziest) method for this example.



Single click on the **Drawing** window toolbar's **Undo** icon (**1**) *eight* times to undo all of the drawing commands associated with the previous **Bearing-Bearing Intersection**. The following information contains an outline of the **Undo** process.

<u>Undo #</u>	Does this to the Drawing
1	Erases the dot at point 5
2	Erases the point number label at point 5
3	Erases the line between points 5 and 4
4	Erases the distance label between points 5 and 4
5	Erases the bearing label between points 5 and 4
6	Erases the line between points 5 and 18
7	Erases the distance label between points 5 and 18
8	Erases the bearing label between points 5 and 18

Whenever you edit a drawing, it is a good habit to issue the **Re-Draw** command to clean up the drawing. Click the **Re-draw** icon $\left(\underbrace{\mathbb{P}}_{\mathbf{P}} \right)$ on the **Drawing** window toolbar (or type **RD**). Press **Esc** to activate the **Traverse** entry window.

Traverse: From Point To Point


4 (By default).

Type **5*** **Enter** to override the point overwrite protection.

14

PROMPT	RESPONSE / NOTES / ETC.
Bearing Distance	Type SOE - Enter to enter a bearing of zero degrees Southeast. Type 115 - Enter to enter the horizontal distance.
	In some of the following routines, instead of typing in the actual point numbers, distances, or bearings, we will use the mouse to select them from the Drawing window.
Traverse:	
From Point	5 (By default).
To Point	Type BB to select the Bearing-Bearing routine.
Bearing-Bearing Intersection:	
From Point	5 (By default).
Bearing	Press <i>Etter</i> to accept the default last entered bearing of 0.0000SE .
Inter. Point	Type 6 <i>Enter</i> to set the intersection point number.
Close Bearing	To select this bearing from the Drawing window, move the mouse cursor over the Drawing window and click the <i>right</i> mouse button. From the menu that appears, select the item Select <u>Bearing</u> (SB).
Select the starting point for bearing calculation	The cursor will change to the Grab All cursor (\boxdot) to allow for easier selection of drawing points. Since we want this bearing to be parallel to the bearing from point 3 to point 12, move the cursor to the upper left of the Oakwoods Subdivision near point 3. Position the cursor so that the actual coordinate location for point 3 (upper left corner of the subdivision) is located <i>within</i> the cursor box. Click the mouse to select the point.
Select the ending point for bearing calculation	Next, we need to select point 12 from the drawing. Move the cur- sor to the upper right of the Oakwoods Subdivision. Position the cursor so that the actual coordinate location for point 12 (repre- sented by the dot) is located <i>within</i> the cursor box, as shown to the


left. Click the mouse to select the point. "Sight" Survey will calculate the exact bearing from point 3 to point 12 (90.0000NE) and enter it as the needed **Bearing**.



Close Point

cursor over the **Drawing** window and click the *right* mouse button. From the menu that appears, select the item Select Point (SP).


Select a Point




Move the cursor toward the lower right corner of the Oakwoods Subdivision. Position the cursor so that the actual coordinate location for point 9 is located within the cursor box. Even if you do not see the actual dot which represents point 9 on your screen, it actually is on the screen, but is hidden behind the ruler at the bottom of the Drawing window. You may either pan the Drawing window upwards by clicking once in the lower half of the right scroll bar, or you may just approximate where the dot would be. To approximate the point location, position the cursor as shown to the left and click the mouse to select the point. "Sight" Survey will use point 9 as the Close Point and will complete the Bearing-Bearing Intersection calculation.

PROMPT	RESPONSE / NOTES / ETC.	
To Point	Type IN to select the Inverse routine.	
Traverse: From Point	9 (By default).	
_		

Inverse:	
From Point	9 (By default).
To Point	Type SP to indicate that we want to Select this Point from the Drawing window.
Select a Point	To select point 12 from the Drawing window, position the cursor so that the dot which represents point 12 on your screen is located <i>within</i> the cursor box. Click the mouse button to select the point. "Sight" Survey will use point 12 as the To Point and will inverse from point 9 to point 12.
Inverse: From Point	12 (Dr. dofault)
To Point	12 (By default).Type BB to select the Bearing-Bearing routine.
Proving Proving Interpretions	
Bearing-Bearing Intersection: From Point	12 (By default).
Bearing	Type R12 , 9 •Entri to recall the bearing from point 12 to point 9.
Inter. Point	Type 11 First to set the intersection point number.
Close Bearing	Type 90NW <u>Enter</u> to enter a bearing of 90° Northwest.
Close Point	Type 14 <i>Letter</i> to set the point number of the closing point.
Traverse:	
From Point	14 (By default).
To Point	Type GT to select the Go To Point routine.
Go To Point #	Type 11 where to set the new occupied point.
Traverse:	
From Point	11 (By default).
To Point	Type 10 Finter to set the point number.
Bearing	Type R <i>Enter</i> to indicate that you wish to recall a bearing.
Distance	Type 'R enter to indicate that you wish to recall a distance. (You must type the quote (') before you type the R or the R will be
	taken as part of a routine code.)
Recall Bearing	
From	Type 12 First to set the starting point of the recalled bearing.



PROMPT	RESPONSE / NOTES / ETC.
Inter. Point	Type 15
Arc Center Point	Type 19 - Enter to set the arc center point number.
Close Point	Type 14 <i>-Enter</i> to set the arc ending point number.
Recall Distance	
From	Type 10 - Enter to set the starting point of the recalled distance.
То	Type 19 - Enter to set the ending point of the recalled distance.
Plus	Type -65 Page D to subtract the radius length from the recalled distance. (By pressing Page D instead of Peter, we are able to by pass the Multiplied by prompt and accept the entered data.)
Traverse:	
From Point	14 (By default).
To Point	Type GT to select the Go To Point routine.
Go To Point #	Type 6 -Enter to set the new occupied point.
Traverse:	
From Point	6 (By default).
To Point	Type EP to select the Enter Backsight Point routine.
Enter Backsight Point:	
Point #	Type 9 Find to set the backsight point number. "Sight" Survey will calculate the correct backsight bearing.
Traverse:	
From Point	6 (By default).
To Point	Type 7 Firer to set the point number.
Bearing	Type 0 Fine to enter zero degrees without a directional/quad code.
Code	Type 6 <i>Enter</i> to specify an angle right.
Distance	Type 90 -Enter the horizontal distance.
Traverse:	
From Point	7 (By default).
To Point	Type 8 Finer to set the point number.
Bearing	Type ODL — Inter a deflect left of zero degrees.
Distance	Type 181 - Enter the horizontal distance.




Bearing

Distance

Type **R19,8** — to recall the bearing from point 19 to point 8.

Type 65 *Enter* to set the radius length.

PROMPT	RESPONSE / NOTES / ETC.
Traverse:	
From Point	16 (By default).
To Point	Type AD to select the Arc-Distance routine.
Arc-Distance Intersection:	
From Point	16 (By default).
Center Point	Press return to accept the default point 19 as the center point.
Inter. Point	Type 17
Distance	Type *19-7-65 . Enter to recall the distance from point 19 to point 7 and subtract the 65 foot radius.
Close Point	Type 7 -Enter to set the closing point.
Traverse:	
From Point	7 (By default).
To Point	Type GT to select the Go To Point routine.
Go To Point #	Type 19 Henter to set the new occupied point.
Traverse:	
From Point	19 (By default).
To Point	Type 18 * Fine to set the point number and override the point overwrite protection.
Bearing	Type R19-5 To recall the bearing from point 19 to point 5.
Distance	Type 65 <i>Letter</i> to set the radius length.
	At this point, all of the property corners for the Oakwoods Subdivision have been computed. However, we will now place some control points for the street intersection.
Traverse:	
From Point	18 (By default).
To Point	Type GT to select the Go To Point routine.
Go To Point #	Type 13 - Enter to set the new occupied point.




<u>88 Setup</u>

PROMPT	RESPONSE / NOTES / ETC.
2nd Distance	Type -40 . (This is entered as a negative value because it lies to the left of the base line bearing from point 13 to point 12.)
Description for Pt. 20	Type Centerline Intersection Pnt -Enter.
Traverse:	
From Point	13 (By default).
To Point	Press 1 to access the From Point prompt.
From Point	Type 19 - Enter to set the new occupied point.
To Point	Type IN to select the Inverse routine.
Inverse:	
From Point	19 (By default).
To Point	Type 20 — Enter to set the reference/backsight bearing.
Inverse:	
From Point	20 (By default).
To Point	Type OS to select the Offset routine.
Offset Distance:	
Point	Type 21 - Enter to set the offset point number.
Offset Distance	Type -185.5 Ferrer to set a left offset.
Point	Type 22 - Enter to set the offset point number.
Offset Distance	Type 186.5 to set a right offset.
Point	Press Ess to exit the Offset routine and resume at point 20.
I	<i>At this point, we will use two different methods to add</i> Point Names to points that do not have names assigned to them.
Inverse:	
From Point	20 (By default).
To Point	Type ID to select the Identify Point routine.
Enter & Assign:	
Point #	Type 11 <i></i> to set the point number.

Description

Type **11** Finer to set the point number. Type **SE Corner Lot 7** Finer to set the point name.



 (\square) on the Main (top) toolbar (or type SC).

PROMPT


RESPONSE / NOTES / ETC.

Save As

File <u>N</u>ame:

Enter & Assign: Point # *Next, we'll erase the cluttered drawing and create a simple point plot for reference.*

Type **DX** to select the **Drawing Erase** routine.




Press Y or click Yes to indicate that you are sure you want to erase the drawing. You will then be prompted:

Delete C	Curve, Line, and Symbol Tables	\times
ৃ	Do you want to remove the curve, line, and symbol tables from the database file? Doing so will force the next curve created to be labeled 'C1' and the next line to be labeled 'L1'. This is recommended so that the drawing and the curve, line, and symbol tables will be in sync.	
	<u>Yes</u> <u>N</u> o	

Press \heartsuit or click \checkmark to indicate that you also want to erase the line, curve and symbol table files.



The Drawing Erase command may be used at any time to reset the curve, line and symbol tables without erasing the drawing. To do this, simply select <u>No</u> in response to the Drawing Erase prompt, and select <u>Yes</u> in response to the Delete Curve, Line, and Symbol Tables prompt.



Backsight Point	
From Point	
Backsight Point	
Max. Foresight Distance	

To Points

Press *end* to signify no foresight limit.

Type **12 ...** to set the instrument location point. Type **9 ...** to set the backsight point number.

PROMPT

RESPONSE / NOTES / ETC.

Radial Stake Out: From Point	12 (By default).
Backsight Point	9 (By default).
Max. Foresight Distance	(blank) (By default).
To Points	Press Esc, 1 to enter new setup information.
Radial Stake Out: From Point	Type 19 to set the instrument location point.
Backsight Point	Type 12 <i>Enter</i> to set the backsight point number.
Max. Foresight Distance	Type 300 to set a foresight limit of 300 feet.
To Points	Type A \rightarrow Ener to stake out, in numerical order, all of the assigned points in the file which are within 300 feet of point 19.

(By default). (By default).

Traverse Length Accumulators.

1. The foresight points may be entered individually such as 1
"Enter, 2 "Enter, 3 "Enter, etc., or as a point string such as 1, 3, 4-6 "Enter.


 By carefully inspecting the point locations, you could key in a point string designed to give you all of the turned angles in an ascending fashion. In the case of Oakwoods, that string would be entered like this: 11,15,10,9,16,8,17,7,6,18,5,4,3,21,1,2, 20,13,14,22,12 [Fine].

The next portion of this example illustrates the area routines.


Radial Stake Out:	
From Point	19
Backsight Point	12
Max. Foresight Distance	30
To Points	Ту

300 (By default).Type ST to select the Start At routine.Type 1 reme to set the starting point and clear the Area Sum and


Start At



PROMPT	RESPONSE / NOTES / ETC.
Obtuse Curve: From Point Center Point	 (By default). (By default).
To Point	Type AR to print the Area of the subdivision.
Ę	 Although we have already calculated the area of the subdivision by inversing through all of the boundary points, the next section shows how to obtain the area without having the inversed bearings & distances printed. The cul-de-sac, despite being made up of five (5) segments, may be broken down into fewer segments provided that each segment spans less than 180°. The following point to point area calculation has the cul-de-sac split into two parts, the first arc spans from point 14 to point 17 and the second arc spans from point 17 to point 1.
Obtuse Curve:	
From Point	1 (By default).
Center Point To Point	19 (By default). Type PA to select the Point To Point Area routine.
Point to Point Area: Point String	Type 1-14*19, 17*19, 1 -Enter to enter the point string.
Do you want to print courses?	Press N or click <u>No</u> to indicate that you do not want to print the courses (bearings and distances) between points.
	Instead of breaking the cul-de-sac into two curves, you may also use the greater than (>) sign to indicate that you want to get the area around the obtuse curve, as shown in the follow- ing entry:
Point to Point Area:	
Point String	Type 1-14>19, 1 - Enter to print the Area.



PROMPT	RESPONSE / NOTES / ETC.
Point to Point Area: Point String	Type 17,7,8,16*19 Find to print the Area of lot four.
Point to Point Area: Point String	Type 16, 8-10, 15*19 Ferrer to print the Area of lot five.
Point to Point Area: Point String	Type 15, 10, 11, 14*19 - Enter to print the Area of lot six.
Point to Point Area: Point String	Type 11-14 <i>Henter</i> to print the Area of lot seven.
Point to Point Area: Point String	Type LC to select the List Coordinates routine.
Point Plot / List Coordinates:	Type A reference at the end of this example with the Oakwoods printout.
	We will now delete the drawing file again, and construct a better looking, more complete plat drawing using "Sight" Survey's CAD features.
Point to Point Area: Point String	Type DX to select the Drawing Erase routine.
Drawing Erase?	When presented with the Drawing Erase message box, press Υ or click Υ estimates to indicate that you are sure you want to erase the drawing.
Delete Curve, Line, and Symbol Tables?	Press Y or click Yes to indicate that you are sure you want to erase the line, curve and symbol table files.
Point to Point Area: Point String	Type PP to access the Point Plot routine.



Point Plot / List Coordinates:

Click <u>Select all</u>, then click on point ~BS1 to deselect it. Finally, click <u>Accept</u>, then click <u>Done</u> to produce a point plot containing the desired points.

For the rest of this example, we do not want anything to print to the Text Output window. We also do not need to place point numbers at the points since the previous point plot has already placed them. In addition, since we now have all the drawing points on the screen, we can shut off the Auto Zooming feature to increase the drawing processing speed.

On the Main (top) toolbar, click the Continuously Scale Drawing to Fit on Screen icon ((), the Text Output icon (), and the Add End Point Labels icon () to deactivate them. (They are deactivated when a red X appears over their icons.)

First, click once on the **Text Output** window to bring the title bar into view. Next, click once on the Minimize button ($_$,or \checkmark in Windows 3.1) in the upper right corner of the **Text Output** window to reduce the window to an icon. Next, use your mouse to resize


	KESPUNSE / NUTES / ETC.
	and move the Data Entry and Drawing window to their desired positions.
	Once your "Sight" Survey screen is setup the way you want, click Properties (PR) and set the following Properties as specified below:
	Line TypeContinuousLabel TypePoint NumberEnd Point SymbolDotText PlacementDist / BngText Size10
	Click <u>Properties</u> (PR) to deselect the Properties window. We have decided that we want distances on top of the line for all interior lot lines. However, for the subdivision boundary, we want distances on the inside and bearings on the outside. We can start by drawing these lines and labeling them with distances over bearings.
Drawing Window	Type ZA (Zoom All) to view the entire drawing within the Drawing window. Also click the Quick Pick icon (\boxed{V}) on the Main (top) toolbar to activate it.
Drawing Window	Type IN to select the Inverse routine.
Inverse: From Point	11 (By default).
To Point	Press 1 to access the From Point prompt.
From Point	Click on point number 4.
To Point	Click on point number 1 . <i>A line will be drawn from point 4 to point 1, and the distance & bearing will be placed along the line.</i>
Inverse:	
From Point	1 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1 .)

PROMPT


RESPONSE / NOTES / ETC.

	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
PROMPT	RESPONSE / NOTES / ETC.
From Point	Click on point number 14.
To Point	Click on point number 11 . <i>A line will be drawn from point 14 to point 11, and the distance and bearing will be placed along the line.</i>
Inverse:	
From Point	11 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1 .)
From Point	Click on point number 18.
To Point	Click on point number 5. <i>A line will be drawn from point 18 to point 5, and the distance and bearing will be placed along the line.</i>
Inverse:	
From Point	5 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1.)

PROMPT	RESPONSE / NOTES / ETC.
From Point	Click on point number 17.
To Point	Click on point number 7. <i>A line will be drawn from point 17 to point 7, and the distance and bearing will be placed along the line.</i>
Inverse: From Point	7 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1.)
From Point	Click on point number 16.
To Point	Click on point number 8. A line will be drawn from point 16 to point 8, and the distance and bearing will be placed along the line.
Inverse:	
From Point	8 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1.)
From Point	Click on point number 15.
To Point	Click on point number 10 . <i>A line will be drawn from point 15 to point 10, and the distance and bearing will be placed along the line.</i>
Inverse: From Point	10 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1.)
From Point	Click on point number 1.
To Point	Click on point number 2. Since the line from point 1 to point 2 is too short for the bearing and distance to fit, the line will be labeled as L1 and the information will be sent to a file for the Short Line Table.




PROMPT	RESPONSE / NOTES / ETC.
To Point	Click on point number 13 . Since the line from point 14 to point 13 is too short for the bearing and distance to fit, the line will be labeled as L2 and the information will be sent to a file for the Short Line Table .
Inverse: From Point	13 (By default).
To Point	Click on point number 12 . A line will be drawn from point 13 to point 12, and the distance and bearing will be placed along the line.
Properties: Text Place	Click <u>Properties (PR)</u> to activate the Properties window. Select / Dist . After making your selection, click <u>Properties (PR)</u> again, then press <u>Esc</u> to activate the Data Entry window.
Inverse:	
From Point To Point	 12 (By default). Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1.)
From Point	Click on point number 3.
To Point	Click on point number 4 . <i>A line will be drawn from point 3 to point 4, and the distance will be placed below (or inside) the line.</i>
Inverse:	
From Point To Point	4 (By default). Click on point number 5 . <i>A line will be drawn from point 4 to point 5, and the distance will be placed below (or inside) the line.</i>
To Point	Click on point number 6. <i>A line will be drawn from point 5 to point 6, and the distance will be placed below (or inside) the line.</i>
Properties: Text Place	Click <u>Properties (PR)</u> to activate the Properties window. Select Dist /. After making your selection, click <u>Properties (PR)</u> again, then press Ess to activate the Data Entry window.
Inverse:	
From Point To Point	6 (By default). Click on point number 7. <i>A line will be drawn from point 6 to point 7, and the distance will be placed above (or inside) the line.</i>
To Point	Click on point number 8. A line will be drawn from point 7 to point 8, and the distance will be placed above (or inside) the line.



PROMPT RESPONSE / NOTES / ETC.

Inverse:	
From Point	12 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, if you prefer to use the keyboard, press 1.)
From Point	Click on point number 3.
To Point	Click on point number 6. <i>The bearing will be placed above the line from point 3 to point 6.</i>
Properties: Text Place	Click <u>Properties (PR)</u> to activate the Properties window. Select / Bng . After making your selection, click <u>Properties (PR)</u> again, then press <u>Esc</u> to activate the Data Entry window.
Inverse: From Point	6 (By default).
To Point	Click on point number 9. <i>The bearing will be placed below the line from point 6 to point 9.</i>
To Point	Click on point number 12 . <i>The bearing will be placed below the line from point 9 to point 12.</i>
	You will notice that the point number at point 10 has the bearing overwritten on it. We will address this later in this example.
Properties: Line Type	Click <u>Properties (PR)</u> to activate the Properties window. Go to Line Type select Center2. After making your selection, click <u>Properties (PR)</u> again, then press <u>Esc</u> to activate the Data Entry window.
	We do not want to place annotation on these next lines, so we will need to shut off the annotation. However, we will also need to turn back on the drawing of lines between points.
	On the Main (top) toolbar, click the Dimension Lines icon (\square) to deactivate it. Also, click once on the Draw Lines Between Points icon (\square) to reactivate it.
Inverse: From Point	12 (By default).
To Point	Click on the text entry box next to the From Point prompt to access the From Point prompt. (Or, from the keyboard, press 1 .)



On the Main (top) toolbar, click once on the Quick Pick icon (\bigcirc) to deactivate it, and click once on the Dimension Lines icon (\bigcirc) to reactivate it.

Inverse: From Point To Point

19 (By default). Type **IC** to select the **Inverse Curve** routine.

Inverse Curve: From Point Center Point From Point Center Point To Point Acute / Obtuse / Interval

Inverse Curve: From Point Center Point To Point 19 (By default).
Press 1 to access the From Point prompt.
Type 14 Fine to set the occupied point.
Type 19 Fine to set the known center point.
Type -18 Fine to set the point number for the end of arc.
Press Fine to accept the default of Acute.


18 (By default).

19 (By default).

Type **1** Page **D** to set the point number for the end of arc and bypass the last prompt on the screen.

We have now drawn all the lines that are needed on this drawing. Next, we will change the location of some of the point numbers for a cleaner looking drawing, but first, you should click once on the Save Job icon () to save your work.

If you notice on your drawing that some of the diagonally placed text and lines look darker or more bold than others, this is the result of Windows' screen font conversions. This is not a bug, and the text will appear correctly on your printer or plotter.



The rest of this example will not use the **Traverse** window, so click once on the **Minimize** button (, or in Windows 3.1) in the upper right corner of the **Traverse** window to reduce it to an icon.

By looking at the drawing on the screen, you can see that the point numbers for some of the points should be moved to a different location to avoid being overwritten by other text or lines on the drawing. There are several ways that you may do this, but we will focus on two of them.

The easiest way, shown next, is perfect if you don't need (or want) the point numbers to be in an exact location. You simply left click on the point number and hold the button down while moving the mouse cursor to the new point number location. Then, release the mouse button to complete the move.

Drawing Window Click (and hold) the mouse button on the point number label 15. Now, move the mouse slightly to the left to move it (15) away from the 80.20' arc length and onto the concave side of the arc, between the C1 and C2 arc labels. When you have the label where you want it, simply release the mouse button. (If you moved the point

PROMPT	RESPONSE / NOTES / ETC.
	number too far away, or need to adjust it further, repeat this step. If you wish to put the point label back where it was, simply click the Undo icon ($\textcircled{1}$) on the Drawing window toolbar.
Drawing Window	Repeat the last procedure for the point number label at point 10 . This makes the bearing easier to read, and leads to a cleaner looking drawing. (Remember, click and hold the mouse button on the point number label, move the mouse to where you want to place the label, then release the button. Be careful when clicking on the point number so that you don't accidentally click on the bearing annotation.)
	Now, use the same procedure to move the arc length label 81.67' on the curve between points 18 and 1. Move the text just slightly downwards, away from the N90°00'00"E bearing annotation. By moving the arc label, the text gets too far away from the arc. We can correct this by editing the angle. Double-click on the 81.67' arc label, then click $\Box K$ at the Edit Text Warning message and the Text Entry Dialog Box will appear.
Text Entry Dialog	Click the Text Defaults \rightarrow button to display the Set Text Defaults window. Double-click on the 73.9 in the Angle text entry box, and type 85 Fine. Click on OK in the Text Entry Dialog box to return to the drawing. Depending upon how far you originally moved the arc label in the previous step, you may need to change the angle slightly more or slightly less than 85 to get it to an angle that looks good.
	Now, use the same procedure to move the arc length label 80.20 ' on the curve between points 14 and 15. Move the text just slightly downwards and to the right, away from the N90°00'00"E bearing annotation. This time we will change the angle of the arc label by selecting the text and rotating it right on the screen.
	Click once on the 80.20' arc label; the text will become highlighted with eight handles (\blacksquare) appearing around it. There is also a rotate icon near the top center handle, but it is too small to see. Move the mouse cursor over the top center handle until the cursor is in the shape of a circular arrow ($\textcircled{3}$), then click the mouse button.

PROMPT	RESPONSE / NOTES / ETC.
Enter point to rotate to	Move your mouse to rotate the text. We recommend rotating the text so that the bottom of the text is now to the right of the screen. Since the text will be quite close to vertical, this will make the text more readable from the right side of the page,which will keep it consistent with the formatting that "Sight" Survey uses when placing text. When you are satisfied with the rotation, click your mouse again to set the position.
Drawing Window	The next few commands will show you another way to move (or add new) point labels, but first you must click once on the Add End Point Labels icon (
Properties:	Click <u>Properties (PR)</u> to activate the Properties window. Go to Label Place select Quad #3. Click <u>Properties (PR)</u> to deselect the Properties window.
Drawing Window	Press and hold [cff] as you right click on the dot that represents point 7. This procedure is a shortcut for the Get a Point routine, which you would normally use to capture a point off of the draw- ing and add it to your COGO file. However, we are using it here to do a "mini point plot" of one point, which results in the precise placement of a point label at the selected point.
Enter & Assign: Point Number	Press Page Dr to accept the coordinates at point 7 and label it with the point number in quadrant 3. (If the Enter & Assign dialog box does not display a point number 7, you did not click close enough to the point. Press Esc or click Cancel, then repeat the previous step.) After completing this step, point 7 will have two point number labels so we will have to delete the original point number.
Drawing Window	First left click on the point number label 7 in the upper right quad- rant of point 7. Be careful when clicking on the point number so that you don't accidentally select the line or the bearing annotation. After the point number has been selected, press Deter to delete it.
	If you accidentally delete something that shouldn't have been de- leted, simply click the Undo icon (1) on the Drawing window toolbar, and repeat this step. (If you ever need to delete more than one label at a time, you would select all the labels by pressing the

PROMPT	RESPONSE / NOTES / ETC.
	Ctrl key as you select them, and then press Delete once they have all been selected.)
Į	Before continuing, check to be certain the Continuously Scale Drawing to Fit on Screen icon (((a)) on the Main (top) toolbar is showing an inactive status (i.e. covered by a red X).
Drawing Window	We still need to move the point number label for point 16, but it is in the middle of text and an arc and it is not easy to select. How- ever, if we enlarge that portion of the drawing, we should be able to select it more easily. To enlarge this part of the drawing, click on the Zoom Window icon (()) on the Drawing window toolbar.
Zoom Window:	
Enter a corner of zoom box	Position the cursor midway between point 19 and the C3 arc label below it, then click the mouse.
Enter second corner of rectangle	Move the cursor down and to the right until it is about a third of the way into lot 5 (Southeast lot), then click the mouse.
Drawing Window	Click (and hold) the mouse on the point number label 16 . Now, move the mouse slightly to the left and down to place the point number label in between the arc labels C2 and C3 . When you have the label where you want it, simply release the mouse button.
Drawing Window	Type ZA (Zoom All) to bring the entire drawing back into view.
	We will now add end point symbols to our drawing.
Properties: End Point Symbol	Click <u>Properties</u> (PR) to activate the Properties window. Go to End Point Symbol select Iron_Pin. Click <u>Properties</u> (PR) to deselect the Properties window.
Drawing Window	Type PS to access the Point / Symbol routine.
Select the position for the end point symbol	Place your mouse cursor over point 2. Press J — to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Place your mouse cursor over point 13. Press J - Enter to jump to the exact point location and place the symbol

RESPONSE / NOTES / ETC.

Select the position for the end point symbol	Place your mouse cursor over point 1. Press J Enter to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Place your mouse cursor over point 14. Press J — Enter to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Click on the Cancel button at the top of the Drawing Window .
Properties: End Point Symbol	Click <u>Properties (PR)</u> to activate the Properties window. Go to End Point Symbol select Concrete_Mon . Click <u>Properties (PR)</u> to deselect the Properties window.
Drawing Window	Type PS to access the Point / Symbol routine.
Select the position for the end point symbol	Place your mouse cursor over point 3. Press J — Enter to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Place your mouse cursor over point 12. Press J — Enter to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Place your mouse cursor over point 6. Press J - Enter to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Place your mouse cursor over point 9. Press J <i>Enter</i> to jump to the exact point location and place the symbol.
Select the position for the end point symbol	Click on the Cancel button at the top of the Drawing Window .
the end point symbol	On the Main (top) toolbar, click the Save Job icon () to save your work. Also click the Continuously Scale Drawing to Fit on Screen icon () to reactivate it. Now type ZS (Zoom Sheet) to create room on the screen for placement of supplements.
Drawing Window Select the North arrow position	From the Draw menu, select Draw Supplemental North Arrow . Indicate the position by clicking your mouse to the right of the drawing, aligned slightly below the top of the subdivision, approximately across from point 11.

Convert attributes to text during load? No/Yes

Click No or press N.

PROMPT **RESPONSE / NOTES / ETC. Drawing Window** From the Draw menu, select Draw Supplemental >Scale Bar >2 inch Scale Bar. Select the scale bar position Indicate the position by clicking your mouse to the right of the drawing, below and to the left of the North arrow. Click No or press N. Convert attributes to text during load? No/Yes **Drawing Window** Type SL access the Short Line Table supplemental routine.

Save ? Should this data be saved for the next line table? Yes <u>N</u>o

Indicate the position by clicking your mouse to the right

of the North arrow that was previously placed.

Press N or click No to delete the short line data. By doing this, the next short line, if any, would be labeled as L1. If you prefer, you may save this data, but by the time you place the short line table, you most likely are done with your drawing and the data may never be needed again.

Type CL access the Curve Table supplemental routine. Indicate the position by clicking your mouse below the short line table that was previously placed.



Press N or click No to delete the curve data. By doing this, the next curve, if any, would be labeled as C1.

Drawing Window Select the curve table position

Select the short line

table position

RESPONSE / NOTES / ETC.

Drawing Window Coordinate Table X Enter the points you would like printed, or type a for all. OK Cancel A	From the Draw menu, select Draw Supplemental Coordinate List . Press A Entry to list all the points.
Select the coordinate table position	Indicate the position by clicking your mouse to the right of the drawing, below the curve table.
Drawing Window	From the Draw menu, select Draw Supplemental ⇒Component Table .
Select the component table position	Indicate the position by clicking your mouse underneath the subdivision.
Drawing Window	Right-click the Zoom Menu icon (\square) on the Drawing window toolbar to Zoom All and bring the entire drawing back into view. Also click once on the Save Job icon (\square) on the Main (top) toolbar to save your work.
Drawing Window Select the page center	Click the Center Paper icon () on the Main toolbar (or type CE). Indicate the new center of the paper by clicking your mouse near the center of the entire drawing, including the text.
Printing or Plotting the Drawing	To send the drawing to your printer or plotter, select File \Rightarrow Plot Drawing \Rightarrow Plot to Scale . You will need to set your output device to a landscape mode to fit the drawing on the paper.
Printing the Text	To obtain a hard copy printout of the information in the Text Out- put Window, select File Print Text , or AltE, P. After verifying your print options, click on $\bigcirc K$ or press Film. A copy of the fi- nal printout is presented here for your convenience. Formatting has been altered to fit the manual pages.

PRINTOUT	Point #	Bearing	Distance	Northing	Fasting
	r unit #	Dearing	Distance	Northing	Easting
	Accianad points				
	Assigned points Start				
	3	NW Corner Lot 1		10126.23440	19824.49650
	9	SE Corner Lot 5		9811.75440	20190.04720
	12	NE Corner Lot 7		10126.23440	20186.45650
	Start			10120.20440	20100.40000
	3	NW Corner Lot 1		10126.23440	19824.49650
	Raw: *3-12				
	EB	N 90°00'00.0" E		New Backsight E	Bna.
	Raw:	0AR	135.5		5
	TR	N 90°00'00.0" E	135.500		
	2	NE Corner Lot 1		10126.23440	19959.99650
	Raw:	0DR	80		
	SS	N 90°00'00.0" E	80.000	From Base Poin	t 2
	13	NW Corner Lot 7		10126.23440	20039.99650
	Resuming at poir	nt 2			
	2	NE Corner Lot 1		10126.23440	19959.99650
	Raw:	90.00AL	75		
	TR	S 0°00'00.0" E	75.000		
	1	SE Corner Lot 1		10051.23440	19959.99650
	Raw:	90AR	80		
	SS	N 90°00'00.0" E	80.000	From Base Poin	t 1
	14	SW Corner Lot 7		10051.23440	20039.99650
	Resuming at poir				
	1	SE Corner Lot 1		10051.23440	19959.99650
	From Point: 1	Distance: 65	_		
	Inter. Point: 19		Close Point: 14		
	DD	S 37°58'47.5" E	65.000		
	19	Center of Cul-de-S		9999.99965	19999.99650
	DD	N 37°58'47.5" E	65.000	10051 00110	
	14	SW Corner Lot 7		10051.23440	20039.99650
	Go to	05.0		40054 00440	40050 00050
	1 Energy Desirets 1	SE Corner Lot 1		10051.23440	19959.99650
	From Point: 1	Bearing: 90NW			
	Inter. Point: 4	Close Bng: 0NW			
	BB	N 90°00'00.0" W	135.500	40054 00440	40004 40050
	4	SW Corner Lot 1	75 000	10051.23440	19824.49650
	BB	N 0°00'00.0" E	75.000	40400 00440	40004 40050
	3	NW Corner Lot 1		10126.23440	19824.49650
	Go to				

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	1		1	10051.23440	19959.99650
	TA To Cntr. Pt.	S 37°58'47.5" E			
	19			9999.99965	19999.99650
	Calculation	ns based on Arc (to the		_	
		Arc 80.000	Central Angl		0°31'04.4"
		Chord 75.045	Chord Bearin		45'40.3" W
		Radius 65.000	Bng from Cn	$tr Pt = 571^\circ$	30'08.1" W
	18	Tangent 45.953		9979.37726	10020 25465
	From Point: 18	Bearing: *19-18		9919.31120	19938.35465
	Inter. Point: 5	Close Bng: 0AZ C	loco Point: 1		
	BB	S 71°30'08.1" W	120.061		
	5	071 30 00.1 W	120.001	9941.28581	19824.49650
	BB	N 0°00'00.0" W	109.949	3341.20301	10024.40000
	4			0051.23440	19824.49650
	Raw:	S0E	115		
	TR	S 0°00'00.0" E	115.000		
	5			9936.23440	19824.49650
	From Point: 5	Bearing: 0.00000 SE			
	Inter. Point: 6	Close Bng: 90.0000	0 NE Close P	oint: 9	
	BB	S 0°00'00.0" E	124.480		
	6			9811.75440	19824.49650
	BB	N 90°00'00.0" E	365.551		
	9			9811.75440	20190.04720
	IN	N 0°39'15.0" W	314.500		
	12		1	10126.23440	20186.45650
	From Point: 12	Bearing: R12,9			
	Inter. Point: 11	Close Bng: 90NW	Close P	oint: 14	
	BB	S 0°39'15.0" E	75.005		
	11			10051.23440	20187.31284
	BB	N 90°00'00.0" W	147.316		
	14		1	10051.23440	20039.99650
	Go to			0054 00440	20407 24204
	11 Receiver received	from 12 to 0		10051.23440	20187.31284
	Bearing recalled				
	Distance recalle		в		
	Raw: TR	*12, 9 S 0°39'15.0" E	R 115.000		
	10	30 33 13.0 E	115.000	9936.24190	20188.62581

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	From Point: 10 Int. Point: 15 DA	Distance: R Arc Ctr Pt: 19 C N 71°19'28.1" W	lose Point: 14 134.113		
	15 DA To Cntr. Pt.	N 71°19'28.1" W		9979.18609	20061.57406
	19			9999.99965	19999.99650
		Arc 80.202 Chord 75.210 Radius 65.000 Tangent 46.104	Central Ang Chord Bear Bng from C	ring N 16°4	0°41'44.4" 40'20.3" W 58'47.5" E
	14 Go to			10051.23440	20039.99650
	6 EP Raw:	N 90°00'00.0" E 0 6	365.551 90	9811.75440 New Backsight	19824.49650 Bng. (B.S. is 9)
	TR 7 Raw:	N 90°00'00.0" E 0DL	90.000 181	9811.75440	19914.49650
	TR 8	N 90°00'00.0" E	181.000	9811.75440	20095.49650
	Go to 19 Raw:	R19,8	65	9999.99965	19999.99650
	TR 16	S 26°53'58.0" E	65.000	9942.03253	20029.40420
	From Point: 16 Inter. Point: 17 AD To Cntr. Pt.	Ctr Point: 19 Distance: *19-7-65 N 26°53'58.0" W	Close	Point: 7	
	19	Arc 58.228 Chord 56.301 Radius 65.000 Tangent 31.231	Central Ang Chord Bear Bng from C	ring S 88°4	19999.99650 1°19'36.3" 45'50.1" W 25'38.3" W
	17 AD	S 24°25'38.3" W	141.752	9940.81801	19973.11651
	7 Go to			9811.75440	19914.49650
	19 Raw: TR	R19-5 S 70°01'55.8" W	65 65.000	9999.99965	19999.99650

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
				~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	<u> </u>
	18			9977.80262	19938.90401
	Go to				
	13			10126.23440	20039.99650
	Offset Intersection				
	01	S 0°00'00.0" E	40.000		
	OI	N 90°00'00.0" E	-40.000		
	By Offset Interse	ction			
	20	Centerline Intersection	on Pnt	10166.23440	19999.99650
	Resuming at Poi	nt			
	13			10126.23440	20039.99650
	Go to				
	19	Center of Cul-de-Sac		9999.99965	19999.99650
	IN	N 0°00'00.0" E	166.235		
	20	Centerline Intersection	on Pnt	10166.23440	19999.99650
	OS	N 90°00'00.0" W	185.500	From Base Point	20
	21	OS 185.5 L @ Pt. 20		10166.23440	19814.49650
	OS	N 90°00'00.0" E	186.500	From Base Point	20
	22	OS 186.5 R @ Pt. 20		10166.23440	20186.49650
	Exit offsets, resu	me at point			
	20	Centerline Intersection	on Pnt	10166.23440	19999.99650
	Assigned point				
	11	SE Corner Lot 7		10051.23440	20187.31284
	Editing Coordina	tes, resuming at point	11		
	<b>1</b> 1	SE Corner Lot 7		10051.23440	20187.31284
	Database Saved:	Monday, December 04	, 1995  3:45 p	om.	
	List/Plot Coordin	ates			
	Resuming at poin	nt 11			
	11	SE Corner Lot 7		10051.23440	20187.31284
	Go to				
	12	NE Corner Lot 7		10126.23440	20186.45650
	Radial Stake out				
	12	NE Corner Lot 7		10126.23440	20186.45650
		Instrument Location			
	9	SE Corner Lot 5		9811.75440	20190.04720
	•	Backsight Point			
	BS S 0°39'15.0	-	314.500		
		-	••••••		

PRINTOUT	Poir	nt #	Bearing	Distance	Northing	Easting
					3	
	RS		56°33'21.2" AR	225.172		
		19	Center of Cul-de-Sac		9999.99965	19999.99650
	Go to					
		19	Center of Cul-de-Sac		9999.99965	19999.99650
	Radia	I Stake out				
		19	Center of Cul-de-Sac		9999.99965	19999.99650
			Instrument Location			
		12	NE Corner Lot 7		10126.23440	20186.45650
			Backsight Point			
		N 55°54'06.	2" E	225.172		
	-	Points				
	RS		266°07'06.3" AR	65.000		40050 00050
		1	SE Corner Lot 1		10051.23440	19959.99650
	RS		286°30'59.2" AR	132.421		40050 00050
	-	2	NE Corner Lot 1		10126.23440	19959.99650
	RS	•	249°49'30.8" AR	216.184	40400 00440	40004 40050
	-	3	NW Corner Lot 1	400.000	10126.23440	19824.49650
	RS		230°22'21.7" AR	182.826	40054 00440	40004 40050
	DO	4	SW Corner Lot 1	400 705	10051.23440	19824.49650
	RS	-	194°07'49.6" AR	186.725	0000 00440	40004 40050
	DC	5		057.005	9936.23440	19824.49650
	RS	•	167°05'29.5" AR	257.365	0044 75440	40004 40050
	DC	6	SW Corner Lot 3	206.752	9811.75440	19824.49650
	RS	7	148°31'32.1" AR	200.752	0044 75440	10014 40650
	DC	1		044.004	9811.75440	19914.49650
	RS	•	97°11'55.8" AR	211.084	0044 75440	20005 40050
	RS	8	78°49'29.4" AR	267 400	9811.75440	20095.49650
	RO	9	SE Corner Lot 5	267.499	0044 75440	20400 04720
	RS	9	52°46'25.7" AR	100 112	9811.75440	20190.04720
	RO	10	52 40 25.7 AR	199.113	0026 24400	20100 62501
	RS	IU	18°48'03.2" AR	194.197	9936.24190	20188.62581
	КJ	11	SE Corner Lot 7	134.137	10051.23440	20187.31284
	RS		0°00'00.0" AR	225.172	10031.23440	20101.31204
	NO	12	NE Corner Lot 7	223.112	10126.23440	20186.45650
	RS	14	321°40'48.5" AR	132.421	10120.23440	20100.40000
	NO	13	NW Corner Lot 7	132.421	10126.23440	20039.99650
	RS	13	342°04'41.4" AR	65.000	10120.23440	20033.33030
	NO	14	SW Corner Lot 7	00.000	10051.23440	20039.99650
	RS	1.4	52°46'25.7" AR	65.000	10031.23440	20033.33030
	NЭ		JZ 40 ZJ./ AK	03.000		

PRINTOUT	Poir	nt #	Bearing	Distance	Northing	Easting
	FUI	IU #	Dearing	Distance	Northing	Lasting
		15			9979.18609	20061.57406
	RS	10	97°11'55.8" AR	65.000	9979.10009	20001.37400
	NO	16	37 11 33.0 AIX	05.000	9942.03253	20029.40420
	RS	10	148°31'32.1" AR	65.000	JJ42.00200	20023.40420
		17		00.000	9940.81801	19973.11651
	RS		194°07'49.6" AR	65.000		
		18			9977.80262	19938.90401
	RS		304°05'53.8" AR	166.235		
		20	Centerline Intersecti	on Pnt	10166.23440	19999.99650
	RS		255°57'47.5" AR	249.087		
		21	OS 185.5 L @ Pt. 20		10166.23440	19814.49650
	RS		352°23'11.1" AR	249.832		
		22	OS 186.5 R @ Pt. 20		10166.23440	20186.49650
	-					
	Resu	ming at poi			0000 00005	40000 00050
	Chart	19	Center of Cul-de-Sac	;	9999.99965	19999.99650
	Start	1	SE Corner Lot 1		10051.23440	19959.99650
	IN	1	N 0°00'00.0" E	75.000	10001.20440	19909.99000
		2	NE Corner Lot 1	75.000	10126.23440	19959.99650
	IN	2	N 90°00'00.0" W	135.500	10120.23440	13333.33030
		3	NW Corner Lot 1	100.000	10126.23440	19824.49650
	IN	•	S 0°00'00.0" E	75.000	10120120110	10021110000
		4	SW Corner Lot 1		10051.23440	19824.49650
	IN		S 0°00'00.0" E	115.000		
		5			9936.23440	19824.49650
	IN		S 0°00'00.0" E	124.480		
		6	SW Corner Lot 3		9811.75440	19824.49650
	IN		N 90°00'00.0" E	90.000		
		7			9811.75440	19914.49650
	IN		N 90°00'00.0" E	181.000		
		8			9811.75440	20095.49650
	IN		N 90°00'00.0" E	94.551		
		9	SE Corner Lot 5	101.105	9811.75440	20190.04720
	IN	40	N 0°39'15.0" W	124.496	0000 04400	00400 00504
		10		445.000	9936.24190	20188.62581
	IN	11	N 0°39'15.0" W	115.000	10051 02440	20407 24204
	IN	T1	SE Corner Lot 7 N 0°39'15.0" W	75.005	10051.23440	20187.31284
	IN	12	NE Corner Lot 7	75.005	10126 22440	20186.45650
		12	NE COTTIET LOU /		10126.23440	20100.40000

PRINTOUT	Point #	Bearing	Distance	Northin	ng Easting
	IN 13 IN 14	N 90°00'00.0" W NW Corner Lot 7 S 0°00'00.0" E SW Corner Lot 7	146.460 75.000	10126.234 10051.234	
	OC To Cntr. Pt. 19	S 37°58'47.5" W Center of Cul-de-Sac Arc 322.233 Chord 80.000 Radius 65.000	Central An Chord Bea Bng from (	ring N	65 19999.99650 284°02'24.9" I 90°00'00.0" W I 37°58'47.5" W
	1	SE Corner Lot 1		10051.234	40 19959.99650
	Area = 95871.805	3 Sq. Feet or 2.2009 A	cres		
	Point to Point Are Boundary: 1-14*1				
	Area = 95871.805	3 Sq. Feet or 2.2009 A	cres		
	Point to Point Are Boundary: 1-14>				
	Area = 95871.805	3 Sq. Feet or 2.2009 A	cres		
	Point to Point Are Boundary: 1-4,1	ea			
	Area = 10162.500	0 Sq. Feet or 0.2333 A	cres		
	Point to Point Are Boundary: 1-4	ea			
	Area = 10162.500	0 Sq. Feet or 0.2333 A	cres		
	Point to Point Are Boundary: 1,4,5,1				
	Area = 10908.202	4 Sq. Feet or 0.2504 A	cres		
	Point to Point Are	ea			

PRINTOUT	Point #	Bearing	Distance	Northing	Easting			
	Boundary: 18,5-7,17*19 Area = 17712.7012 Sq. Feet or 0.4066 Acres							
	Point to Point Area Boundary: 17,7,8,16*19							
	Area = 15143.7	734 Sq. Feet or 0.34	77 Acres					
		Point to Point Area Boundary: 16,8-10,15*19						
	Area = 18957.0	1895 Sq. Feet or 0.43	52 Acres					
	Point to Point Boundary: 15,							
	Area = 11970.9260 Sq. Feet or 0.2748 Acres							
	Point to Point Area Boundary: 11-14							
	Area = 11016.6	6128 Sq. Feet or 0.25	i29 Acres					
	List/Plot Coord	dinates						
	1	SE Corner Lot 1		10051.23440	19959.99650			
	2	NE Corner Lot		10126.23440	19959.99650			
	3	NW Corner Lot	1	10126.23440	19824.49650			
	4	SW Corner Lot	1	10051.23440	19824.49650			
	5			9936.23440	19824.49650			
	6	SW Corner Lot	3	9811.75440	19824.49650			
	7			9811.75440	19914.49650			
	8			9811.75440	20095.49650			
	9	SE Corner Lot 5	5	9811.75440	20190.04720			
	10			9936.24190	20188.62581			
	11	SE Corner Lot 7	,	10051.23440	20187.31284			
	12	NE Corner Lot 7	7	10126.23440	20186.45650			

PRINTOUT	Point #	Bearing D	vistance Nor	thing	Easting
	40		40400	00440	00000 00050
	13	NW Corner Lot 7		23440	20039.99650
	14	SW Corner Lot 7	10051.	23440	20039.99650
	15		9979.	18609	20061.57406
	16		9942	03253	20029.40420
	17		9940.	81801	19973.11651
	18		9977.	80262	19938.90401
	19	Center of Cul-de-Sac	9999.	99965	19999.99650
	20	Centerline Intersection	Pnt 10166.	23440	19999.99650
	21	OS 185.5 L @ Pt. 20	10166	23440	19814.49650
	22	OS 186.5 R @ Pt. 20	10166	23440	20186.49650
	~BS1 Auto	matic created BS Point	10056.84054	19968.2	7727

# END of Example 3


### Example 4: Building Location from Two Points

This example illustrates how to place a building on a lot when you have two corners of the building tied to two lot corners. To accomplish this task, "Sight" Survey uses the macro file **DrawBldg.mac**.

Begin by loading the "Sight" Survey program, and running example 3 to construct Oakwoods Subdivision. If you have already run the example, select File **Den Job** and load the file **Oakwood.Zak**.

In this example, the building will be located on Lot 5. Click the **Zoom Window** icon ( ( $\bigcirc$ ) ) in the **Drawing** window toolbar and enlarge the area around Lot 5.

The field notes are shown below.



#### **RESPONSE / NOTES / ETC.**

Traverse: From Point Click the mouse in the **Drawing** window to activate the window. You need to set the dimension text size to a value more compatible with the small point-tie dimensions you'll be placing on the drawing. Right-click the **Dimension** icon (


Dimension Settings	×
Witness & Arrow <u>U</u> nits (on paper)	points 💌
Witness <u>G</u> ap	8
Witness <u>O</u> vershoot	8
Witness Pen	
Arrowhead Length	15 • Arrow
Arrowhead <u>W</u> idth	5
✤ Mechanical style	Number Decimals
◇ A <u>r</u> chitectural style	2
<u>T</u> ext Height 6	Line <u>f</u> eed 2.5
Text Pen	Arial
OK Car	ncel <u>He</u> lp

Press Alt T to select **Text Height**. Press **Delete** to clear the present **Text Height** value, then type 6 and click OK to close the dialog box.

Press AttS, D, W to select <u>Start > Draw</u> <math>> Draw Building Location.</u>

If the setting for **Surveying Dimensions** is not set to **Distance Only**, "Sight" Survey will suggest that you change the setting. In the **Drawing** window command line, you are prompted:

For best results, set Survey Dimension Format to Distance Only.



Since you have measured only distances to tie the lot corners to the building corners, the bearings of the tie lines to the corners are irrelevant and should not be printed. Therefore, you should instruct "Sight" Survey to print only the distances. To change the setting for **Surveying Dimensions**, click <u>Yes</u>. The **Survey Dimensions Setup** dialog box appears:

### **RESPONSE / NOTES / ETC.**

Survey Dimension Setup					
Survey Dimension Orientation					
$\diamond$ Text follows bearing direction					
Text is always upright					
Survey Dimension Format					
$\diamond$ Bearing on top, Distance on bottom					
$\Diamond$ Distance on top, Bearing on bottom					
$\diamond$ Both Bearing and Distance on top					
Distance only					
Bearing direction is counter-clockwise					
Round to 0 Seconds.					
(0 uses default angular decimals)					
<u>O</u> K <u>C</u> ancel					

Under the **Survey Dimension Format** section, click the option **Distance only**. Click  $\Box \kappa$  to close the dialog box.


In the **Drawing** window command line, you are prompted:

#### Select 1st Lot Corner

The cursor has changed to the **Grab All** cursor ( $\bigcirc$ ). Move the cursor so point 15 is in the box and click.

3

We start at point 15 and go to point 16 because the macro requires distance-distance intersections to be performed in a clockwise direction. Starting at point 16 and going to point 15 would result in the structure begin located on the other side of the lot line.



In the **Drawing** window command line, you are prompted:

#### Enter distances to Near & Far corner separated by a space

Type 40.04 83.87 and press — These numbers represent the distance from point 15 to the near corner of the building, and the distance from point 15 to the far corner of the building. In the Drawing window command line, you are prompted:

Select 2nd Lot Corner

Move the **Grab All** cursor  $(\Box)$  cursor so point 16 is in the box and click. In the **Drawing** window command line, you are prompted:

Enter distances to Far & Near corner separated by a space


#### **RESPONSE / NOTES / ETC.**

3

Type **65.82 61.92** and press Fine. These numbers represent the distance from point 16 to the far corner of the building, and the distance from point 16 to the near corner of the building.

Notice that in this prompt you are asked for the Far & Near distances while in the previous distance prompt you were asked for Near & Far distances. The order of distance entry is crucial to the success of this macro. Distances must be properly paired. The first distance in both entries must go to the first point, and the second distance in both entries must go to the second point.


Upon successful data entry, an option menu appears in the **Drawing** window.



This menu governs how the ties and tie distances are to be shown on the drawing. The options are: <u>1</u>. Continue - continue without drawing lines or distances; <u>2</u>. Lines and Dimensions - draw dashed lines and label the distances; <u>3</u>. Dimensions Only - label the distances without drawing dashed lines; and <u>4</u>. Quit - quit the macro. For this example, press [2] or click on option two.

"Sight" Survey performs two distance-distance intersections and locates the building corners. Dashed lines are drawn from the lot corners to the building corners, and the tie distances are labeled. In the **Drawing** window command line, you are prompted:

Set Building Starting Corner



Move the cursor somewhere into an open area of the **Drawing** window and click or press -Enter). At this time, the location is unimportant. You have just set building corner **B** on the drawing. In the **Drawing** window command line, you are prompted:

```
      Set Next Corner


      You will now draw the building outline using the arrow keys to move the cursor measured distances. Press the right arrow ( ) and a distance prompt box appears:

      Move Right: How far?
      Type 22 ··Ener ··Ener. (The first ··Ener moves the cursor 22' to the right, the second ··Ener sets the point.) A line is drawn. In the Drawing window command line, you are prompted:

      Enter next point of polyline
```


<u>130 Setup</u>

PROMPT	RESPONSE / NOTES / ETC.
	Press the down arrow ( ]) and a distance prompt box appears:
Move Down: How far?	Type 8 <i>Enter Enter</i> . A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	
	Press the right arrow ( $\boxdot$ ) and a distance prompt box appears:
Move Right: How far?	Type <b>16</b> -Enter -Enter. A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	
	Press the up arrow ( 1) and a distance prompt box appears:
Move Up: How far?	Type <b>24</b> <u>Enter</u> . A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	
	Press the right arrow ( $\boxdot$ ) and a distance prompt box appears:
Move Right: How far?	Type <b>24</b> EnterEnter. A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	
	Press the down arrow ( ]) and a distance prompt box appears:
Move Right: How far?	Type <b>46</b> <u>-Enter</u> . A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	



PROMPT	RESPONSE / NOTES / ETC.
	Press the left arrow ( 🖃 ) and a distance prompt box appears:
Move Left: How far?	Type <b>38</b> <u>Enter</u> . A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	
	Press the up arrow ( 1) and a distance prompt box appears:
Move Up: How far?	Type <b>24</b> <u>Enter</u> . A line is drawn. In the <b>Drawing</b> window command line, you are prompted:
Enter next point of polyline	
	You have once again reached point <b>B</b> , your building has been drawn. Press $Esc$ to cancel the building drawing operation.
Enter point that must move	
	Move the <b>Grab All</b> cursor (:) so building corner B is in the box and click. In the <b>Drawing</b> window command line, you are prompted:
Enter point it should move to	
	Move the <b>Grab All</b> cursor ( $\bigcirc$ ) to the point computed by the tie distances 61.92 and 83.87, and click. The building moves to the new location. In the <b>Drawing</b> window command line, you are prompted:
Enter point about which to rotate	

The point we are at is the point around which we want to rotate. Without moving the **Grab All** cursor  $(\bigcirc)$ , press  $\bigcirc$  or click. In the **Drawing** window command line, you are prompted:



Enter angle from keyboard (else from cursor)

Since we are going to be using the other computed building corner to set our building rotation, we will not be entering the angle from the keyboard. Press  $\mathbb{N}$  or click  $\mathbb{N}^{\circ}$ . In the Drawing window command line, you are prompted:

Enter point that must rotate

Move the **Grab All** cursor  $(\Box)$  so building corner **A** is in the box and click. In the **Drawing** window command line, you are prompted:

Enter point it must rotate to

### **RESPONSE / NOTES / ETC.**

Move the **Grab All** cursor  $(\bigcirc)$  to the point computed by the tie distances 40.04 and 65.82, and click. The building rotates to the new location. In the **Drawing** window command line, you are prompted:

#### Enter point that must move

Press **Esc** to end the macro.

We will now cross-hatch the building. Since the building was constructed as polyline, "Sight" Survey can use the <u>Start</u> → <u>Settings</u> → Polyline Defaults (XP) to apply a hatch boundary. Begin by clicking the cursor on the building outline to select the building object. Type XP or right-click the Draw Polyline icon ( ) on the Drawing window toolbar to open the Polyline Style dialog box.



To cross-hatch: Press  $Alt \square$  or click on  $\underline{H}atch$ . Select a hatch pattern from the drop-down, scrollable selection menu. Press  $Alt \square$  or click  $\underline{Apply}$ .

OR To fill: Press Att S or click on Solid Fill. Select a fill color by clicking on the Solid Color button, then selecting a color from the color palette that appears. Press Att A or click Apply.



Do not be alarmed at the color of your fill. The color of selected items is always distorted. Once you de-select the item, the color will appear as you have selected it.

#### **RESPONSE / NOTES / ETC.**

Click **DK** to close the **Polyline Style** dialog box.

If you are not hatching or filling other objects at this time, you should press Att or click on Empty before closing the dialog box. Otherwise, objects drawn with polylines may automatically be hatched or filled.

If you have several building locations to draw, and you are hatching of filling each building, set your polyline defaults before entering the **Draw Building Location** routine.

When setting the polyline defaults, press Att C or click on Closed. When you do this, you do not need to enter the final building leg. Instead of entering the final leg, press s. The final leg will automatically be drawn and the building will be hatched/filled.

For example, if your building was a 50' x 30' rectangle, your keystrokes to draw the building would be as follows:

- *Enter* (to set the starting point)
- → 50 Enter (to draw 50' to the right)
- ↓ 30 Enter (to draw 30' down)
- ← **PEnter** (to draw 50' to the left)
- Esc (to draw the final 30' side and hatch/fill the building.)

### **END of Example 4**

<u>136 Setup</u>

This page intentionally left blank.

## Example 5: Least Squares Adjustment

This example illustrates the closure and adjustment of a closed traverse using the Least Squares Adjustment method. This example sets traverse points using the Enter & Assign (EA) and Traverse (TR) routines, and enters cross-ties using the Enter Diagonal (ED) routine. All distances used for the purpose of corner establishment are horizontal.

Begin by loading the "Sight" Survey program.

### PROMPT RESPONSE / NOTES / ETC.

Traverse: From Point

When the "Sight" Survey program appears, press AttG, T to access the <u>Text Output Configuration Menu</u>. In order for your prompts and printed output to follow this manual, you must set your configuration options to match the following menu screens before running the rest of this example.

Configuration Screen				×
[Text Output] Slope Entry	CAD	CO <u>G</u> O	Angle Setup	File <u>P</u> aths
Printed Precision Prin, Prec Agea: Prin, Prec <u>B</u> ings: Prin, Prec Crds: Prin, Prec Dist Prin, Prec Ejev:		Printing Print I Print E Print F	nput Data	
<u></u> K	<u>C</u> an	cel	<u>H</u> elp	

After setting your <u>Text Output</u> configuration, press Ats to access the <u>Slope Entry Configuration Menu</u>.

Configuration Screen	×
I ext Output	COGO Angle Setup File Paths
Slope Type Prompt for slope input EDM Stadja Simple Slope Angles Leveling C Total Stations EDM (Mining Option) Assigned Elevations EDM Options Difference in H.I.'s of the EDM and EDM - H.I. of Theod. ) Difference in H.I.'s of the prism and H.I. of Prism - H.I. of Target )	
<u><u> </u></u>	Cancel <u>H</u> elp

After setting your <u>Slope Entry</u> configuration, press <u>Alt</u> to access the CAD Configuration Menu.

Configuration Screen		x			
Text Output Slope Entry	CAD COGO Angle Setup File Paths				
Paper Size / Scale 1 foot = 6000 fee A 8.5x11" Cad Background Color	CAD Units Page Center C Eeet North 10700 C Meters East 10700 White				
Printed Prec Bing: 1 CIds: 5	Dimensioning of Short Lines C Shrink tegt to fit along line C Create a short line table				
Dist: 2 Elev: 2 Dist. Smbl. Text Offset	Elev: 2 Pad with space Custom Lines				
3.0	6.0 Reset OS Lavers				
<u><u> </u></u>	<u>Cancel</u> <u>H</u> elp				

After setting your CAD configuration, press  $\mbox{Alt}\mbox{G}$  to access the COGO Configuration Menu.

<u>Setup 139</u>

Itext Output     Slope Entry     CAD     COGO     Angle Setup     File Paths       Least Squares     Std. Dev. of Angle     30.000000     Sec.     Std. Dev. of Angle     0.000000     Constant Security     C0.0000       Std. Dev. of Dist.     0.0500000     Feet     C0±000.00     C0±000.00       Display Standard Deviations     Offsets (DD)     Constant Factor (CF)       Acres & Square Feet     Constant Factor (CF)       Defined Figures (DF)     Change Cogo Font	Configuration Screen	X
Std. Dev. of Angle         30.000000         Sec.         © 0+00.00           Std. Dgv. of Dist.         0.050000         Feet         © 0±000.00           Im Display Standard Deviations         Offsets (DD)         Constant Factor (CF)           Area Units         Defined Figures (DF)         Defined Figures (DF)           Acres & Square Feet         Change Cogo Font         Change Cogo Font	Text Output Slope Entry CAD CO	DGO Angle Setup File Paths
Close Tips Arter Startup     Restore All Defaults     Vindow     Automatic Point <u>N</u> umbering     Show Tool Tips     Point <u>Overwrite Protection     Create Backup File on Save </u>	Std. Dev. of Angle 30.00000 Sec. Std. Dev. of Dist. 0.050000 Feet Display Standard Deviations Area Units Acres & Square Feet Close Tips After Startup Prompt for Point Description Automatic Point Numbering Show	© 0±00.00 C 0±000.00 Constant Factor (CF) Defined Figures (DF) Change Cogo Font Restore All Defaults Old Style Cogo Window w Tool Tips
<u>DK</u> <u>C</u> ancel <u>H</u> elp	<u> </u>	Help

After setting your COGO configuration, press Att to access the <u>Angle Setup Configuration Menu</u>.

Configuration Screen					X
Text Output Slope Entry	CAD	CO <u>G</u> O	Angle Setup	File <u>P</u> aths	
Default Angle Angle Right	<u> </u>				
← Angular Units ──		⊂ Azimu			
Angle Output		⊙ SSI	Code Set Angle Codes		
CAzimuths		О∐Р	Angle Codes		
<u><u> </u></u>	<u>C</u> ano	cel	<u>H</u> elp		

When all of the items have been set to match the screens shown, press  $\overline{-Ener}$  or click on  $\overline{OK}$  to accept the changes and return to the main "Sight" Survey program screen. (On the Angle Setup screen, your Default Angle <u>must</u> be set to Angle Right.)

#### PROMPT **RESPONSE / NOTES / ETC. Traverse:** When the main "Sight" Survey program screen appears, click the **From Point** Drawing window Properties (PR) button to display the Properties. **Properties** Many drawing Properties can be set however you wish, however, if you will be sending your drawing to a plotter, the Text Font that you choose should be a plotter font such as Roman font. In addition, please set the following items as specified below. Line Type Continuous Label Type Point Number End Point Symbol Dot **Text Placement** Dist / Bng **Text Size** 10 COGO Drawing Properties Object Color 14 - Black LineType Continuous Line Width 01 Point Number Label Type Label Place Quad #1 Label Angle +0* - Horizontal End Pt. Sym Dot Dist / Bng Text Place Text Font Arial 10 Text Size 08 - Blue Text Color Text Bold No Text Italic No Text Underline No Text Strikeout No Symbols Lyr SYMBOLS COORDINATES Coords. Lyr COORDLIST Coord. List Lyr ELEVATIONS Elevations Lyr ASCII File Lyr ASCIITEXT Line Lyr LINES

Pt. Name Lyr

Points Lyr Sup. Table Lyr

Station Lyr

Pt. Number Lyr

Line Annot Lyr

PTNAMES PTNUMBERS

POINTS

SUPTABLES

LINETEXT

STATIONS


4 A A 1 5	3         Known Point         Northing         Easting           1         10000.0000         10000.0000           5         8000.0000         9997.57399           Traverse Legs           Occ.Pt         BS         FS         Angle Right         Distance           1         5         2         253*00'00"         2359.24           2         1         3         95*47'57"         2559.01           3         2         4         87*09'09"         2078.42           4         3         1         98*35'36"         2707.94           2         1         4         2         78*27'06"         2359.24           Diagonal Shots         Occ.Pt         BS         FS         Angle Right         Distance           1         5         3         208' 47'51"         3651.69         2           2         1         4         55*35'35"         3215.68         3         2         1         39*59'51"         3651.69         4         3         2         52*38'18"         3215.68
PROMPT	RESPONSE / NOTES / ETC.
Traverse: From Point	Click Properties (PR) to deselect the Properties window. Click on the Text Output window to bring the full window back into view (or select Window $\ge 1$ Text Output). Now, press $$ to activate the Traverse Entry window, and then type EA to select the Enter & Assign routine.
Enter & Assign: Point # Northing Easting Elevation Description	Type 5Enter to set the point number. Type 8000Enter. Type 9997.57399Enter. PressEnter. Type Initial BacksightEnter.
Enter & Assign: Point # Northing Easting Elevation	Type 1 - Enter to set the point number. Type 10000 - Enter. Type 10000 - Enter. Press - Enter.

	3         Known Point         Northing         Easting           1         10000.0000         10000.0000           5         8000.0000         9997.57399           Traverse Legs         Occ.Pt         BS         FS         Angle Right         Distance           1         5         2         253*00'00"         2359.24         2         1         3         95*47*57"         2559.01           3         2         4         87*09'09"         2078.42         4         3         1         98*35'36"         2707.94         2         4         3         1         98*35'36"         2707.94         2         4         2         78' 27' 06"         2359.24           2         1         4         2         78' 27' 06"         2359.24         2         1         4         2         78' 27' 06"         2359.24           2         1         4         2         78' 27' 06"         2359.24         2         1         4         2         78' 27' 06"         2359.24         2           Diagonal Shots         0         0         2         1         4         55' 35' 35'' 3215.68         3         2         1         39' 59' 51"         3651.69
5 PROMPT	4 3 2 52°38'18" 3215.68 RESPONSE / NOTES / ETC.
Description	Type SW Corner -Enter.
Enter & Assign:	
Point #	Type <b>EB</b> to select the <b>Enter Backsight Bearing</b> routine.
Enter Backsight: BS Bng	Type $*1-5$ is to recall the bearing from point 1 to point 5 and set it as the reference/backsight bearing.
Traverse: From Point	1 (Der default)
To Point	<ol> <li>(By default).</li> <li>Type ST to select the Start At routine.</li> </ol>
Start At Point: Point #	Press <b>Enter</b> to set the occupied point (1) as the starting point, and to clear the <b>Area Sum</b> and <b>Traverse Length</b> accumulators.
Traverse: From Point	1 (By default).
To Point	Type <b>ED</b> to select the <b>Enter Diagonal</b> routine.
Enter Diagonal: From Point	1 (By default).


PROMPT	<b>RESPONSE / NOTES / ETC.</b>
To Point	Type 3 we the point number.
Bearing	Type 208.4751 <i>Enter</i> to enter an angle right of 208° 47' 51".
Distance	Type 3651.69 Fine to enter the horizontal distance.
Enter Diagonal:	
From Point	1 (By default).
To Point	Type <b>TR</b> to select the Traverse routine.
raverse:	
From Point	1 (By default).
To Point	Type 2 Finer to set the point number.
Bearing	Type <b>253</b> <i>Here The to enter an angle right of 253° 00' 00".</i>
Distance	Type <b>2359.24</b> — Ito enter the horizontal distance.
Description for Pt. 2	Type SE Corner -Enter.
raverse:	
From Point	2 (By default).
To Point	Type <b>ED</b> to select the Enter Diagonal routine.
Enter Diagonal:	
From Point	2 (By default).
To Point	Type 4 we to set the point number.
Bearing	Type <b>55.3535</b> $\longrightarrow$ to enter an angle right of 55° 35' 35".
Distance	Type <b>3215.68 •Enter</b> to enter the horizontal distance.
Enter Diagonal:	
From Point	2 (By default).
To Point	Type <b>TR</b> to select the Traverse routine.
raverse:	
From Point	2 (By default).
To Point	Type 3 Fine to set the point number.
Bearing	Type <b>95.4757</b> — Enter to enter an angle right of 95° 47' 57".
Distance	Type 2559.01 <i>Penter</i> to enter the horizontal distance.

A A A A A	3         Known Point         Northing         Easting           1         10000.0000         10000.00000           5         8000.00000         9997.57399           Traverse Legs         Occ.Pt         BS         FS         Angle Right         Distance           1         5         2         253*00*00"         2359.24         2         1         3         95*47*57"         2559.01           3         2         4         87*09*09"         2078.42         4         3         1         98*35*36"         2707.94           2         1         4         2         78*27*06"         2359.24           Diagonal Shots         Occ.Pt         BS         FS         Angle Right         Distance           1         5         3         208*47*51"         3651.69         0
	2 1 4 55°35'35" 3215.68 3 2 1 39°59'51" 3651.69 4 3 2 52°38'18" 3215.68
PROMPT	RESPONSE / NOTES / ETC.
Description for Pt. 3	Press Home Delete N - Enter to edit the default (last used) description to read <b>NE Corner</b> - Enter. (If you wish, just type <b>NE Corner</b> - Enter.)
Traverse: From Point	<b>3</b> (By default).
To Point	Type <b>ED</b> to select the Enter Diagonal routine.
Enter Diagonal: From Point	<b>3</b> (By default).
To Point	Type 1
Bearing	Type <b>39.5951</b> $\longrightarrow$ to enter an angle right of 39° 59' 51".
Distance	Type <b>3651.69</b> <i>Enter</i> to enter the horizontal distance.
Enter Diagonal: From Point	<b>3</b> (By default).
To Point	Type <b>TR</b> to select the Traverse routine.
Traverse: From Point	3 (By default).
To Point	Type 4 <i>Enter</i> to set the point number.
Bearing	Type $87.0909$ $results$ to enter an angle right of $87^{\circ}$ 09' 09".
Distance	Type <b>2078.42</b> - Ito enter the horizontal distance.

PROMPT	<b>RESPONSE / NOTES / ETC.</b>
Description for Pt. 4	Press Home  Delete W  -Enter to edit the default (last used) description to read NW Corner -Enter.
Traverse:	
From Point	4 (By default).
To Point	Type <b>ED</b> to select the Enter Diagonal routine.
Enter Diagonal:	
From Point	4 (By default).
To Point	Type 2
Bearing	Type <b>52.3818</b> It enter an angle right of 52° 38' 18".
Distance	Type <b>3215.68 </b> Enter the horizontal distance.
Enter Diagonal:	
From Point	4 (By default).
To Point	Type <b>TC</b> to select the <b>Traverse Closure</b> routine.
Traverse Close:	
From Point	4 (By default).
Close to	Type 1
Bearing	Type <b>98.3536</b> <i>Enter</i> to enter an angle right of 98° 35' 36".
Distance	Type 2707.94
Enter closing ANGLE RIGHT a backsighting Pt. 4 foresighting	
Press <enter> if unknown</enter>	Type <b>78.2706</b> $\longrightarrow$ to enter an angle right of 78° 27' 06".



Press Y or click Yes to save this job before proceeding with the traverse adjustment. (Up to this point, your data has been saved in a temporary file called COGO.ZAK, used to store COGO data until the job is saved to a different file name, or a new job is opened.)



Save As File <u>N</u>ame:

**Unbalanced Traverse** 

Type LstSqrs File. "Sight" Survey will save your file and display the Unbalanced Traverse window showing the current traverse statistics and your raw traverse data. The Northing and Easting of the Calculated Closing Point, closure bearing, and distance have also been printed in the Text Output window.

Calculated Closing Point	9999.84901	10000.23838
TC N 57°38'55.9" W	0.282	


Status 0.151 0.151											
Precision Ratio: 1 : 34392 Error in Latitude: 0.151 A Length Traversed: 9704.610 Error In Departure: 0.238											Add <u>L</u> eg
										DelLeg	
Area: 5785222.5650 Sq. Feet or 132.8104 Total Angular Error: 0°00'12.0"											
Acres Error per station: 0*00'03.0"									Со <u>р</u> у		
н										Help	
									Cancel		
<u>D</u> 017	singi		ipuss		union .	Lot ogi		- <u>a</u> n	- i ilin		
Leg	Act	BS Pt	At Pt	Bearing	S.Dev	Distance	S.Dev	FS Pt	Northing	Easting	Description
BS	EB	N/A	~BS1	0.0410200117 SW	0.000	10.000	0.0000	1	10000.00000	10000.00000	SW Corner
1	ST	~BS1	1	N/A	0.000	N/A	0.0000	1	10000.00000	10000.00000	SW Corner
2	ED	~BS1	1	208.4751 AR	30.000	3651.690	0.0500	3	13197.94098	11762.95586	NE Corner
3	TB	~BS1	1	253 AR	30.000	2359.240	0.0500	2	10687.03779	12256.98747	SE Corner
4	ED	1	2	55.3535 AR	30.000	3215.680	0.0500	4	12695.97756	9746.05959	NW Corner
5	TB	1	2	95.4757 AR	30.000	2559.010	0.0500	3	13197.90573	11762.94864	NE Corner
6	ED	2	3	39.5951 AR	30.000	3651.690	0.0500	1	9999.93911	10000.03930	SW Corner
7	TB	2	3	87.0909 AR	30.000	2078.420	0.0500	4	12695.83548	9746.08098	NW Corner
8	ED	3	4	52.3818 AR	30.000	3215.680	0.0500	2	10687.02962	12257.11600	SE Corner
9	TC	3	4	98.3536 AR	30.000	2707.940	0.0500	1	9999.84901	10000.23838	Temporary
10	CA	4	1	78.2706AR	30.000	N/A	0.0000	2	10687.03779	12256.98747	SE Corner

## RESPONSE / NOTES / ETC.

The **Unbalanced Traverse** window allows you to easily review and edit your traverse data. More importantly, however, it allows you to manipulate the weighting of the Standard Deviations for **angles** and **distances**. Please refer to Standard Deviations in **Section 9.16** for more information.

If you make any modifications to this window, you must press Alt or click **Re-Run** to recalculate the data before proceeding with an adjustment.

Press Alt O or click Lst Sgr to choose the Least Squares option. "Sight" Survey will automatically save the raw data and display:



# Click Yes

#### **Reviewing the Adjustment**

**Select an Adjustment Option** 

Depending upon your video resolution, you may need to increase the width of the adjustment window to view the entire window.

Traverse Adjusted by Least Squares     Status Precision Ratio:     1:3.47E+12 Error in Latitude:     0.000 Length Traversed     9704.515 Error in Departure:     0.000 Length Traversed:     9000 Error in Elevation:     00000 Del Leng Area:     5785733.7615 Sq. Feet or 132.8222 Total Angular Error:     0'0000.0" Cogy													
Letter         Difference         Difference         Difference         Help           Bel Angli         Compass         Grandali         Transit         Lat Sgr         Fie Figur         Primt         Accept         Cancel													
		BS Pt		Bearing		Distance			Northing	SDev			SDev E
BS	EB	N/A		0.0410200117 SW					10000.0000			10000.00000	
1	ST	~BS1	1	N/A	0.000				10000.0000			10000.00000	
2	ED	~BS1	1	28.5159280800 NE								11762.92552	
3	TR	~BS1		73.0405611595 NE								12256.97265	
4	ED	1	_	51.2016846529 NW								9746.02510	
5	TR	1	-	11.0753453068 NW								11762.92552	
6	ED	2		28.5159280800 SW					10000.0000	-		10000.00000	
7	TR	2		76.0128225218 SW								9746.02510	
8	ED	3		01.2010040020 02								12256.97265	
9	TC	3		5.2253844325 SE	30.000	2707.939	0.0500	1	10000.0000	0	n/a	10000.00000	n/a
10	CA	4	1	73.0405611595 NE	30.000	N/A	0.0000	2	10687.0881	4 +/- 0.0	35760	12256.97265	+/-0.013249
4													Þ

# PROMPT

PROMPT	RESPONSE / NOTES / ETC.
	To review the adjustment, look closely at values computed in the columns entitled <b>SDev N</b> and <b>SDev E</b> to determine if the adjustment results are satisfactory.
Printing Adjustment Data	The <b>Standard Deviation</b> values are not a part of the normal text printout in the <b>Text Output</b> window, and therefore do not get printed when the <b>Print</b> function is selected. However, if you do want to print these values, you can highlight the desired column(s) or the entire grid and click the <b>Copp</b> button (or press <b>AHP</b> ) to copy the highlighted data to the Windows Clipboard. Then you can Paste the copied data into "Sight" Survey's <b>Text Output</b> window, into your favorite word processor, or into the Microsoft <b>Excel®</b> spreadsheet program.
ஞ	To copy the entire <b>Traverse Adjustment</b> grid, click on the <b>Leg</b> column heading (first column) to highlight the entire grid and then click the <b>Copy</b> button (or press <b>AITP</b> ). Next, use the <b>Paste</b> function to paste the data into the desired program.
Ĩ	When copying information from any of the Traverse Adjustment windows, you must use the Copy BUTTON (or press AltP). DO NOT use the Copy routine from the Edit pull-down menu.
Accepting the Adjustment	Click the Accept button, or press Att A to accept the adjustment data. The adjustment windows will be closed and the traverse adjustment data will automatically re-run. As the traverse data is re-run, the Drawing and Text Output Windows will be updated accordingly.
Saving the Data	Now would be a really good time to save your work. To save all data associated with this job, click the $\blacksquare$ icon on the toolbar (or type SC, or select File $\Rightarrow$ Save).
Listing the Final Coordinates	Type LC to select the List Coordinates routine. Press Area to list all the coordinates in the file. After the coordinate list has been

PROMPT	RESPONSE / NOTES / ETC.
	sent to the <b>Text Output</b> window, you will regain control at the "Sight" Survey <b>Data Entry</b> window.
Printing or Plotting the Drawing	To send the drawing to your printer or plotter, select <b>File</b> $\Rightarrow$ <b>Plot Drawing</b> $\Rightarrow$ <b>Plot to Scale</b> .
Printing the Text	To obtain a hard copy printout of the information in the <b>Text</b> <b>Output Window</b> , select <b>File</b> $\Rightarrow$ <b>Print Text</b> , or <b>Aft F</b> , <b>P</b> . After verifying your print options, click on <b>OK</b> or press <b>Print</b> . A copy of the final printout is presented here for your convenience.

DDINTOUT	Doint #	Description	Distance	Neuthin	Fasting
PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	Assigned points				
	Start				
	5	Initial Backsight		8000.0000	9997.57399
	1	SW Corner		10000.00000	10000.00000
	Raw:	*1-5			
	EB	S 0°04'10.2" W		New Bac	cksight Bng.
	Start				
	1	SW Corner		10000.00000	10000.00000
	Raw:	208.4751 AR	3651.69		
	ED	N 28°52'01.2" E	3651.690	From Base P	oint 1
	3			13197.94098	11762.95586
	Resuming at poir	nt 1			
	1 '	SW Corner		10000.00000	10000.00000
	Raw:	253 AR	2359.24		
	TR	N 73°04'10.2" E	2359.240		
	2	SE Corner		10687.03779	12256.98747
	Raw:	55.3535 AR	3215.68		
	ED	N 51°20'14.8" W	3215.680	From Base P	oint 2
	4		0210.000	12695.97756	9746.05959
				12000.01100	5740.00000
	Resuming at poir				
	2	SE Corner		10687.03779	12256.98747
	Raw:	95.4757 AR	2559.01		
	TR	N 11°07'52.8" W	2559.010		
	3	NE Corner		13197.90573	11762.94864

1

PRINTOUT	Point #	£	Bearing		Distance	Northing	Easting
	Raw:		39.5951	AR	3651.69		
	ED		S 28°51'5	58.2" W	3651.690	From Base F	
	1	l				9999.93911	10000.03930
	Posumin	g at poin	12				
	Resumm		NE Corne	ar		13197.90573	11762.94864
	Raw:		87.0909		2078.42	10101.00010	11102.04004
	TR		S 76°01'1		2078.420		
	4	L .	<b>NW Corn</b>			12695.83548	9746.08098
	Raw:		52.3818	AR	3215.68		
	ED		S 51°20'2	25.8" E	3215.680	From Base F	Point 4
	2	2				10687.02962	12257.11600
	Decumin						
		g at poin I	t 4 NW Corn	~~		12695.83548	9746.08098
	Raw:	ŀ	98.3536		2707.94	12095.05540	9740.00090
	TC		S 5°23'07		2707.94		
	1	I		ed Closing P		9999.84901	10000.23838
	TC		N 57°38'		0.282		
	1	•	SW Corn			10000.00000	10000.00000
				2 = AR 78°		(RAW: 78.2706	)
	Database	e Saved:	Tuesday,	September	17, 1996 1:3	6 pm.	
	Entering	Traverse	Adjustme	ent mode			
	Lintoning	inaroioo	/ lajuotini				
	Precisior	n Ratio	=	1 : 34392			
		raversed	=	9704.610			
	Length T	o Close	=	0.282			
			_	0.454			
	Error in L		=	0.151 0.238			
	Error in E	Departure	_	0.230			
			-	0.000			
	Area = 5	785222.56	50 Sq. Fe	et or 132.8	104 Acres		
	Total And	gular Erro	or =	00°00'12.0"			
	Error Per	-	- =	0°00'03.0"			

Traverse Adjusted by Least Squares

PRINTOUT	Poin	t #	Bearing	Distance	Northing	Easting
	Porun	ning Trovo	rse Adjusted by Leas	Squaraa		
	Refuii	ining mave	TSE AUJUSTEU DY LEAS	Judies		
	Invers	ing Adjust	ed Points			
	Go to		0111 0		(	40000 00000
		1	SW Corner	40.000	10000.00000	10000.00000
	EP		S 0°04'10.2" W	10.000	New Backsight	Bng. (B.S. is ~BS1)
	Start	1	SW Corner		10000.00000	10000.00000
	RI	1	N 28°52'01.1" E	3651.689	From Base Pc	
	RI .	3	NE Corner	3031.009	13197.94093	11762.95361
		5			13131.34033	11702.93301
	Resum	ning at poi	nt 1			
	neoun	1	SW Corner		10000.00000	10000.00000
	Raw:		73.0407659598 NE	2359.2418		10000.00000
	TR		N 73°04'07.7" E	2359.242		
		2	SE Corner		10687.06614	12256.98080
	RI	-	N 51°20'15.1" W	3215.680	From Base Po	
		4	NW Corner		12696.00198	9746.05029
	Resum	ning at poi	nt 2			
		2	SE Corner		10687.06614	12256.98080
	Raw:		11.0751773612 NW	2559.0144	761166	
	TR		N 11°07'51.8" W	2559.014		
		3	NE Corner		13197.94093	11762.95361
	RI		S 28°52'01.1" W	3651.689	From Base Po	oint 3
		1	SW Corner		10000.00000	10000.00000
	Resum	ning at poi	nt 3			
	Result	3	NE Corner		13197.94093	11762.95361
	Raw:	•	76.0129699905 SW	2078.4228		11102.33301
	TR		S 76°01'29.7" W	2078.423	000001	
		4	NW Corner	2010.420	12696.00198	9746.05029
	RI		S 51°20'15.1" E	3215.680	From Base Po	
	N.	2	SE Corner	5215.000	10687.06614	12256.98080
		2			10007.00014	12230.30000
	Resum	ning at poi	nt 4			
		4	NW Corner		12696.00198	9746.05029
	IN		S 5°22'51.9" E	2707.936		
		1	SW Corner		10000.00000	10000.00000

PRINTOUT	Point #	Bearing	Distance	Northing	Easting
	$\Lambda_{ro2} = 5785734.07$	746 Sq. Feet or 132.82	22 Acres		
	Alea - 5105154.01	140 0q. 1 eet 01 102.02			
	Precision Ratio	= 1:9.80E+11			
	Length Traversed	= 9704.615	5		
	Length To Close	= 0.000	)		
	Error in Latitude	= 0.000	)		
	Error in Departure	e = 0.000	)		
	Error in Elevation		)		
	Area = 5785734.07	746 Sq. Feet or 132.82	22 Acres		
	Total Angular Erro	or = 0°00'00.0'			
	Error Per Station	= 0°00'00.0'			
	Database Saved:	Tuesday, September	17, 1996 1:36	δ pm.	
	List/Plot Coordina	ates			
	1	SW Corner		10000.00000	10000.00000
	2	SE Corner		10687.06614	12256.98080
	3	NE Corner		13197.94093	11762.95361
	4	NW Corner		12696.00198	9746.05029
	5	Initial Backsight		8000.00000	9997.57399
	201				

• A backsight point is automatically created when the Enter Backsight Bearing (EB) routine is used. If you wish to avoid having these points created, use the Enter Backsight Point (EP) routine instead.

9990.00001

9999.98787

# END of Example 5

*Automatic created BS point

~BS1

## **Routine Index**

Adjustment Compass Rule - 52 Crandall Rule - 53 Least Squares - 47 Adjustments: Comparing - 54 Angle Balance - 51 Angle Setup Configuration - 44 Arc-Distance Intersection - 87 Auto Zooming - 98 Backsight Bearing: Enter - 75 Point: Enter - 61 Balance Angles - 51 Bearing: Recall - 83 Bearing-Bearing Intersection: - 77 CAD Configuration - 43 Center Paper - 114 COGO Configuration - 44 Comparing Adjustments - 54 Compass Rule Adjustment - 52 Component Table - 114 Configuration Angle Setup - 44 CAD - 43 COGO - 44 Slope Entry - 43 Text Output - 42 Continuously Scale Drawing - 98 Coordinates: Edit - 90 Crandall Rule Adjustment - 53 Cross Hatch - 135 Curve Table - 113 Curve Inverse Obtuse - 94 Inverse - 107 Diagonal Enter - 142

**Dimension Settings - 125** Distance Recall - 84 Distance-Arc Intersection - 84 Distance-Distance Intersection - 76 Draw Component Table - 114 Curve Table - 113 North Arrow - 112 Point/Symbol - 111 Scale Bar - 112 Short Line Table - 113 Draw Building Location - 125 Drawing Erase - 91 Edit Coordinates - 90 Enter and Assign - 46 Enter Backsight Bearing - 75 Enter Backsight Point - 61 Enter Diagonal - 142 Erase Drawing - 91 Hatch/Fill - 135 Go To Point - 77 Intersection Arc-Distance - 87 Bearing-Bearing - 77 Distance-Arc - 84 Distance-Distance - 76 Offset - 88 Inverse - 47 Inverse Curve - 107 Inverse Obtuse Curve - 94 Least Squares Adjustment - 147 List Coordinates - 97

# 3.06

Modified Traverse Window - 50 Moving Text - 109 North Arrow - 112 Object Explode - 135 Offset - 89 Offset Intersection - 88

Plotting the Drawing - 56 Point Name Output Toggle - 88 Point Plot - 92 Point to Point Area - 95 Point/Symbol - 111 Polyline Defaults - 135 Printing the Text - 56 Properties Window - 45

Quick Pick - 98

Radial Stake Out - 92 Recall Bearing - 83 Recall Distance - 84 Rotating Text - 109

Save Job - 55 Save Job As - 49 Scale Bar - 112 Select Bearing (from the drawing) - 81 Select Point (from the drawing) - 81 Set Polyline Defaults - 135 Short Line Table - 113 Side Shot - 75 Slope Entry Configuration - 43 Start At - 47 Start Draw Draw Building Location - 125 Start Draw Draw Building Location - 125 Start Diget Diget Explode - 135 Survey Dimension Setup - 127

Text Output Configuration - 42 Text Moving - 109 Rotating - 109 Traverse - 47 Traverse Arc - 78 Traverse Close - 48

Unbalanced Traverse Window - 49 Undo - 79

Zoom

All - 99 Menu - 114 Window - 111

This index only covers routines used in the examples. A comprehensive index is contained at the end of the COGO Reference Manual and also the Drawing Window Reference Manual.



4.01	General Data Entry Procedures
	All "Sight" Survey routines have been standardized to accept data entries in a manner which is common throughout the program. This section deals with the nature of the data entry as it pertains to points, bearings, distances, stations, coordinates, and point names.
Backup Your Data	When you close a "Sight" Survey session, you're given an oppor- tunity to save your data. However, you can save your data at any time by selecting the <b>File</b> $\Rightarrow$ <b>Save Job</b> option by typing ARF, <b>S</b> or the two letter code <b>SC</b> (for Store Coordinates).
	A very important habit to maintain involves taking the time to back up your data. The price of an extra disk is a small amount to pay to insure yourself against the loss of many hours of labor. If you are using floppy disks, keep in mind that they are somewhat fragile and data loss can be caused in the blink of an eye by dust, moisture, fingerprints, bending, etc. You can back up your data files using the <b>File Copy Job</b> routine (Att F, J). If you regularly store your jobs on a hard drive, you should periodically back them up to a floppy disk or a tape drive.

4.02

# **Point Identifiers**

"Sight" Survey is designed to allow point entry in a wide variety of convenient methods. While a point number (numeric or alphanumeric) is a required element for all points, you also have the option of referring to points by names or by station numbers.

Point Numbers

Entering point numbers into "Sight" Survey is as easy as typing them on your keyboard. Any number is a valid number, from 0 up to 99999999, as is any alphanumeric combination up to eight characters long. We hate to admit it, but "Sight" Survey does have



a limit on the number of points it can accept, albeit one we think you can live with it. What's the limit? *"Sight" Survey can accept over 3.5 trillion points!* (3,512,479,453,392 to be exact, disk storage space permitting.)

"Sight" Survey includes optional Automatic Point Numbering. In most COGO routines that compute and set a data point, automatic point numbering may be used to seek out the next available point number. To activate or deactivate automatic point numbering, type in AN (or AltiG, G, AltiN, "Ener) at any data entry prompt.

Alphanumeric Point Numbers "Sight" Survey allows the use of numeric or alphanumeric point numbers, up to 8 characters in length. To use an alphanumeric point number, press the single quote (') *before* typing any alphabetic characters. For example, to use point number 100A, type 100'A or '100A, and to use point number NECORNER, type 'NECORNER.

Because "Sight" Survey uses alphabetic characters for routine codes, you must press the single quote ( ' ) to notify the program that the characters you will type are not routine codes. After pressing the single quote, the status bar at the bottom of the screen will display the message:

Entering alphanumeric data - Automatic Routine Jumping Turned Off.

If you have accidentally press the quote key, simple press it again and the status bar at the bottom of the screen will display:

Entering numeric data - Automatic Routine Jumping Turned On.



You will not see the single quote on the screen. It is simply a toggle code and is not part of the actual point number.

Points may also be entered through the **Select Point** function. The **Select Point** function is used to pick a point from the drawing to be used as data entry into a point number field. The point that is selected must be an existing COGO point.

Select Point

To access **Select** <u>Point</u> from the keyboard, use the command **SP** or press <u>Att</u>D, P. The **Drawing** window command line prompts:

#### Select a point

Using the **Grab All** cursor ( $\Box$ ) in the **Drawing** window, click on the point to be picked. You don't have to be exact, but the point must lie within the **Grab All** cursor box or you may not get the point you want. The point number of the selected point will be automatically entered into the point field in the **Data Entry** window.

- 3
- Before using the Select Point feature, be certain your cursor is located in a point entry field in the Data Entry window.

"Sight" Survey includes **Point Overwrite Protection**. To activate or deactivate this feature, type **CM** and then press **Alt**, **Alt**, **Alt**, **Pene** (or **Alt**, **G**, **Alt**, **V**, **Pene**).

If you attempt to reuse an existing point while the overwrite protection is off, *the old point will be overwritten with no warning*. If you attempt to reuse a point while the overwrite protection is on, you will receive this warning window:

Po	int Number Error	×
	Point "1" is already in use!	
	Enter New Pt <u>O</u> verwrite Pt	

The warning window offers two options, **Enter New Point**, or **Overwrite Point**. Select an option with your mouse or keyboard.



#### **Point Overwrite Protection**

### **Point Names**

Naming a point may be done at any request for a point number, or by using the **Identify Point** routine. Call this routine by typing **ID** (or **Att**P, **1**) at any data entry prompt. Point names may be up to 28 characters in length.

**Description Dialog Box** When you enter a point name, the description dialog box appears:

	Description for Pt. 4
	NW Corner Lot 11
Alt - 1	Iron Pin
Alt - 2	Concrete Monument
Alt - 3	
Alt - 4	
Alt - 5	

From this dialog box, you have several options. You can:

- Enter a point description by typing the description into the top line and pressing *energy*.
- Enter point descriptions into any of the alternate description fields for later use. If you press with alternate description will also be used as the current description. You can fill all the alternate fields while the dialog box is open by using your mouse to move between fields. If you fill alternate fields but do not want to enter a point description for the current point, delete any text in the top description field and press with. The descriptions entered into the five alternate description fields are retained between "Sight" Survey sessions.
- Select an alternate descriptions by pressing Alt followed by the description number and <u>-Ener</u>, such as: Alt <u>-Ener</u>;
- Click the down arrow and select one of the previously entered descriptions. All descriptions entered during a "Sight" Survey session are accumulated in the drop-down menu for easy re-use, however the descriptions are not retained between sessions.

#### **Edit Coordinates Window**

You can also add, edit or delete a point name from within the **Edit Coordinates** (**EC**) window.

Point	Northing	Easting	Elevation Description	
1	10051.23475	19960.00000	101.700 SE Cor Lot 1	
2	10126.23475	19960.00000	101.700 NE Cor Lot 1	
3	10126.23475	19824.50000	101.700 N₩ Corner Blk 1	
4	10051.23475	19824.50000	102.400	
5	9936.23475	19824.50000	100.600	
6	9811.75475	19824.50000	99.800 SW Cor Blk 1	
7	9811.75475	19914.50000	100.400	
8	9811.75475	20095.50000	101.400	
9	9811.75475	20190.05000	103.500 SE Cor Blk 1	
10	9936.24225	20188.62862	102.800	
11	10051.23475	20187.31565	102.200	
12	10126.23475	20186.45931	101.300 NE Cor Blk 1	
13	10126.23475	20040.00000	100.800 N₩ Cor Lot 7	-
				•

In this window you can edit points and descriptions, renumber points, add points, delete points, select a point to use, and copy a point or block of points.

To add, edit or delete a point name, click your mouse on the chosen description. If you are adding or replacing a description, simply begin typing to overwrite the contents of the existing line. To delete an existing description, press [Space Bar] (-Enter].

To edit a description, click your mouse on the description again. The field color will change from dark gray to white and the text cursor will move to the front of the text. Use your mouse, or the  $\bigcirc$  or  $\bigcirc$  keys to position the cursor at the edit point. Make your editing changes and press  $\bigcirc$ .

If you frequently use point names in COGO, you can instruct "Sight" Survey to automatically prompt for names (CM Aft G, Aft M) and include them in all printouts by activating the Names Output toggle (NO). This on/off switch is actuated by typing NO at any data entry prompt.

When "Sight" Survey computes stations, they are formatted in an *English* or *metric* format as specified in the Config OGO Configuration menu, (CM (AttG) or (AttG), (M), (AttG)). Stationing precision matches the distance precision, from 0 to 6 decimal places, as specified in the Config OGO Text Output Configuration menu, (CM (AttG), (T)).

**Stations** 

## **Entering Stations**

When **Traversing with Stations** and when computing **Circular Curves** (by deflections, tangent, or chord offset methods), **Vertical Curves and Alignment**, and **Spiral Curves**, you will be required to enter station data. Enter the station in a format as shown in the following examples:

ENGLISH UNITS			
Station Distance	Enter as Station		
25.0 feet	0.25 or 0+25		
600.0 feet	6 or 6+00		
1675.0 feet	16.75 or 16+75		
1550.4 feet	15.504 or 15+50.4		
12535.3 feet	125.353 or 125+35.3		

Care must be taken to avoid entering an erroneous station. For example, entering 1+50 as 150 results in a station of 150+00. The station should be entered as 1+50 or 1.50.

METRIC UNITS				
Station Distance	Enter as Station			
25.0 meters	0.025 or 0+025			
600.0 meters	.6 or 0+600			
1675.0 meters	1.675 or 1+675			
1550.4 meters	1.5504 or 1+550.4			
12535.3 meters	12.5353 or 12+535.3			

Care must be taken to avoid entering an erroneous station. For example, entering a station at 150 meters as **150** results in a station of 150+000. The station should be entered as **.150** or **0+150**.

# 4.03

# Searching For A Point By Name

As previously stated, the COGO program requires the assignment, of point numbers. However, COGO is also capable of searching for a particular point if it has been given a description or name.

To search for a point by name, type a ? followed by a point name, or a portion thereof. This type of entry results in a search for a partial match. That is, even if you only have a portion of the name, or wish to see which points may share a common element of a name, the routine will still work.

For example, with the *Oakwoods* file loaded, a point entry of **?NW** results in the **Matching Points** window shown below:



These are the two points in the file that contain names starting with the characters **NW**. Use your mouse or **1** and **1** keys to highlight a point and then press <u>-Enter</u> or click <u>Accept</u>. If you don't see the point you want, check to see if the selection window has a scroll bar on the right side. If it has a scroll bar, scroll down through the list. If you want to cancel the operation, press <u>Esc</u> or click <u>Cancel</u>.



Searches are not case sensitive. In other words, NW = nw = Nw = nW.

Point name searching allows the use of the wildcard characters ***** and **?** within the specified description. (A **?** used *within* the description is different from a **?** at the *beginning* of the description where it calls the search mode.) A **?** replaces a single character while the ***** replaces any number of characters.

For example: in the *Oakwoods* file, a search for the name **?*n?e** will return only point **19**, whose description is **Center of Cul-de-Sac**. This is because you are asking "Sight" Survey to search for any point name containing an "n" followed by any other character, which is followed by an "e". (Center) Similarly, an entry of **?*cor** will return eight points that contain the characters **cor**.

#### **Wildcard Characters**



An entry of ? or ?* will return a list of the points having a description of any kind. The list will display a maximum of 200 points at a time.

#### **Point Ranges**

In "inverse" type coordinate geometry routines, (routines that *measure between* points, rather than routines that *compute* points), you may speed your data entry by entering a point range instead of a single point at a time. For example, suppose you wanted to inverse the outside boundary of the Oakwoods subdivision. In a single entity entry scheme, you would press the following keys:

ST, 1-Enter, 1N, 2-Enter, 3-Enter, 4-Enter, 5-Enter, 6-Enter, 7-Enter, 8-Enter, 9-Enter, 10-Enter, 11-Enter, 12-Enter, 13-Enter, 14-Enter, 1C, 19-Enter, 15-Enter-Enter, 16-Enter-Enter, 17-Enter-Enter, 18 -Enter-Enter, 1-Enter-Enter

Contrast that entry sequence of 61 key presses with one incorporating point ranges and using only 23 key presses:

ST, 1-Enter, IN, -14-Enter, IC, 19-Enter, -18-Enter, -1-Enter-Enter

The results for the second sequence are the same as the first, yet you've used less than 40% of the key presses. Not only that, but your time savings are even greater.

It's even more dramatic if you have a larger point list to inverse through. For example, say you have a meander line containing 200 points, consecutively numbered. Method one requires 696 key presses to inverse through 199 legs. Even streamlining the first method by replacing each point number with a + key requires 404 key presses. However with method 2, "Sight" Survey requires only 11 key presses: ST, 1-Enter, IN, -200-Enter.

4.04



1. A point range may cross over from one routine into another. For example, a point string may automatically change between the **Inverse** and **Inverse Curve** routine. See

2. Point ranges are not allowed when working with alphanumeric point numbers.

the **Point Strings** discussion below.

You may group points into point strings called **Defined Figures**. Defined figures can be accessed as a single entity, such as **Lot 1**, allowing for much greater ease of data entry. Defined figures are discussed in detail beginning on page 249 of this manual.

Using a point string or defined figure, you can cross over from the line-inverse routines into the arc-inverse routines and vice-a-versa. For example, assuming you are already in the Inverse routine, the string 2,1*19,18,5-7,17>19,14,1 goes from Inverse (IN) to Inverse Curve (IC) back to Inverse (IN) and into Inverse Obtuse Curve (OC) and back to Inverse (IN). When used within a point string, the * character signals "Sight" Survey to run Inverse Curve (IC) and the character > signals "Sight" Survey to run Inverse Obtuse Obtuse Curve (OC). The data entry rules for point strings are listed on page 252 of this manual.

Directiona

## **Directional Entries**

When entering angular data, both horizontal and vertical, enter all angular data in one of two user-selected formats: *degrees* (as **D.MMSS**), or *grads*. The format selection is made through the use of the **Config**  $\Rightarrow$  <u>Angle Configuration</u> window which is discussed on page 408.

The D.MMSS Format Enter angular entries in the D.MMSS format by separating the degrees value from the remainder of the entry with a decimal. For example; enter 45° 30' 50" as 45.3050. There is no need to enter any trailing values if the values are zero. For instance, 45° 30'

## 4.05

**Point Strings** 

SSI (Simplicity Systems)

Angle Code Set

00" may be entered as 45.30 (or 45.3). Likewise, an even  $55^{\circ}$  should be entered simply as 55.

In the D.MMSS format, you must not use decimal points on fractional seconds entries. Simply omit the decimal point. An angle entry of 45° 25' 35.65" should be entered as **45.253565** and not as **45.2535.65** or the bearing entry will be interpreted as "zero".

The Grads FormatThe grad is a unit of measure equivalent to 1/400th of a circle.Grads are expressed as decimal values and may be formatted in<br/>"Sight" Survey with up to 6 decimal places.

Angle Codes & Function Keys In the degrees format, directional entries may be in the form of bearings, angles left or right, deflection angles left or right, or as North or South referenced azimuths. In the grads format, while entries may be made as bearings, they will always be output as North or South referenced azimuths.

The information that identifies the directional type is referred to as the *angle code*. Angle codes may be entered by number, by two letter alpha codes, or by pressing function keys. "Sight" Survey provides angle codes in two flavors, largely as a result of keyboard changes over the years, and also as an attempt to provide you with compatibility to other COGO programs you may also be using. These Angle Code Sets are shown below. The desired Angle Code Set is selected in the Config  $\Rightarrow$  Angle Configuration menu.

Angle Code	Alpha Code	Numeric Code	Function Key
Northeast	NE	1	F1
Southeast	SE	2	F2
Southwest	SW	3	F3
Northwest	NW	4	<b>F4</b>
Azimuth	AZ	5	F5
Angle Right	AR	6	F6
Angle Left	AL	7	F7
Deflect Right	DR	8	none
Deflect Left	DL	9	none
90° Right	90AR	none	F8
90° Left	90AL	none	F9

HP (Hewlett Packard)	Angle Code	Alpha Code	Numeric Code	Function Key
Angle Code Set	Northeast	NE	1	F1
	Southeast	SE	2	F2
	Southwest	SW	3	F3
	Northwest	NW	4	F4
	Azimuth	AZ	5	F5
	Angle Left	AL	6	F6
	Angle Right	AR	7	F7
	Deflect Left	DL	8	none
	Deflect Right	DR	9	none
	90° Left	90AL	none	F8
	90° Right	90AR	none	F9

(The Hewlett Packard code set is so named to recognize the numeric codes used by HP and some other manufacturers.)



**Combining Angle Entries** 

and Codes

*If you are using grads,* 90°AR *and* 90°AL *will be renamed to* 100g AR *and* 100g AL.

In "Sight" Survey, all directional data may be incorporated into a single entry by simply adding an **alphabetic** or **numeric** angle code immediately following the angular data, before pressing *entry*, or by completing your entry by pressing a function key.

For example, in the **D.MMSS** or **Grads** entry modes, the same entry may be input as **37.0845NW**, or as **N37.0845W**, or as **37.0845-4**, or finally as **37.0845**.

In any mode, a space between the numeric entry and an angle code will not cause a problem.

Recalling Bearings"Sight" Survey contains the ability to recall a bearing between any<br/>two points residing in the memory for use in the forthcoming cal-<br/>culation. To recall any bearing, enter an asterisk (*) or the letter<br/>R followed by a beginning and ending point (separated by a comma<br/>or a hyphen) at any Bearing or Angle prompt. For example:

*15-21 (or *15, 21, or R15-21, or R15, 21)

will input the bearing as it lies from point 15 to point 21. If you omit one or both of the point numbers and simply enter * Form or at a bearing request, you will be prompted for them. After you make a distance entry, "Sight" Survey will prompt you for the point numbers through the use of a **Recall Bearing** window.

Enter the point numbers one at a time pressing *-Enter* or *Table* after each number. The recalled bearing will travel in a direction from the first point to the second point.

Recall Bearing			
From			
To			
Plus			
<u>A</u> ccept	<u>C</u> ancel		

The **Recall Bearing** window contains one other optional entry, a **Plus** text entry box. Use this box to enter a value (in the chosen D.MMSS or grads format) that will be added to the recalled bearing. Enter negative numbers to subtract a value from the recalled bearing. For example, suppose the bearing from point 1 to point 5 is  $45^{\circ}$  NW. To enter the recalled bearing from point 1 to point 5 plus  $10^{\circ}$  15' 25'', (in a D.MMSS format) enter **10.1525** in the **Plus** box which results in a bearing entry of  $34^{\circ}$  44' 35'' NW.

Mathematical functions may also be performed using the **In-Line Calculator**. To make an in-line calculation, simply type the expression ending with the  $\equiv$  key.



Multiplication and division are not allowed in angular entries.

3

The angular entry is treated as a **deflection** from the recalled course, with positive entries deflecting to the right, and negative entries deflecting to the left.

A second method of recalling a bearing is to recall the value last used. In "Sight" Survey this is an automatic function. For example, suppose you traverse from point 20 to point 21 at a bearing of 10NW and a distance of 75.5. After traversing to point 21, you want to continue on and set three more points along the same bearing and at the same distance. As you proceed to the next point, both the bearing and distance are retained from the last calculation. All you have to do is accept them, not re-enter them. The quickest way to accomplish this is to press Page Dn after typing in the target point number.

Select a Bearing from the Drawing

The **Select Bearing** function is used to pick a bearing from the drawing which will be used as data entry into a bearing field. The bearing picked is actually calculated by "Sight" Survey, so you must have two existing COGO points to use this routine.

To access **Select** <u>Bearing</u> from the keyboard, use the command **SB** or press <u>Att</u>D, <u>B</u>. The **Drawing** window command line prompts:

#### Select the starting point for bearing calculation

Using the **Grab All** cursor ( $\Box$ ) in the **Drawing** window, click on the first point to be used in the calculation. The prompt bar prompts:

Select the ending point for bearing calculation

Again, using the **Grab All** cursor ( $\Box$ ) in the **Drawing** window, click on the ending point to be used in the calculation. "Sight" Survey will compute the bearing between the points and enter the value into the field.



Before using the Select Bearing feature, be certain your cursor is located in a bearing entry field in the Data Entry window.

#### Recalling the Last Used Bearing

4.07

#### The Reference Bearing

After the first traverse or inverse procedure in the COGO program, a bearing will be retained in the memory as a *reference* (or backsight) *bearing*. The reference bearing is simply the reverse of the bearing which you traveled on to get to the point which is now occupied. The reference bearing is the bearing referenced every time you enter an angle or deflection to the right or left. You may change this bearing through the use of the Enter Backsight Bearing (EB) or Enter Backsight Point (EP) routine. Enter a backsight bearing in the same manner as you would enter any other bearing. You can even recall a bearing, or **Select a Bearing** (SB) from the Drawing window.

### **Horizontal Distance Entry**

In all "Sight" Survey routines, horizontal distances are entered just as if you were keying data into a calculator. Trailing zeros need not be entered.

**Recalling Distances** "Sight" Survey allows you to recall a distance between any two points residing in the memory for use in the forthcoming calculation. To recall any distance, enter an asterisk * or an apostrophe followed by the letter **R** followed by a beginning and ending point (separated by a comma or hyphen) at any **Distance** prompt. For example:

#### *15-21 (or *15, 21, or 'R15-21, or 'R15, 21)

will input the distance as it lies from point 15 to point 21. If you omit one or both of the point numbers and simply enter \star 🖃 or **P R e** at a distance request, the program will prompt you for the point numbers through the use of a **Recall Distance** window.

"Sight" Survey also allows you to enter a recalled distance with an addition, subtraction, multiplication or division operator (+, -, *, /). This may be done either through the In-Line Calculator, or through the Recall Distance window.

Recall Distance			
From			
To			
Plus			
Multiplied by			
<u>A</u> ccept	<u>C</u> ancel		

In the **Recall Distance** window, you can add, subtract, multiply or divide against a recalled value by completing the appropriate **Plus** or **Multiplied by** text-entry boxes. Of course if you want to subtract and/or divide you'll have to use negative and reciprocal values respectively.

Mathematical functions with a recalled distance may also be performed using the In-Line Calculator. To make an in-line calculation, simply type the expression ending with the *Enter* key. (*Do not use the* **:** *key in this instance.*) For example, to enter the distance from point 1 to point 5 less 150.25 feet, enter ***1**, **5**-**150**.25 *Enter*. When you press the *Enter* key, the value is computed and used, but it is not entered into the text entry box.

A second method of distance recall involves recalling the value last used. In "Sight" Survey this is an automatic function. For example, suppose you traverse from point 20 to point 21 at a bearing of 10NW and a distance of 75.5. After traversing to point 21, you want to continue on and set three more points along the same bearing and at the same distance. As you proceed to the next point, both the bearing and distance are retained from the last calculation. All you have to do is accept them, not re-enter them.

Additionally, whenever you are prompted for a distance entry within COGO, the function keys F1 through F9 will be predefined to the following values (where L is the last used distance):

F1 = L	Enter	F5 = L/8	←Enter
F2 = L/2	←Enter	F6 = L*2	⊷Enter
F3 = L/3	←Enter	F7 = <b>L*3</b>	⊷Enter
[F4] = L/4	Enter	[F8] = L*4	⊷Enter

Recalling the Last Used Distance **Select a Distance** The Select Distance function is used to pick a distance from the from the Drawing drawing which will be used as data entry into a distance field. The distance picked is actually calculated by "Sight" Survey, so you must have two existing COGO points to use this routine. To access Select Distance from the keyboard, use the command SD or press AltD, D. The command line at the top of the Drawing window prompts: Select the starting point for distance calculation Using the **Grab All** cursor ( ) in the **Drawing** window, click on the first point to be used in the calculation. The command line prompts: Select the ending point for distance calculation Again, using the **Grab All** cursor (  $\Box$  ) in the **Drawing** window, click on the ending point to be used in the calculation. "Sight" Survey will compute the distance between the points and enter the value into the field. Before using the **Select Distance** feature, be certain your 3 cursor is located in a distance entry field in the Data Entry

4.08

## The In-Line Calculator

window.

"Sight" Survey contains a second type of calculator in addition to the pop-up surveying calculator. This second calculator is an *inline calculator*. This calculator has already been briefly discussed under **Recalling Bearings** and **Recalling Distances**. It is however, more powerful than those discussions indicated.

The in-line calculator is a one-line entry calculator. In other words, you may enter an expression at a bearing or distance prompt

and "Sight" Survey will calculate and use your result as the entry to the prompt.

For example, suppose that you are traversing to a point and you do not know the polar distance, but you do know the X and Y components (75 and 382 respectively) of the distance in question. Knowing that the polar distance equals the square root of the quantity  $(X^2 + Y^2)$ , you can compute this value by entering the expression SQR ((75^2) + (382^2)) =. "Sight" Survey will calculate the result and enter 389.293 into the program as your response.

3

Note the extra parenthesis in the equation above. It is important that you enclose each term in parenthesis or the command line calculator may not function correctly.

"Sight" Survey includes many trigonometric and conversion functions that are available to the command line calculator.

Aside from the standard *addition*, *subtraction*, *multiplication* and *division*, "Sight" Survey supports many additional math functions, scientific notation and three constants: **pi** (3.14159); **L** (the last used distance); and **DEG** (pi/180). You may also use parenthesis, but be sure they are matched pairs or an error will result.

A list of supported operations follows. Included in the list is a reference example of the correct syntax. For illustration, we will use variables N1 and N2 as the objects of the operator.

Notice that each example equation begins with a single quote (`) ends with an equal sign (=). The quote tells "Sight" Survey that you are not entering a two-letter command, while the equal sign is used to close out the equation and return the result. Do not forget to add these to your in-line equation.

Math Functions	+	Function: Example:	Addition <b>`N1+N2=</b>
	-		Subtraction <b>`N1-N2=</b>

3

	*	Function: Example:	Multiplication <b>`N1*N2=</b>
	/	Function: Example:	Division י <b>n1/n2=</b>
	λ	Function: Example:	Integer Division <b>`N1\N2=</b>
	*	Function: Example:	Exponent <b>`N1^N2=</b>
	ABS	Function: Example:	Absolute Value <b>ABS (N1) =</b>
	INT	Function: Example:	Integer `INT (N1) =
	SQR	Function: Example:	Square Root SQR (N1) =
Trigonometric Functions	ATN	Function: Example:	Arc Tangent <b>ATN (N1) =</b> where <b>N1</b> is a number and the result is in radians.
		or Example:	<b>'DMS (ATN (N1) )</b> = where <b>N1</b> is a number and the result is in D.MMSS.
	COS	Function: Example:	Cosine COS(N1) = where N1 is in radians
		or Example:	COS (RAD (N1)) = where N1 is in D.MMSS
	SIN	Function: Example:	Sine SIN(N1) = where N1 is in radians
		or Example:	<b>`SIN (RAD (N1) )</b> = where <b>N1</b> is in D.MMSS
	TAN	Function: Example:	Tangent <b>`TAN (N1) =</b> where <b>N1</b> is in radians
		or Example:	<b>TAN (RAD (N1) )</b> = where <b>N1</b> is in D.MMSS

į	Internally, "Sight" Survey uses radians when computing trig functions. For example, when you compute a SIN, COS, or TAN of an angle N1, "Sight" Survey expects N1 to be in radi- ans. Likewise, when you compute the ATN function of value N1, N1 is assumed to be in radians. To make life easier for you, "Sight" Survey contains the functions RAD and DMS. These functions let you use D.MMSS values in your calcula- tions so you don't have to make manual conversions.		
Conversion Functions	RAD DMS	Function: Example: Function: Example:	Convert D.MMSS to Radians <b>`RAD (N1) =</b> where <b>N1</b> is in D.MMSS Convert Radians to D.MMSS <b>`DMS (N1) =</b> where <b>N1</b> is in radians
3		function <b>, N1</b> t an equation unction must b	must be a numeric value such as such as 45.2738+10.5002. be the most outside function, not
Logarithmic Functions	LOG10	Function: Example:	Common Log (base 10) LOG10 (N1) =
	EXP	Function: Example:	Exp (or <b>e</b> ^x ) <b>`EXP (N1) =</b>
	LOG	Function: Example:	Natural Log (base <i>e</i> ) LOG (N1) =

4.09

# Vertical And Zenith Angles


All *vertical angles* and *zenith angles* must be entered in the same format as horizontal angles. The routines contained in "Sight" Survey are set up to accept either vertical or zenith entries, with the

program determining your intent by using break points set at every 45 degree (50 grad) point from the horizontal plane. The illustrations that follow indicate how the data entries will be treated.




To enter a zenith angle in the range of -45° to 45°, 135° to 225°, or 315° to 360°, preface your angle entry with the letter "Z", for example "Z44.2835".

All values between 45 and 135 degrees (50 and 150 grads), and all values between 225 and 315 degrees (250 and 350 grads).



Any value lying between 0 and 45 degrees (0 and 50 grads), between -45 and 0 degrees (-50 and 0 grads), between 315 and 360 degrees (350 and 400 grads), and between 135 and 225 degrees (150 and 250 grads).



#### **Vertical Angles**

## **Zenith Angles**

# **Slope Entries & Slope Types**

When entering distances in the COGO routines, (except within the Intersection and Offset routines), you may be prompted for a **Slope Angle**. This may either be a *zenith* or a *vertical* angle as discussed in **Section 4.09**. The angle entry rules found in **Section 4.05** also apply to slope angle entries. If you are entering a horizontal distance with no slope distance, simply press the **Finer** key at the prompt for the slope angle.

On "Sight" Survey's **Config** > **Slope Entry Configuration** menu you will be given the opportunity to select whether or not you want to be prompted for the slope angle after every distance entry. If the majority of your distances were taken without the use of a slope angle, you might wish to disable the automatic prompt. If the **Prompt for slope input** option is disabled, a slope angle may still be entered by placing a / or \ immediately after the distance, for example, **1250.44**/ or **1250.44**\. (Slashes are used because they are sloping lines, and should be easily remembered. The two-letter command **SA** may also be used to toggle slope prompting on and off.)

In "Sight" Survey, there are five available methods for entering elevations and slope distances and reducing the entered data to horizontal and vertical distances. Two additional methods exist for those instances when you are using horizontal distance data along with plus/minus readings or elevations. The methods are:

- 1. by Assigned Elevations;
- 2. by EDM Slope distances;
- 3. by EDM Slope distances Mining Option;
- 4. by Levels (plus and minus shots);
- 5. by Simple Slope Angles;
- 6. by Stadia distances;
- 7. by Total Station.

The desired method is selected from the Config Selope Entry Configuration menu (CM AttS). A discussion of each method follows, including data entry instructions. Refer to these instructions whenever you see the Slope Angle prompt.

4.10

Assigned Elevations	The Assigned Elevations method is actually not a slope reduction method at all, but rather just a convenient way for you to enter the known elevation at each target point. Type the elevation and press "Enter". If you do not know the elevation for a particular point, just press (zero) 0 "Enter". Pressing "Enter" without first typing in an eleva- tion value causes "Sight" Survey to use the "last used" elevation.
<u>E</u> DM	Upon entering the <b>EDM</b> reduction routine, you will be asked to provide certain information regarding your instrument and target setups. These are:
	<b>H.I. Theod.</b> (or <b>Height of the Theodolite</b> ) - Type the actual height of the scope of the theodolite above the point of known elevation and press <i>This is not an elevation!</i>
	<b>H.I. Target</b> (or <b>Height of the Target</b> ) - Type the actual height of the target (sighted by the theodolite) above the target point and press <i>remer</i> ). <i>This is not an elevation!</i>
	The Height of the Distance Meter and the Height of the Prism Assembly are set in the Config_ → Slope Entry Configuration menu under EDM Options.
	After entering the required data, "Sight" Survey computes the horizontal distance based on the elevation selected on the <b>Config</b> ⇒ <u>Slope Entry Configuration</u> menu under the Horizontal distance option.
<b>i</b>	If you have activated the Curvature and Refraction slope correction on the Config_ $COGO$ Configuration Menu $COGO$ Entry sub-menu, all EDM computations are corrected for curvature and refraction through the use of the formula $C + R$ = (0.574) (K2) where K is the distance measured in miles. ¹
EDM (Mining Option)	The <b>EDM</b> (Mining Option) reduction routine, is functionally equiva- lent to the regular EDM routine. The only difference being that the instrument H.I.'s are measured down from the roof of the mine in- stead of up from the floor. Refer to the <b>EDM Slope Reductions</b> section for a discussion of the prompts.

¹. BOUCHARD, H. and MOFFITT, F. H. *Surveying*.: International Textbook Company, Scranton, PA, 1965.

_

Simple Slope Angles

Stadia Reductions

The Leveling method is not actually a valid method for handling slope distances. Instead, this routine is only to be used for setting the elevations of points by using plus and minus shots. Upon entering the levels routine, you will be asked to provide certain information regarding your instrument and target setups. These are:

**Instr. Ht.** (or **Height of the Instrument**) - Type the actual height of the scope of the instrument above the point of known elevation and press **.** *This is not an elevation!* 

**Rod Reading** - Type the actual rod reading at the foresight point and press **.** *This is not an elevation!* 

"Sight" Survey assumes that the original distance entered is not a slope distance at all, but rather it is a horizontal distance. The only effect that the H.I. and rod readings have on the leg in question, is in establishing the elevation at the foresight point.

When you are computing the locations and elevations of several points using the Side Shot routine, after your initial height of the instrument entry, the program will present the HI for your confirmation. Simply press it to bypass the prompt and proceed to the Rod Reading prompt.

A **Simple Slope Angle** is the only entry required for this method. Basically, the program assumes that the H.I.'s of your EDM, theodolite, target and prism assembly are relatively equal and any differences lying therein do not adversely affect the distance reduction.

Upon entering the **Stadia Reductions** routine, you will be asked to provide certain information regarding your instrument and target setups. These are:

**Instr. Ht.** (or **Height of the Instrument**) - Type the actual height of the scope of the instrument above the point of known elevation and press *etere*. *This is not an elevation!* 

**Reading** - Type the actual rod reading (middle stadia hair) at the foresight point and press *This is not an elevation!* 

**Total Stations** 

The Stadia Interval Constant (K) and the Distance from Center of Instrument to Principal Focus (C) are set in Config  $\gg$  Slope Entry Configuration menu under Stadia Options.

To utilize Stadia reductions, the program prompts you to enter the Interval (the difference between the top and bottom stadia hairs) as the actual distance entry. Entering an actual distance instead of the interval at the Interval prompt will result in a warning message. The program will require verification of any interval value greater than 9.

The **Total Stations** option is another slope reduction method that does not actually reduce a slope distance. Instead, "Sight" Survey assumes that the distance entered is a horizontal distance. You are then asked to supply additional information regarding your setup, after which an elevation is computed.

**Instr. Ht.** (or **Height of the Instrument**) - Type the actual height of the scope of the instrument above the point of known elevation and press *etere*. *This is not an elevation!* 

Vert. Dist. (or Vertical Distance) - Type the actual measured vertical distance and press *etener*. Enter this value as a negative if you are shooting downhill. *This is not an elevation!* 

**Prism Height** - Type the actual height of the prism center above the target point and press *Enter*. *This is not an elevation!* 

After the first time you enter this data, the program will retain the H.I.'s of the total station and also the prism. In each subsequent access this information is presented for your approval. If the setup information has not changed, simply press *Enter* to accept each entry. Otherwise, type the correct values before pressing *Enter*.



#### Entering Coordinates

When entering coordinate values into the "Sight" Survey routines, you will most often use the Enter & Assign routine. Whenever this

# 3

routine is called, it may or may not have coordinate values shown in the entry fields. This depends upon whether or not the point number you entered already has coordinates.

If the routine's entry fields show coordinates, you can clear each field by simply typing the correct value over the value shown. Then press <u>-Enter</u> or <u>Tables</u> until you have corrected and/or completed all of the entries. In "Sight" Survey you will have three or four entries to complete, these being the Northing, the Easting, the Elevation, and possibly the Point description.

Whether or not you are prompted for the point description depends upon the setting for the Prompt for point description item on the Config_ COGO Configuration Menu. See page 401.

#### **Correcting Your Entered (Raw) Data**

3

Despite using the utmost care in gathering and entering data, it is inevitable that mistakes will be made. "Sight" Survey contains features and routines to help you easily correct errors.


Raw data files are not saved between sessions. You must correct your raw data during the session in which it was entered into "Sight" Survey.

The data correction procedure is illustrated in **Section 3 - Example 1**, which covers the construction, correction and balancing procedures for a small closed traverse. Before continuing, please review **Example 1** for basic instructions.

Welcome back! Certain features of the data correction window were not included in **Example 1**, so they are covered here. You already learned how to edit a bearing or a distance, and you can apply those principles to the **Action**, **Point Number**, **Coordinates**, **Slope Reduction Data**, and **Description** fields as well. You also saw how to balance angles and adjust your traverse. The following features were not discussed: **Adding a Leg** (**Add Leg**); **Deleting a** 

Leg ( <u>D</u> el Leg	); Copying to the Clipboard ( Copy ); and	l
Resizing the I	Data Presentation Grid.	

Adding a Leg	To add a leg, position your mouse cursor at the insertion point and click. For example, it you want to insert a leg between leg 2 and 3, click your cursor on leg 3. Now click Add Leg. Click Yes when you are asked to confirm your action. The highlighted leg is reproduced as a new leg. In other words, you now have two leg 3 entries. Don't worry about the leg numbers, they will be corrected automatically when you Re-Run the traverse. However, you do need to correct the data in the first leg 3, cell by cell.
Deleting a Leg	To delete a leg, position your mouse cursor on the target leg and click. For example, it you want to delete leg 2, click your cursor on leg 2. Now click $\boxed{\text{Del Leg}}$ . Click $\underline{\text{Yes}}$ when you are asked to confirm your action. The highlighted leg is deleted and your leg numbers now read 1, 3, etc. Don't worry about the leg numbers, they will be corrected automatically when you <b>Re-Run</b> the traverse.
Copy to the Clipboard	To copy a leg's data to the Windows Clipboard, position your mouse cursor on the target leg and click. For example, if you want to copy the information for leg 2, click your cursor on leg 2. Now click Copy.
Resizing the Grid	Depending upon your screen resolution, you may want to resize the columns in the data grid. You can accomplish this by using your mouse to drag the column borders to new locations. For example, to move the right-side border of the <b>DISTANCE</b> column about two digits to the left, place your mouse cursor in the column headings on the line between <b>DISTANCE</b> and <b>POINT</b> . Your cursor will look like $\leftrightarrow$ . Click and hold your mouse while dragging it to the left. A dotted line will appear to mark the changing position of the column border. When you are satisfied with the new location, release the mouse button.
Balancing Long Traverses	If you are balancing a long traverse that will take more than one session to complete, run the <b>Adjust Traverse</b> ( <b>AT</b> ) routine before you exit the "Sight" Survey program. When you are prompted:




Press <u>Fine</u> (or Y) or click on <u>Yes</u>. When the **Unbalanced Traverse** window appears, press <u>Alt</u> or click the <u>ReRun</u> button. This important step forces "Sight" Survey to save your raw data file with your coordinate file so that you can begin your next session right where you left off. If you already have an existing raw data file, you will be prompted:

Raw Dat	a Exists 🛛 🕅
?	Do you want to replace the existing raw data file with the data in this window?
	Yes <u>N</u> o

Press <u>-Ener</u> (or Y) or click on <u>Yes</u>. When the **Modified Traverse** window appears, press <u>Alt</u> C or click on <u>Eancel</u> to close it. Next, close the <u>Unbalanced Traverse</u> window by pressing <u>Alt</u> C or by clicking on <u>Cancel</u>. You can now exit "Sight" Survey without losing your raw data file.

When you begin your new session, run the Edit  $\Rightarrow$  Edit Original Raw Data (ER) routine. You will be prompted:



Since you are just re-running an existing file from disk, press  $\mathbb{N}$  or click on  $\mathbb{N}_{0}$ . When the **Raw Data** window appears, press  $\mathbb{A}$ t  $\mathbb{U}$ 

or click the **BeBun** button. This important step will force "Sight" Survey to internally re-run your raw traverse data up to the point where you previously left off. You will be prompted:

Raw Dat	a Exists 🛛 🔀
?	Do you want to replace the existing raw data file with the data in this window?
	Yes <u>N</u> o

Since you are just re-running an existing file from disk, you do not want to overwrite the raw data so press  $\mathbb{N}$  or click on  $\mathbb{N}_{0}$ . When the **Modified Traverse** window appears, press  $\mathbb{A}$  or click on  $\mathbb{A}$  or click on  $\mathbb{A}$  or click data and close the **Traverse Adjustment** windows. Your entire traverse will be reconstructed up to the point where you previously left off and areas and distances will be properly accumulated. When the traverse re-run is finished, you can continue entering your traverse data.

¥

- Use extreme caution when overwriting existing raw data files. Only overwrite raw data files when you are absolutely certain that the raw angles and distances that are showing in the ACTIVE Traverse Adjustment window are the ones that you want to keep as your "original raw data file". Once you overwrite a raw data file, you cannot recover the previous raw data file.
- 2. The Start At (ST) routine resets the area and length accumulators. If you use the Start At (ST) routine WITHIN a traverse, the traverse Length and Area will be incorrect.
- 3. "Sight" Survey version 2.0 & 3.0 raw data files are not backwards-compatible with "Sight" Survey version 1.0 due to a major change in the file format. This does not apply to the coordinate points they are fully interchangeable between the two versions. However, if you load a version 2.0 or 3.0 file into version 1.0 and attempt to use the Edit 
  SEdit Original Raw Data (ER) routine, "Sight" Survey will likely issue an unforeseeable error or may even crash.

#### **Rounding Errors**

"Sight" Survey uses up to 16 significant digits for internal calculations. However, despite this high degree of accuracy, there may be times when you experience rounding errors. Generally these errors manifest themselves somewhere in the second or third decimal place, or beyond. But in almost every case except accumulated stationing, these are not errors generated by the program's handling of data. They are user-introduced errors.

We are often asked what data items will produce the best solution. For example, in terms of curve solutions it seems that many users believe that a curve solution based on certain parameters may be more accurate than that same solution based on a different set of parameters. Actually, the parameter type makes no difference at all. The accuracy of any solution is based on the precision of the data entered. Once this fact is understood, you will have an easier time of selecting the best data to be entered.

For example, suppose that you have the following curve data:

Delta	Radius	Arc	Tangent	Chord
35°00'00"	750.00	458.15	236.47	451.06

Depending upon which two parameters you use to compute the other values, you will generate slightly different curve data every time as seen in the table below:

Parameters Used	Delta & Radius	Radius & Chord	Tangent & Chord	Arc & Radius
Delta	35°00'00"	35°00'00.4"	34°59'33.6"	35°00'00.3"
Radius	750.00	750.00	750.154506	750.00
Arc	458.148929	458.150293	458.147245	458.15
Tangent	236.474092	236.474841	236.47	236.474681
Chord	451.058699	451.06	451.06	451.059721

As you can see in the above table, the precision of the data directly affects the accuracy of the solution. Only the first solution based on the delta and radius is exact, as every other solution failed to produce the exact same delta and radius. *Remember: For the* most accurate solution, use the most precise data that you have.

4.13

#### Introduced Errors

"Sight" Survey Examples

When you work through the example solutions presented in this manual, you may experience slight deviations from the printed results. This is not uncommon, and can be traced to the methods used to establish the given data. Generally, if you use the **Enter & Assign (EA)** routine to assign the given points, you will have greater success in matching the printouts.




## Section 5 Windows Everywhere

#### 5.01

#### "Sight" Survey's Main Screen

Not only is "Sight" Survey a Windows program, it has its own windows as well. Three main windows make up the "Sight" Survey screen as shown below. The windows are: the **Data Entry** window; the **Drawing** window; and the **Text Output** window. A fourth window, the **Properties** window, appears and disappears when you click **Properties** (PR) at the top of the **Drawing** window.



All three main windows can be sized and arranged to best fit your monitor's optimum resolution. The arrangement shown above was captured on a 1024x768 resolution which is a good resolution for "Sight" Survey operation. A 1024x768 or 1280x1024 resolution monitor will easily display all three windows. However, if you are using a monitor smaller than 17", 1280x1024 is generally too small for comfortable viewing. If your monitor's resolution is 800x600 or lower (such as a standard VGA resolution of 640x480) you may find it easier to minimize the **Text Output** window.

5.02

Minimizing a Window	To minimize a <b>Windows 3.1</b> window, click on the <b>v</b> button in the upper right corner of the window.
	To minimize a <b>Windows 95/98/NT</b> window, click on the <b>_</b> button in the upper right corner of the window.
Maximizing a Window	To enlarge a window stored as a <b>Windows 95/98/NT</b> icon, double- click on the icon, or click on the 🗗 button inside the icon. The window will return to its previous size and position.
	To maximize a window stored as an icon, click on the 🔲 button inside the icon. The window will fill the entire screen.
	To enlarge a <b>Windows 3.1</b> window stored as an icon, double-click the icon.

### The Data Entry Window

"Sight" Survey's **Data Entry** window is your interactive link to the COGO program. The window contains six parts as shown below.

Title Bar	Traverse
Message window	Enter a point number
User-customizable Toolbar 🛛 🗕 ►	ST_GTFrom Point1002EBEPTo Point907INICBearing5.0133 NVV
Prompt Titles	TR TA Distance 107.25
Data Entry boxes	TS IS
Accept Button	BD DB Accept (PgDn)

Title Bar		The <b>Title Bar</b> displays the name of the routine in progress. It serves as a reminder in the event that you have jumped between windows in the middle of a routine.
Message Window		The <b>Message Window</b> contains prompt-sensitive instructions to assist you with data entry. Typical information includes items such as angular quad code entries, mathematical operators for in-line calculations, and specific prompt instructions.
User Cu	stomizable Toolbar	The <b>User Customizable Toolbar</b> contains buttons giving you one- click access to your most commonly used routines. Instructions for setting up your own tool bar are contained on page 411.
Prompt	Titles	The <b>Prompt Titles</b> area displays all data entry prompts needed by the routine named in the <b>Title Bar</b> . These prompts change from routine to routine.
Data Entry Boxes		To proceed through the <b>Prompt Titles</b> , you must type data into the <b>Data Entry Boxes</b> . After typing the data, move to the next prompt by pressing <b>Entry</b> , <b>The I</b> , key. To correct any entry before final acceptance, use the <b>1</b> key or press <b>Shift Tables</b> to move back up through the prompts, or simply click your mouse in any data entry box that needs correction.
Accept Button		When you have completed all required data entry fields, there are four ways to continue: press Immediately after the last data entry box has been filled; press Alt A; press Page Dn; or click the Accept (PgDn) button.
Help		To access "Sight" Survey's on-line <b>Help</b> feature, right-click your mouse anywhere on the <b>Data Entry</b> window, except within the <b>Data Entry Boxes</b> . This will activate a small menu containing five options.
	<u>C</u> ontents	Press C to activate the Help system's Table of Contents.
	Current <u>T</u> opic	Press <b>(</b> (or <b>F1</b> ) to get <i>context sensitive</i> help on the current routine or prompt.
	<u>S</u> earch for Help On … <u>H</u> ow to Use Help	Press (5) to <b>Search</b> the <b>Help System</b> for a specific topic. Press (1) for <b>instructions</b> on using the <b>Help</b> system.

### Section 5

**System Information (SI)** Press () (or SI) for **System Information**, which is presented in three screens as shown below. These are information screens only and are not editable.

#### The Text Output Window

"Sight" Survey's **Text Output** window is a fully-editable, scrollable window that contains all of the text data generated by "Sight" Survey.

	Fext Output Point Direction Distance Northing Easting Elevation
	<u>+ 1 1 + 1 + 1 + 1 + 1 + 1 + 1 + 1 + 1 +</u>
	Start 10051.23475 19960.00000 101.700
	IN N 0°00'00.0'' E 75.000 2 10126.23475 19960.00000 101.700
	IN S 34°38'08.9" E 178.721 0.300 15 9979.18637 20061.57754 102.000
	IN N 16°40'20.1" W 75.210 -0.300 14 10051.23475 20040.00000 101.700
	Page 5/7 Line 190 Col 1
Editing Text	Click anywhere in the <b>Text Output</b> window to activate the window. Notice the prompt in the "Sight" Survey <b>Status Bar</b> reads: Text Output Window (press "Insert" to edit) Press [nsert] to activate the text editing features and the prompt changes to:
	Text Output Window (editing turned on)
	The <b>Insert</b> key acts as a toggle switch. To turn off the editing features press <b>Insert</b> or jump to another "Sight" Survey window.
Moving the Cursor	To place the text cursor at a specific location, click on the location with your mouse, or use the $\uparrow$ , $\downarrow$ , $\frown$ , $\neg$ , $\bigcirc$

5.03

Selecting Text	To change any existing text, you must first select the text by following these simple Windows conventions.		
To Select a Word	Mouse:	Double-click anywhere on that word.	
	Keyboard	Place the mouse cursor at the beginning (or end) of the word and press Ctrl Shift → (or Ctrl Shift →).	
To Select a Line	Mouse:	Place the mouse cursor at the beginning (or end) of the line. Click and drag the mouse to the right (or left) until the line is highlighted.	
	Keyboard	Place the mouse cursor at the beginning (or end) of the line and press Shift (or Shift ), or Shift End (or Shift Home).	
To Select Everything	Mouse:	Place the mouse cursor at the beginning (or end) of the document. Click and drag the mouse down and to the right (or up and left) until the entire document is high-lighted.	
	Keyboard:	Press Ctrl Home (or Ctrl End) to jump to the beginning or end of the document. Now press Ctrl Shift End (or press Ctrl Shift Home) to highlight the entire document.	
To Select Everything from the Cursor Point	Mouse:	Click and drag the mouse down and to the right (or up and left) until the desired portion of the document is highlighted.	
	Keyboard:	Press Ctrl Shift End (or press Ctrl Shift Home) to highlight from the cursor to the end (or beginning) of the document.	
To Select a Paragraph	Mouse:	Place the mouse cursor at the beginning (or end) of the paragraph. Click and drag the mouse down and to the right (or up and left) until the paragraph is highlighted.	
	Keyboard:	Place the mouse cursor at the beginning of the first line of the paragraph. Press Shift 1 to highlight each line in the paragraph.	
The Editing Menu		cess to the <b>Text Output</b> window's editing commands, e menu by right-clicking anywhere within the <b>Text</b>	


**Output** window. To use any menu item, press the item's hot key (underlined character).

<u>U</u> ndo	<u>U</u> ndo	Right-click to activate the menu, then press U to Undo the last text operation. <i>You can only undo your last</i>
<u>C</u> ut Cop <u>v</u>		operation.
Paste	<u>C</u> ut	Right-click to activate the menu, then press C to <u>Cut</u>
S <u>e</u> lect All Delete <u>S</u> elected <u>I</u> nsert Page Break		selected text. <b>Cut</b> may also be performed from the keyboard by pressing <b>Ctrl</b> (or <b>Shift Delete</b> ). The selected text is removed from its present location and sent to the clipboard.
View <u>H</u> eaders/Footers P <u>r</u> int Print Pre <u>v</u> iew E <u>x</u> port Text	Сор <u>у</u>	Right-click to activate the menu, then press Y to <b>Copy</b> selected text. <b>Copy</b> may also be performed from the keyboard by pressing <b>Ctrl</b> [nset]. The selected text is copied (but not removed) from its present location and
Select <u>G</u> lobal Font Select <u>F</u> ont For Selected		sent to the clipboard.
Properties	<u>P</u> aste	Locate the text cursor at the desired insertion point, right-click to activate the menu, then press then press
<u>H</u> elp		$\square$ to <u>Paste</u> text from the clipboard. You can also paste from the keyboard by pressing Ctrl (or Shift Inset).
S <u>e</u> lect All	Right-click to activate the menu, then press (E) to Select the entire document.	
Delete <u>S</u> elected	Right-click to activate the menu, then press S to <b>Delete Selected</b> text. You can also <b>Delete Selected</b> text from the keyboard by pressing Delete. The selected text is removed from its present location but it is not sent to the clipboard. Text deleted in this manner may only be recovered by immediately using the Undo function.	
Insert Page Break	Right-click to activate the menu, then press i to <b>Insert a Page</b> <b>Break</b> into your document. The break will be inserted immediately below the line containing the cursor. To remove a page break, place the cursor on the line immediately above the existing page break and select <b>Insert a Page Break</b> again.	

Under normal conditions, "Sight" Survey will fill a page before issuing a page break. Use this feature to issue a page break at any other location.

Page breaks may also be added or deleted by pressing Ctrl-Enter. All text is repaginated before a **Print Preview**.

View <u>H</u>eaders/Footers When "Sight" Survey prints a page of information, it may add a header and/or footer to the page. Headers and footers are lines of informational text that typically are used to include the job name, program name and version, date, page numbers, and standard headings. To activate the <u>Header/Footer</u> split window, right-click to activate the menu, then press <u>H</u>ereme.




Edit the <u>Header/Footer</u> areas just as though they were regular text windows. The only exceptions to this rule are the **field markers** (??), which hold positions for data that is automatically inserted when printing. To identify what each field marker represents, position the cursor in the middle of the question marks and read the field type on the **Text Output** window's **Status Line**.

When you have finished editing your headers and footers, close the <u>Header/Footer</u> split window the same way you opened it.

3

If you delete a field marker, you may not be able to replace it. Rather than deleting the markers, you may want to line them all up in a single row, or at the end of a row, and set the text color to "white" so the text won't print.

P <u>r</u> int	Right-click to activate the menu, then press $\square$ to Print your document. This command is covered in detail on page 202.
Print Pre <u>v</u> iew	Right-click to activate the menu, then press $\heartsuit$ to activate the <b>Print Preview</b> feature. This command is covered in detail on page 201.
E <u>x</u> port Text	Right-click to activate the menu, then press $X$ to <b>Export Text</b> to another file. This command is covered in detail on page 220.
Select <u>G</u> lobal Font	Right-click to activate the menu, then press (a) to Select a Global Font for the Text Output window (including headers and footers). This action is essentially the same as selecting the entire document then changing the text formatting just as you would for selected text as described under Select Font for Selected.
Select <u>F</u> ont for Selected	Right-click to activate the menu, then press 🕞 to Select a Font for Selected text. A Replace Font dialog box appears, from which you



Properties 🕫

Right-click to activate the menu, then use your mouse or arrow keys to access the **Properties** item. The  $_{\odot}$  symbol indicates the presence of a sub-menu. From the sub-menu, select **Ruler**, **Icon Bar**, or **Status Line**. Each of these items toggles the display of the named item.

Tab Selection Buttons —	Text Output
Icon Bar	Point         Direction         Distance         Northing         Easting         Elevation           Arial         12         ■         ■         12         ■         ■         12         ■         ■         12         ■         ■         ■         12         ■         ■         12         ■         ■         ■         12         ■         ■         ■         12         ■         ■         ■         12         ■         ■         ■         12         ■         ■         ■         ■         ■         12         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■         ■
Status Line	▲ ▼ Page 5/7 Line 190 Col 1
<b>₽</b> >Ruler	When displayed, the <b>Ruler</b> not only provides a graphical represen- tation of the size of your paper, but it also allows you to format paragraphs and set tabs.
To Format Paragraphs	To format the left paragraph margin, click on the bottom half of the left paragraph marker ( ) and drag the marker to its new location.
	To set a hanging first line, click on the top half of the left para- graph marker ( $\blacklozenge$ ) and drag the marker to its new location.
	To format the right paragraph margin, click on the bottom half of the left paragraph marker ( $\blacktriangleleft$ ) and drag the marker to its new location.
To Set Tabs	Select the type of tab desired by using the <b>Tab Selection</b> buttons on the <b>lcon Bar</b> . Now, on the bottom half of the <b>Ruler</b> , click on the desired tab location.
	To move an existing tab, click and drag the tab marker to a new location.
	To erase a tab, click and drag the tab marker straight up through the top half of the <b>Ruler</b> .
The Paragraph Dialog Box	The <b>Paragraph Dialog Box</b> offers a convenient selection method for all paragraph and tab formatting. To activate this dialog box, double-click anywhere in the numeric portion (the top half) of the <b>Ruler</b> .

Section 5 ♣ Icon Bar

Arial

Paragraph formatting done in this manner will apply to the paragraph in which the cursor is located. All subsequent, but currently not existing, paragraphs will be formatted in the same style. All other existing paragraphs will retain their existing formats. (Text entered as the result of COGO calculations *will not* retain **tab** and **margin** settings, but *will* retain **font** and **spacing** information.)

Paragraph Margins: Left: 0.000 Right: 0.000 First line: 0.000	Alignment: C Left C Centered C Right C Justify	Line spacing: © 1 line © 1,5 lines © 2 lines	Cancel
Labulators:           1.500           1.2600           1.6000	Ta <u>b</u> ulatortype: — © Left © Right © Centered © Decimal	<u>S</u> tandard Tab: 0.590	Delete <u>A</u> dd Delete all

When displayed, the **lcon Bar** provides you with a full set of formatting commands. By clicking on the various fields and buttons you can: format text; change your paragraph layout; and vary the line spacing.

Click the rext to the scrollable Font Name menu to change the font of the selected text. Scroll through the font list and select the desired font.

Click the next to the scrollable **Font Size** menu to change the font size of the selected text. Scroll through the size list and select the desired size.



12

•

•

The Justification buttons control text justification. Your choices are: Left; Center; Right; and Full.

Paragraph justification done in this manner will apply to the paragraph in which the cursor is located. All subsequent, but currently not existing, paragraphs will be formatted in the same style. All other existing paragraphs will retain their existing formats.



The **Text Attribute** buttons are toggle switches. Click on them to: Bold and un-bold text; change text to and from italics; underline words and characters, or cancel an underline; strike-through text or remove a strike-through.



The **Line Spacing** buttons control the spacing of the text lines. Your choices are: **Single**; **One and a half**; and **Double**.

Line spacing done in this manner will apply to the paragraph in which the cursor is located. All subsequent, but currently not existing, paragraphs will be formatted in the same style. All other existing paragraphs will retain their existing formats.



The **Superscript** (H^{$\uparrow$}) and **Subscript** (L^{$\downarrow$}) buttons are used to raise and lower selected text by two points.



T

The **Tab Selection** buttons are used to set your tabs as: **Left**; **Right**; **Decimal Point Centered**; and **Centered**.

Click the format indicator to show or hide text formatting characters that are contained in your text file. These characters are for reference only, and will not print. The characters represent: tabs  $(\rightarrow)$ , spaces (•); and paragraph markers (¶).



Click on the text color button to change the text color of the selected text. Select your new text color by double-clicking on the new color.

Font color	×
OK	Cancel

**€**Status Line

When displayed, the **Status Line** displays the page number, a total page count, the cursor's position by line (relative to the top of the page) and column, and occasionally some messages relevant to the currently accessed feature. For example, the **Status Line** shown

#### Section 5

below indicates that the cursor is on page 1 of 8 pages, on line 1, in column 21.

(Message Area)	Page	1/8	Line	1	Col	21	
----------------	------	-----	------	---	-----	----	--

<u>H</u>elp

5.04

Right-click to activate the menu, then press **HH**-**Ene** to activate the **Help** file. The help file will open to the topic "Additional Text Features."

#### The Drawing & Properties Windows

"Sight" Survey's **Drawing** and **Properties** windows are discussed in detail in the **Drawing Window Reference Manual**.



<u>N</u> ew Job (NJ) <u>O</u> pen Job (LO)
<u>S</u> ave Job (SC) Save Job <u>A</u> s
Print Pre⊻iew/Adjust Margins <u>P</u> rint Text P]ot Drawing Print <u>C</u> oordinates
Import ► Export ►
Copy <u>J</u> ob <u>D</u> elete Job
1. 2. 3. 4.
E <u>x</u> it (SY)

## Section 6 The <u>F</u>ILE Menu

The **File** menu contains all commands related to transferring information. Here you will find commands to do things like create a new job, print or plot your drawing, and make a backup file.

All commands are discussed in the order in which they appear on the menu. You can access menu routines by using your mouse on the pull-down menu. Therefore, this selection method will not be mentioned in each routine's discussion. Keyboard shortcuts to each routine will be noted.

#### 6.01 <u>N</u>ew Job (NJ)

**FUNCTION:** The <u>New Job</u> function is used to close the current job and start a new job.

To access <u>New Job</u> function, click the **Tool Bar** icon B, or use the keyboard command **NJ**, or press Att, N.

If you have any unsaved work, "Sight" Survey prompts:

New Job		×
😲 Would you	⊔ like to save	your work first?
Yes	<u>N</u> o	Cancel

Click <u>Yes</u> or <u>No</u>, or click <u>Cancel</u> to quit the <u>New Job</u> routine. If you select <u>Yes</u> or <u>No</u>, "Sight" Survey will close the current job and you may begin a new job from scratch, or by using the <u>File  $\xrightarrow{\sim}$  Open Job or <u>File</u>  $\xrightarrow{\sim}$  <u>Import</u>  $\xrightarrow{\sim}$  <u>Coordinates</u> command.</u> section 6 6.02



You do not need to issue a <u>New Job</u> command before using the <u>Open Job</u> command to start a new job.

#### Open Job (LO)

**FUNCTION:** The <u>Open Job</u> function is used to open an existing "Sight" Survey (or Survey 4.0) job.

To access **Open Job** from the keyboard, use the command **LO** or press Att[F],  $\bigcirc$ . The dialog box title bar will display: **Open**.

Open		? ×
File name: oakwoods.zak	Eolders: c:\sightsrv c:\ sightsrv program utility	OK Cancel
List files of <u>type:</u> "Sight" Survey Files (*.a	Drives:	

#### **Opening Files**

Anytime an <u>Open Job</u>, <u>Import</u>, Copy <u>Job</u>, or <u>Delete Job</u> command is issued, you'll see a Filename Dialog Box. To open a file:

- If the file you want to open is on a different drive, select the drive you want from the Drives box.
- In the <u>Directories</u> box, choose the directory you want to open. (Double-click the directory, or press the <u>1</u> or <u>1</u> arrows to select the directory, and then press <u>-Enter</u>.)
- 3. Windows displays the names of all files in that directory that are of the type selected in the List Files Of Type box. To display a different type of file, select the type you want from the List Files Of Type box.
- 4. From the list of files, select the file you want to open.
- 5. Click OK or <u>Open</u>.

#### Save Job (SC)

i

¥

**FUNCTION:** The <u>Save Job</u> function is used to save a "Sight" Survey job (COGO and drawing), using the same file name it was opened under.

To access <u>Save Job</u> from the keyboard, use the command SC (Store Coordinates) or press Att F, S.

- 1. If the job was never named, i.e. started from scratch, use the **Save Job** <u>As</u> instructions.
  - 2. Whenever you save a drawing, a backup copy of the drawing, with the extension **. BAK** is automatically made. This copy is stored in the same directory that the drawing is saved in.

When you save a drawing that contains a bitmap, the bitmap is not stored in the drawing. Only a reference to the bitmap is stored. It is therefore important that you do not delete the bitmap. If you delete the bitmap or move it to another directory, an error message will appear next time you try to load any drawings containing the bitmap.

Saving Files	The <b>File</b> menu contains two commands for saving files: <b>Save Job</b> and <b>Save Job</b> As. Copy Job and <b>Export</b> also use the <b>Save Job</b> As box. The <b>Save Job</b> command is used to save changes to an existing file. The <b>Save Job</b> As command is used to name and save a new file or to save an existing file under a new name. For example, you might want to make changes to a file, yet keep a copy of the file as it existed before you began working on it. By using the <b>Save Job</b> As command, you can save another copy of the original file by giving it a different name.
Save an Existing File	To save an existing file under the same name:

1. Click on the disk icon on the Main toolbar ( ), or press Att F, S, or type SC (to Store Coordinates). Sectior 6  If the file has previously been named, the file will automatically be saved. Otherwise follow the instructions for the Save Job As command shown below.

#### Save Job <u>A</u>s a New File

## To Save a Job <u>As</u> a new file or to save an existing file under a new name:

1. From "Sight" Survey's <u>File</u> menu, choose Save Job <u>As</u>. The Save As dialog box appears.

Save As		? ×
File <u>n</u> ame: c:\sightsrv\oakwoods.zak cox.zak oakwoods.zak	Eolders: c:\sightsrv	OK Cancel
Save files of <u>type:</u> Sight" Survey Files	Dri <u>v</u> es:	

- 2. If you want to save the file on a different drive, select the drive you want from the **Drives** box.
- 3. In the Folder and File Selection menu, choose the folder you want to open. (Double-click the folder, or press the f or l arrows to select the folder, and then press **-**Enterl.
- 4. If you need to create a new folder, you must use the Windows Explorer. Access Explorer using the Start button.
- 5. In the File <u>Name</u> box, type a name for the file. If you don't specify a filename extension, "Sight" Survey will add ".zak".

¥

Never use a **BAK** extension when naming files or you may overwrite data you want to keep. Also, never rename a file to have a **BAK** extension!

6. Click <u>Save</u> (or <u>OK</u>).



When you save a file, "Sight" Survey can create a backup file of the previous coordinate data. The backup coordinate file will have a .ZBK extension. To reload backup file, rename the file to have .ZAK extension. Automatic file backup creation is set on the COGO Configuration Menu. See page 401.

#### Section 6

6.04

6.05

#### Save Job <u>A</u>s

**FUNCTION:** The **Save Job** <u>As</u> function is used to save a "Sight" Survey job using a different file name than what it was opened under.

To access Save Job <u>As</u> from the keyboard, press Alt F, A. The dialog box title bar will display: Save As

Follow the instructions for saving a file under a new name as contained in **Section 6.03**.


#### Print Preview/Adjust Margins

**FUNCTION:** Print Preview/Adjust Margins is used to set page size and margins, and to show you just how your printed text (*not drawings*) will appear when you print it out. You can also select your output device using this routine.

To access **Print Preview/Adjust Margins** from the keyboard, press At, F,  $\nabla$ . The "Sight" Survey print preview screen (shown on the next page) will appear.

The center of the display contains an image of your output as it will appear when printed. Depending upon the size and resolution of your monitor, you may be able to read the page, although that is unlikely. The upper left portion of the display contains a control pad. Use this control pad to set the page size and margins. You may also use the **Page**  $\blacksquare$  and  $\blacktriangleright$  buttons to step through the printout page-by-page.

To switch back to "Sight" Survey's normal view, press  $Alt \in \mathbb{R}$ ,  $\mathbb{V}$ , or click **Cancel**.



6.06

#### Print Text

FUNCTION: <u>Print Text</u> is used to print the contents of "Sight" Survey's Text Output window.

To access **Print Text** from the keyboard, press **Att F**, **P**. A standard Windows **Print** dialog box will appear: (Windows 95/98 box shown.)

Print	? ×
Printer: Default Printer (AccelaWrite on LPT1:)	r 8100 OK
Print range	Cancel
⊙ <u>A</u> II	<u>S</u> etup
C Selection	
C <u>P</u> ages	
<u>F</u> rom: 1 <u>I</u> o: 6	
Print guality: 960 dpi 💌	<u>C</u> opies: 1
	Collate copies

Verify or select your **Print range**, **Print quality**, number of **Copies**, and **Printer** and click **OK**. If you need to adjust your printer settings, click **Setup**... and the **Print Setup** window will appear: (*Windows 95/98 box shown.*)

Print Setup		? ×
Printer		ОК
<ul> <li>Default printer</li> <li>(currently AccelaW)</li> </ul>	riter 8100 on LPT1:)	Cancel
O Specific <u>p</u> rinter:		Options
AccelaWriter 8100	) on LPT1:	
Orientation	Paper	
• Po <u>r</u> trait	Size: Letter 8 1/2 x 11 in	
$\mathbf{A}$ $\circ$ Landsca	pe <u>S</u> ource: AutoSelect Tray <b>v</b>	

Due to the many printers supported by Windows, setting up your printer is beyond the scope of this manual. Please refer to your Windows and printer documentation for this information.

|--|

#### P<u>l</u>ot Drawing �<u>F</u>it to Page

**FUNCTION:** The **Plot Drawing**  $\Im$  **Fit to Page** routine plots your drawing at a size that will fit on a pre-selected page size.

To access Plot Drawing [™] <u>Fit</u> to Page, press Alt F, L, <u>"Enter</u> (or F).

•

- 1. In Windows, both printers and plotters are classified under the general heading "**Printers**", and printing refers to both printing and plotting. For information on how to install printers and on how to select the default printer, see your Windows documentation.
- 2. You can output bitmaps to printers, but not to vector (pen type) plotters.

When you select **Plot Drawing * <u>Fit</u> to Page**, the following appears:

Print	? >
Printer: HP DraftMaster II on LPT1:	OK
Print range	Cancel
• AII	<u>S</u> etup
C Selection	
C Pages	
Erom: Lo:	
Print guality: 203 dpi	<u>C</u> opies: 1
	🗹 Collate cop <u>i</u> es

¥

If you are outputting to a vector (pen) plotter, you should use one of the plotter fonts, **Modern, Roman, Script**, or some type of **stroke font** for your text and dimensions. (**HPGL Users** - if you use any other font on your drawing it will be converted for the plotter but all your text will be plotted horizontally, regardless of its orientation on the drawing.)

When you click  $\Box \kappa$ , the prompt bar at the top of the **Drawing** window command line prompts:

#### Plot to Fit? (else at exact scale)

If you click <u>No</u>, you can specify the exact scale at which your drawing will be printed. Please continue at <u>Plot Drawing</u>  $\Rightarrow$  <u>Plot to</u> Scale on page 209.

If you click <u>Yes</u>, "Sight" Survey will read the paper size and orientation of your printer or plotter and will print your drawing so that it fits onto the paper exactly. You'll be prompted:

Enter border in mm	×
10	
OK Cancel	

Type the width of the border you want around your drawing, then click  $\Box K$  or press  $\blacksquare Enter$ . The Drawing window command line prompts:

#### Satisfied with zoom?

The part of your drawing that will be printed or plotted appears on the screen enclosed by dashed lines indicating the edges of the paper. If you are satisfied with what is to be printed or plotted, click <u>Yes</u>. If you are not satisfied, click <u>No</u> button. The **Drawing** window command line prompts:

#### Enter new center of zoom box

Move the zoom box to a new position and press Fine or click your mouse. The **Drawing** window command line prompts:

#### Satisfied with zoom?

Continue until you are satisfied with the plot, or abort Plot Drawing  $\Pr{Fit}$  to Page by pressing the Space Bar.

After you are satisfied with the orientation of the drawing, the **Drawing** window command line prompts:

#### Enter point for compass insertion (space bar for no compass)

Press the Space Bar if you do not want a North arrow on your drawing. If you want a North arrow, position your cursor at the chosen location and press - Enter or click your mouse.

•

If you have rotated your print/plot, the message **Transforming** plot back again will appear. Click OK. Your drawing will return to the orientation it was at prior to rotation.


Printer Defaults
Printer Profile PRINT
Delete Save New
$\underline{X}$ offset (mm) $\underline{0}$ $\underline{Y}$ offset (mm) $\underline{0}$
Minimum Pen 1 Maximum Pen 15
• Use <u>Plotter Arcs</u> $\diamond$ Make arcs from <u>Lines</u>
Zoom Print Scale Hatch Z Scale Fat lines
All Colors to <u>B</u> lack Pen <u>Mappings</u>
OK Cancel Help

downwards from the top), you should specify minimum and maxi-

X and Y offsetThe X and Y offset boxes allow you to offset the drawing (relative<br/>to its current position) on the paper. The offset is measured in mm.<br/>The X offset box displaces the drawing to the right if a positive<br/>value is entered, and to the left if a negative value is entered. The Y<br/>offset box displaces the drawing downwards if a positive value is<br/>entered and upwards if a negative value is entered.Minimum Pen, Maximum PenThe Minimum Pen and Maximum Pen boxes allow you to specify the<br/>range of pens with which to plot when you are outputting to a<br/>plotter. The minimum pen is 1 and the maximum pen is 15. These<br/>boxes may be grayed out if they are not applicable to your setup.If you are using a plotter with less than 15 pens, such as a six pen<br/>plotter, but you have used more than the first six colors in the Pen<br/>Selection Area (red, olive, yellow, lime, green and teal counting

	mum pens 1 and 15. If you do not, the parts of your drawing that are drawn with other colors will not be plotted.
Use <u>P</u> lotter Arcs / Make Arcs from <u>L</u> ines	If the <b>Use Plotter Arcs</b> option is checked, "Sight" Survey will plot arcs created by your plotter driver. If the <b>Make Arcs from Lines</b> option is checked, "Sight" Survey will plot arcs made out of very small lines.
	If no arcs appear when you try to plot, or if arcs are plotted incorrectly, use the Make Arcs from Lines option.
Zoom Print - Scale <u>H</u> atch Scale <u>F</u> at Lines	Selecting either the <b>Scale Hatch</b> or <b>Scale Fat Lines</b> options under the <b>Zoom Print</b> heading tells "Sight" Survey to scale line weight and/or hatch patters accordingly when you change the scale on your drawing. <i>These boxes may be grayed out if they are not</i> <i>applicable to your setup.</i>
All Colors to <u>B</u> lack	If your printer prints colors as different shades of grey, meaning that some colors are printed very faintly, check this option. All colors will then be printed as black.
Pen <u>M</u> appings	This function allows you to use a printer such as an inkjet or laser printer as though it was a pen plotter. It does this by letting you map each color on the screen to a different line width on the printer. For example you could make red lines print at 0.3 mm, green lines print at 0.7 mm etc.
	When you click on the <b>Per Mappings</b> button, the <b>Pen Width Mappings</b> dialog box (shown on the next page) appears.
	The pens are listed on the left hand side of the box and are numbered from 0 to 15, where 0 is the top color in the <b>Pen</b> <b>Selection Area</b> at the right of the screen and 15 is the bottom color. Click on a pen to which you want to assign a width. The pen's number appears in the <b>Edit</b> part of the dialog box. Type a width (measured in mm) into the white part of the dialog box.

# Section 6



Now click on another pen to which you want to assign a width. The width associated with the first pen you edited appears next to that pen's number in the dialog box, and the second pen's number appears in the <u>Edit</u> area. Assign a width to the second pen and repeat until you have assigned a width to each pen. Then click on OK



Pen mappings only affect those lines with a width of 0. For example, if you map the red pen to print at 0.3 mm, and there is a red line on the drawing that you have given a width of 0.7 mm using the Line Defaults dialog box, then that red line will print at 0.7 mm even though you have mapped the red pen to print at 0.3 mm.



This function is very useful for thickening dimension witness lines (see Section 30.11 - Dimension Defaults) which often print very faintly on modern high resolution inkjet printers. To thicken witness lines, set aside one color and draw all your witness lines in that color. Map that color to the desired thickness.

When you click **OK**, the message **Busy printing** appears while your drawing is printed or plotted.

#### **Busy printing**

**Change Pens in Plotter** If you specified a maximum pen greater than the number of pens your plotter driver provides for, you will get the message Change **Pens in Plotter**. Simply click on **OK** after changing them.

#### P<u>l</u>ot Drawing [®] <u>P</u>lot to Scale

9

FUNCTION: This routine plots your drawing at a specified scale. There are two ways to **Plot to Scale**: from the **File** menu, and from the **Plot Drawing**  $\Rightarrow$  **Fit to Page** routine.

To access Plot Drawing [™]→ Plot to Scale, press Att F, □, P.

()

*The instructions for* **Plot Drawing Plot to Scale** *are identical* to the instructions for **Start Pile Zoom Print**, contained in Section 22.12 of the Drawing Window Reference Manual.

#### 6.09

6.08

#### Print Coordinates

FUNCTION: The Print Coordinates routine simply sends a coordinate listing to your printer.

To access Print Coordinates, press Att F, C and the Print Coordinates dialog box will appear.

Print Coordinates	×
Enter the points you would like printed, or	OK
type <a><enter> for all.</enter></a>	Cancel
1-14,19	

In the text entry box, type the point numbers you want to list. In the sample shown above, "Sight" Survey will list points 1 through 14, and then point 19. When you have entered your point numbers, click  $\square K$  and the **Print** dialog box (shown on page 203) appears.

Notice the **Print Range**, **Collate Copies**, and **Print to File** sections of the dialog box are grayed out. At this time these settings are not relevant.

When you click **OK**, "Sight" Survey will print the specified coordinate list to your output device.

#### 6.10

#### Import [®]<u>C</u>oordinates

FUNCTION: The Import [™]> <u>C</u>oordinates routine is used to import coordinates from a "Sight" Survey, Survey 4.0, or third party data file. The Import [™]> <u>C</u>oordinates process replaces your current job file. This routine is most commonly used to begin a new "Sight" Survey job from a third party data file. To add coordinates from another file to your current job file, use Import [™]> Merge Coordinates (see page 214).

To <u>Import</u> [™] <u>Coordinates</u>, press <u>Alt</u> [F, ], <u>Enter</u> (or C). The Open dialog box appears. (Windows 95/98 version shown.)

Open		? ×
File <u>n</u> ame: oakwoods.zak cox.zak oakwoods.zak	Eolders: c:\sightsrv c:\ sightsrv program utility	OK Cancel
List files of <u>type:</u> "Sight" Survey Files (*.2	Dri <u>v</u> es:	

Follow basic Windows procedures for opening a file and select the coordinate data file you wish to import. When you click  $\Box K$  or  $\Box pen$ , you may see the dialog box:

New Job		×
😲 Would yo	u like to save	your work first?
<u>Y</u> es	<u>N</u> o	Cancel

This box will only appear if you have existing, unsaved data. Click <u>Yes</u> to save your data, <u>No</u> to proceed with the import without saving your data, or <u>Cancel</u> to exit this routine.

"Sight" Survey will automatically recognize files in a "Sight" Survey or Survey 4.0 format. However, if you are importing a third party file, you must choose the correct file type from the File Format dialog box.

File Format 🛛 🛛	]
ASCII - Custom formats Autocogo BenchMark - ASCII Bischoff C & G - ASCII Carl Zeiss Rec 500 - ASCII CivilComp CC-Surv CivilSoft Cogo PC Plus CO-OP 41 - Native Collier DigiMate	
<u>O</u> K <u>C</u> ancel <u>H</u> elp	

At this time, "Sight" Survey directly supports several file formats as listed on the next page. (List subject to change without notice.)



The most common type of ASCII file is a comma delimited file. While this does not appear on the menu, the Lewis & Lewis selection is a comma delimited file. ASCII - Custom Formats Autocogo Benchmark - ASCII Bischoff C & G ASCII Carl Zeiss Rec 500* - ASCII CivilComp CC-Surv CivilSoft Cogo PC Plus CogoMate ~ CO-OP 41 - Native Collier DCA (Softdesk) ~ DigiMate* GEM - SDF File Geodimeter* - ASCII

Houseman PC-Cad HP-71 Surveying Pac* - Text Lewis & Lewis LI Contour Lietz SDR Comms/Text/Map MapTech - Native Micromate* MTI 3000 Nikon* - ASCII NOAA State Plane PacSoft Pentax* - ASCII Plus III - ASCII Simplicity "Sight" Survey Simplicity Survey 2 Simplicity Survey 3 Simplicity Survey 4 Star * Net* Surfer ~ Surv-A-Soft Ver. 4 Surveyor II SurveySoft Technical Advisors TopCon* - ASCII Traverse PC Tri-Pod Data Sys.* - ASCII WildSoft - ASCII * Import Only ~ Export Only



The Import O Coordinates routine contains Point Overwrite Protection identical to the Import O Merge Coordinates routine described on page 214.

#### **ASCII Custom Formats**

Almost every COGO program currently on the market will export its coordinate data into an ASCII style format. If the format you need is not directly supported by "Sight" Survey, you can probably import it by using the **ASCII - Custom Formats** option.

To define a custom format, select the **ASCII - Custom Formats** option. This will open the **ASCII - Custom Import** dialog box which will contain the first line of the specified data file. This is where you will define the actual data file format.

Drag fields to the correct position and select O	K. Other		
	Other		
North			
East Elev Desc 1, 12452.124533, 25113.548812, 830.115, Benchmark 131	÷		
Number of header lines: Fields are divided by :			
Value used for null entry     Can       Comma Delimited (Only order matters)     He			

Drag Fields	In the <b>Drag Fields</b> box, move the <b>Name</b> , <b>North</b> , <b>East</b> , <b>Elev</b> , <b>Desc</b> , and <b>Other</b> fields to indicate the various elements of the data line. To move a field, click and drag the field name to a new location. Position the fields so the vertical separator line falls before the data in the field, as illustrated above.
Number of header lines	Some ASCII files contain header lines that typically identify the filename, and other job information. If the first line in the file does not contain coordinate data, use the $\triangle$ and $\checkmark$ buttons to count the number of header lines. Stop when you reach the first data line and type the number of header lines into this entry box.
Value used for null entry	Many programs use a value other than zero to signify a null entry. Often this is a number such as <b>99999</b> . If your data file uses a value other than zero, type the number into this entry box.
Comma Delimited	Most programs produce ASCII data files with comma delimited fields. If this applies to your data file, activate this checkbox. In a comma delimited file, the exact start column for each data field is ignored. The <b>Drag Fields</b> items need only be in the correct order.
Fields are divided by	If your data file is not comma delimited, you must type the delim- iting character into this entry box.
	When your data file format has been established, click $\bigcirc K$ and the data will be imported. You will then be presented with the Edit Coordinates window.
	& Edit Coordinates

& Edit Co	ordinates			_ 🗆 ×
Point	Northing	Easting	Elevation Description	<b>A</b>
1	10051.23475	19960.00000	101.700 SE Cor Lot 1	
2	10126.23475	19960.00000	101.700 NE Cor Lot 1	
3	10126.23475	19824.50000	101.700 NW Corner Blk	1
4	10051.23475	19824.50000	102.400	
5	9936.23475	19824.50000	100.600	
6	9811.75475	19824.50000	99.800 SW Cor Blk 1	
7	9811.75475	19914.50000	100.400	
8	9811.75475	20095.50000	101.400	
9	9811.75475	20190.05000	103.500 SE Cor Blk 1	
10	9936.24225	20188.62862	102.800	
11	10051.23475	20187.31565	102.200	
12	10126.23475	20186.45931	101.300 NE Cor Blk 1	
13	10126.23475	20040.00000	100.800 NW Cor Lot 7	-
•				•
Add Delete Use Pt. Copy Accept Cancel Help				

You may now review the data to check its accuracy. When you are satisfied, click  $\[ \underline{Accept} \]$ .

#### 6.11

6.12

#### <u>I</u>mport <u>⊅</u>Text

**FUNCTION:** The **Import Text** routine is used to import any text file into "Sight" Survey's **Text Output** window.

#### To **Import** ² → <u>T</u>ext, press Alt F, □, □.

The **File Open** dialog box will appear. Following basic Windows procedures for opening a file, select the text file you wish to import and click  $\Box K$  or  $\Box pen$ . Text files are imported using a monospaced font for best formatting results.

and

A more convenient method of importing text is to use Windows' Cut(or Copy) & Paste functions to paste text from a text editor into "Sight" Survey.

•

To import text into a drawing, use the <u>Start</u> **№**<u>File</u> **№**<u>Import</u> ASCII <u>Text</u> function described in Section 22.08 in the Drawing Window Reference Manual.

#### Import ₱<u>M</u>erge Coordinates

**FUNCTION:** The **Import** [™] Merge Coordinates routine is used to merge an *existing coordinate file* into the current data file.



The difference between the  $\underline{Import} \stackrel{>}{\to} \underline{Coordinates}$  and the  $\underline{Import} \stackrel{>}{\to} \underline{Merge}$  Coordinates routines is that  $\underline{Import} \stackrel{>}{\to} \underline{Merge}$  Coordinates merges the points into the CURRENT job, and  $\underline{Import} \stackrel{>}{\to} \underline{Coordinates}$  places the points into a NEW job.

To <u>Import</u>  $\mathbb{P}$  <u>Merge</u> Coordinates, press <u>Alt</u>  $\mathbb{F}$ ,  $\Pi$ ,  $\mathbb{M}$ . The Open dialog box will appear. Following basic Windows procedures for

opening a file, select the coordinate file you wish to merge and click **OK** or **Dpen**. "Sight" Survey will display:

Copy Bl	ock of Points			1
?	Do you wai	nt point ove	erwrite prot	ection?
	<u>Y</u> es	<u>N</u> o	<u>C</u> ancel	

To preserve your existing points, click <u>Yes</u>, otherwise click <u>No</u>. Click <u>Cancel</u> to end this routine.

If you have activated the point overwrite protection, the **Point Al**ready Exists dialog box appears whenever an existing point is about to be overwritten.

Point Already Exists	
Point 1 already exists. 1 12452.12453 25113.54881 830.115 Benchmark 131 Trying to overwrite with point 1 1 10051.23475 19960.00000 101.700 SE Cor Lot 1	
<u>Skip</u> <u>O</u> verwrite <u>N</u> ew Number <u>Exit</u>	

To **skip** the point press Att S or click **Skip**. The incoming point will not be merged into the file.

To **overwrite** the old point with the point from the merging file press Att O or click **Qverwrite**.

To **assign a new point number** to the point from the merging file press **Att N** or click **New Number**.

To exit this routine at any time press Alt E or click Exit

If you choose to **assign a new point number** to the point from the merging file, enter a point number into the **New Point** dialog box and click **Accept** or press **Alt**[**A**].

Input the new point	
Point	
Accept	<u>C</u> ancel

When you have finished the merging operation, you will find that "Sight" Survey produced a report in the **Text Output** window. An example report is shown below:

Merging with coordinates from D:\SIGHTSRV\OAKWOODS.ZAK Skipping point 1 Renumbering point 2 with 60 Overwriting point 4

The report tells you which points were skipped, renumbered, and overwritten. Any point number not specifically placed into the report was merged without incident.

If you merge files using Point Overwrite Protection, and you choose to <u>Overwrite</u>, <u>Skip</u>, or enter a <u>New Number</u> for any of the incoming points: If those points are referenced in any defined figures, you must be aware that your figures may now be incorrect. When points are overwritten, renumbered, or skipped, a list is sent to the <u>Text Output</u> window. We recommend checking this list for point numbers referenced in your defined figures.

When importing coordinate files from *Survey 3.0* and *Survey 4.0*, both of these routines will convert the **defined figures (.FIG)** file into "Sight" Survey, provided that a **.FIG** file exists for the file that is being imported. If an incoming defined figure contains the letters **R** (for acute curve) or **O** (for obtuse curve), they will be changed to the < and > symbols, respectively, so that they will not be interpreted as alphanumeric point numbers. When merging files, if an incoming coordinate file has a figure name that exactly matches a figure name in the existing file, the incoming figure name will have the prefix "**Imported**:" attached to it. For

example, Lot One would become Imported: Lot One. (If

¥

#### **Defined Figures**

the prefix causes the figure name to become longer than 65 characters, the name will be truncated.)

¥

If you merge files using Point Overwrite Protection, and you choose to <u>Overwrite</u>, <u>Skip</u>, or enter a <u>New Number</u> for any of the incoming points: If those points are referenced in any defined figures, you must be aware that your figures may now be incorrect. When points are overwritten, skipped, or renumbered, a list is sent to the Text Output window. We recommend checking this list for point numbers referenced in your defined figures.

#### 6.13

#### <u>Export ≫Coordinates</u>

**FUNCTION:** The **Export**  $\Rightarrow$  **Coordinates** routine is used to export all the coordinates from an existing "Sight" Survey job to a different data file. The target file may be a third party format or a "Sight" Survey format.

To **Export** [™]**Coordinates**, press Alt F, E, **Enter** (or C).

The **Save As** dialog box will open and allow you to enter the name of the target file.

Save As		? ×
File <u>n</u> ame: c:\sightsry\oakwoods.zak cox.zak oakwoods.zak	Eolders: c:\sightsrv c:\ sightsrv program utility	OK Cancel
Save files of <u>type:</u> Sight" Survey Files	Dri <u>v</u> es:	

In the Save file as type box, you have three choices:

"Sight" Survey Files Survey 4 Files (*.dat) All files (*.*)	
Survey 4 Files (*.dat)	
All files (*.*)	

Select the file type to which you want to save. If you want to save to a file type other than a Simplicity file type, select All files and enter a filename extension other than or .zak. If you select a file type other than "Sight" Survey or Survey 4, the File Format dialog box will appear, and you must choose the export file type. If the format you need is not directly supported by "Sight" Survey, you can probably export it using the ASCII - Custom Formats option.

٩

If you do not specify an extension, "Sight" Survey adds a default extension of ".CRD" to the end of your filename. If you don't want an extension on the filename, append a "." to the end of the file name. For example: Entering "Oakwoods" will give a file name of Oakwoods.crd, while entering "Oakwoods." will give a file name of Oakwoods.



If you choose to use an ASCII Custom Format, the Custom ASCII Export dialog box appears. When it first appears, the option button Fields divided by commas is marked as active, and the Field Size column of text entry boxes is not present. (Field size is only relevant when fields are structured in length and not separated by commas. If this matches your situation, click on the option button designated Each field is a certain size.) First set the field order, the order in which the data fields are placed into the file. Then type in values (number of characters) for the field sizes, if necessary.


	Order		
<u>P</u> oint Number	1	• Fields divided	l by commas
<u>N</u> orthing	2	C Eac <u>h</u> field is a	a certain size
<u>E</u> asting		🗌 Place <u>q</u> uotes	around desc.
Ele <u>v</u> ation	4	🗌 <u>I</u> nclude unass	signed points
<u>D</u> escription	5	Accept	<u>C</u> ancel

The **Custom ASCII Export** routine also allows you to specify the number of digits printed after the decimal, as well as the total size of the field. To create a field that is 10 characters wide and has 3 characters displayed after the decimal simply enter **10.3** in the field width dialog box.

If you need to place quotes around the point description, click the **Place quotes around desc.** checkbox to enable it. If you have also enabled the option designating **Each field is a certain size**, be sure to include the two quotes as part of the **Description** length.

To include all unassigned point numbers in the exported file, even those points which have zero coordinate values for their Northing, Easting, and elevation, click the **Include unassigned points** checkbox to enable it. For example, let's assume you have coordinates assigned for points 1, 2, 5, and 10. If you enable this checkbox, your ASCII file will contain TEN points, numbered 1 through 10; if you do not enable this checkbox, your file will contain only the FOUR points 1, 2, 5, and 10.

When you have completed the dialog box, click **Accept**. You must now specify the points you wish to export into the new file.



Specify the point string or press  $\triangle$  for all points. When you click  $\bigcirc K$ , the routine will run to its completion.


#### 

**FUNCTION:** The **Export**  $\Rightarrow$  **Text** routine is used to export the contents of the **Text Output** window to a different file.

To **Export**  $\xrightarrow{\mathbb{P}}$  **Text**, press **AHF**, **E**, **T**. The **Save As** dialog box opens to allow you to enter the name and location of the target file.

File <u>n</u> ame: Sample.txt test.txt	Eolders: e:\sightsrv a:\ e:\ sightsrv	OK Cancel
V	<ul> <li>program</li> <li>utility</li> </ul>	<b>*</b>
Save file as <u>t</u> ype: ASCII Text Files (*.txt)	Dri <u>v</u> es:	

In the Save files of type box, you have three choices:



To preserve formatting information use the .rtf extension. When you click  $\Box K$ , the routine will run to its completion.

6.15

#### Copy Job

**FUNCTION:** The **Copy Job** routine is used to copy a "Sight" Survey job (including all associated files) to a different location on your hard disk, or to a floppy disk. Essentially this routine utilizes the **Open** routine to retrieve the subject job's file name, and the **Save Job <u>As</u>** routine to save the job to its new location. To access **Copy Job**, press **AttF**, **J**. The **Open** dialog box will open and allow you to enter the name of the job you want to copy. Follow general Windows procedures for opening a file.

When you click **OK**, the **Save As** dialog box will open and allow you to enter the new name and location for the job. Follow general Windows procedures for saving a file.

When you click **OK**, the **Copy Job** routine will copy (and optionally rename) the job to its new location.



6.16

If you are running an existing job and you need to use the **Copy Job** routine, you do not need to close your currently running job. **Copy Job** does not affect your current job in any way. However, if you want to copy the current job you will have to close the job before copying it.

#### <u>D</u>elete Job

**FUNCTION:** The <u>Delete Job</u> routine is used to erase a "Sight" Survey job (and all associated files) from your disk. This routine utilizes the <u>Open</u> routine to retrieve the file name of the job to be deleted.

To access **Delete Job**, press **AltF**, **D**.

The **Open** dialog box will open and allow you to enter the name of the job you want to delete.

When you click  $\bigcirc$ , a dialog box will open to ask for confirmation of your intent

"Sight" S	Survey
?	The file d:\sightsrv\oakwood.zak and all associated files including drawing files are about to be deleted. Are you sure you want to continue?
	OK Cancel

When you click **OK**, the specified job will be erased.



If you are running an existing job and you need to use the **Delete Job** routine, you do not need to close your currently running job. **Delete Job** does not affect your current job in any way. **You cannot delete the current job.** 

#### 6.17

#### Last Used Job List

**FUNCTION:** The **Last Used Job List** contains names of the last four jobs you have work on. You may use this list for fast loading of any job shown.

To activate a job using this list, simply press Att F, 1 (2, 3 or 4) where the number corresponds to the job you want to open, or click on the filename with your mouse.

#### 6.18

#### E<u>x</u>it (SY)

**FUNCTION:** The **Exit** function closes all files and exits the "Sight" Survey program.

To **Exit** "Sight" Survey, type **SY** (or **QU** to **QU**it), or press Ath F, X (or Ath F4), or click the **Exit** icon ( ) on the **Main** toolbar.



You will be given the opportunity to save any unsaved data before "Sight" Survey closes all job files and discontinues operations.



<u>U</u> ndo	Ctrl+Z
Cu <u>t</u>	Ctrl+X
<u>C</u> opy	Ctrl+C
<u>P</u> aste	Ctrl+V
Edit Coordinates (EC)	F12
Clear Text Output (CW)	
Edit <u>O</u> riginal Raw Data (ER)	

# Section 7 The <u>E</u>DIT Menu

The **<u>E</u>dit** menu contains options for modifying work that you have already done. Here you will find commands that will allow you to change the values of current coordinates, undo changes that were made in error, and Transfer information between "Sight" Survey and other Windows programs.

All commands are discussed in the order in which they appear on the menu. You can access menu routines by using your mouse on the pull-down menu. Therefore, this selection method will not be mentioned in each routine's discussion. Keyboard shortcuts to each routine will be noted.

The Cut, Copy, and Paste items deal with the Windows clipboard. The Windows clipboard is a temporary storage location for information you cut or copy. Information in the clipboard remains there until you either copy another piece of information to the clipboard, or until you exit Windows.

7.01

#### 

**FUNCTION:** The <u>Undo</u> function is used to remove an error that was entered.

Activate the Undo function by pressing Ctrl Z or Alt E, U.

<u>Undo</u> will undo multiple layers of changes to the **Drawing** Window, or to the **Text Output** window, however it's "Undo-ability" is limited to these types of things. It cannot, for example undo a traverse adjustment.

When the **Drawing** window is active, <u>**Undo**</u> operates on drawing elements. When the **Text Output** is active, <u>**Undo**</u> operates on text elements within the **Text Output** window.

7.02	
	<b>FUNCTION:</b> The <b>Cut</b> function is used to move selected objects to the Windows clipboard. When an object is cut, it is
	removed from the active window and placed in the clipboard.Activate the $Cut$ function by pressing $Crix$ or $Atten, T$ .
	Cut is a drawing command which has been included on this menu as a convenience. The instructions are contained in Section 23.03 in the Drawing Window Reference Manual.
7.02	
7.03	<u>C</u> opy CtrlC
	<b>FUNCTION:</b> The <u>Copy</u> function is used to copy selected objects to the Windows clipboard. When an object is copied, it remains in the active window and a copy of it is placed in the clipboard.
	Activate the <b>Copy</b> function by pressing <b>Ctrl</b> or <b>Att</b> , <b>C</b> .
	<b>Copy</b> is a drawing command which has been included on this menu as a convenience. The instructions are contained in Section 23.04 in the Drawing Window Reference Manual.

Paste CtrlV

**FUNCTION:** The **Paste** function is used to place into the active window a copy of the object in the Windows clipboard. When an object is pasted from the clipboard, a copy of it still remains in the clipboard.

Activate the **Paste** function by pressing **Ctrl V** or **Alt E**, **P**.

Paste is a drawing command which has been included on this menu as a convenience. The instructions are contained in Section 23.05 in the Drawing Window Reference Manual.

Edit Coordinates (EC) F12

**FUNCTION:** The <u>Edit Coordinates</u> function is used to display and modify all aspects of the points in the current file.

Activate the **Edit Coordinates** function by pressing F12 or ARE, E, or by typing **EC** at any data entry prompt. "Sight" Survey will display a listing of all points in the current file, as well as the points Northing, Easting, Elevation, and Description. "Sight" Survey will also display the point's Station, if stationing is in use.

& Edit Co	ordinates			_ 🗆 ×
Point	Northing	Easting	Elevation Description	<b>A</b>
1	10051.23475	19960.00000	101.700 SE Cor Lot 1	
2	10126.23475	19960.00000	101.700 NE Cor Lot 1	
3	10126.23475	19824.50000	101.700 NW Corner Blk 1	
4	10051.23475	19824.50000	102.400	
5	9936.23475	19824.50000	100.600	
6	9811.75475	19824.50000	99.800 SW Cor Blk 1	
7	9811.75475	19914.50000	100.400	
8	9811.75475	20095.50000	101.400	
9	9811.75475	20190.05000	103.500 SE Cor Blk 1	
10	9936.24225	20188.62862	102.800	
11	10051.23475	20187.31565	102.200	
12	10126.23475	20186.45931	101.300 NE Cor Blk 1	
13	10126.23475	20040.00000	100.800 NW Cor Lot 7	•
•				•
	Add Delete Use Pt.	Сору <u>А</u> сс	ept <u>C</u> ancel <u>H</u> elp	

Section 7

7.05

Any aspect of a point can be changed from this window. Simply select the point you would like to change, then click on the property with the mouse to enter the edit mode, or just start typing to overwrite the current property.

A point can be added by clicking on the <u>Add</u> button. After selecting <u>Add</u> you will be prompted with the <u>Enter & Assign</u> pop-up window (see page 231).

To **edit** point numbers, descriptions, coordinates, stations, or elevations, click your mouse on the field you want to edit, pause a moment, then click again. Make your editing changes and press <u>--Enter</u>.

You can select multiple points by moving the cursor to the far left of the point name column. When the mouse changes into a check mark ( $\checkmark$ ), click on the point name that you would like to select or delete.

After selecting points you may:

- Delete the selected points by clicking on the Delete button.
- Click the **Copy** button to copy the points to the clipboard. From there they may be pasted into any windows program that supports the clipboard. For example, you could bring the points into your word processor, or you could bring them into a spreadsheet for further manipulation.
- Click on the Accept button to close the Edit Coordinates window and print the name of the selected point into the last used text box. This allows you to easily retrieve a point name to be used in a calculation such as a distance - distance intersection.

#### Clear Text Output (CW)

**FUNCTION:** The **Clear Text Output** function is used to erase the **Text Output** window.

Activate the Clear Text Output function by pressing Att [E], [L], or by typing CW at any data entry prompt.

Clearing the **Text Output** window permanently deletes all text currently in the window. Unless you have saved your work, there will be no way to recover this data. *Use this routine with caution.* 

Section 7

#### 7.07

#### Edit Original Raw Data (ER)

**FUNCTION:** The **Edit** <u>O</u>riginal Raw Data function is used to correct errors in initial data entry.

Activate the Edit Original Raw Data function by pressing Att E, O, or by typing ER at any data entry prompt.

Despite using the utmost care in gathering and entering data, it is inevitable that mistakes will be made. "Sight" Survey contains features and routines to help you easily correct errors.

## 3

Raw data files are not saved between sessions. You must correct your raw data during the session in which it was entered into "Sight" Survey.

The data correction procedure incorporates the use of the **Unbalanced Traverse** window which allows you to easily review and edit your traverse data.

To illustrate the use of this window, suppose we see a problem in the **Bearing** column for **LEG 4**. The angle you entered as **88.3536** should have been **98.3536**. Double-click your mouse on the bad angle entry which reads **88.3536** AR.

7.06

		l Traverse						_ 🗆 >
Length Traversed:         9704 610         Error In Departure:         464           Length To Close:         472.232         Error in Elevation:         00           Area:         51 48592.0085 Sq. Feet on 110 1954         Total Angular Error:         10'00'				84.941 464.530 0.000 0*00*12.0* 2*30*03.0*	Add Leg Del Leg Copy <u>H</u> elp			
Bal Angl Cgmpass Ctandall Iransit Lst Sgr Re-Ryn Print Accept Cancel				<u>C</u> ancel				
Leg	Action	Bearing	Distance	FS Pt	Northing	Easting	Description	
Leg BS	Action EB	Bearing 0.0410200117 SW	Distance 2000.001	FS Pt 1	Northing 10000.00000			/ Corner
				1		10000.00000	SW	/ Corner / Corner
	EB	0.0410200117 SW	2000.001	1	10000.00000	10000.00000	SW SW	
BS 1	EB ST	0.0410200117 SW N/A	2000.001 N/A	1	10000.00000 10000.00000 10687.03779	10000.00000 10000.00000 12256.98747	SW SW SE	/ Corner
BS 1 2	EB ST TR	0.0410200117 SW N/A 253AR	2000.001 N/A 2359.240	1 1 2 3	10000.00000 10000.00000 10687.03779	10000.00000 10000.00000 12256.98747 11762.94864	SW SW SE NE	/ Corner E Corner
BS 1 2 3	EB ST TR TR	0.0410200117 SW N/A 253AR 95.4757AR	2000.001 N/A 2359.240 2559.010	1 1 2 3 4	10000.00000 10000.00000 10687.03779 13197.90573	10000.00000 10000.00000 12256.98747 11762.94864	SW SW SE NE	/ Corner E Corner E Corner / Corner

"Sight" Survey will present a pop-up editing box for you to make the changes.

Modify a Value	×
Enter the new value	OK
	Cancel
88.3536AR	

Press Home, then Delete, and then (9) to change the line to read 98.3536 AR, then press Fine or click OK. Select Re-Run with your mouse or press (Alt (1) to accept the change and re-run the traverse using the corrected angle entry.

In a similar manner, you can change the **Action** (routine code), **Point Number**, **Coordinates**, **Slope Reduction Data**, and **Description** fields of any point.

After computing new coordinates based on the traverse changes, "Sight" Survey will display a **Modified Traverse** window showing the new traverse statistics and raw traverse data.

Adding a LegTo add a leg, position your mouse cursor at the insertion point and<br/>click. For example, it you want to insert a leg between leg 2 and 3,<br/>click your cursor on leg 3. Now click Add Leg. Click Yes when<br/>you are asked to confirm your action. The highlighted leg is re-<br/>produced as a new leg. In other words, you now have two leg 3<br/>entries. Don't worry about the leg numbers, they will be corrected

automatically when you **Re-Run** the traverse. However, you do need to correct the data in the first leg **3**, cell by cell.

Deleting a Leg	To delete a leg, position your mouse cursor on the target leg and click. For example, it you want to delete leg 2, click your cursor on leg 2. Now click <u>DelLeg</u> . Click <u>Yes</u> when you are asked to confirm your action. The highlighted leg is deleted and your leg numbers now read 1, 3, etc. Don't worry about the leg numbers, they will be corrected automatically when you <b>Re-Run</b> the traverse.
Copy to the Clipboard	To copy a leg's data to the Windows clipboard, position your mouse cursor on the target leg and click. For example, if you want to copy the information for leg <b>2</b> , click your cursor on leg <b>2</b> . Now click <b>COPY</b> .
Resizing the Grid	Depending upon your screen resolution, you may want to resize the columns in the data grid. You can accomplish this by using your mouse to drag the column borders to new locations. For example, to move the right-side border of the <b>DISTANCE</b> column about two digits to the left, place your mouse cursor in the column headings on the line between <b>DISTANCE</b> and <b>POINT</b> . Your cursor will appear as a double-headed arrow ( $\leftrightarrow$ ). Click and hold your mouse while dragging it to the left. A dotted line will appear to mark the changing position of the column border. When you are satisfied with the new location, release the mouse button.

230 The EDIT Menu

This page intentionally left blank.



Enter and Assign (EA) Enter Elevation (E<u>2)</u> Identify Point (ID) En<u>t</u>er Station (ES)

<u>S</u>tart At (ST) <u>G</u>o To (GT) Enter Backsight P<u>o</u>int (EP) Enter <u>B</u>acksight Bng (EB)

Point Plot (PP) List Coordinates (LC)

Blan<u>k</u> Point Scan (BP) <u>R</u>enumber Points (RP) Copy Block of Points (CB)

Clear Coordinates (CC) Clear Point Names (CN) Clear Point Stations (CS)

Define Figures (DF) F11 Edit Default Descriptions (AP) The **Points** menu contains commands that generally deal only with an individual point and not with that point's relationship to other points. Here you will find commands to change aspects of a point, such as the point's coordinates or station, as well as commands to change information about the currently held position.

#### 8.01 <u>Enter and Assign</u> (EA)

The **POINTS Menu** 

Section 8



**FUNCTION:** The **Enter and Assign** routine is used to assign Northing, Easting, and elevation coordinates to a point, or to edit coordinates of an existing point. Point descriptions may also be added or changed using this function.

Activate the <u>Enter and Assign</u> routine by pressing <u>Alt</u> P, E, or by typing **EA** at any data entry prompt.

层 Ente	😴 Enter & Assign					
	Enter ti		or this point (maximum 28 racters)			
ST	GT	Point #	1			
EB	EP	Northing	10000			
IN	IC	Easting	20000			
TR	TA	Elevation	1210.23			
TS	IS					
PO	SS					
TC	ED					
PA	BP					
BB	DD					
BD	DB		Accept (PgDn)			

To enter a point and assign coordinates to it, simply complete the data entry window.

Point #	Type the number of the point and press -Enter.
Northing	Type the Northing coordinate for this point and press <i>enter</i> .
Easting	<i>Type</i> the Easting <i>coordinate</i> for this point and press <i>enter</i> .
Elevation	<i>Type</i> the elevation for this point and press <i>-Enter</i> .
	Upon the conclusion of the data entry for each point, click the <u>Accept (PgDn)</u> button or simply press <u>Page Dn</u> . "Sight" Survey will display the point number, ID, and its Northing, Easting and elevation in the <u>Text Output</u> window (if it is active). You will be returned to the <u>Enter &amp; Assign Point #</u> prompt.

8.02

### Enter Elevation (EZ)

**FUNCTION:** The **Enter Elevation** routine is used to assign (or change) an elevation to an existing point.

Activate the Enter Elevation routine by pressing AHP, Z, or by typing EZ at any data entry prompt.

🗃 Ente	er&As	sign	_ 🗆 🗙
		Enter the Elev	ation for this point
ST	GT	Point #	1
EB	EP	Northing	10000
IN	IC	Easting	20000
TR	TA	Elevation	1210.23
TS	IS		
PO	SS		
TC	ED		
PA	BP		
BB	DD		
BD	DB		Accept (PgDn)

Point #

Type the number of the point you wish to assign an elevation to and press *Enter*. If the point exists, the **Elevation** field will contain

a blinking cursor (or it will be highlighted), waiting for you to type in a new value. However, if the point has not been previously assigned coordinates, the entry field for the **Northing** will be the highlighted field, and you may treat the data entry as though you were in the **Enter & Assign** routine

Type the elevation for this point and press Fine. "Sight" Survey will display the point number, ID, and its Northing, Easting and elevation in the **Text Output** window (if it is active). You will be returned to the **Enter & Assign Point #** prompt.

#### Identify Point (ID)

Section 8

**FUNCTION:** The <u>ldentify Point</u> routine is used to add or change an identifying name on a previously assigned point.

Activate the <u>ldentify Point</u> routine by pressing <u>Att</u>, <u>I</u>, or by typing <u>ID</u> at any data entry prompt.

层 Ente	er & As	sign	
	Enter ti		or this point (maximum 28 racters)
ST	GT	Point #	1
EB	EP	Northing	10000
IN	IC	Easting	20000
TR	TA	Elevation	1210.23
TS	IS		
PO	SS		
TC	ED		
PA	BP		
BB	DD		
BD	DB		Accept (PgDn)

To enter or change the elevation at a point and assign coordinates to it, simply complete the data entry window.

8.03

Elevation

Point #	Type the number of the point you wish to assign a description to and press <i>end</i> .
	If the point has not been previously assigned coordinates, the entry field for the Northing will be the highlighted field, and you may treat the data entry as though you were in the Enter & Assign routine.
Description	If the point exists, the <b>Description</b> dialog box will appear, awaiting your description entry.

#### Enter Station (ES)

**FUNCTION:** The **Enter Station** routine is used to change stationing information on a previously assigned point.

Activate the **Enter Station** routine by pressing Alt P, T, or by typing **ES** at any data entry prompt. If you are not currently occupying a point, you will be prompted for a point number. The **Enter Station** dialog box will appear, showing the occupied point number.



When you accept your data entry, "Sight" Survey will display the point number, station, and its Northing, Easting and elevation in the **Text Output** window (if it is active).

8.04

**Station** 

8

### Start At (ST)

**FUNCTION:** The **Start At** routine is used to introduce a new currently occupied point into the COGO routines. This routine should be used before inversing for area calculation to clear the **Area Sum** and **Traverse Length** accumulators.

Activate the <u>Start At</u> routine by pressing <u>Alt</u> P, <u>S</u>, or by typing <u>ST</u> at any data entry prompt. The <u>Data Entry</u> window will display:

•	Star	t At Po	int	
			Enter a l	Point Number
1	ST	GT	Point #	1
	EB	ΕP		
	IN	IC		
	TR	TA		
	TS	IS		
	PO	SS		
	TC	ED		
	PA	BP		
	BB	DD		
]	BD	DB		Accept (PgDn)

Point #

Type the number of the point you start at and press enter or click the **Accept (PgDn)** button.

If the point has not yet been assigned coordinates, the program will request them. Follow the **Enter and Assign** procedure to assign coordinates and a description to the point.

"Sight" Survey will display the word **START** followed by the point number, ID, Northing, Easting and elevation in the **Text Output** window (if it is active).



1. This routine is the only routine that clears the Area Sum and Traverse Length accumulators.

2. You must use this routine when you begin a new traverse that you intend to balance.

8.05

3 *DO NOT* use the Start At routine in the middle of an area calculation or your area will be cleared. Use the <u>Go To</u> routine instead.

#### <u>G</u>o To (GT)

**FUNCTION:** The <u>Go</u> To routine is used to introduce a new currently occupied point into the COGO routines without clearing the Area Sum and Traverse Length accumulators.

Activate the <u>Go</u> To routine by pressing <u>Att</u>, <u>G</u>, or by typing <u>GT</u> at any data entry prompt. The <u>Data Entry</u> window will display the <u>Go To Point</u> prompt.

F	🚽 Go	To Poi	int	
l			Enter	a Point Number
l	ST	GT	Point #	
Ш	EB	EP		
Ш	IN	IC		
Ш	TR	TA		
Ш	TS	IS		
Ш	PO	SS		
Ш	TC	ED		
Ш	PA	BP		
	BB	DD		
	BD	DB		Accept (PgDn)

Point #

Type the number of the point you start at and press *Enter* or click the **Accept (PgDn)** button.

If the point has not yet been assigned coordinates, the program will request them. Follow the **Enter and Assign** procedure to assign coordinates and a description to the point.

"Sight" Survey will display the word GO TO followed by the point number, ID, Northing, Easting and elevation. You will regain control at the Traverse routine.

8.06



- 1. This routine **DOES NOT** clear the **Area Sum** and **Traverse Length** accumulators.
- The Go To routine should only be used before the running of a routine that does not increment the Area Sum and Traverse Length accumulators.

### 8.07

#### Enter Backsight Point (EP)

**FUNCTION:** The **Enter Backsight Point** routine is used to change the backsight point.




Activate the Enter Backsight Point routine by pressing AttP, O, or by typing EP. The Data Entry window prompts:

😴 Ent	er Bacl	csight Point	×
		Enter a Point Number	
ST	GT	Point #	
EB	EP		
IN	IC		
TR	TA		
TS	IS		
PO	SS		
TC	ED		
PA	BP		
BB	DD		
BD	DB	Accept (PgDn)	



Type the number of the point you want to become your new backsight point and press *Ener* or click the **Accept (PgDn)** button.




8.08

#### Enter Backsight Bearing (EB)

**FUNCTION:** The Enter <u>Backsight Bearing</u> routine is used to change the value of the reference bearing.

Activate the Enter Backsight Bearing routine by pressing AltP, B, or by typing EB at any data entry prompt. The Data Entry window prompts:

层 Enter Bac	ksight Bearing
E	ter the bearing to the Backsight Point
ST GT	BS Bng.
EB EP	
IN IC	
TR TA	
TS IS	
PO SS	
TC ED	
PA BP	
BB DD	
BD DB	Accept (PgDn)



PP at any data entry prompt. The Point Plot/List Coordinates point selection window appears.


From this window you can add a list of coordinates to the Text Output window or plot points in the Drawing window. You may list and/or plot all of the points, a single point, or anything in between. You can also use the Text and Drawing check boxes to output to the Text Output window, the Drawing window, or both.

BS Bng.

When the **Point Plot / List Coordinates** window first opens, the cursor is located in a text entry box in the upper right portion of the window, above the **A** button.

Point Plot	/ List Coordinate	s		_ 🗆 2
Point	Northing	Easting	Elevation Descriptio	Enter points:
1	10051.23475	19960.00000	101.700 SE Cor La	
2	10126.23475	19960.00000	101.700 NE Cor Lc	
3	10126.23475	19824.50000	101.700 NW Corne	All
4	10051.23475	19824.50000	102.400	
5	9936.23475	19824.50000	100.600	A <u>c</u> cept
6	9811.75475	19824.50000	99.800 SW Cor B	
7	9811.75475	19914.50000	100.400	<u>S</u> elect all
8	9811.75475	20095.50000	101.400	
9	9811.75475	20190.05000	103.500 SE Cor BI	<u>U</u> n-Sel. all
10	9936.24225	20188.62862	102.800	
11	10051.23475	20187.31565	102.200	Ad <u>v</u> anced
12	10126.23475	20186.45931	101.300 NE Cor BI	Text
13	10126.23475	20040.00000	100.800 NW Cor L	
14	10051.23475	20040.00000	101.700 SW Cor L	☑ D <u>r</u> awing
15	9979.18637	20061.57754	102.000	🔽 Trim Symbol
16	9942.03288	20029.40770	101.600	
17	9940.81836	19973.12001	99.800	<u>D</u> one
18	9977.80298	19938.90751	102.000	
				<u>H</u> elp
•				

To select a sequential and/or comma delimited list of points	Type in your list here and click on the button. Your list can include individual points and point ranges. For example, the entry: 1-10,15,18,31-50 will list points 1 through 10, point 15, point 18, and points 31 through 50.
To select all of the points	Click on the <u>All</u> button and then on the button, or press A <u>-Enter</u> .
To select a random group of points	Click on each point you want to include. To clear an individual point selection, click on the selected point.
To clear all point selections	Click on the Un-Sel. all button.
Advanced Point Selection	You can also list and/or plot special point sets. Click on the Advanced button on the Point Plot / List Coordinates window to open the Advanced Point Selection window.



disable the listing by clicking on the check box to remove the  $\checkmark$  or **X** before you place any points using this routine.

D <u>r</u> awing	The <b>D</b> <u>r</u> <b>awing</b> check box lets you choose whether or not you want to plot the coordinate points in the <b>D</b> <u>r</u> <b>awing</b> window. By default, this box will be checked when you have activated the <b>Point Plot / List</b> <b>Coordinates</b> window by using the <b>Plot Points</b> routine. If you do not wish to plot the coordinate points in the <b>D</b> <u>r</u> <b>awing</b> window, disable the listing by clicking on the check box to remove the $\checkmark$ or $X$ <i>before you place any points using this routine.</i>
<u>T</u> rim Symbol	<b>Trim Symbol</b> lets you choose whether or not you want to trim under symbols when they are placed using the <b>Point Plot</b> routine. When the <b>Point Plot / List Coordinates</b> window first opens, the <b>Trim Symbol</b> check box is enabled. If you do not wish to trim under the symbols, disable the trimming by clicking on the check box to remove the $\checkmark$ or $\mathbf{X}$ before you place any points using this routine.
Done	To plot and/or list the points you have selected, click on the <b>Done</b> button.

### 8.10

### List Coordinates (LC)

**FUNCTION:** The List Coordinates routine is used to display a listing of points which have been assigned coordinates.

Activate the List Coordinates routine by pressing Att P, L, or by typing LC at any data entry prompt.

The <u>List Coordinates</u> routine functions exactly like the <u>Point Plot</u> routine. Please refer to the instructions for the <u>Point Plot</u> routine described in <u>Section 8.09</u>.

#### Blank Point Scan (BP)

**FUNCTION:** The **Blank Point Scan** routine reads through the data file and reports all unused point numbers.

Activate the Blank Point Scan routine by pressing Alt P, K, or by typing BP at any data entry prompt.

"Sight" Survey will report all unused point numbers found. Reported points are presented in a linear fashion, not in a column. Where applicable, points will be reported in ranges consisting of a beginning point, a dash to indicate a range of points, and an ending point. Ranges presented in this manner are all inclusive, that is the beginning and ending points specified have also been found to be blank. A typical report may look something like: **12**, **15**, **57-155**, **175-5000** 

#### 8.12

#### <u>Renumber Points</u> (RP)

**FUNCTION:** The **Renumber Points** routine is used to relocate a block of points from their current numerical basis to some other numerical basis. The original point numbers are cleared.

Activate the <u>Renumber Points</u> routine by pressing <u>Alt</u> P, R, or by typing **RP** at any data entry prompt.


After you are given an option to save your work, "Sight" Survey automatically performs a Blank Point Scan (listing the results in the Text Output window). This listing is provided as a guide for use in determining the target range for point relocation.

The Data Entry window displays the Renumber Points prompts.

#### 8.11

Enter the first point to renumber
ST GT From Point
EB EP To Point
IN IC New start at
TR TA
TSIS
PO SS
TC ED
PA BP
BB DD
BD DB Accept (PgDn)

From Point	Enter the number marking the start of the point range you wish to renumber and press and press <i>Finer</i> .	
To Point	Enter the number marking the end of the point range you wish to renumber and press <u>rener</u> , or just press <u>rener</u> if you want to renumber only a single point.	
New Start At	Enter the new starting point number and press <b>Enter</b> . It is this value that marks the beginning of the <b>targeted range</b> . The targeted range extends from this point to a point number equal to the value of this point plus the difference between the starting and ending points previously entered.	
Do you want Point Overwrite protection?	If your <b>Point Overwrite</b> protection is disabled, you are given an opportunity to reinstate it. Overwrite protection guards against the accidental erasure of point data as "Sight" Survey renumbers points and it is strongly suggested. Answer by pressing $\heartsuit$ or $\mathbb{N}$ . At this time, "Sight" Survey will begin renumbering the given point(s).	



If you are using overwrite protection, you may from time to time see a request for instructions on how to handle a point overwrite situation. The point numbers are given in the prompt, along with each point's coordinates and name, if available. You may also exit the renumbering process at this prompt, but be aware that any points accessed before this message have been renumbered.

At the conclusion of the renumber routine, you are returned to the initial Start at prompt. If you do not want to continue this routine, type the next routine code, or select the routine from the pull-down

This routine may overwrite points that lie within the target range. Use this routine with caution!

#### Copy Block of Points (CB)

menus.

¥

FUNCTION: The Copy Block of Points routine is used to copy a block of points from their current numerical basis to some other numerical basis, while not erasing original points.

Activate the Copy Block of Points routine by pressing AttP, Y, or by typing **CB** at any data entry prompt. After you are given an option to save your work, "Sight" Survey automatically performs a Blank Point Scan (listing the results in the Text Output window). This listing is provided as a guide for use in determining the target range for point reproduction.

From Point



The **Copy Block of Points** routine works identically to the **<u>Renumber Points</u>** routine except that the original points are not erased. Please refer to the <u>**Renumber Points**</u> instructions in **Section 8.12**.

#### 8.14

#### Clear Coordinates (CC)

**FUNCTION:** The **Clear Coordinates** routine is used to erase all coordinate point data from a point or range of points.

Activate the Clear Coordinates routine by pressing AHP, A, or by typing CC at any data entry prompt.

After you are given an option to save your work, "Sight" Survey's **Data Entry** window displays the **Clear Coordinates** prompt.

🚽 Clea	🖁 Clear Coordinates 📃 🗆 🗙				
Ent	Enter a single point number, a range of points, a point string, or <a> to clear ALL points</a>				
ST	GT	Points			
EB	EP				
IN	IC				
TR	TA				
TS	IS				
PO	SS				
TC	ED				
PA	BP				
BB	DD				
BD	DB	Accept (PgDn)			

**Points** 

Enter any of the following:

- 1. A single point number, such as 5 Enter;
- 2. A comma delimited string of points, such as 3, 5, 7 Enter;
- 3. A range of points separated by a dash, such as 3-17 -Ener;
- 4. A combination of methods 2 & 3, such as 1, 3-7, 9 -Enter;

5. Press Area to clear ALL of your data points.

The coordinates and point names will be cleared from each point in the specified range including the starting and ending points.

The clearing routine is bi-directional. You may clear from a lower point number to a higher point number or vice versa.

#### 8.15

#### Clear Point Names (CN)

**FUNCTION:** The <u>Clear Point Names</u> routine is used to erase point names from a point or range of points.

Activate the <u>Clear Point Names</u> routine by pressing <u>Alt</u>, <u>C</u>, or by typing <u>CN</u> at any data entry prompt.

After you are given an option to save your work, "Sight" Survey's **Data Entry** window displays the <u>Clear Point Names</u> prompt.

🚽 Clea	Clear Point Names			
En	Enter a single point number, a range of points, a point string, or <a> to clear ALL names</a>			
ST	GT	Points		
EB	EP			
IN	IC			
TR	TA			
TS	IS			
PO	SS			
TC	ED			
PA	BP			
BB	DD			
BD	DB		Accept (PgDn)	

**Points** 

Enter any of the following:

- 2. A comma delimited string of points, such as 3, 5, 7 [1];

Section 8

- 3. A range of points separated by a dash, such as 3-17 etail;
- 4. A combination of methods 2 & 3, such as 1, 3-7, 9 -Emer;
- 5. Press Altered to clear ALL of your data points.

The point names will be cleared from each point in the specified range including the starting and ending points.

The clearing routine is bi-directional. You may clear from a lower point number to a higher point number or vice versa.

#### Clear Point Stations (CS)

**FUNCTION:** The **Clear Point Stations** routine is used to erase point stations from a point or range of points.

Activate the Clear Point Stations routine by pressing AttP, N, or by typing CS at any data entry prompt.

After you are given an option to save your work, "Sight" Survey's **Data Entry** window displays the **Clear Point Stations** prompt.

🚽 Clea	Clear Point Stations				
Enter a single point number, a range of points, a point string, or <a> to clear ALL stations</a>					
ST	GT	Points			
EB	EP				
IN	IC				
TR	TA				
TS	IS				
PO	SS				
TC	ED				
PA	BP				
BB	DD				
BD	DB	Accept (PgDn)			

8.16

**Points** 

Enter any of the following:

- 1. A single point number, such as 5 -Enter;
- 2. A comma delimited string of points, such as 3, 5, 7 -Enter;
- 3. A range of points separated by a dash, such as 3-17 Enter;
- 4. A combination of methods 2 & 3, such as 1, 3-7, 9 -Enter;
- 5. Press Area to clear ALL of your data points.

The stations will be cleared from each point in the specified range including the starting and ending points.

The clearing routine is bi-directional. You may clear from a lower point number to a higher point number or vice versa.



#### 8.17

### Define Figures (DF) F1

**FUNCTION:** The **Defined Figures** routine is used to group points to function as a single, named entity.

Activate the **Defined Figures** routine by any of the following methods:

- Type DF
- Press F11
- Press Alt P, D
- Click the Define Figures icon ( 🖭 ) on the Main toolbar.
- Click Defined Figures (DF) on the Config → COGO Configuration Menu.

Selecting the **Defined Figures** routine will open the **Defined Figures** edit window. Using this window, you can add, edit, delete, and print groups of points known as defined figures. A **defined figure** is a list of random and/or sequential point numbers which you access as a single entity, thus saving you from having to enter the particular point string each time you want to access it.

🗑 Defined Figures				
Figure Name	Point String	Comment/Description		
LOT 1	1,2,3,4,1AR			
LOT 2	3,4,5,6*10,11,3AR			
Add Delete Print Use Fig. Cancel Close Help				

The **Defined Figures** edit window will accommodate an unlimited number of figure entries, turning into a scrolling menu as needed. The figures are displayed in alphabetical order by **Figure Name**. Figures that are added to the end of the list are sorted into their correct alphabetical order the next time the routine is executed.



Unlike most other **Configuration** items, **Defined Figures** must be set up for each job in which you want to use them.

To **add** an entry, click the Add button, or press Alt D. The Figure Name field in the first available row will be highlighted, awaiting your entry. A figure name can be any combination of letters, numbers and spaces, up to 65 characters in length. Type in a name for your figure and press Tabua.

The **Point String** field becomes highlighted, awaiting your entry. Point strings can be any combination of letters, numbers and spaces, up to 125 characters in length. Type in the point string (no point descriptions are allowed) according to the rules and examples found below and press **Tab**.

A point string can include individual points and point ranges. Enter a point string by typing the point numbers separated by a comma, or a dash to indicate a range. For example, to define a

#### **Adding Figures**

figure from point 1 to 2 to 7 to 9 to 10 to 11 to 12 to 13 and back to 1, enter the string: 1, 2, 7, 9-13, 1

Curves may also be included in a point string by the addition of a center point identifier character immediately preceding the number of the curve's center (or radius) point. Use the characters * or < to mark the center point of an *acute* curve (delta less than 180° or 200 grads). Use the character > to mark the center point of an *obtuse* curve (delta angle greater than or equal to 180° or 200 grads). For example, to inverse from point 1 to 2 to 7 (a PC) and then around an obtuse curve whose center point is 8 to 9 (the PT) to 10 to 11 and back to 1, enter the string: 1,2,7>8,9-11,1

Multiple consecutive curves, having the same center point, may be addressed individually, or in a range. For example, to inverse from point 1 through 7 (a PC) and then around four acute curves whose curve points are 10, 15, 16 and 17, and then on a line back to 1, enter the string in any one of the four following ways:

```
1-7*8-10*8,15*8,16*8,17,1 or
1-7*8,10*8,15*8-17,1 or
1-7<8-10<8,15<8,16<8,17,1 or
1-7<8,10<8,15<8-17,1
```

٩

Point ranges are not allowed when working with **alphanumeric** point numbers. Each point number must be entered individually, separated by commas. For example:

NECorL1, SECorL1, NWCorL2, NWCorL1

Defined figures can also call *other* defined figures, overcoming any potential limitation of the 125 character point string length. For example, suppose the figure *BLOCK 1* contains the points 1, 7, 9, 5*8, 6 and figure *BLOCK 2* contains additional points that you would like to append to *BLOCK 1*. Simply define *BLOCK 1* as: 1,7,9,5*8,6,F:BLOCK 2

When figure *BLOCK 1* has been completed, figure *BLOCK 2* will be run automatically. Keep in mind though, that because figures can call other figures, it is possible to lock your computer into an endless loop. For example, *BLOCK 1* may call *BLOCK 2* which may call *BLOCK 3* which may call *BLOCK 1*, and so on. Use care when calling other figures as to avoid lock-ups.

Another time saving feature allows you to place the code AR for ARea after a defined figure point string, which sends the program to the Area routine to report the area enclosed by the figure. A comma should be placed *after* the last point number in the point string, and *before* the AR code. For example: 1-4, 1, AR

If you wish, you may use the **Comment** field to store additional information about the figure. This field can contain up to 255 characters and is provided strictly for your own information since it is not used anywhere else in "Sight" Survey. To add another figure, press AltD or Tabharener. To exit the routine, click **Close** or press AltD.

#### **RULES FOR DEFINED POINT STRINGS**

- 1. Separate single points by a comma, for example: 1,3,5,7
- 2. Separate a consecutive range of *numeric* point numbers by a dash, for example: 1-7
- Enter all *alphanumeric* point numbers individually and separate them by a comma, for example: PT1,PT3,PC8,NCorL1
- 4. Preface any radius points with an asterisk (*) or less than size (<) for acute curves or a greater than sign (>) for obtuse curves, and use only the *, <, or > to separate the PC and the radius point of a curve, for example 5*10,8 sets the acute curve from 5 through center point 10 to end point 8; and 5>10,8 sets the obtuse curve from 5 through center point 10 to end point 8. Don't place a comma after the 5.
- Curve points may be entered in ranges, if desired, for example: 1-7*8,10*8,15*8-17,1 is the same as 1-7*8-10*8,15*8,16*8,17,1.
- 6. DO NOT start your point string with a radius point (* or >) designation.
- 7. Preface any referenced figures with an **F**: and do not add any points after the referenced figure.

	Use care when entering your point string since the program will not attempt to screen your entry for illegal characters or unassigned points.	
Deleting Figures	To select a figure to <b>delete</b> , move your mouse to the left of the <b>Figure Name</b> until the cursor becomes a check mark ( $\checkmark$ ). Click your mouse cursor ( $\checkmark$ ) on the figure(s) you want to delete and then click on the <b>Delete</b> button or press <b>Att</b> . If you delete a figure by accident, you can click <b>Cancel</b> to cancel all deletions and editing.	
Printing Figures	To <b>print a listing</b> of all the defined figures in the current job, click your mouse on the <b>Print</b> button or press <b>AITP</b> . When the <b>Print</b> dialog box appears, click <b>OK</b> to send the figure list to your printer and the <b>Text Output</b> window, or click <b>Cancel</b> to send the list only to the <b>Text Output</b> window.	Section 8
Editing Figures	To edit the Figure Name, Point String, or Comment fields for any figure, click your mouse on the field you want to edit, pause a moment, then click again. If the field is longer than the display allows, the field will open and scroll downwards, allowing you to see the entire field. Make your editing changes and press <u>Finer</u> . Click <u>Close</u> or press <u>Alt</u> to exit the routine.	
Using Figures in the COGO Routines	If the <b>Defined Figures</b> edit window is <i>not</i> open, press <b>F1</b> or type <b>DF</b> or <b>F</b> : to open it. To move quickly through the edit window, press and hold <b>Gtr</b> while typing the first letter of the desired <b>Figure Name</b> . The cursor will move to the first figure which begins with that letter. Use your mouse or the <b>1</b> or <b>1</b> keys to make your selection and then click the <b>Use Fig.</b> button or press <b>Att</b> . The <b>Point String</b> will automatically be placed into the current text box in the COGO window. (The <i>current text box</i> is the field where the <b>Defined Figures</b> routine was executed.) Modify the point string if desired, and press e to use the selected point string.	
	Within the Point Plot (PP - page 239) and List Coordinates (LC - page 242) routines you can only access Defined Figures by	

- page 242) routines, you can only access Defined Figures by pressing F11.

8.18

Canceling Changes	To <b>cancel</b> all changes or deletions that you have made, click on the <b>Cancel</b> button or press ARC. This will cancel <i>everything</i> that you have done since the <b>Defined Figures</b> edit window was last opened. If you made some changes that you wanted to keep, you will need to rerun the routine and make those changes again.
Exit & Save Changes	To <b>exit</b> this routine and <b>save</b> any changes that you have made, click on the <b>Close</b> button or press <b>AitS</b> . If you closed the <b>Defined Figures</b> edit window by accident and had made changes that you did not wish to save, you can reload the job file (without saving) to get the figures back from the original file on disk. However, once you have saved the current COGO job file, the figure changes have also been saved.

#### Edit Default Descriptions (AP)

**FUNCTION:** The **Edit Default Descriptions** routine is used to enter and edit a list of alternate point name descriptions.

Activate the Edit Default Descriptions routine by typing AP.

	Edit Default Descriptions
Alt - 1	
Alt - 2	Concrete Monument
Alt - 3	Nail
Alt - 4	Wood Stake
Alt - 5	Spike

Enter point descriptions into any of the alternate description fields. You can fill all the alternate fields while the dialog box is open by using your mouse or to move between fields. Press - Enter to quit and accept the changes, or press Esc to quit and discard the changes. All descriptions entered into the alternate description fields are retained between "Sight" Survey sessions.



Inverse (IN) Field Data Inverse (FI) Radial Inverse (RI) Deflection Inverse (DI) Radial Stake Out (RS)

<u>Side Shots (SS)</u> <u>Offset (OS)</u> <u>Iraverse (TR)</u> Traverse with Offsets (TO) Traverse <u>C</u>lose (TC) Enter Diagonal (ED)

Inverse with Stations (IS) Traverse with Stations (TS) Traverse Right of  $\underline{W}$ ay (RW)

Best Fit Line (BF)

#### **From Point** This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the From Point is equivalent to running the Go To routine. To Point Enter an individual foresight point number. If the foresight point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request. What Happens Next "Sight" Survey will respond to an accepted foresight point by printing the computed bearing and the horizontal and vertical distances from the currently occupied point to the foresight point, the foresight point number, ID, and its Northing, Easting and elevation. The foresight point becomes the currently occupied point and the reference bearing becomes the bearing just inversed.

at any data input prompt.

Section 9

routines.

9.01

The <u>LINES Menu</u>

Inverse (IN)

The **Lines** menu contains functions that define one point's position, in relation to another point. Routines such as traverse and inverse

are located here, as are several routines that deal with stations and

offsets. The traverse closure and traverse adjustments routines are

also accessed menu, as are the radial stakeout and radial inverse

**FUNCTION:** The **Inverse** routine is used to compute and

Access the **Inverse** routine by pressing Att, n, or by typing IN

report the bearing, horizontal distance and difference in

elevation between any two points of known coordinates.

To inverse from your point through a series of consecutive points, enter your **To Point** as the negative value of the last point number in the series. For example, you are at point 3 and you want to inverse to 4, 5, 6, 7, 8, 9, and 10. In the **To Point** text box, type -10 error. To inverse through all points in a consecutive manner, type **A** error.

To inverse through all points in a consecutive manner, type A Lefte

#### Enter & Assign points 1-4, then Inverse from point 1 to 2 to 3 to 4.



Text O	utput				
P	oint Direction	Distance	Northing	Easting	Elevation
Arial	💌 [13 💌 🔳		3 <u>7</u> <u>U</u> ABC :		i ¶ Te
. 10	<u>   ¹    ²</u>		<u>3 </u>		<u> 6</u>
Assig	ned points				
-	1		10000.00000	20000.00000	0.000
	2		10091.74344	20118.67241	0.000
	3		9990.03708	20146.70929	0.000
	4		10026.00941	20354.36659	0.000
Start					
	1		10000.00000	20000.00000	0.000
IN	N 52°17'35.0'' E	150.000			
	2		10091.74344	20118.67241	0.000
IN	S 15°24'42.0'' E	105.500			
I	3	040 750	9990.03708	20146.70929	0.000
IN	N 80°10'20.0'' E	210.750	10000 000 11	00054 00050	0.000
	4		10026.00941	20354.36659	0.000
			Page 1/1	Line 2	Col 1

9.02

#### Field Data Inverse (FI)

**FUNCTION:** The **Field Data Inverse** routine is used to compute and report the field angle (as turned to the right from the previous backsight), horizontal distance and the difference in elevation between any two points of known coordinates.

Access the <u>Field Data Inverse</u> routine by pressing <u>Att</u>, F, or by typing **FI** at any data input prompt.

#### Example

From PointThis is the currently occupied point. If you have an occupied<br/>point, this box will automatically be filled for you. Changing the<br/>From Point is equivalent to running the Go To routine.

**To Point** 


Example

What Happens Next

Enter an individual foresight point number. If the foresight point has not been assigned coordinates, the program will prompt for them. Respond as you would to a standard coordinate request.

"Sight" Survey will respond to an accepted foresight point by printing the computed angle right and the horizontal and vertical distances from the currently occupied point to the foresight point, the foresight point number, ID, and its Northing, Easting and elevation. The foresight point becomes the currently occupied point and the reference bearing becomes the bearing just inversed.

**Enter & Assign** points 1-4, then perform a **Field Data Inverse** from point 1 to 2 to 3 to 4.



🟅 Text Ou	utput					- D ×
P	oint D	irection	Distance	Northing	Easting	Elevation
Arial	1:			B Z U ABC		
. [0	<u></u>			<u>3</u>	4 <u></u>	<u>1   1⁶ 1 </u>
Assiar	ned points					<b>`</b> _
-	1			10000.00000	20000.000	0.000 🗐
	2			10091.74344	20118.672	41 0.000
	3			9990.03708	20146.709	29 0.000
	4			10026.00941	20354.366	59 0.000
Start						
	1			10000.00000	20000.000	000.00
FI	152°07'′	15.0" AR	150.000			
	2			10091.74344	20118.672	41 0.000
FI	292°17'4	13.0'' AR	105.500			
	3			9990.03708	20146.709	29 0.000
FI	95°35'0	02.0'' AR	210.750			
	4			10026.00941	20354.366	59 0.000
				Page 1/1	Line 1	Col 1

9.03	<u>R</u> adial Inverse (RI)
	<b>FUNCTION:</b> The <b><u>R</u>adial Inverse</b> routine is functionally similar to the <u>Inverse</u> routine except the <i>Currently Occupied Point</i> is held constant throughout the routine. This routine computes and reports the bearing, horizontal distance and the difference in elevation between the currently occupied point and a series or range of foresight points of known coordinates.
	Access the <b><u>Radial Inverse</u></b> routine by pressing <u>At</u> , <u>R</u> , or by typing <b>RI</b> at any data input prompt.
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
To Point	Enter an individual foresight point number. If the foresight point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request.
What Happens Next	"Sight" Survey will respond to an accepted foresight point by printing the computed bearing and the horizontal and vertical distances from the currently occupied point to the foresight point, the foresight point number, ID, and its Northing, Easting and elevation. The currently occupied point and the reference bearing are left unchanged. The backsight bearing is retained for use when or if you resume a routine requiring one.
Example	<b>Enter &amp; Assign</b> points 1-4, then perform <b>Radial Inverse</b> from base point 1 to points 2, 3, and 4.
	2 N 52° 17350'E N 85° 48'07.9''E S 86° 06'54.2''E 147.05' 3


📮 T ex	at Output				
	Point Direction	Distance	Northing	Easting	Elevation
Arial	▼ 13 ▼		3 <u>7</u> <u>U</u> ABC =		†¶ <b>T</b> a
<u>.  0</u>	·····	2	<u>} 4.</u>	···· ¹⁵ ····	<u> </u>
Ass	signed points				· ` `
	<b>1</b>		10000.00000	20000.00000	0.000
	2		10091.74344	20118.67241	0.000
	3		9990.03708	20146.70929	0.000
	4		10026.00941	20354.36659	0.000
Sta	rt				
	1		10000.00000	20000.00000	0.000
RI	N 52°17'35.0'' E	150.000		ase Point 1	
	2		10091.74344		0.000
RI	S 86°06'54.2'' E	147.047		ase Point 1	
	3		9990.03708	20146.70929	0.000
RI	N 85°48'07.9'' E	355.320		ase Point 1	
	4		10026.00941	20354.36659	0.000
			Page 1/1	Line 2	Col 1

9.04	<u>D</u> eflection Inverse (DI)
	<b>FUNCTION:</b> The <u>Deflection Inverse</u> routine is used to compute and report the deflection angle (from the forward extension of the previous bearing), horizontal distance, and the difference in elevation between any two points of known coordinates.
	Access the <b>Deflection Inverse</b> routine by pressing AttL, D, or by typing <b>DI</b> at any data input prompt. This routine is performed in an identical manner to the <b>Inverse</b> routine described on page 255.
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
To Point	Enter an individual foresight point number. If the foresight point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request.
What Happens Next	"Sight" Survey will respond to an accepted foresight point by printing the computed deflection angle and the horizontal and vertical distances from the currently occupied point to the foresight

# Section 9

point, the foresight point number, ID, and its Northing, Easting and elevation. The currently occupied point and the reference bearing are left unchanged. The backsight bearing is retained for use when or if you resume a routine requiring one.

**Enter & Assign** points 1-4, then perform a **Deflection Inverse** from point 1 to 2 to 3 to 4.




📮 Text Ou					- <b>-</b> ×
Po	pint Direction	Distance	Northing	Easting	Elevation
Arial	13 💌 🧮		<u>7</u> <u>U</u> ABG		† ¶ <b>E</b>
- <u>l</u>	11		3		6
Assian	ned points		T.	T.	
/ looigi	1		10000.00000	20000.00000	0.000
	2		10091.74344	20118.67241	0.000
	3		9990.03708	20146.70929	0.000
	4		10026.00941	20354.36659	0.000
Start					
	1		10000.00000	20000.00000	0.000
DI	27°52'45.0'' DL	150.000			
	2		10091.74344	20118.67241	0.000
DI	112°17'43.0'' DR	105.500			
	3		9990.03708	20146.70929	0.000
DI	84°24'58.0'' DL	210.750			
	4		10026.00941	20354.36659	0.000
			Page 1/1	Line 4	Col 1

#### Example

9.05	R <u>a</u> dial Stake Out (RS)
	<b>FUNCTION:</b> The <b>Radial Stake Out</b> routine is used to compute and report an angle (as turned to the right, from a known backsight point), the horizontal distance and difference in elevation between the currently occupied point and a series or range of foresight points of known coordinates. The currently occupied point and backsight bearing are held constant throughout this routine.
	Access the <b>Radial Stake Out</b> routine by pressing Attl, A, or by typing <b>RS</b> at any data input prompt.
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine. Enter the instrument point location.
B.S. Point	Enter the number of the backsight point.
Max FS Dist.	Enter the maximum foresight distance desired from this set up. If you want all of the points in the data file to be included, press without entering any distance value.
To Points	Enter the individual foresight point number(s), a point number string, or the letter $\mathbf{A}$ (for all points).
What Happens Next	The program will respond to an accepted foresight point by printing the instrument and backsight points and their respective coordinates then printing the angle right (as turned from the backsight) and the horizontal and vertical distances from the currently occupied point to the foresight point, the foresight point number, ID, Northing, Easting and elevation.
Example	<b>Enter &amp; Assign</b> points 1-4, then perform a <b>Radial Stake Out</b> from base point 1 to points 3 and 4, backsighting point 2.

# Section 9



🍣 Text Output					
Point	Direction	Distance	Northing	Easting	Elevation
Arial	13 💌 🧮				- T Te
<u>. P 1</u>			<u>3 </u>		
<b>)</b> TT			T.	T.	T. ◀
Assigned point	s				
1			10000.00000	20000.00000	0.000
2			10091.74344	20118.67241	0.000
3			9990.03708	20146.70929	0.000
4			10026.00941	20354.36659	0.000
Start					
1			10000.00000	20000.00000	0.000
Radial Stake ou	ıt				
	 rument Loca	ation	10000.00000	20000.00000	0.000
	ksiaht Point		10091.74344	20118.67241	0.000
	7'35.0'' E	150.000	10031.74044	20110.07241	0.000
	35.0 E	150.000			
Sight Points		4 47 0 47			
	5'30.8'' AR	147.047			
3			9990.03708	20146.70929	0.000
RS 33°30	)'32.9'' AR	355.320			
4			10026.00941	20354.36659	0.000
			Page 1/1	Line 2	Col 1

9.06

#### Side Shots (SS)

**FUNCTION:** The <u>Side Shots</u> routine is similar to a <u>Traverse</u> routine (see page 265) in that it is used to compute the coordinates for a point(s) when given a bearing (or angle from a backsight) and a distance from the currently occupied point. Both the currently occupied and the backsight bearing are held constant throughout the computation of all side shot points relative to a particular occupied point.

Access the <u>Side Shots</u> routine by pressing <u>Att</u>, <u>S</u>, or by typing <u>SS</u> at any data input prompt.

From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
To Point	Enter the number of the foresight point to which you are shooting.
Bearing	Enter the bearing, angle, deflection or azimuth in your chosen format, recall a bearing between any two points in memory, or compute the correct data using the in line calculator.
Distance	Enter the distance, or recall a distance between two existing points.
What Happens Next	If the <b>Slope Angle</b> prompt is active you will also be prompted for the data that is necessary for slope reduction according to the method you have specified on the <b>Slope Entry Configuration Menu</b> .
	Following a correct distance entry, the program will print the bearing, horizontal and vertical distances from the currently occupied point to the side shot point, and also the point number, ID, Northing, Easting and elevation of the side shot point. The currently occupied point, and the reference bearing remain unchanged.
Example	<b>Enter &amp; Assign</b> points 2 and 3, <b>Inverse</b> from point 2 to point 3, then set a <b>Side Shot</b> to point 5 at 60°20'10"AR and 125 feet.
	2 0 5

N 52° 173504E N44 125.00 S 15°24'42.0"E 105.50' 4 N 80°10'20.0"E 210.75' 3

## Section 9

📮 Text Ou	itput								
Po	oint Direction	Distance	Northing	Easting	Elevation				
Arial	🔽 13 🔽 🧮		B Z U ABC =		t ¶ Ta				
<u>-101.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1</u>									
Assign	ned points								
	2		10091.74344	20118.67241	0.000				
	3		9990.03708	20146.70929	0.000				
Start									
	2		10091.74344	20118.67241	0.000				
IN	S 15°24'42.0'' E	105.500							
	3		9990.03708	20146.70929	0.000				
Raw:	60.2010ar	125							
SS	N 44°55'28.0'' E	125.000	From Ba	ase Point 3					
	5		10078.54191	20234.98100	0.000 🚽				
			Page 1/1	Line 4	Col 1				

9.07

#### Offset (OS)

**FUNCTION:** The **Offset** routine is similar to a **Side Shot** routine in that it is used to compute the coordinates for a point(s) while holding both the currently occupied point and the backsight bearing. Offsets are set perpendicular to the current bearing, with left (negative)/right (positive) directions relative to the foresight.

Access the Offset routine by pressing  $Alt \square$ , O, or by typing OS at any data input prompt.

<b>.</b> ,	×				
OffSet	Distance				
Point	6				
O.S. Dist.	-50				
Accept	Cancel				

Point

O.S. Dist.


Enter a number for the offset point.

Enter the distance from the offset point to the point of offset. If the offset is to the left of the line, relative to the direction of the foresight, enter the distance as a negative value.

What Happens Next

Following a correct offset entry. "Sight" Survey will print the bearing and distance to the offset point, the offset point number, description, and coordinates.

Enter & Assign points 3 and 4, Inverse from point 3 to point 4, then set an Offset left (point 6) at 50 feet.



🐱 Text Ou	david				
	pint Direction	Distance	Northing	Easting	Elevation
-		Distance			
Arial	I3 ▼ ■		B Z U ABE		÷¶ 🖪
			3		
+	ÎÎ		T.	T.	↑. ◀
Assigr	ned points				<u> </u>
Ĭ	3		9990.03708	20146.70929	0.000
	4		10026.00941	20354.36659	0.000
Start					
	3		9990.03708	20146.70929	0.000
IN	N 80°10'20.0'' E	210.750			
	4		10026.00941	20354.36659	0.000
os	N 9°49'40.0'' W	50.000	From Ba	ase Point 4	
	6		10075.27567	20345.83223	0.000
					-
			Page 1/1	Line 3	Col 1

9.08

#### Traverse (TR)

**FUNCTION:** The **Traverse** routine is used to compute the coordinates of a new point along a line of known bearing and distance from the currently occupied point.

Access the **Traverse** routine by pressing **A**lt **L**, **T**, or by typing **TR** at any data input prompt.

Example

Sectio **9** 

From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine. Enter the number of the point to which you are traversing.
Bearing	Enter the bearing, angle, deflection or azimuth, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.
Distance	Enter the distance, or recall a distance between two existing points.
What Happens Next	If the <b>Slope Angle</b> prompt is active you will also be prompted for the data that is necessary for slope reduction according to the method you have specified on the <b>Slope Entry Configuration Menu</b> .
	Following a correct distance entry, the program will print the bearing, horizontal and vertical distances from the currently occupied point to the new point number, and also the point number, point ID, and the Northing, Easting and elevation of the new point. The new point becomes the currently occupied point, and the reference bearing becomes the bearing just traversed.
Example	Enter & Assign points 1, then Traverse from point 1 to 2 to 3 to 4.
	N 52° 1735.0'E N 52° 1735.0'E 1 N 50° 10'20.0''E 1 N 80° 10'20.0''E 3 210.750'

📮 Text Output					
Point	Direction	Distance	Northing	Easting	Elevation
Arial	14 💌 🔳		ZU ABC :		
) î î			Т.	Т.	◀
Start					
1		1	0000.00000	20000.00000	0.000
Raw: 52.1	735ne	150			
TR N 52°1	7'35.0" E	150.000			
2		1	0091.74344	20118.67241	0.000
Raw: 15.24	442se	105.5			
TR S15°2	4'42.0" E	105.500			
3			9990.03708	20146.70929	0.000
Raw: 80.1	020ne	210.75			
TR N 80°1	0'20.0" E	210.750			
4		1	0026.00941	20354.36659	0.000 🖵
			Page 1/1	Line 241	Col 1

9.09	Tra <u>v</u> erse with Offsets (TO)
	<b>FUNCTION:</b> The <b>Traverse with Offsets</b> routine is used to compute the coordinates of a new point along a line of known bearing and distance from the currently occupied point, and then set perpendicular offset points at the foresight point.
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
To Point	Enter the number of the point to which you are traversing.
Bearing	Enter the bearing, angle, deflection or azimuth, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.
Distance	Enter the distance, or recall a distance between two existing points.
What Happens Next	If the <b>Slope Angle</b> prompt is active you will also be prompted for the data that is necessary for slope reduction according to the method you have specified on the <b>Slope Entry Configuration Menu</b> .

### Section 9

If an offset table has been defined "Sight" Survey will use the table values to set the offset points. If you are not using an offset table, you will be prompted with the offset dialog box.

Following a correct distance entry, the program will print the bearing, horizontal and vertical distances from the currently occupied point to the new point number, and also the point number, point ID, and the Northing, Easting and elevation of the new point. The new point becomes the currently occupied point, and the reference bearing becomes the bearing just traversed.

(

Offsets are not handled within the traverse balancing routines, therefore you should balance your traverse data before entering any offset information.

This routine functions similar to the **Offset** routine in **Section 9.07**, except you **Traverse** (not **Inverse**) to the foresight point.

9.10	Traverse <u>C</u> lose (TC)
	<b>FUNCTION:</b> The <b>Traverse Close</b> routine is used to determine the length and direction of the linear error and the amount of angular error in a traverse. This routine must be used prior to traverse adjustment routines.
Procedural Order for TRAVERSE CLOSURE	<ol> <li>Enter a starting point using the Start At routine (ST - page 235).</li> <li>Enter a backsight bearing using the Enter a Backsight Bearing routine (EB - page 238).</li> <li>Using the Traverse routine (TR - page 265), traverse the courses up to, but not including, the final leg.</li> <li>Specify Traverse Closure by typing pressing Att , C or by typing TC, and proceed with the data entry for the closing leg as discussed in the instructions that follow.</li> </ol>
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.

Example

I

The LINES Menu Page 269

Section 9

Close to	Enter the number of the point to which you are closing.
Bearing	Enter the bearing, angle, deflection or azimuth, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.
Distance	Enter the distance, or recall a distance between two existing points.
	If the <b>Slope Angle</b> prompt is active you will also be prompted for the data that is necessary for slope reduction according to the method you have specified on the <b>Configuration Menu</b> .
What Happens Next	Following a correct distance entry, the program will print the bearing, horizontal and vertical distances from the currently occupied point to a temporary point, and then inverse the bearing, distance and elevation from the temporary point to the closing point to obtain the <b>Closure Error</b> . The inversed bearing, distance and elevation of the error will be printed along with the <b>Precision Ratio</b> .
Example	The <b>Traverse Closure and Adjustment</b> routine is illustrated in the <b>Quick Start</b> manual, <b>Section 3 - Examples</b> .

#### Traverse Adjustment - Balance Angles

**FUNCTION:** The **Traverse Adjustment - Balance Angles** routine is used to spread the angular error of a traverse across the stations of the traverse.

Example

9.11

The **Balance Angles** routine is illustrated in the **Quick Start** manual, **Section 3 - Examples**.

9.12	Traverse Adjustment - Compass Rule
	<b>FUNCTION:</b> The <b>Traverse Adjustment - Compass Rule</b> routine is a procedure used to adjust a traverse network.
	The <b>Compass</b> (Bowditch) <b>Rule Adjustment</b> is a traverse adjustment procedure that yields good results when distances and angles are measured with equal precision. It assumes no correlation and that all measurements are of equal weight.
Example	The <b>Compass Rule Adjustment</b> routine is illustrated in the <b>Quick</b> <b>Start</b> manual, <b>Section 3 - Examples</b> .
0.40	
9.13	Traverse Adjustment - Crandall Rule
	<b>FUNCTION:</b> The Traverse Adjustment - Crandall Rule routine is a procedure used to adjust a traverse network.
	The <b>Crandall Rule Adjustment</b> is a traverse adjustment procedure best used when adjusting stadia traverses, or other traverses where the distances most likely contain larger random errors than the angles. The angular error is first distributed equally to all angles and the distances then receive all the remaining corrections.
Example	The Crandall Rule <b>Adjustment</b> routine is illustrated in the <b>Quick</b> <b>Start</b> manual, <b>Section 3 - Examples</b> .
9.14	Traverse Adjustment - Transit Rule

**FUNCTION:** The **Traverse Adjustment - Transit Rule** routine is a procedure used to adjust a traverse network.

Example

The **Transit Rule Adjustment** routine is illustrated in the **Quick Start** manual, **Section 3 - Examples**.

#### **Traverse Adjustment - Least Squares**

**FUNCTION:** The **Traverse Adjustment - Least Squares** routine is a procedure used to adjust a traverse network.

**Background Information**Least Squares Adjustment is an iterative procedure whereby the previously calculated coordinates are used for the next calculation, and those new coordinates are then used for the next calculation, etc. In "Sight" Survey, the calculations continue in this manner until the largest difference between successive coordinate calculations is "negligibly small" (less than .000005 units), or until a total of 5 iterations have been performed.

A good survey adjustment takes a series of imperfect measurements and derives more reliable estimates of the true values of the quantities measured in the field. The **Crandall Rule Adjustment** (see page 270) is best used when adjusting stadia traverses, or other traverses where the distances most likely contain larger random errors than the angles. The angular error is first distributed equally to all angles and the distances then receive all the remaining corrections. The **Compass Rule** (or Bowditch) **Adjustment** (see page 270) gives good results when distances and angles are measured with equal precision. It assumes no correlation and that all measurements are of equal weight. Least squares adjustment, on the other hand, imposes no restrictions and adjusts angles and distances simultaneously.

Least squares is not an exact solution. It gives the solution that is the most probable with the given data. This means that for any individual point or station in a traverse network there may be a better solution than the one arrived at, however, for the whole overall network, the solution found is the best.

The computed least squares estimate is always the simple mean of the observations, as long as they are uncorrelated and of equal precision (weight). When the measurements are uncorrelated but unequal in precision, the weighted mean is used.

To properly perform a least squares adjustment, diagonals or redundancies are necessary. The more redundancies you have, the better the chances are that the solution obtained is the best. In a

Diagonals

traverse with no redundancies, performing a least squares adjustment will give comparable results to the Crandall Rule Adjustment. With enough redundancies, a leg that has a major blunder will not have as much effect on the entire traverse. For example, if you have five measurements to a particular point, and four of them correspond but one is way off, the erroneous measurement will not carry much weight because of the other four, good measurements.

The Least Squares Adjustment routine is illustrated in the Quick Start manual, Section 3 - Examples.

#### 9.16

Example

#### Enter Diagonal (ED)

**FUNCTION:** The **Enter Diagonal** routine is used to enter diagonal shots into your traverse network for least squares adjustment.

Diagonals can be entered within a traverse network using the Lines Enter Diagonal (ED) routine. They can also be added directly into the Traverse Adjustment window using the Add Leg option, although it is much more cumbersome to use this method. We strongly recommend that you run the Least Squares Adjustment (see page 271) example to familiarize yourself with the data entry procedure for diagonals within a traverse.



When entering diagonals into the **Traverse Adjustment** window (i.e. not using the **Enter Diagonal** routine), you must be sure that the leg you add has the correct Backsight Point, At (occupied) Point, and Foresight Point.

The Enter Diagonal routine is similar to the Side Shot (see page 262) routine in that it computes coordinates for a point when given a bearing (or angle from a backsight) and a distance from the currently occupied point, while both the currently occupied point and the backsight bearing are held constant throughout the computations. However, the Enter Diagonal routine is different in the fact that it can accumulate several bearing and distance

references to the same point number, without overwriting the actual coordinates for that point which normally are calculated using the **Traverse** (see page 265) routine. These multiple bearing and distance values are then manipulated with the **Least Squares** Adjustment routine to arrive at the best possible coordinates for each point in the network. To enter a diagonal into your traverse network, select the Enter **Diagonal** routine by pressing AttL, G, or type ED. From Point The From Point is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. If you wish to change the From Point, press 1 and enter the new occupied point number. Changing the From Point is equivalent to running the Go To routine. Be aware that if you change the occupied point, the previous backsight bearing is retained and may not be correct for your new setup. If necessary, enter a new backsight point or backsight bearing using either Enter Backsight Point (EP- page 237) or Enter Backsight Bearing (EB - page 238). *Click on the* **Status** *toolbar icon* ? *to display the currently* (ad) occupied point, the backsight point, and the current backsight bearing. **To Point** Enter the number of the foresighted diagonal point. Bearing Enter the bearing, angle, deflection or azimuth to the diagonal point. Distance Enter the distance to the diagonal point. If **Slope Angle Prompting** is on you will also be prompted for the data that is necessary for slope reduction according to the method you have specified on the Slope Entry Configuration Menu (see page 390). What Happens Next The program will print the bearing, horizontal and vertical distances from the currently occupied point to the diagonal point, and also the point number, point ID, and the Northing, Easting and elevation of the diagonal point. The currently occupied point and the reference bearing remain unchanged.

#### Section 9

	<ol> <li>If the backsight point for a diagonal is not the same point that you traversed from to get to the occupied point, you must use either the Enter Backsight Point (EP) (see page 237) or Enter Backsight Bearing (EB) (see page 238) routine to set the correct backsight before you use the Enter Diagonal (ED) (see page 272) routine to enter the diagonal shot. Using the EP routine usually produces better results than the EB routine because the EP routine ties the entered angle to an actual point within the network, whereas the EB routine results in only a reference bearing which is not directly tied to a third point within the network.</li> </ol>
	2. Points <b>DO NOT</b> have to be set by the <b>Traverse</b> routine before they can be used in the <b>Enter Diagonal</b> ( <b>ED</b> ) (see page 272) routine. However, the <b>Enter Diagonal</b> routine does not actually add a new point to the data file like the <b>Traverse</b> routine does.
	3. It is not standard procedure to Balance Angles before performing a Least Squares Adjustment.
Example	The Least Squares Adjustment routine is illustrated in the Quick Start manual, Section 3 - Examples.
Other Considerations Averaging	If you ever sight your traverse points more than once and use the average of your shots as the actual input measurement, "Sight" Survey's least squares adjustment procedure can give you more accurate results. The results are more accurate because instead of using a simple average of those redundant shots, least squares weights those shots based on how they fit in with the entire traverse network. For example, assume your field technician takes three shots and obtains the following results:
	Shot #1:45.2343AR100.10 feet;Shot #2:45.0055AR100.20 feet;Shot #3:40.4234AR105.00 feet;Average:43.4224AR101.77 feet.

Given the data shown above, the simple average of the angles is 43.4224AR, however, common sense tells us that the true angle is

more than likely closer to 45 degrees. The simple average of the distances is 101.77 feet, but common sense tells us that the true distance is more than likely closer to 100 feet. However, nothing guarantees that the two similar shots are the correct ones. The least squares adjustment routine not only weights each of the shots against each other, but also weights them based upon the entire network solution.

Redundant shots such as those just previously discussed are entered into "Sight" Survey using the **Traverse** (**TR**) routine for one of the shots and the **Enter Diagonal** (**ED**) routine for the other two shots. It really doesn't matter which shot(s) are entered using which routine, as long as you enter the two legs using the **Enter Diagonal** routine before you enter the one traverse leg. (If you enter the traverse leg first, your occupied point and backsight bearing will change, and you will need to go through a couple more steps to produce the same results.) You must enter **one** of them, and **only one** of them, using the **Traverse** routine.

If you take three shots to each point, the following steps explain the procedure to follow for entering this data into "Sight" Survey:

- If you have not already done so, use the Enter & Assign (EA) routine to assign coordinates to the starting point and backsight point for your traverse.
- If you are just beginning to construct your traverse network, use the Start At (ST) routine to occupy the starting point of your traverse, and then use the Enter Backsight Point (EP) or Enter Backsight Bearing (EB) routine to set the reference bearing.
- 3. Use the Enter Diagonal (ED) routine to enter the first shot to the foresight point. (Be sure to note the point number that you use since the same point number must be entered for all three shots). Your occupied point and reference bearing will remain unchanged.
- 4. Use the Enter Diagonal (ED) routine to enter the second shot to the foresight point. (Enter the same point number that you entered in Step 3). Your occupied point and reference bearing will remain unchanged.

5.	Use the <b>Traverse</b> ( <b>TR</b> ) routine to enter the final shot to
	the foresight point. (Enter the same point number that
	you entered in Steps 3 & 4). The foresight point
	becomes the currently occupied point and the reference
	bearing becomes the reverse of the bearing just
	traversed.

 Repeat Steps 3, 4 and 5 for each point in the traverse. When you are ready to close the traverse, perform Steps 3 & 4 for the closing point, and then perform Step 5 using the Traverse Close (TC) routine instead of the Traverse (TR) routine.

Stationary PointsPoints which have been introduced into the traverse network using<br/>the Start At Point (ST), Enter & Assign (EA), and as the Close To<br/>point within the Traverse Close (TC) routine are considered control<br/>points and will remain stationary. These points are shown in the At<br/>Pt column of the Unbalanced Traverse window.

If you wish to designate specific coordinate points within the network as stationary points, you must define them based on two other stationary points, preferably at the very start of your traverse network. The following procedure outlines the necessary steps to hold an internal traverse point stationary.

- If you have not already done so, use the Enter & Assign (EA) routine to assign coordinates to the starting point for your traverse.
- If you have not already done so, use the Enter & Assign (EA) routine to assign coordinates to another known, stationary point, most likely this would be your known backsight point.
- If you have not already done so, use the Enter & Assign (EA) routine to assign coordinates to the point(s) in the traverse that you will want to hold stationary.
- 4. If you are just beginning to construct your traverse network, use the **Start At** (**ST**) routine to occupy the starting point of your traverse. *However, if you are in the middle of your traverse network, it is extremely*

*important that you use the* **Go To Point** (GT) *routine instead.* 

- 5. Use the Enter Backsight Point (EP) routine to set the other known point as your backsight point.
- 6. Use the Enter Diagonal (ED) routine to enter a cross-tie to the point(s) *within the traverse network* which you want to hold stationary. At the Bearing and Distance prompts, simply recall the bearing from the starting point to the foresight point.
- Complete the traverse network as usual, using the Traverse (TR), Enter Diagonal (ED) and Traverse Close (TC) routines.
- Upon closing the traverse, edit the angle and distance Standard Deviation columns in the Unbalanced Traverse window for the legs you wish to hold stationary. Change the values from the default values to 0 (zero).
- Click the Re-Run button with your mouse or press Alt U to accept the change and re-run the traverse. After re-running the traverse changes, "Sight" Survey will display the Modified Traverse window.
- 10. Click the Lst Sgr button with your mouse or press Alt O to choose the Least Squares Adjustment option.

tmentLeast Squares Adjustment is accessed from "Sight" Survey's<br/>Traverse Adjustment window. The Traverse Adjustment window is<br/>displayed automatically after completion of the Traverse Closure<br/>(TC) routine, or upon executing the Edit Raw Data (ER) or Adjust<br/>Traverse (AT) routines. To perform a Least Squares Adjustment,<br/>click on the Lst Sgr button or press Altic when the Traverse<br/>Adjustment window is displayed.

The **Traverse Adjustment** window contains additional fields, which will not always appear. These are: **BS Pt**, **At Pt**, **S.Dev** (for angles), **S.Dev** (for distances), **SDev N** (for Northings), **SDev E** (for Eastings).

#### Traverse Adjustment

Section 9

		e Adju	sted	by Least Squares								_ 🗆 X
Length Traversed: 9704.615 Error In Departure: 0.000												
<u>B</u> al A	Bel Angl Compass Crendel Trensit Lat Sgr Reffyr Print Accept Cancel											
Leg	Act	BS Pt	At Pt	Bearing	S.Dev	Distance	S.Dev	FS Pt	Northing	SDev N	Easting	SDev E
BS	EB	N/A	~BS1	0.0410200117 SV					10000.0000		10000.00000	n/a
1		~BS1	1		0.000		0.0000		10000.0000		10000.00000	n/a
2		~BS1	1	20.010020000011						3 +/- 0.028094		
3		~BS1	1	10.0100011000111						4 +/- 0.035760		+/- 0.013249
4	ED	1	_	51.2016846529 NV						9 +/- 0.009245		
5	TR	1	_	11.0753453068 NV						3 +/- 0.028094		+/- 0.050235
6	ED	2	-	28.5159280800 SV					10000.0000		10000.00000	n/a
7	TR	2	3	76.0128225218 SV						9 +/- 0.009245		
8	ED	3	4	011201001002001				-		4 +/- 0.035760		+/- 0.013249
9	TC	3	4	5.2253844325 SE		2707.939			10000.0000		10000.00000	n/a
10	CA	4	1	73.0405611595 N	E 30.000	N/A	0.0000	2	10687.0881	4 +/- 0.035760	12256.97265	+/-0.013249
•												►

To save space in the **Traverse Adjustment** window, the **Backsight Point** and **At (Occupied) Point** columns are displayed only if you have used the **Enter Diagonal (ED)** routine within the current traverse or if you elect to add or delete a traverse leg. You can manually toggle the display of these columns between **on** and **off** by double-clicking on the **FS Pt** column heading.

If you add or delete a leg in the middle of your traverse, you will need to edit the **Backsight Point**, **At (Occupied) Point**, and **Foresight Point** columns for the leg preceding, and for one or more of the legs which follow the added or deleted leg.

**Standard Deviation** is a statistic used as a measure of the dispersion or variation in a distribution, equal to the square root of the arithmetic mean of the squares of the deviations from the arithmetic mean. If you were to draw a graph of a measurement versus the number of measurements to that station and you had a *perfect* sample, the graph would be shaped like a bell. If you then found the highest point on the graph, that point would be called the mode. If the sample fit the model perfectly, that point would also be the average (i.e. both sides of the mode would have the same number of measurements.) If you then moved away from the mode (average) the same distance in both directions until the area enclosed contained 73% of the sample, the area to the mode.

#### BS Pt & At Pt

**Standard Deviations** 

The **Traverse Adjustment** window contains four new columns which represent the Standard Deviations of angles, distances, Northings, and Eastings.

The Standard Deviations for angles and distances are displayed if you enabled the **Display Standard Deviations** check box on the **COGO Configuration Menu (CM)**. You can also toggle the Standard Deviation columns display between **on** and **off** by doubleclicking on the **Bearing** or **Distance** column headings.

The Standard Deviation values for angles and distances will initially appear as either 0 (zero) or as the values that you specified on the COGO Configuration Menu (CM).

The Standard Deviation values will initially appear as 0 for all legs which contain the following routine actions: Enter & Assign (EA), Enter Backsight Bearing (EB), Enter Backsight Point (EP), Start At (ST), Go To Point (GT), Inverse (IN), and Side Shot (SS).

The Standard Deviations will initially appear as the default values (specified on the **Configuration Menu**) for all legs which contain the following routine actions: **Enter Diagonal (ED)**, **Traverse (TR)**, **Traverse Close (TC)**, and **Closing Angle (CA)**.

A value of 0 (zero) for the Standard Deviation means that the foresight point will be held stationary, or as close to stationary as possible. Therefore, the higher that your confidence is in the angle and distance measured for each leg, the lower that the angle and distance Standard Deviation values should be. For Enter Diagonal (ED), Traverse (TR), Traverse Close (TC), and Closing Angle (CA) legs, you can change the default values based upon your confidence in the angles and distances you measured.

**Decreasing** the Standard Deviation value(s) causes "Sight" Survey to place more weight on the angles and/or distances and therefore adjusts them less. Likewise, **increasing** the Standard Deviation value(s) causes "Sight" Survey to place less weight on the angles and/or distances and therefore adjusts them more. To understand this more clearly, it may help to think of the Standard Deviation value as the amount of variance that the measurement may have in it. If you are extremely confident in any measurement and do not want that measurement to change, change the Standard Deviation for that measurement to 0 (zero).

The Standard Deviation values are very important if they vary within the traverse. A leg with a smaller standard deviation will carry more weight that a leg with a larger standard deviation. Also, a leg which has a small angle Standard Deviation and a large distance Standard Deviation will, when adjusted, have its distance adjusted more than the angle. However, the other legs in the neighboring area will also have an effect on this leg.

SDev N & SDev E The Standard Deviation (or error) values for the Northings and Eastings are displayed only after you have selected the Least Squares Adjustment option. These values are calculated during the adjustment process, and as such, cannot be changed directly by editing the fields.

> These overall values are indicative of the accuracy of your survey network. The lower the values are, the more accurate your survey network is; and likewise, the higher the value, the less accurate it is. A Northing or Easting Standard Deviation value of:

indicates an extremely accurate coordinate position, whereas a value of:

+/-4.40E+5 (or +/-440000.0)

indicates an extremely large blunder at this coordinate position or an adjacent coordinate position. If a specific Northing has a Standard Deviation value of +/-0.05000, it indicates that there is a 73% chance that the true Northing for that point lies within five one-hundredths (5/100ths) of a foot (or meter, depending upon your units) from the Northing shown in the preceding column.

You must determine for yourself what is an acceptable closure for your traverse, and then determine if the adjusted network is acceptable to you. For example, if you expect a certain angle to have a Standard Deviation of 1 second, yet the adjustment process modifies the angle by 30 seconds, you are justified to conclude that there is a blunder in one or more of the entered measurements. The Standard Deviation values are not a part of the normal text printout in the **Text Output** window, and therefore do not get printed when the **Print** function is selected. However, if you do want to print these values, you can highlight the desired column(s) and click the **Copy** button (or press AITP) to copy the highlighted data to the Windows Clipboard. Then you can Paste them into "Sight" Survey's **Text Output** window or into your favorite word processor.

If you wish to copy the entire **Traverse Adjustment** grid, click on the Leg column heading (first column) to select the entire grid and then click the **Copy** button (or press AltP). Next, use the Windows Paste function to copy the data into the "Sight" Survey **Text Output** window or to any other Windows program. (The data pastes perfectly into Microsoft's Excel[®] spreadsheet program.)

#### 9.17

#### Inverse with Stations (IS)

**FUNCTION:** The <u>Inverse with Stations</u> routine is used to toggle a stationing mode on and off. When active, the stationing mode computes horizontal stationing data along the inversed course. Stationing always proceeds in an increasing fashion.

To compute and print stationing while inversing lines and arcs, type **IS** in any text box. A message box will open and display:

"Sight" Survey 🛛 🕅					
<b>i</b>	Inverse Stationing turned on.				
	OK				

Click **OK**. The **IS** command is actually a toggle switch. If the current status of the inverse with stationing routine is **OFF**, it will

Printing


be turned **ON**. Likewise, if the current status of the inverse with stationing routine is **ON**, it will be turned **OFF**.

After turning the stationing feature on, each straight leg (and/or arc) inversed will also have a station computed. This station will be carried along with the point. Consequently, to begin with a particular station, you must assign a station value to your starting point by using the Enter Station routine (ES - page 234), or use the Start At routine (ST - page 235) to place an existing station value into the computer's memory.

As is also the case with the **Traverse with Stationing** mode, you should follow these steps to successfully begin your stationing.

- 1. Use Enter Station (ES page 234) to set a station at your beginning point, if the point has not yet been stationed.
- Turn on the stationing mode using the IS, (TS, if using <u>Traverse</u>), command.
- 3. Use the <u>Start At command</u> (ST page 235) to set the initial point.
- Enter the <u>Inverse</u> command (IN page 255) to begin inversing, (TR, - page 265, if using <u>Traverse</u>).

**Enter & Assign** points 1-4, then **Enter Station** 0+00 at point 1 and **Inverse with Stations** from point 1 to 2 to 3 to 4.



Example

📮 T ex	t Output					
	Point	Direction	Distance	Northing	Easting	Elevation
Arial		✓ 14				† ¶ <b>T</b> e
<u>.  0</u>	<u>.</u>	1 2	<u>.</u>	<u></u>	<u></u>	<u> </u>
-						`
Sta	n 1		1	0000.00000	20000.00000	0.000
Ass	igned St	tation				
	⁻ 1	0+00.000	1	0000.0000	20000.00000	0.000
IN	N 52	°17'35.0" E	150.000			
	2	1+50.000		0091.74344	20118.67241	0.000
IN	S 15	°24'42.0" E	105.500			
	3	2+55.500		9990.03708	20146.70929	0.000
IN	N 80	°10'20.0" E	210.750			
	4	4+66.250	1	0026.00941	20354.36659	0.000 🖵
				Page 1/1	Line 144	Col 1

#### Traverse with Stations (TS)

**FUNCTION:** The **Traverse** with **Stations** routine is used to toggle a stationing mode on and off. When active, the stationing mode computes horizontal stationing data along the traversed course. Stationing always proceeds in an increasing fashion.

To compute and print stationing while traversing lines and arcs, type **TS** in any text box, or press **Att**, **E**. A message box will open and display:

"Sight"	Survey 🔣
٩	Traverse Stationing turned on.
	OK

Click **OK**. The **TS** command is actually a toggle switch. If the current status of the traverse with stationing routine is **OFF**, it will be turned **ON**. Likewise, if the current status of the traverse with stationing routine is **ON**, it will be turned **OFF**.

i

After turning the stationing feature on, each traverse leg computed will also have a station computed. This station will be carried along with the point. Consequently, to begin with a particular station, you must assign a station value to your starting point by using the **Enter Station** routine (**ES** - page 234), or use the **Start At** routine (**ST** - page 235) to place an existing station value into the computer's memory.

**CURVES:** The stationing routine handles horizontal curves in the **Traverse Arc** routine by assuming that the currently occupied point is the PC point. The PI point will be computed and printed. Stationing of the PT will be computed by adding the length of curve to the PC station.

As is also the case with the **Inverse with Stationing** mode, you should follow these steps to successfully begin your stationing.

- 1. Use Enter Station (ES page 234) to set a station at your beginning point, if the point has not yet been stationed.
- Turn on the stationing mode using the TS, (IS, if using <u>Inverse</u>), command.
- 3. Use the <u>Start At command</u> (ST page 235) to set the initial point.
- 4. Enter the <u>Traverse</u> command (TR page 265) to begin inversing, (IN, page 255, if using <u>Inverse</u>).

This routine functions similar to the **Inverse with Stations** routine in **Section 9.17**, except you **Traverse** (not **Inverse**) to the foresight point.

Example


Section 9

	<b>FUNCTION:</b> The <b>Traverse Right of </b> <u>W</u> <b>ay</b> routine functions as a multiple offset intersection routine to lay out one or two lines parallel to a centerline.			
	To access the <b>Traverse Right of</b> $\underline{W}$ ay routine, type <b>RW</b> in any text box, or press $\underline{Att}$ , $\underline{W}$ .			
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.			
B.S. Point	This is the current backsight point. If you already have a backsight point, this box will be filled for you.			
Left Offset	Enter the offset distance to the left. If you do not want to set a right-of-way on the left side, just press Finer. The direction left, refers to the position of the line with respect to the forward direction of travel.			
Right Offset	Enter the offset distance to the right. If you do not want to set a right-of-way on the right side, just press <i>reference</i> . The direction right, refers to the position of the line with respect to the forward direction of travel.			
Next Point	Type in individual point numbers, pressing <i>end</i> after each number. You may also type in a point string and press <i>end</i> .			
What Happens Next	"Sight" Survey will respond to each accepted right-of-way point by computing and printing the offset point coordinates and a point name. Offset point numbers are automatically assigned. "Sight" Survey will also update the data entry screen by correctly displaying the current point and the correct backsight point.			
	If the backsight point specified is the same as the occupied point, the offsets will be placed perpendicular to the leg extending from the occupied point to the foresight point.			

#### Traverse Right of <u>W</u>ay (RW)

If the foresight point specified is the same as the occupied point, the offsets will be placed perpendicular to the leg extending from the backsight point to the currently occupied point.

**Enter and Assign** the coordinate data for points 1 through 7 as shown below, then **Traverse a Right-of-Way** with a 40 foot left offset and a 60 foot right offset.



😽 Text Output					
Point	Direction	Distance	Northing	Easting	Elevation
Arial	▼ 13 ▼ <b>Ξ</b>		<u>ℤ</u> <u>Ш</u> АВ€ =		†¶ <b>E</b>
· [0, · · · · · · · · · · · · · · · · · · ·	11	······ []] 3			<u> </u>
Assigned p	oints				<b>_</b>
1 ī			1000.00000	2000.00000	0.000
2			1000.00000	2200.00000	0.000
3			1068.40400	2387.93850	0.000
4			1196.96160	2541.14740	0.000
5			1370.16660	2641.14740	0.000
6			1498.72420	2794.35630	0.000
7			1301.76260	2759.62670	0.000
					<b>~</b>
			Page 1/1	Line 1	Col 1

Example

🍹 Text Output					
Point	Direction	Distance	Northing	Easting	Elevation
Arial	💌 13 💌 🔳		<u>8</u> <u>Z</u> <u>U</u> AB€ —		† ¶ Te
	1 2.		3		6
► [⊥]	1 1	T T	1 1	1 1	
Start					
1			1000.00000	2000.00000	0.000
Right of Wa	y offsets at Po	Int 1	940.00000	2005.15847	0.000
8			1040.00000	1996.56102	0.000
ีเท ทั90	0°00'00.0'' E	200.000	1040.00000	1000.00102	0.000
2			1000.00000	2200.00000	0.000
Right of Wa	y offsets at Po	int 2			
11			940.00000	2210.57962	0.000
10			1040.00000	2192.94692	0.000
	0°00'00.0'' E	200.000	1000 1010-		
3	<i></i>		1068.40400	2387.93850	0.000
Right of Wa	y offsets at Po	int 3	1015.64089	2418,40130	0.000
13			1015.64089	2367.62996	0.000
	9°59'59.9'' E	200.000	100.07941	2001.02990	0.000
4		200.000	1196.96160	2541,14740	0.000
Right of Wa	y offsets at Po	int 4			
Ŭ 15			1157.79938	2587.81911	0.000
14			1223.06974	2510.03292	0.000
IN N30	0°00'00.0'' E	200.000			
5			1370.16660	2641.14740	0.000
	y offsets at Po	int 5			
17			1331.00438	2687.81911	0.000
16 IN N49	9°59'59.9'' E	200.000	1396.27474	2610.03292	0.000
6	5 09 09.9 E	200.000	1498.72420	2794,35630	0.000
•	v offsets at Po	int 6	1430.12420	2134.00000	0.000
19	.,		1346.79884	2706.64220	0.000
18			1600.00778	2852.83237	0.000
IN S10	0°00'00.0'' W	200.000			
7			1301.76260	2759.62670	0.000
Right of Way offsets at Point 7					
21			1312.18148	2700.53823	0.000
20			1294.81668	2799.01901	0.000
	0°00'00.0'' E	0.000	4004 70000	0750 00070	
7			1301.76260	2759.62670	0.000 🖵
			Page 1/1	Line 1	Col 1


9.20

#### Best Fit Line (BF)

**FUNCTION:** The **Best Fit Line** routine is used to compute the bearing and end point coordinates of a line which best fits the coordinates of any three or more known points.

To access the **Best Fit Line** routine, type **BF** in any text box, or press Att .

Points	Type in individual point numbers or a point string and press <i>Enter</i> .
Point on Line	Type in a point number that will be assigned to a location through which the best fit line will pass, and press <i>renter</i> .
What Happens Next	"Sight" Survey will respond by computing and printing the bearing of the best fit line, and the coordinates of a point through which the line passes.
Example	<b>Enter &amp; Assign</b> the coordinate data for points 1 through 8 as shown below, then compute a <b>Best Fit Line</b> through point 9.



Section 2015					
Point	Direction	Distance	Northing	Easting	Elevation
Arial			} <u>Z U</u> ABC		9 6
	11	للمصحف	3		
<b>•</b>					
Assigned p	oints				
1			1000.00000	2000.00000	0.000
2			1100.00000	1975.00000	0.000 🗕
3			1200.00000	2045.00000	0.000
4			1300.00000	2080.00000	0.000
5			1400.00000	1910.00000	0.000
6			1700.00000	1925.00000	0.000
7			1900.00000	2100.00000	0.000
8			2000.00000	1990.00000	0.000
Best fit to a	line for all poir	nts			
	0°01'38.5" E				
Through po					
9	/int.		1450.00000	2003.12500	0.000
5			1450.00000	2003.12500	0.000
			Page 1/1	Line 3	Col 1



Inverse <u>C</u>urve (IC) <u>O</u>btuse Curve (OC) Three <u>P</u>oint Curve (TP)

Inscribe Arc (IA) Iraverse Arc (TA) Traverse Arc with Offsets (AO) Cur<u>v</u>e Offset (CO)

Þ

Best Fit Curve (BC)

# Section 10 The <u>C</u>URVES Menu

The <u>Curves</u> menu contains functions that are used to define the relationship of points based on curves. Here you will find routines such as **Inverse Curve**, **Traverse Arc**, **Inscribe Arc**, **Curve Offsets**, and **Best Fit Curve**. The **Inscribe Arc** sub-menu includes options for tangent and non-tangent curves.

10 01		
		<b>T</b> .

## Inverse Curve (IC)

	<b>FUNCTION:</b> The <b>Inverse Curve</b> routine is used to calculate and report the measurement data along an acute circular arc, having a delta angle of less than 180° (or 200 grads). This routine calculates the central angle, arc length, chord, chord bearing, tangent and radius of a curve when given the coordinates of the point of curvature (PC), the circle's center
	point and the curve's end point.         To access the Inverse Curve routine, type IC in any text box, or press Atto, C.
From Point	This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Center Point	Enter the circle's center point number.

**To Point** 

Enter the point number of the circle's end point. If the end point has not been assigned coordinates, the program will prompt for

them and you must respond as you would to a standard coordinate entry request.

1) A 2) O 3) I Enter an A or a 1 if you want the calculations to be based on an acute central angle. Enter an O or a 2 for the obtuse angle, and enter an I or a 3 to divide the arc into a desired number of intervals.


What Happens Next "Sight" Survey will respond to an accepted end point by first checking for a radii match. If the measured difference in radii is greater than 0.01 feet, the message RADII DO NOT MATCH, will be displayed.

If the radii match successfully, the program will compute and print the Central Angle, Radius, Arc Length, Tangent, Chord, and Chord Bearing from the P.C. to the end point. The end point becomes the currently occupied point and the bearing from the end point to the center point becomes the reference bearing for use in the next calculation.

Enter & Assign points 2, 3 and 7, then perform an Inverse Curve

from point 3 to point 7, centered at point 2.

## Example



🍹 Text Output				_ 🗆 🗙
Point Dire	ction Distar	nce Northing	Easting	Elevation
Arial 🔽 14				[†]
• • • • • • • • • • • • • • • • • • • •		<u></u>		L
Start				-
3		9990.03708	20146.70929	0.000
IC To Cntr. Pt.	N 15°24'42.0	" W		
2		10091.74344	20118.67241	0.000
Arc	138.099	Central	Angle 75°00	0'00.0"
Chord	128.449	Chord E	Bearing N 67°54	4'42.0" W
Radius	105.500	Bng fro	m Cntr PtS 59°38	5'18.0" W
Tangent	80.953	Elevatio	on Change	0.000
7		10038.33835	20027.68809	0.000
		Page 1/1	Line 167	Col 1



The C1 designation of the arc in the drawing signifies a curve listed in the curve table constructed by "Sight" Survey. Curve tables are placed by the Draw [™] Draw [™] Draw Supplemental [™] Curve Table function (CL - page 379.)

10.02	Obtuse Curve (OC)
	<b>FUNCTION:</b> The <u>Obtuse Curve</u> routine is used to calculate and report the measurement data along a circular arc, having a delta angle of greater than or equal to 180° (or 200 grads). This routine calculates the central angle, arc length, chord, chord bearing and radius of a curve when given the coordinates of the point of curvature (PC), the circle's center point and the curve's end point.
	To access the <b>Obtuse Curve</b> routine, type $OC$ in any text box, or press Aft $\bigcirc$ .
From Point	This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Center Point	Enter the circle's center point number.
To Point	Enter the point number of the end point. If the end point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request.
1) A 2) O 3) I	Enter an A or a 1 if you want the calculations to be based on an acute central angle. Enter an O or a 2 for the obtuse angle, and enter an 1 or a 3 to divide the arc into a desired number of intervals.
What Happens Next	"Sight" Survey will respond to an accepted end point by first checking for a radii match. If the measured difference in radii is greater than 0.01 feet, the message <b>RADII DO NOT MATCH</b> , will be displayed.
	If the radii match successfully, the program will compute and print the Central Angle, Radius, Arc Length, Tangent, Chord, and Chord Bearing from the PC. to the end point. The end point becomes the currently occupied point and the bearing from the end point to the center point becomes the reference bearing for use in the next calculation.


I

## Example

10.03

**3rd Crv Point** 

**Enter & Assign** points 2, 3 and 7, then perform an **Inverse Obtuse Curve** from point 3 to point 7, centered at point 2.



🍑 Text Output					_ 🗆 ×	<
Point	Direction	Distance	Northing	Easting	Elevation	
Arial	▼ 14 <b>▼ ≡</b>		<u>ℤ</u> <u>⊔</u> АВ€ =		† ¶ 🚡	
•••••	11				·····	-
Start						
3			9990.03708	20146.70929	0.000	
OC To Cntr	.Pt. N 15°	24'42.0" W				
2		1	0091.74344	20118.67241	0.000	
Are	c 524	.777	Central /	Angle 285°0	0'00.0"	
Ch	ord 128	.449	Chord B	earing N 67°5	4'42.0" W	
Ra	ndius 105	.500	Bng from	n Cntr PtS 59°3	5'18.0" W	
			Elevation	n Change	0.000	
7		1	0038.33835	20027.68809	0.000	-
			Page 1/1	Line 176	Col 1	

Ų

The C2 designation of the arc in the drawing signifies a curve listed in the curve table constructed by "Sight" Survey. Curve tables are placed by the <u>Draw</u>  $\Rightarrow$  Draw Supplemental  $\Rightarrow$  <u>Curve</u> Table function (CL - page 379.)

## Three Point Curve (TP)

**FUNCTION:** The **Three Point Curve** routine is used to compute the center point of a curve that passes through three known points.

To access the **Three Point Curve** routine, type **TP** in any text box, or press AltC, P.

1st Crv PointEnter the number of the first point on the curve.2nd Crv PointEnter the number of the second point on the curve.

Enter the number of the third point on the curve.

## **Cntr Point**

What Happens Next

Example

Enter the number you want to assign to this point.

"Sight" Survey will respond to your completed point entries by calculating the coordinates of the center point of an (acute) arc that passes through the three known points. The center point number and coordinates will be printed in the **Text Output** window. Use the **Inverse Curve** routine (**IC** - page 289) to view the curve data.

**Enter & Assign** points 1, 3 and 4 using the coordinates shown below, then calculate a **Three Point Curve** passing through points 1, 3, and 4. Make the curve's center point 8.



🐺 Text Output				
Point Dire	ction Distan	ce Northing	Easting I	Elevation
Arial 💌 14		BZU ABC =		1
<u>-  0</u>		. <u></u>	<u></u>	→ ⁶
4		10026.00941	20354.36659	0.000 🛋
IC To Cntr. Pt.	N 17°54'37.9'	'W		
8		10739.13880	20123.88730	0.000
Arc	211.451	Central A	Angle 16°09'	55.8"
Chord	210.750	Chord B	earing S 80°10'	20.0" W
Radius	749.449	Bng from	Cntr Pt S 1°44	42.1" E
Tangent	106.432	Elevation	n Change	0.000
3		9990.03708	20146.70929	0.000
IC To Cntr. Pt.	N 1°44'42.1'	'W		
8		10739.13880	20123.88730	0.000
Arc	147.284	Central A	Angle 11°15'	35.8"
Chord	147.047		earing N 86°06'	
Radius	749.449	Bng from	n Cntr Pt S 9°30'	53.7" W
Tangent	73.880	Elevation	n Change	0.000
1		10000.00000	20000.00000	0.000 💌
		Page 1/1	Line 212	Col 1

•


The C1 and C2 designations of the arcs in the drawing signifies a curve listed in the curve table constructed by "Sight" Survey. Curve tables are placed by the <u>Draw</u> Draw Supplemental Draw <u>Curve</u> Table function (CL - page 379.) Section 10 

10.04	Inscribe Arc <u></u> angent from the PC		
	from a known point of curvat	e center point and tangent point	
	and select the item from the me	•	
	<b>This routine may be solved by</b> Delta & Chord known; Delta & Arc known; Delta & Tangent known; Delta & Radius known;	any of the following criteria: Chord & Tangent known; Chord & Radius known; Arc & Radius known; Tangent & Radius known.	
	Enter data for at least two of the additional data, you may enter in Insufficient data will result in ar	t but it is not necessary to do so.	
Р.С.	have an occupied point, this box	oint, which is also the PC. If you will automatically be filled for s equivalent to running the <b>Go To</b>	
Center Point	Enter the desired point number.		
End Point	Enter the desired point number.		
Delta	Enter the delta angle. If unknow	wn, just press <i>-</i> Enter .	
Chord	Enter the chord length. If unknow	own, just press -Enter.	
Arc	Enter the arc length. If unknow	n, just press -Enter.	
Tangent	Enter the tangent length. If unk	nown, just press <i>enter</i> .	
Radius	Enter the radius length. If unkn	own, just press <i></i> Enter].	
Enter Curve Direction	-	the left, otherwise press <b>1</b> . The to the forward direction of travel.	

What Happens Next"Sight" Survey will respond to correct and sufficient data by<br/>computing the arc center point and end point, and then printing the<br/>center point number and coordinates, the central angle, arc, radius,<br/>tangent, chord length and chord bearing; and the arc end point<br/>number and coordinates.

Enter & Assign point 1, then Traverse to point 2 which becomes the PC. Inscribe an Arc Tangent from the PC through center point 3 to PT point 4. Use a delta of 72° and a radius of 270 feet. Curve to the right.

Parison				
Point Direc	tion Distance	Northing	Easting E	_□× levation
Arial 14				
- <u>P</u> <u>.</u> <u> </u>	<u></u>	<u>1³ · · · · <u>1</u> · · · · · <u>1</u>⁴ · ·</u>		<u> </u>
Assigned points				<b>`</b> _
		1000.00000	2000.00000	0.000
Start		1000.00000	2000.00000	0.000
1		1000.00000	2000.00000	0.000
TR N 90°00'00.0	"E 100.000			
2		1000.00000	2100.00000	0.000
Inscribe an Arc Tan				
Calculations Based				
To Cntr. Pt.	S 0°00'00.0" E			
3		730.00000	2100.00000	0.000
Arc	339.292	Central A	Angle 72°00'	0.00"
Chord	317.404	Chord Be	earing S 54°00'	00.0" E
Radius	270.000		Cntr PtN 72°00'	
Tangent	196,166		n Change	0.000
4		813.43459		0.000
		Page 1/1	Line 8	Col 37



10.05	Inscribe Arc �Tangent from the PI		
	FUNCTION: The Inscribe Arc To Tangent from the PI routine is used to compute the PC, center point, and end point of a tangent arc from a known point of intersection.         To access the Inscribe Arc To Tangent from the PI routine, type IA		
	and select the item from the menu, or press Att C, I, A.This routine may be solved by any of the following criteria:Delta & Chord known;Chord & Tangent known;Delta & Arc known;Chord & Radius known;Delta & Tangent known;Arc & Radius known;Delta & Radius known;Tangent & Radius known;		
	Enter data for at least two of these known items. If you have additional data, you may enter it but it is not necessary to do so. Insufficient data will result in an incorrect solution.		
P.I.	This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.		
P.C.	Enter the desired point number.		
Center Point	Enter the desired point number.		
End Point	Enter the desired point number.		
Delta	Enter the delta angle. If unknown, just press <i>enter</i> .		
Chord	Enter the chord length. If unknown, just press <i>enter</i> .		
Arc	Enter the arc length. If unknown, just press <i>Enter</i> .		
Tangent	Enter the tangent length. If unknown, just press -Enter.		
Radius	Enter the radius length. If unknown, just press <i>Enter</i> .		

action 10

Enter Curve Direction	Press <b>1</b> if the curve proceeds to the left, otherwise press <b>1</b> . The direction of the curve is relative to the forward direction of travel.
What Happens Next	"Sight" Survey will respond to correct and sufficient data by computing the arc's PC, center point, and end point; and then printing the PC point number and coordinates; the center point number and coordinates; the central angle, arc, radius, tangent, chord length and chord bearing; and the arc end point number and coordinates.
Example	For an <b>Inscribe Arc</b> example, see page 295.

10.06

## Inscribe Arc ₱Non-Tangent from the PC

FUNCTION: The Inscribe Arc >> Non-Tangent from the PC routine is used to compute the center point and end point of a non-tangent arc from a known point of curvature.

To access the Inscribe Arc >> Non-Tangent from the PC routine, type IA and select the item from the menu, or press AtC,  $\Box$ , N.

## This routine may be solved by any of the following criteria:

	This routine may be solved by any of the following effectia.	
	Delta & Chord known;	Chord & Tangent known;
	Delta & Arc known;	Chord & Radius known;
	Delta & Tangent known;	Arc & Radius known;
	Delta & Radius known;	Tangent & Radius known.
	Enter data for at least two of the additional data, you may enter in Insufficient data will result in a	t but it is not necessary to do so.
P.C.	have an occupied point, this bo	point, which is also the PC. If you x will automatically be filled for is equivalent to running the Go To
Center Point	Enter the desired point number.	
End Point	Enter the desired point number.	

Delta	Enter the delta angle. If unknown, just press
Chord Arc	Enter the chord length. If unknown, just press <i>Enter</i> . Enter the arc length. If unknown, just press <i>Enter</i> .
Tangent	Enter the tangent length. If unknown, just press <i>Enter</i> .
Radius	Enter the radius length. If unknown, just press -Enter.
Enter Curve Direction	Press <b>1</b> if the curve proceeds to the left, otherwise press <b>1</b> . The direction of the curve is relative to the forward direction of travel.
Enter the Chord Bearing	Enter the chord bearing.
What Happens Next	"Sight" Survey will respond to correct and sufficient data by computing the arc's center point and end point; and then printing the center point number and coordinates; the central angle, arc, radius, tangent, chord length and chord bearing; and the arc end point number and coordinates.
Example	For an <b>Inscribe Arc</b> example, see page 295.

10.07

## Inscribe Arc �Tangent from the PC with Offsets

**FUNCTION:** The **Inscribe Arc** Tangent from the PC with **Offsets** routine is used to compute the center point and tangent point of a tangent arc from a known point of curvature, and then set radial offsets to the curve end point.

To access the <u>Inscribe Arc</u>  $\Rightarrow$  Tangent from the PC with <u>Offsets</u> routine, type **IA** and select the item from the menu, or press <u>Alt</u><u>C</u>, <u>I</u>, <u>O</u>.

## This routine may be solved by any of the following criteria:

Delta & Chord known;ChoDelta & Arc known;ChoDelta & Tangent known;ArcDelta & Radius known;Tan

Chord & Tangent known; Chord & Radius known; Arc & Radius known; Tangent & Radius known.

	Enter data for at least two of these known items. If you have additional data, you may enter it but it is not necessary to do so. Insufficient data will result in an incorrect solution.
P.C.	This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Center Point	Enter the desired point number.
End Point	Enter the desired point number.
Delta	Enter the delta angle. If unknown, just press
Chord	Enter the chord length. If unknown, just press -Enter.
Arc	Enter the arc length. If unknown, just press <i>eterter</i> .
Tangent	Enter the tangent length. If unknown, just press .
Radius	Enter the radius length. If unknown, just press <i>enter</i> .
Enter Curve Direction	Press <b>1</b> if the curve proceeds to the left, otherwise press <b>1</b> . The direction of the curve is relative to the forward direction of travel.
Point	Enter a number for the offset point.
O.S. Dist.	Enter the distance from the curve to the offset. Enter the distance as a negative value to offset to the left, relative to the direction of travel.
Point	Enter another offset point, or click <b>Cancel</b> if you have finished entering offset points.
What Happens Next	"Sight" Survey will respond to correct and sufficient data by computing the arc's center point and end point; and then printing the center point number and coordinates; the central angle, arc, radius, tangent, chord length and chord bearing; and the arc end point number and coordinates.

 Following a correct offset entry, "Sight" Survey will print the bearing and distance to the offset point, the offset point number, description, and coordinates.

For an	Inscri	be Ai	rc exampl	e, see	page 295.	•
--------	--------	-------	-----------	--------	-----------	---

10.08

Example

## Inscribe Arc Tangent from the PI with Offsets

FUNCTION: The Inscribe Arc Tangent from the Pl with Offsets routine is used to compute the point of curvature, center point and end point of a tangent arc from a known point of intersection, and then set radial offsets to the curve end point.

To access the <u>inscribe Arc</u>  $\Rightarrow$  Tangent from the PI with Offsets routine, type IA and select the item from the menu, or press Arc,  $\square, \square, \square$ .

	This routine may be solved by a Delta & Chord known; Delta & Arc known; Delta & Tangent known; Delta & Radius known;	Chord & Tangent known; Chord & Radius known; Arc & Radius known; Tangent & Radius known.
	Enter data for at least two of these additional data, you may enter it b Insufficient data will result in an in	ut it is not necessary to do so.
P.I.	This is the currently occupied point have an occupied point, this box v you. Changing the <b>From Point</b> is e routine.	vill automatically be filled for
P.C.	Enter the desired point number.	
Center Point	Enter the desired point number.	
End Point	Enter the desired point number.	

Delta	Enter the delta angle. If unknown, just press .
Chord	Enter the chord length. If unknown, just press <i>et al.</i>
Arc	Enter the arc length. If unknown, just press <i>PEnter</i> .
Tangent	Enter the tangent length. If unknown, just press <i>Etter</i> .
Radius Enter Curve Direction	Enter the radius length. If unknown, just press Fine. Press if the curve proceeds to the left, otherwise press 1. The direction of the curve is relative to the forward direction of travel.
Point	Enter a number for the offset point.
O.S. Dist.	Enter the distance from the curve to the offset, as a negative value to offset to the left, relative to the direction of travel.
Point	Enter another offset point, or click <b>Cancel</b> if you have finished entering offset points.
What Happens Next	"Sight" Survey will respond to correct and sufficient data by computing the arc's PC, center point, and end point; and then printing the PC point number and coordinates; the center point number and coordinates; the central angle, arc, radius, tangent, chord length and chord bearing; and the arc end point number and coordinates.
	Following a correct offset entry, "Sight" Survey will print the bearing and distance to the offset point, the offset point number, description, and coordinates.
Example	For an <b>Inscribe Arc</b> example, see page 295.

10.09

## Inscribe Arc ♣Non-Tangent from the PC with Offsets

FUNCTION: The Inscribe Arc > Non-Tangent from the PC with Offsets routine is used to compute the center point and end point of a non-tangent arc from a known point of curvature, and then set offsets to the curve end point.

	To access the Inscribe Arc $\Rightarrow$ Non-Tangent from the PC with Offsets routine, type IA and select the item from the menu, or press AttC, $\square$ , $\square$ .
P.C.	This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Center Point	Enter the desired point number.
End Point	Enter the desired point number.
Delta	Enter the delta angle. If unknown, just press -Enter.
Chord	Enter the chord length. If unknown, just press <i>Enter</i> .
Arc	Enter the arc length. If unknown, just press <i>Enter</i> .
Tangent	Enter the tangent length. If unknown, just press <i>Enter</i> .
Radius	Enter the radius length. If unknown, just press .
Enter Curve Direction	Press (1) if the curve proceeds to the left, otherwise press (1). The direction of the curve is relative to the forward direction of travel.
Enter the Chord Bearing	Enter the chord bearing.
Point	Enter a number for the offset point.
O.S. Dist.	Enter the distance from the curve to the offset. Enter the distance as a negative value to offset to the left, relative to the direction of travel.
Point	Enter another offset point, or click <b>Cancel</b> if you have finished entering offset points.
What Happens Next	"Sight" Survey will respond to correct and sufficient data by computing the arc's center point and end point; and then printing the center point number and coordinates; the central angle, arc, radius, tangent, chord length and chord bearing; and the arc end point number and coordinates.

Following a correct offset entry, "Sight" Survey will print the bearing and distance to the offset point, the offset point number, description, and coordinates.

Example

For an **Inscribe Arc** example, see page 295.

10.10	Traverse Arc (TA)	
	<b>FUNCTION:</b> The <u>Traverse Arc</u> routine is used to compute the coordinates of a point lying along an arc when given the coordinates of the point of curvature, the coordinates of the center point of the arc and one other of the following four parameters: the arc length; the chord length; the tangent length; or the central angle (delta) of the arc.	
	To access the <b>Traverse Arc</b> routine, type <b>TA</b> from the menu, or press $AttC$ , <b>T</b> .	10
From Point	This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.	
Center Point	Enter the number of the center point of the arc.	
To Point	Enter the number of the point you which you are traversing.	
Value	Enter the known item of data, (Arc, Chord, Tangent or Delta). The numeric sign of the data entered determines the direction to be traversed. If you are traversing in a CLOCKWISE direction, enter your data as POSITIVE value. Use a NEGATIVE value if you are traversing COUNTER-CLOCKWISE.	
Select one of the following Options 1) Arc 2) Chord 3) Tangent 4) Delta	Enter 1, 2, 3, or 4 to indicate the type of data entered in the previous prompt.	

What Happens NextThe program will compute the coordinates for the new PT point,<br/>print the Central Angle, Radius, Arc, and Tangent Length, Chord<br/>and Chord Bearing from PC to the PT.

At this point, two events have occurred. The PT has become the currently occupied point, which is also the new PC should you continue to traverse along the arc. Also, the bearing from the PT back to the Center Point is now the reference bearing, if one is needed for the next calculation. Therefore, to proceed away from the PT tangent to the traversed arc, you would enter the **Traverse** routine (**TR** - page 265) and input an angle of **90** degrees **AR** or **AL** as the case may be.

ExampleEnter & Assign point 1 (the arc center point) and Traverse to point<br/>2 (the PC). Traverse Arc from point 2 to point 3 using a 75 foot<br/>arc. Enter the arc length as -75 to make the arc curve to the left.

🍹 Text Output				
Point Direc	tion Distance	Northing	Easting E	evation
Arial 🔽 14		B Z U AR =		¶ 🚡
• [0		<u> 3 4.</u>	···· <u>··</u> ·· ¹⁵ ·····	···· 16. · · · · · ·
Assigned point				
1		1000.00000	2000.00000	0.000
Start				
1		1000.00000	2000.00000	0.000 🔟
Raw: 90ne	150			
TR N 90°00'00.0	)"E 150.000			
2		1000.00000	2150.00000	0.000
TA To Cntr. Pt.	N 90°00'00.0" V			
1		1000.00000	2000.00000	0.000
Calculations I	based on Arc (to	the left)		
Arc	75.000		ngle 28°38'5	
Chord	74.221	Chord Be	earing N 14°19'2	6.2" W
Radius	150.000	Bng from	Cntr PtN 61°21'0	7.6" E
Tangent	38.301	Elevation		0.000
3		1071.91383	2131.63738	0.000 🖵
		Page 1/1	Line 5	Col 59

10.11	Traverse <u>A</u> rc with Offsets (AO)
	<b>FUNCTION:</b> The Traverse Arc with Offsets routine is used to compute the coordinates of a point lying along an arc when given the coordinates of the point of curvature, the coordinates of the center point of the arc and one other of the following four parameters: the arc length; the chord length; the tangent length; or the central angle (delta) of the arc. This routine will also set offset points at the curve end point.
From Point	To access the <b>Traverse Arc with Offsets</b> routine, type <b>AO</b> from the menu, or press <b>Arc</b> , <b>A</b> . This is the currently occupied point, which is also the PC. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Center Point	Enter the number of the center point of the arc.
To Point	Enter the number of the point to which you are traversing.
Value	Enter the known item of data, (Arc, Chord, Tangent or Delta). The numeric sign of the data entered determines the direction to be traversed. If you are traversing in a CLOCKWISE direction, enter your data as POSITIVE value. Use a NEGATIVE value if you are traversing COUNTER-CLOCKWISE.
Select one of the following Options 1) Arc 2) Chord 3) Tangent 4) Delta	Enter 1, 2, 3, or 4 to indicate the type of data entered in the previous prompt.
Point	Enter a number for the offset point.
O.S. Dist.	Enter the distance from the curve to the offset. Enter the distance as a negative value to offset to the left, relative to the direction of travel.
Point	Enter another offset point, or click <b>Cancel</b> if you have finished entering offset points.

What Happens Next	The program will compute the coordinates for the new PT point, print the Central Angle, Radius, Arc, and Tangent Length, Chord and Chord Bearing from PC to the PT.
	At this point, two events have occurred. The PT has become the currently occupied point, which is also the new PC should you continue to traverse along the arc. Also, the bearing from the PT back to the Center Point is now the reference bearing, if one is needed for the next calculation. Therefore, to proceed away from the PT tangent to the traversed arc, you would enter the <u>Traverse</u> routine ( <b>TR</b> - page 265) and input an angle of <b>90</b> degrees <b>AR</b> or <b>AL</b> as the case may be.
	Following a correct offset entry, "Sight" Survey will print the bearing and distance to the offset point, the offset point number, description, and coordinates.
Example	Except for placing offset points, this routine functions similar to the <b>Traverse Arc</b> routine discussed in the previous section. Refer to the <b>Traverse Arc</b> example.

10.12	Cur <u>v</u> e Offset (CO)
	<b>FUNCTION:</b> The <b>Curve Offset</b> routine is used to set radial offsets to a point on a curve.
	<b>This routine requires that a curve be current in memory.</b> You may only run this routine <b>immediately</b> after setting or accessing a point through the <b>Traverse Arc</b> ( <b>TA</b> - page 303), <b>Inverse Curve</b> ( <b>TC</b> - page 289) or <b>Inverse Obtuse Curve</b> ( <b>OC</b> - page 291) routines. You must currently be in one of these routines to use the <b>Curve Offset</b> routine.
	To set curve offset points, type <b>CO</b> <i>end</i> at the prompt for the next curve point.
Point	Enter a name for the offset point.

Enter the distance from the curve to the offset. Enter the distance as a negative value to offset to the left, relative to the direction of travel.

O.S. Dist.

Point

Example

What Happens Next

Enter another offset point, or click **Cancel** if you have finished entering offset points.

Following a correct offset entry. "Sight" Survey will print the bearing and distance to the offset point, the offset point number, description, and coordinates.

After running the curve in the **Traverse Arc** routine (page 303), set curve offsets **20**' left and **50**' right at the PT.

Point         Direction         Distance         Northing         Easting         Elevation           Avial         I         Image: Im
Image: Constraint of the second sec
Assigned point 1 1000.00000 2000.00000 0.000 Start 1 1000.00000 2000.00000 0.000 Raw: 90ne 150 TR N 90°00'00.0" E 150.000 2 1000.00000 2150.00000 0.000 TA To Cntr. Pt. N 90°00'00.0" W 1 1000.00000 2150.00000 0.000 Calculations based on Arc (to the left) Arc 75.000 Central Angle 28°38'52.4" Chord 74.221 Chord Bearing N 14°19'26.2" W Radius 150.000 Bng from Cntr PtN 61°21'07.6" E Tangent 38.301 Elevation Change 0.000
1         1000.00000         2000.00000         0.000           Start         1         1000.00000         2000.00000         0.000           Raw:         90ne         150         1         1000.00000         2150.0000         0.000           Raw:         90°0'00.0" E         150.000         2         1000.00000         2150.00000         0.000           TA To Cntr. Pt.         N 90°00'00.0" W         1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"           Chord         74.221         Chord Bearing N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
1         1000.00000         2000.00000         0.000           Start         1         1000.00000         2000.00000         0.000           Raw:         90ne         150         1         1000.00000         2150.0000         0.000           Raw:         90°0'00.0" E         150.000         2         1000.00000         2150.00000         0.000           TA To Cntr. Pt.         N 90°00'00.0" W         1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"           Chord         74.221         Chord Bearing N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
Start         1         1000.0000         2000.0000         0.000           Raw:         90ne         150
1         1000.00000         2000.00000         0.000           Raw:         90ne         150           TR         N 90°00'00.0" E         150.000         2           2         1000.00000         2150.00000         0.000           TA To Cntr. Pt.         N 90°00'00.0" W         1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"         Chord         74.221         Chord Bearing N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E         Tangent         38.301         Elevation Change         0.000
Raw:         90ne         150           TR         N 90°00'00.0" E         150.000           2         1000.00000         2150.00000         0.000           TA To Cntr. Pt.         N 90°00'00.0" W         1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"         Chord         74.221         Chord Bearing         N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E         Tangent         38.301         Elevation Change         0.000
TR         N 90°00'00.0" E         150.000         2         1000.00000         2150.00000         0.000           TA To Cntr. Pt.         N 90°00'00.0" W         1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"           Chord         74.221         Chord Bearing         N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
2         1000.00000         2150.00000         0.000           TA To Cntr. Pt.         N 90°00'00.0" W         1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"           Chord         74.221         Chord Bearing         N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
TA To Cntr. Pt.         N 90°00'00.0" W           1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"           Chord         74.221         Chord Bearing         N 14°19'26.2" W         Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
1         1000.00000         2000.00000         0.000           Calculations based on Arc (to the left)         Arc         75.000         Central Angle         28°38'52.4"           Chord         74.221         Chord Bearing         N 14°19'26.2" W           Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
Calculations based on Arc (to the left)Arc75.000Central Angle28°38'52.4"Chord74.221Chord BearingN 14°19'26.2" WRadius150.000Bng from Cntr PtN 61°21'07.6" ETangent38.301Elevation Change0.000
Arc         75.000         Ćentral Angle         28°38'52.4"           Chord         74.221         Chord Bearing         N 14°19'26.2" W           Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
Chord         74.221         Chord Bearing         N 14°19'26.2" W           Radius         150.000         Bng from Cntr PtN 61°21'07.6" E           Tangent         38.301         Elevation Change         0.000
Radius 150.000 Bng from Cntr PtN 61°21'07.6" E Tangent 38.301 Elevation Change 0.000
Tangent 38.301 Elevation Change 0.000
OS N 61°21'07.6" E 20.000 From Base Point 3
4 1081.50234 2149.18904 0.000
OS S 61°21'07.6" W 20.000 From Base Point 3
5 1062.32532 2114.08573 0.000
OS N 61°21'07.6" E 50.000 From Base Point 3
6 1095.88511 2175.51651 0.000
OS S 61°21'07.6" W 50.000 From Base Point 3
7 1047.94255 2087.75826 0.000
Exit offsets, resume at point
Page 1/1 Line 6 Col 31

Section 10

### 10.13 Best Fit Curve (BC) FUNCTION: The **Best Fit Curve** routine is used to compute the center point of a curve that best fits a series of points. To access the **Best Fit Curve** routine, press AtC, B, or type BC. **Points** Type in individual point numbers or a point string and press *et al.* **Point on Line** Type in a point number that will be assigned to a location marking What Happens Next "Sight" Survey will respond by computing and printing the coordinates of the best fit curve center point, and the radius length of the curve. Example **Enter and Assign** the coordinate data for points 1 through 8 as shown below, then compute a **Best Fit Curve** through curve center point 9. Text Output _ 🗆 × Point Direction Distance Northing Easting Elevation Arial . 0. 11. 2 16 ____ - L Assign 1115.00000 1910.00000 0.000 1 1935.00000 1131.00000 0.000 2 3 1132.00000 1965.00000 0.000 4 1140.00000 1997.00000 0.000 5 1140.00000 2028.00000 0.000 1134.00000 2051.00000 0.000 6 1099.00000 2103.00000 0.000 7 2072.00000 8 1130.00000 0.000 Best fit to a curve for points: 1-8

Radius: 150.113 Center Point:

9

992.43886

Page

1/1

2000.24974

1

Line

0.000

Col

74



# Section 11 The <u>M</u>ISC Menu

 Intersections
 ▲

 Area
 ▶

 Pre-determined Area
 (PD)

 Measure a Distance
 (MD)

 Measure an Angle
 (MA)

 Coordinate Transformation
 (CT)

Pop-up Calculator (PC)

The <u>Misc</u> menu contains many functions that generally don't fit into one of the other menu categories. Here, among other things, you will find the intersection routines, area and pre-determined area routines, and routines used to rotate and scale coordinates.

## 11.01 <u>Intersections [™]>Arc-Arc</u> (AA)

**FUNCTION:** The <u>Arc-Arc Intersection</u> routine is used to calculate the coordinates of a point generated by the intersection of two arcs.

To access the <u>Arc-Arc Intersection</u> routine, type **AA** in any text box, or press Att,  $\square$ ,  $\square$ .


From Point	This is the currently occupied point, also the arc PC. If you have an occupied point, this box will automatically be filled. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
1st Cntr Pt	Enter the center point of the first arc. After the acceptance of a point number the program will inverse the distance from the first center point to the PC to establish the first radius distance.
Inter. Point	Enter the number of the intersection point.
2nd Cntr Pt	Enter the center point of the second arc. After the acceptance of a point number the program will inverse the distance from the second center point to the PT to establish the second radius distance.
Close Point	Enter the number of the closing point.
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired

solution by pressing or clicking  $\triangle$  or  $\square$ . The bearing and distance given in the solution is for the chord.

Sel	ect intersection	point A or B
	Point A	Point B
North:	9849.74562	10043.41205
	20199.80896	20246.20193
Bearing:	s 24°01'42.9″ E	s 47°30'00.0″ E
Distance:	437.189	304.381
A	B	Cancel

"Sight" Survey will print the Central Angle, Radius, Arc, Tangent Length, Chord and Chord Bearing from the PC to the intersection point, the intersection point number, ID, Northing and Easting, and the Central Angle, Radius, Arc, Tangent Length, Chord and Chord Bearing from the intersection point to the closing point. The closing point becomes the currently occupied point (P1), and the bearing from the closing point to the center point of the second arc becomes the reference bearing.

**Enter & Assign** point 1 (PC - point P1 below), point 3 (closing point), point 4 (1st center point), and point 5 (2nd center point). **Start** at point 1 and perform an **Arc-Arc Intersection** to determine point 2. Select solution **B**.



Text Output				_ 🗆 🗵
Point Dire	ction Distanc	e Northing	Easting	Elevation
Arial 💌 14		B Z U ABC =		÷ ¶ 🖪
		3 ,  4		
÷ · ·	<u> </u>		T. T.	
Assigned points				<b>_</b>
1		10249.04867	20021.78894	0.000
3		9837.90759		0.000
4		10000.00000		0.000
5		9868.41207	20549.31084	0.000
Start				
1		10249.04867	20021.78894	0.000
From Point: 1	1st Ctr Pt:			
Inter. Point: 2	2nd Ctr Pt		ose Point: 3	
AA To Cntr. Pt.	S 5°00'00.0"			
4		10000.00000		0.000
Arc	327.249	Central /		0.00'
Chord	304.381		earing S 47°30	
Radius	250.000		n Cntr PtN 80°00	
Tangent	191.832		n Change	0.000
AA To Cntr. Pt.	S 60º00/00 0"	10043.41205	20246.20193	0.000
AA TO Chtr. Pt.	5 80 00 00.0"	⊨ 9868.41207	20549.31084	0.000
Arc	213.803			0.000
Chord	213.803		earing S12°30	
Radius	350.000		1 Cntr PtS 85°00	
Tangent	110.355		n Change	0.000
3	110.000	9837.90759		
·				<b>•</b>
		Page 1/1	Line 7	Col 1

## 11.02

## Intersections PArc-Bearing (AB)

Enter the center point of the arc.

**FUNCTION:** The A<u>r</u>**c**-Bearing Intersection routine is used to calculate the coordinates of a point generated by the intersection of an arc with a line of known bearing.

To access the A<u>r</u>c-Bearing Intersection routine, type AB in any text box, or press Att M,  $\square$ ,  $\square$ .

This is the currently occupied point, in this case the PC of the arc. If you have an occupied point, this box will automatically be filled for you. Changing the **From Point** is equivalent to running the **Go To** routine.

**Center Point** 

From Point


Inter. PointEnter the number of the intersection point.BearingEnter a bearing, angle, deflection or azimuth, or recall a bearing<br/>between any two points in memoryClose PointEnter the number of the closing point of the intersection.What Happens Next"Sight" Survey will calculate the solution(s). If there are two

"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired solution by pressing or clicking  $\triangle$  or  $\square$ . The bearing and distance given in the solution is for the chord.

Choose Intersection Poi	nt		×
North: East:		point A or B Point B 10043.41205 20246.20193 s 47°30'00.0" E 304.381	
A	<u>B</u>	<u>C</u> ancel	

"Sight" Survey will print the Central Angle, Radius, Arc, Tangent Length, Chord and Chord Bearing from the PC to the intersection point, the intersection point number, ID, Northing and Easting, and the bearing and horizontal distance from the intersection point to the closing point. The closing point becomes the currently occupied point (P1), and the bearing from the intersection point to the closing point becomes the reference bearing.

Enter & Assign point 1 (PC - point P1 below), point 4 (curve center point), and point 5 (closing point). Start at point 1 and perform an Arc-Bearing Intersection to determine point 2. Use a bearing of 60°SE. Select solution B.



Text Output Point Dir	ection Distance	e Northing	Easting	_□× Elevation
Arial 🔽 14		B Z U ABC =		
<u>-  0    1</u>	<u>+  ²  </u>	<u> 3 4</u> t*	····	
Assigned points				<u> </u>
1		10249.04867	20021.78894	0.000
3		9837.90759	20200.64269	0.000
4		10000.00000	20000.00000	0.000
5		9868.41207	20549.31084	0.000
Start				
1		10249.04867	20021.78894	0.000
From Point: 1	Center Poi			
Inter. Point: 2	Bearing: 6		ose Point: 5	
AB To Cntr. Pt.	S 5°00'00.0" \			
4		10000.00000	20000.00000	0.000
Arc	327.249		Angle 75°00	
Chord	304.381		earing S 47°30	
Radius	250.000		n Cntr PtN 80°00	
Tangent	191.832		n Change	0.000
2		10043.41208	20246.20193	0.000
AB \$ 60°00'00	0.0"E 350.000			
5		9868.41207	20549.31084	0.000 🖵
		Page 1/1	Line 8	Col 1

11.03

## Intersections ♣Arc-Distance (AD)

**FUNCTION:** The **Arc**-**Distance Intersection** routine is used to calculate the coordinates of a point generated by the intersection of an arc with a line of known distance.


To access the Arc-Bearing Intersection routine, type AD in any text box, or press Att M,  $\square$ , B.

From Point	This is the currently occupied point, in this case the PC of the arc. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Center Point	Enter the center point of the arc.
Inter. Point	Enter the number of the intersection point.
Distance	Enter the horizontal distance, or recall a distance between two existing points. Do not enter a slope distance.
Close Point	Enter the number of the closing point of the intersection problem.
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired solution by pressing or clicking A or B. The bearing and distance given in the solution is for the chord.

<b>Choose Intersection Poi</b>	nt		$\times$
Sel	ect intersection Point A	point A or B Point B	
East:	9849.74562 20199.80896 s 24°01'42.9″ E	10043.41205 20246.20193 s 47°30'00.0″ E 304.381	
A	B	<u>C</u> ancel	

"Sight" Survey will print the Central Angle, Radius, Arc, Tangent Length, Chord and Chord Bearing from the PC to the intersection point, the intersection point number, ID, Northing, Easting and elevation, and the bearing, horizontal distance, and difference in elevation from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the intersection point to the closing point becomes the reference bearing.

Enter & Assign point 1 (PC - point P1 below), point 4 (curve center point), and point 5 (closing point). Start at point 1 and perform an Arc-Distance Intersection to determine point 2. Use a distance of 350'. Select solution B.



🌉 Text Output				
Point Direc	tion Distance	Northing	Easting E	Elevation
Arial 🔽 14		B <u>Z U</u> ABC =		<b>T</b>
<u>- 10</u>		1 <u>3 </u>	<u></u>	···· <u>·</u> ⁶ ·····
Assigned points				
1		10249.04867	20021.78894	0.000
4		10000.00000	20000.00000	0.000
5		9868.41207	20549.31084	0.000
Start				
1		10249.04867	20021.78894	0.000
From Point: 1	Ctr Point: 4			
Inter. Point: 2*	Distance: 3		ose Point: 5	
AD To Cntr. Pt.	S 5°00'00.0" W			
4		10000.00000		0.000
Arc	327.249	Central A		
Chord	304.381		earing S47°30'	
Radius	250.000		Cntr PtN 80°00	
Tangent	191.832	Elevatior	n Change	0.000
2		10043.41204	20246.20193	0.000
AD S 60°00'00.0	"E 350.000			
5		9868.41207	20549.31084	0.000
				-
		Page 1/1	Line 1	Col 1

11.04	<u>Intersections [®]B</u> earing-Arc (BA)		
	<b>FUNCTION:</b> The <b>Bearing-Arc Intersection</b> routine is used to calculate the coordinates of a point generated by the intersection of a line of known bearing with an arc.		
	To access the <b>Bearing-Arc Intersection</b> routine, type <b>BA</b> in any text box, or press $AitM$ , $\square$ , $\square$ .		
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.		
Bearing	Enter the bearing, angle, deflection or azimuth in your pre- specified format, or recall a bearing between any two points in memory.		
Inter. Point	Enter the number of the intersection point.		
Center Point	Enter the center point of the arc.		
Close Point	Enter the number of the closing point of the intersection problem.		
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired solution by pressing or clicking $\triangle$ or $\square$ . The bearing and distance given in the solution is for the chord.		
	Choose Intersection Point		
	Select intersection point A or B           Point A         Point B           North:         9849.74562         10043.41205           East:         20199.80896         20246.20193           Bearing:         \$ 24°01'42.9" E         \$ 47°30'00.0" E           Distance:         437.189         304.381		

A


"Sight" Survey will print the Central Angle, Radius, Arc, Tangent Length, Chord and Chord Bearing from the PC to the intersection point, the intersection point number, ID, Northing and Easting, and

<u>B</u>

<u>C</u>ancel


the bearing and horizontal distance from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the intersection point to the closing point becomes the reference bearing.

Enter & Assign point 1 (point P1 below), point 3 (closing point), and point 5 (arc center point). Start at point 1 and perform an Bearing-Arc Intersection to determine point 2. Use a distance of 47°30′SE. Select solution B.



Fext Output	<i></i>			
Point Dire	ction Distance	Northing	Easting E	Elevation
Arial 💌 14		₿ ℤ Щ ѧв∈ =		¶ <b>T</b> e
• 0		3 4	····· <u>·</u> ··· ¹⁵ ······	
Assigned points				<b>_</b>
1		10249.04867	20021.78894	0.000 —
4		10000.00000	20000.00000	0.000
5		9868.41207	20549.31084	0.000
Start				
1		10249.04867	20021.78894	0.000
From Point: 1	Bearing: 4	7.30se		
Inter. Point: 2*	Center Poir	nt:5 Clo	ose Point: 3	
BA S 47°30'00.	0"E 304.381			
2			20246.20193	0.000
BA To Cntr. Pt.	S 60°00'00.0" E			
5		9868.41207	20549.31084	0.000
Arc	213.803		Angle 35°00'	
Chord	210.494		earing S 12°30'	
Radius	350.000		1 Cntr PtS 85°00'	00.0" W
Tangent	110.355		n Change	0.000
3		9837.90759	20200.64269	0.000
				-
		Page 1/1	Line 1	Col 1

_ 11.05	Intersections �Bearing-Bearing (BB)
	<b>FUNCTION:</b> The <b>Bearing-Bearing Intersection</b> routine is used to calculate the coordinates of a point generated by the intersection of two lines of known bearing.
	To access the <b>Bearing-Bearing Intersection</b> routine, type <b>BB</b> in any text box, or press $Att M$ , $\Box$ , $\Xi$ .
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Bearing	Enter the bearing, angle, deflection or azimuth in your pre- specified, or recall a bearing between any two points in memory.
Inter. Point	Enter the number of the intersection point.
Close Bng	Enter the bearing, angle, deflection or azimuth in your pre- specified, or recall a bearing between any two points in memory.
Close Point	Enter the number of the closing point of the intersection problem.
What Happens Next	"Sight" Survey will print the bearing and horizontal distance from the currently occupied point to the intersection point, the intersection point number, ID, Northing and Easting, and the bearing and horizontal distance from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the intersection point to the closing point becomes the reference bearing.
Example	Enter & Assign point 1 (point P1 below) and point 3 (closing point). Start at point 1 and perform an Bearing-Bearing Intersection to determine point 2. Use an initial bearing of 47°30'SE., and a final bearing of 12°30'SW.



### 11.06

## Intersections �Bearing-Distance (BD)

**FUNCTION:** The **Bearing-Distance Intersection** routine is used to calculate the coordinates of a point generated by the intersection of a line of known bearing with a line of known distance.

To access the **Bearing-Distance Intersection** routine, type **BD** in any text box, or press Alt M,  $\square$ ,  $\square$ .

This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the **From Point** is equivalent to running the **Go To** routine.

**From Point** 

Bearing	Enter the bearing, angle, deflection or azimuth in your pre- specified format, or recall a bearing between any two points in memory.	
Inter. Point	Enter the number of the intersection point.	
Close Dist	Enter the horizontal distance, or recall a distance between two existing points. Do not enter a slope distance.	
Close Point	Enter the number of the closing point of the intersection problem.	
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired solution by pressing or clicking $\triangle$ or $\square$ .	
	Choose Intersection Point	
	Select intersection point A or B           Point A         Point B           North:         10234.92317         10043.41208           East:         19914.49500         20246.20193	

Bearing: N 60°00'00.0" W

Distance: 733.022


"Sight" Survey will print the bearing and horizontal distance from

N 60°00'00.0″ W

350.000

the currently occupied point to the intersection point, the intersection point number, ID, Northing and Easting, and the bearing and horizontal distance from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the intersection point to the closing point becomes the reference bearing.

**Enter & Assign** point 5 (point P1 below) and point 4 (closing point P3). **Start** at point 5 and perform an **Bearing-Distance Intersection** to determine point 2. Use an initial bearing of 60 ° NW, and a distance of 250'. Select solution B.



11.07

## Intersections [®]Distance-Arc (DA)

**FUNCTION:** The **Distance-Arc Intersection** routine is used to calculate the coordinates of a point generated by the intersection of an arc with a line of known bearing.

To access the **<u>Distance-Arc Intersection</u>** routine, type **DA** in any text box, or press Att M,  $\square$ ,  $\square$ .

From Point

This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the **From Point** is equivalent to running the **Go To** routine.


Distance	Enter the horizontal distance, or recall a distance between two existing points. Do not enter a slope distance.
Inter. Point	Enter the number of the intersection point.
Arc Cntr Pt	Enter the center point of the arc.
Close Point	Enter the number of the closing point of the intersection problem.
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired

solution by pressing or clicking  $\triangle$  or  $\square$ .

Choose Intersection Point  $\times$ Select intersection point A or B Point A Point B 9849.74562 North: 10043.41205 20199.80896 20246.20193 East: Bearing: S 24°01'42.9" E s 47°30'00.0″ E Distance: 437.189 304.381 A B Cancel

"Sight" Survey will print the bearing, horizontal distance, and the difference in elevation from the currently occupied point to the intersection point, the intersection point number, ID, Northing, Easting and elevation, and the Central Angle, Radius, Arc, Tangent, Chord and Chord Bearing from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the closing point to the center point of the arc becomes the reference bearing.

Enter & Assign point 4 (point P1 below) and point 3 (closing point), and point 5 (arc center point). Start at point 4 and perform a Distance-Arc Intersection to determine point 2. Use a distance of 250'. Select solution B.



Point         Direction         Distance         Northing         Easting         Elevation           Arial         14         Image: I
↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑         ↑
4         10000.00000         20000.00000         0.000           3         9837.90759         20200.64269         0.000           5         9868.41207         20549.31084         0.000           Start         10000.00000         20000.00000         0.000           From Point: 4         Distance: 250         0.000         0.000           Int. Point: 2         Arc Ctr Pt: 5         Close Point: 3         0.000           2         10043.41205         20246.20194         0.000           DA N 80°00'00.0" E         20000.000         0.000         0.000           2         10043.41205         20246.20194         0.000           DA To Cntr. Pt.         S 60°00'00.0" E         9868.41207         20549.31084         0.000
4         10000.00000         20000.00000         0.000           3         9837.90759         20200.64269         0.000           5         9868.41207         20549.31084         0.000           Start         10000.00000         20000.00000         0.000           From Point: 4         Distance: 250         0.000         0.000           Int. Point: 2         Arc Ctr Pt: 5         Close Point: 3         0.000           2         10043.41205         20246.20194         0.000           DA N 80°00'00.0" E         20000.000         0.000         0.000           2         10043.41205         20246.20194         0.000           DA To Cntr. Pt.         S 60°00'00.0" E         9868.41207         20549.31084         0.000
3         9837.90759         20200.64269         0.000           5         9868.41207         20549.31084         0.000           Start         10000.0000         20000.00000         0.000           From Point:         4         10000.0000         20000.00000         0.000           From Point:         2         Arc Ctr Pt:         5         Close Point:         3           DA         N 80°00'00.0" E         250.000         10043.41205         20246.20194         0.000           DA To Cntr. Pt.         S 60°00'00.0" E         5         9868.41207         20549.31084         0.000         0.000
5         9868.41207         20549.31084         0.000           Start         4         10000.00000         20000.00000         0.000           From Point: 4         Distance: 250         10000.00000         20000.0000         0.000           Int. Point: 2         Arc Ctr Pt: 5         Close Point: 3         2         2         10043.41205         20246.20194         0.000           DA To Cntr. Pt.         S 60°00'00.0" E         5         9868.41207         20549.31084         0.000
Start         10000.00000         20000.00000         0.000           From Point: 4         Distance: 250         0.000         0.000         0.000           Int. Point: 2         Arc Ctr Pt: 5         Close Point: 3         0.000         0.000         0.000           DA         N 80°00'00.0" E         250.000         0.000         0.000         0.000         0.000           DA         To Cntr. Pt.         S 60°00'00.0" E         9868.41207         20549.31084         0.000
4         10000.00000         20000.00000         0.000           From Point: 4         Distance: 250         100         100         100           Int. Point: 2         Arc Ctr Pt: 5         Close Point: 3         100         100         100           DA         N 80°00'00.0" E         250.000         2         10043.41205         20246.20194         0.000           DA         To Cntr. Pt.         S 60°00'00.0" E         9868.41207         20549.31084         0.000
From Point:         4         Distance:         250           Int. Point:         2         Arc Ctr Pt:         5         Close Point:         3           DA         N 80°00'00.0" E         250.000         2         10043.41205         20246.20194         0.000           DA         To Cntr. Pt.         S 60°00'00.0" E         5         9868.41207         20549.31084         0.000
Int. Point: 2 Arc Ctr Pt: 5 Close Point: 3 DA N 80°00'00.0" E 250.000 2 10043.41205 20246.20194 0.000 DA To Cntr. Pt. S 60°00'00.0" E 5 9868.41207 20549.31084 0.000
DA         N 80°00'00.0" E         250.000         2         10043.41205         20246.20194         0.000           DA         To Cntr. Pt.         S 60°00'00.0" E         5         9868.41207         20549.31084         0.000
2 10043.41205 20246.20194 0.000 DA To Cntr. Pt. S 60°00'00.0" E 5 9868.41207 20549.31084 0.000
DA To Cntr. Pt. S 60°00'00.0" E 5 9868.41207 20549.31084 0.000
5 9868.41207 20549.31084 0.000
5 9868.41207 20549.31084 0.000
Arc 213.803 Central Angle 35°00'00.0"
Chord 210.494 Chord Bearing S 12°30'00.0" W
Radius 350.000 Bng from Cntr PtS 85°00'00.0" W
Tangent 110.355 Elevation Change 0.000
3 9837.90759 20200.64269 0.000
Page 1/1 Line 13 Col 1

11.08	Intersections �Distance-Bearing (DB)
	<b>FUNCTION:</b> The <b>Distance-Bearing Intersection</b> routine is used to calculate the coordinates of a point generated by the intersection of a line of known distance with a line of known bearing.
	To access the <b>Distance-Bearing Intersection</b> routine, type <b>DB</b> in any text box, or press <b>AttM</b> , <b>(1)</b> , <b>S</b> .
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Distance	Enter the horizontal distance, or recall a distance between two existing points. Do not enter a slope distance.
Inter. Point	Enter the number of the intersection point.
Close Bng	Enter the bearing, angle, deflection or azimuth, or recall a bearing between any two points in memory.
Close Point	Enter the number of the closing point of the intersection problem.
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired solution by pressing or clicking A or B.
	Choose Intersection Point
	Select intersection point A or B           Point A         Point B           North:         10234.92317         10043.41208           East:         19914.49500         20246.20193           Bearing:         N 20°00'00.0" W         N 80°00'00.0" E           Distance:         250.000         250.000

A


"Sight" Survey will print the bearing, horizontal distance, and the difference in elevation from the currently occupied point to the intersection point, the intersection point number, ID, Northing,

<u>B</u>

<u>C</u>ancel

Easting and elevation, and the bearing, horizontal distance, and the difference in elevation from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the intersection point to the closing point becomes the reference bearing.

Enter & Assign point 4 (point P1 below) and point 5 (closing point). Start at point 4 and perform a Distance-Bearing Intersection to determine point 2. Use a distance of 250', and a bearing of 60°SE Select solution A.



Example

11.09	<u>Intersections [®]Distance-Distance</u> (DD)
	<b>FUNCTION:</b> The <b>Distance-Distance Intersection</b> routine is used to calculate the coordinates of a point generated by the intersection of to lines of known distance.
	To access the <b>Distance-Distance Intersection</b> routine, type <b>DD</b> in any text box, or press $Alt[M]$ , $\square$ , $\square$ .
From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Distance	Enter the horizontal distance, or recall a distance between two existing points. Do not enter a slope distance.
Inter. Point	Enter the number of the intersection point.
Close Dist	Enter the horizontal distance, or recall a distance between two existing points. Do not enter a slope distance.
Close Point	Enter the number of the closing point of the intersection problem.
What Happens Next	"Sight" Survey will calculate the solution(s). If there are two solutions to the problem, you will be prompted to select the desired solution by pressing or clicking $\triangle$ or $\square$ .
	Choose Intersection Point Select intersection point A or B Point A Point B North: 10234.92317 10043.41208

East:

Δ

19914.49500

<u>B</u>

"Sight" Survey will print the bearing, horizontal distance, and the difference in elevation from the currently occupied point to the intersection point, the intersection point number, ID, Northing, Easting and elevation, and the bearing, horizontal distance, and the

Bearing: N 20°00'00.0" W

Distance: 250.000


20246.20193

N 80°00'00.0" E 250.000

<u>C</u>ancel

difference in elevation from the intersection point to the closing point. The closing point becomes the currently occupied point, and the bearing from the intersection point to the closing point becomes the reference bearing.


Enter & Assign point 4 (point P1 below) and point 5 (closing point). Start at point 4 and perform a Distance-Distance Intersection to determine point 2. Use distances of 250' and 350' Select solution B.



Section 2015				_ <b>_</b> ×
Point Direction	on Distance	Northing	Easting	Elevation
Arial 🔽 14 💌		8 <u>Z U</u> ABC		† ¶ <b>Te</b>
· [0 <u>1</u> <u>1</u>		3 <u> 1</u>	1 <u></u>	·····
Assigned points				<b>_</b>
4	1	0000.00000	20000.00000	0.000 —
5		9868.41207	20549.31084	0.000
Start				
4	1	0000.00000	20000.00000	0.000
From Point: 4	Distance: 28	50		
Inter. Point: 2	Close Dist: 3	350 C	Close Point: 5	
DD N 80°00'00.0"	E 250.000			
2	1	0043.41205	20246.20194	0.000
DD S 60°00'00.0"	E 350.000			
5		9868.41207	20549.31084	0.000
		Page 1/1	Line 1	Col 1

Example

11.10	Intersections ३ <u>P</u> erpendicular Offset (PO)
	<b>FUNCTION:</b> The <b>Perpendicular Offset</b> routine is used to calculate the right angle offset horizontal distance from a point (or points) to a known baseline. The horizontal distance along the baseline from the currently occupied point to the point(s) of intersection is also calculated.
	To access the <u>Perpendicular Offset</u> routine, type PO in any text box, or press $Att M$ , $\square$ , $P$ .
Base Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>Base Point</b> is equivalent to running the <b>Go To</b> routine.
Bearing	Type the bearing of the baseline as it travels away from the base point. This bearing may also be a recalled bearing.
Offset Pts	Type a point number or point string.
What Happens Next	"Sight" Survey will compute report the baseline and offset distance. Continue entering points as needed. If you have entered a point string and the routine encounters an undefined point, the point will be skipped.
	Coordinates of the last intersection point are not retained. You can enter this point using <b>Edit Coordinates</b> ( <b>EC</b> - page 225).
(	The tolerance used to determine if a point should be considered to be on the line during a perpendicular offset is user-defineable. An entry labeled <b>POBNGDIFF</b> in the <b>COGO.INI</b> file controls the tolerance. If the difference between the input bearing and the bearing from the base point to the OS point is less than this value, the point is considered to be on the line. The default value for <b>POBNGDIFF</b> is 0.000001 degrees. If you wish to change this default, you must use a text editor to do so.
Example	Except for stationing, this routine functions identically to the Line Station & Offset Intersection discussed on page 331.




## 11.11 Intersections POffset Intersection (OI) FUNCTION: The Offset Intersection routine is used to calculate the location of a point generated by the intersection of two lines lying at known perpendicular distances from two lines of known bearing. To access the Offset Intersection routine, type OI in any text box, or press Alt M, 1, O. From Point This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the From Point is equivalent to running the Go To routine. Inter. Point Enter the number of the intersection point. 1st Bng Enter the bearing, angle, deflection or azimuth, or recall a bearing between any two points in memory. 1st Dist. Enter a positive or negative horizontal offset distance. The sign of the offset distance is determined by facing the same direction as the 1st bearing and noting whether the intersection point will lie to the right or left of the line. Do not enter a slope distance. 2nd Bng Enter the bearing, angle, deflection or azimuth, or recall a bearing between any two points in memory. The 2nd offset bearing must lie clockwise from the 1st bearing at an angle of less than 180 degrees.

2nd Dist.

Enter a positive or negative horizontal offset distance. The sign of the offset distance is determined by facing the same direction as the 2nd bearing and noting whether the intersection point will lie to the right or left of the line. Do not enter a slope distance.

What Happens Next"Sight" Survey will print the Northing and Easting of the offset<br/>intersection point, along with the intersection point number and ID.<br/>As a matter of record, the program will also print the 1st and 2nd<br/>offset bearings and distances, and also the Northing, Easting and<br/>elevation of the point used to set the intersection, along with its<br/>point number and ID.

ExampleEnter & Assign point 4 (point P1 below). Start at point 4 and<br/>perform an Offset Intersection to determine point 2. Your first<br/>bearing and offset are 80°SE and 40' right. Your second bearing<br/>and offset are 40°SW and -25' left.



Text Output Point Direction Dista	ance Northing	Easting E	Levation
	<u></u> 13	·····	
Assigned points			
4	10000.00000	20000.00000	0.000
Start			
4	10000.00000	20000.00000	0.000
Offset Intersection Calculation			
OI S 80°00'00.0" E 40.	000		
OI S 40°00'00.0" W -25.	000		
By Offset Intersection			
5	9959.60513	19998.73986	0.000
Resuming at Point			
4	10000.00000	20000.00000	0.000
	Page 1/1	Line 1	Col 1

11.12	Intersections <b>∛</b> Line Station and Offset (LS)		
3	<b>FUNCTION:</b> The Line Station and Offset routine computes the perpendicular offset distance from a point to a defined baseline and also the baseline station at the point of perpendicular intersection.		
	To access the Line Station and Offset routine, type $LS$ in any text box, or press $ARM$ , $\square$ , $\square$ .		
Base Point	Enter the point number of the beginning of the baseline. This point should also contain the beginning station number as a part of the point name. If no stationing data is available, the station will be assumed to be $0+00$ . Stationing may be entered through the Enter Station routine (ES - page 234). This point defaults to the currently occupied point. Changing the Base Point is equivalent to running the Go To routine.		
Bearing	Enter the bearing of the baseline as it travels away from the base point. This bearing may also be a recalled bearing.		
Offset Pts	Enter a point number or point string.		
What Happens Next	"Sight" Survey will print the station and offset distance. Continue entering points as needed.		
Example	Enter & Assign points 1 through 4. Start at point 1 and perform a Line Station & Offset Intersection to determine the station and offset at points 2, 3 and 4. Your base bearing is 88°NE.		
	<ul> <li>Offset Point</li> </ul>		
	Computes Bearing & Distance from Intersection Point to Offset Point		
	Base Point (P1) at Known Station Known Bearing 90°		
	Computes Distance and Stationing		

Computes Distance and Stationing from Base Point to intersection point

🍹 Text Output					_ 🗆 ×
Point	Direction	Distance		Easting	Elevation
Arial	▼ 14 <b>▼</b> 🔳		} <u>Z</u> <u>U</u> ABC ;		¶ T <u>a</u>
- <u>l</u> a	1 2.				<u>6</u>
⇒ jt			T.	T.	T. 4
Assigned po	oints	1	0255.00000	19144.00000	0.000
2			0255.00000		0.000
3			9975.00000		0.000
· ·		1	0000.00000	20000.00000	0.000
Start					
			0255.00000	19144.00000	0.000
	°00'00.0" E	497.141			
	4+97.141		0272.34998		0.000
	°00'00.0" E			the line	
2		1	0010.00000	19650.00000	0.000
Go to					
1			0255.00000	19144.00000	0.000
	°00'00.0" E	745.768			
STA.		1	0281.02691	19889.31330	0.000
LS S2	°00'00.0" E	306.213	Right of	the line	
3			9975.00000	19900.00000	0.000
Go to					
1		1	0255.00000	19144.00000	0.000
LS N 88	°00'00.0" E	846.579			
STA.	8+46.579	1	0284.54519	19990.06346	0.000
LS S2	°00'00.0" E	284.719	Right of	the line	
4		1	0000.00000	20000.00000	0.000
Go to					
1		1	0255.00000	19144.00000	0.000
			Page 1/1	Line 2	Col 4
2					

## Intersections PArc Station and Offset (AS)

**FUNCTION:** The **Arc Station and Offset** routine computes the perpendicular offset distance from a point to a defined arc and also the baseline station at the point of intersection normal to the arc.

To access the Arc Station and Offset routine, type AS in any text box, or press Att,  $\square$ ,  $\square$ .

Enter the point number of the beginning of the arc baseline and press enter. This point should also contain the beginning station number as a part of the point name. If no stationing data is available, the station will be assumed to be 0+00. Stationing may

**Base Point** 

be entered through the **Enter Station** routine (**ES** - page 234). This point defaults to the currently occupied point. Changing the **Base Point** is equivalent to running the **Go To** routine.

Enter the point number of the center point of the arc.

Center Point

What Happens Next


**Offset Pts** 

Example

Enter a point number or point string.

"Sight" Survey will print the station, offset distance, offset point elevation, and the curve data to the arc station point. The curve data includes the delta angle, arc length and radius. Continue entering points as needed.

Enter & Assign points 1, 2, 4 (PC - point P1 below), and 5 (center point). Start at point 4 and perform an Arc Station & Offset Intersection to determine the station and offset at points 1 and 2.



Text Output				
Point Direction	Distance	Northing	Easting	Elevation
Arial 💌 14 💌		8 <u>7</u> <u>U</u> ABC 1		÷¶1
		3		
▶ ↑t		f.	<b>1</b> .	<u>↑</u> •
Assigned points				
		9976.00000		
2		0004.00000		
4		0000.00000		
l v		9750.00000	20022.00000	0.000
Start		0000.00000	20000.00000	0.000
Arc Offset point from PC	-			0.000
Central Angle		ign center po	ini 5	
Radius	2 29 4 3.9			
Arc	10.931			
Offset @ Station				
Sta. Coords		10000.72081	20010.90616	
Offset From Arc				
1		9976.00000	20012.00000	0.000
Resuming at point 4				
4	1	0000.00000	20000.00000	0.000
Arc Offset point from PC	point 4 throu	ugh center po	int 5	
Central Angle				
Radius	250.966			
Arc	139.177			
Offset @ Station	1+39.177			
Sta. Coords		9974.11688	20134.94079	
Offset From Arc	33.463		~~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	
2	1	0004.00000	20150.00000	0.000
Resuming at point 4				0.000
4	1	0000.00000	20000.00000	0.000
		Page 1/1	Line 4	Col 1
P				

## <u>A</u>rea ₱<u>A</u>rea Print Out (AR)

**FUNCTION:** The Area Print Out routine is used to obtain the area in square feet (or meters) of a closed plane figure.

To access the Area Print Out routine, type AR in any text box, or press Att M, A, A.

What Happens NextIf you have specified your units of area measurement as Acres &<br/>Square Feet (on the COGO Configuration Menu) the program will<br/>print the area in square feet and acres. Likewise, you may choose<br/>to report the area in Hectares & Square Meters or in Cuerdas &<br/>Square Meters.

After reporting the area, the internal area accumulator is cleared to make ready for the next calculation. The starting point for the next routine is the same as the last point number entered prior to calling the area routine. If you wish to begin from a different point, use the <u>Start At</u> routine (ST - page 235).

You may obtain the area of any closed figure, including curves, provided you began your traversed and/or inversed path with the **Start At** routine.

If the subject figure contains any curved segments having a central angle of greater than 180 degrees, you must use the **Inverse Obtuse Curve** routine (OC - page 291).

¥


Area calculations are valid only for closed figures. If the Northing and Easting coordinates of your starting point do not match the Northing and Easting coordinates of your ending point, the area calculated and reported by this routine will be grossly inaccurate.



If you want to place the area text inside a polygon, use the Start [™] Tools [™] Polygon Area function described in Section 28.16 in the Drawing Window Reference Manual.



**Enter & Assign** points 1, 2, 3, and 4. **Start** at point 1 and **Inverse** through points 2, 3, and 4, then back to 1. Type **AR** to get the area.



### Example

🍹 Tex	t Output Point Direction	Distance Northing	Easting	_ □ × Elevation
Arial	▼ 14 ▼			† ¶ <b>Ъ</b>
. 10	 		4	 
•	igned points			
A93	signed points	9794.54000	19731.42000	0.000
	2	10008.73000		0.000
	2 3	9997.4100		0.000
	-			
Sta	4 urt	9769.39000	0 19777.30000	0.000
	1	9794 54000	19731.42000	0 000
IN	N 4°59'51.2" E	215.007		0.000
	2	10008.73000	19750.15000	0.000
IN	S 87°59'53.9" E	324.088		
	3	9997.41000	20074.04000	0.000
IN	S 52°27'38.6" W	374.230		
	4	9769.39000	19777.30000	0.000
IN	N 61°16'11.3" W	52.321		0.000
	1	9794.54000	19731.42000	0.000
		0.01000		0.000
Are	a = 43755.2957 Sq. F	eet or 1.0045 Acres		
	•			
		Page 1/1	Line 1	Col 1

**Point String** 

## Area Point to Point Area (PA)

**FUNCTION:** The <u>Point to Point Area</u> routine is functionally similar to the <u>Area Printout</u> routine, except it is used to obtain an enclosed area without printing out the bearings and distances of the boundaries.

To access the <u>Point to Point Area</u> routine, type **PA** in any text box, or press <u>Att</u>M, <u>A</u>, <u>P</u>.

Type in a point number string and press enter. *You cannot key in individual points during this routine.* All entries must be in the form of a point number string.

Unless your last leg is an arc, it is not necessary that your ending point be the same as your starting point, since "Sight" Survey will automatically return to the starting point. If your last leg is an arc, you must include a reference to the starting point after the arc. For example, in the string **7,2,9,8*6,7**, the final **7** tells "Sight" Survey where to stop the arc. If you were obtaining the area of a four sided tract 1,2,3,4, you do not need to place a reference to point 1 after the 4.

Each time you enter this routine, after entering the first point string you will be prompted:



Click Yes to print courses, or No to just print the point string and area. If you elect to print the courses, this routine is no different from the Area Print Out routine. After you have answered this question once, the setting remains in effect until you exit the routine.

What Happens NextIf you have specified your units of area measurement as Acres &<br/>Square Feet (on the COGO Configuration Menu) the program will<br/>print the area in square feet and acres. Likewise, you may choose<br/>to report the area in Hectares & Square Meters or in Cuerdas &<br/>Square Meters.

After reporting the area, the internal area accumulator is cleared to make ready for the next calculation.

You may obtain the area of any closed figure, including curves, provided you began your inversed path with the <u>Start At</u> routine (ST - page 235).


3

If the subject figure contains any curved segments having a central angle of greater than 180 degrees, you must inverse through intermediate points along the arc to break down all curves into segments of less than 180 degrees. This may require the assignment and calculation of intermediate points along the arc. Intermediate points may be calculated by using the Traverse Arc routine (TA - page 303).



If you want to place the area text inside a polygon, use the <u>Start</u> [®] <u>Polygon Area</u> function described in Section 28.16 in the Drawing Window Reference Manual.


Enter & Assign points 2, 6, 7, 8, and 9. Note that you have a curving side from point 7 to point 8. Use Point to Point Area with the point string 7, 2, 9, 8*6, 7 to calculate the area.



🍹 Text Output				
Point Direction	Distance N	lorthing	Easting	Elevation
Arial 🔽 14 💌 🔳		<u>7 ∐</u> AB€ =		
- [0				······
P JT		Т.	Τ.	Т. ◀
Assigned points				<b>_</b>
2	100	08.72490	19750.15230	0 0.000
6	97	29.79040	19725.74870	0 0.000
7	97	94.54300	19731.4138	0 0.000
8	97	69.39430	19777.29020	0 0.000
9	99	97.41440	20074.04130	0 0.000
Point to Point Area				
Boundary: 7,2,9,8*6,7				
Area = 43560.0014 Sq. F	et or 1.0000	Acres		_
	Pa	.ge   1/1	Line 2	Col 1

Example

11.16	P <u>r</u> e-Determined Area <u>∛2</u> Sides Parallel
	<b>FUNCTION:</b> The <b>Pre-Determined Area</b> [™] <b>2 Sides Parallel</b> routine is used to compute the length of three sides of a four sided tract of known area. This routine requires the subject tract to have two sides that are parallel. Additionally, the directions of the non-parallel sides and the coordinates of the end points of one of the parallel line segments must be known. To access the <b>Pre-Determined Area</b> [™] <b>2 Sides Parallel</b> routine, type
1st Base Point	<b>PD2</b> in any text box, or press Alt M, ℝ, ⊇. Enter a point number which defines one end of the base line lying
2nd Base Pt	between points P1 and P2. Enter the point number which defines the other end of the base line.
Pt on line #1	Enter an identifying point number which will lie on the first line
Pt on line #2	Enter an identifying point number which will lie on the second line
1st Bearing	Enter the bearing, angle, deflection or azimuth, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.
2nd Bearing	Enter the bearing, angle, deflection or azimuth, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.
Req'd Area	Enter the required data in square feet (or square meters if metric).
What Happens Next	If a solution is possible, "Sight" Survey will print the bearing and distance data. The required area will also be printed.
Example	Enter & Assign points 1 and 2. Use the Predetermined Area - Two Sides Parallel routine to compute a tract having an area of 76230.00 sq. ft., bounded by these lines: Bearing from P2 to P3 - 5°NE; Bearing from P1 to P4 - 15°NE.



Text 1	Output					
_		rection	Distance	Northing	Easting	Elevation
Arial	14			<u>ℤ</u> <u>Ш</u> АВ-С		÷ ¶ Ta
<u>.  0</u>			······		<u></u>	<u> </u>
Assig	gned points					-
	1		1	0000.0000	20000.0000	0.000 –
	2		1	0008.72490	19750.15230	0.000
Pred	etermined A	rea				
	1		1	0000.00000	20000.0000	0.000
IN	N 88°00'0	0.0" W	250.000			
	2		1	0008.72490	19750.1523	0.000
IN	N 15°00'0	0.0" E	357.351			
	4		1	0353.89967	19842.6416	0.000
IN	S 88°00'0	0.0" E	187.861			
	3		1	0347.34338	20030.3886	0.000
IN	S 5°00'0	0.0" W	348.670			
	1		1	0000.00000	20000.0000	0.000
Area	= 76230.00	00 Sq. Fe	et or 1.750	0 Acres		-
				Page 1/1	Line 1	Col 1

## Pre-Determined Area [®]Line Through a Point

**FUNCTION:** The **Pre-Determined Area** 2 Line Through a**Point** routine is used to compute the length of two sides of a three sided tract of known area. This routine requires the coordinates of the end points of one of the line segments and also the direction of one of the other two line segments.

To access the **Pre-Determined Area Line Through a Point** routine, type **PDL** in any text box, or press **Mt**, , .

**1st Base Point** 

Enter a point number which defines one end of the base line.

2nd Base Pt	Enter the point number which defines the other end of the base line.			
Pt on line #2	Enter an identifying point number which will lie on the line extending from the second base point.			
Bearing	Enter the bearing, angle, deflection or azimuth from the second base point to the point on line #2, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.			
Req'd Area	Enter the required data in square feet (or square meters if metric).			
What Happens Next	If a solution is possible, "Sight" Survey will print the bearing and distance data. The required area will also be printed.			
Example	<b>Enter &amp; Assign</b> points 1 and 2. Use <b>Predetermined Area - Line</b> <b>Through a Point</b> to compute a tract having an area of <b>43560.00</b> sq. ft., bounded by Line 1:2 and a Bearing from P2 to P3 of <b>30°NE</b> .			
	P3 Known Bearing, Compute Distance			

P2 🖋

Known Area

• P1

Known Bearing & Distance



📮 Te	xt Output						×
	Point	Direction	Distance	Northing	Easting	Elevation	
Arial		▼ 14 ▼ <b>≣</b>		} <u>Z</u> <u>U</u> ABC	=== H+ L+		
<u>0</u>		.  1		³		<u></u> , <u> 6</u> ,	╉╌
As	signed p	oints					
	<u>1</u>		1	0000.00000	20000.000	000.0 000	
	2		1	0008.72490	19750.152	30 0.000	
Pre	edetermi	ned Area					
	1		1	0000.00000	20000.000	000.0 000	
IN	N 8	8°00'00.0" W	250.000				
	2		1	0008.72490	19750.152	30 0.000	
IN	N 3	0°00'00.0" E	394.678				
	3		1	0350.52607	19947.491	30 0.000	
IN	S	8°31'10.3" E	354.437				
	1		1	0000.00000	20000.000	000.0 000	
Are	Area = 43560.0000 Sq. Feet or 1.0000 Acres						
				Page 1/1	Line 5	Col 1	
	_			rage 1/1	Life 5		

## P<u>r</u>e-Determined Area <u></u>adial Sides


	<b>FUNCTION:</b> The <b>Pre-Determined Area</b> Radial Sides routine is used to compute the three unknown sides of a four sided tract of known area, when the tract has a curved side of known radius. This routine requires the coordinates of the end points of one of the line segments and also the direction of the straight line segment lying adjacent to the known line segment. The coordinates of the center point of the arc must also be known.		
	To access the <b>Pre-Determined Area</b> $\Rightarrow$ <b>Radial Sides</b> routine, type <b>PDR</b> in any text box, or press <b>Alt M</b> , <b>R</b> , <b>R</b> .		
1st Base Point	Enter a point number which defines one end of the base line.		
2nd Base Pt	Enter the point number which defines the other end of the base line.		
Pt on line #2	Enter an identifying point number which will lie on the line extending from the second base point.		

Pt on Arc #1	Enter an identifying point number which will lie on the arc extending from the first base point.	
Radius Point	Enter center point number which defines the arc extending from point the first base point to the point on arc #1.	
Bng line #2	Enter the bearing, angle, deflection or azimuth from the second base point to the point on line #2, recall a bearing between any two points in memory, or compute the data using the in-line calculator.	
Req'd Area	Enter the required data in square feet (or square meters if metric).	
What Happens Next	If a solution is possible, the program will compute and print the bearing and distance data. The required area will also be printed.	
<b>i</b>	The radial sides solution to a predetermined area problem is actually a trial and error solution which may require from 20	

The radial sides solution to a predetermined area problem is actually a trial and error solution which may require from 20 to 35 incremental calculations. The program assumes that the calculation is completed when the generated area is within 0.0001 square units of the desired area.

**Enter & Assign** points 1 (P1 below), 2 (P2), and 5 (P5 - arc center point). Use **Predetermined Area - Radial Sides** to compute a tract having an area of **43560.00** sq. ft., bounded by Line 1:2 and a Bearing from P2 to P3 of **88°SE**.





Example

落 Text O					
	oint Direction	Distance	Northing	Easting	Elevation
Arial	▼ 14 ▼				T To
10	<u></u>		3 4.		<u> </u>
•	1 1 1		<u> </u>		
Assigned points					
	5 972	9.79040	9725.74870 0	.000	
Start	-		0700 70040	40705 74070	
TR	5 N 5°00'00.0" E	65.000	9729.79040	19725.74870	0.000
	1	65.000	9794,54306	19731.41382	0.000
TR	N 5°00'00.0" E	215.000	5754.54500	15751.41502	0.000
	2	210.000	10008.72492	19750.15231	0.000
Prede	termined Area				
	1		9794.54306	19731.41382	0.000
IN	N 5°00'00.0" E	215.000			
	2		10008.72492	19750.15231	0.000
IN	S 88°00'00.0" E 3	324.086	9997.41446	20074.04131	0.000
IN	S 52°27'42.2" W	374.238	9997.41446	20074.04131	0.000
	4	574.250	9769.39432	19777.29023	0.000
To Cr	ntr.Pt. S52	°27'42.2" V		10777.20020	0.000
	5		9729.79040	19725.74870	0.000
	Arc 5	3.844	Central /	Angle 47°27	'42.2"
		2.317		earing N 61°16	
		5.000		n Cntr PtN 63°36	
	Tangent 2	8.575		n Change	0.000
	1		9794.54306	19731.41382	0.000
Area =	Area = 43560.0007 Sq. Feet or 1.0000 Acres				
			Page 1/1	Line 2	Col 1
,					

## Pre-Determined Area 3>2 Lines Through a Point

FUNCTION: The Pre-Determined Area > 2 Lines Through a Point routine is used to compute the two unknown sides of a three sided tract of known area. This routine requires the coordinates of the intersection point of two of the line segments and also the direction of the two line segments that intersect at the know point.

To access the **Pre-Determined Area** 2 Lines Through a Point routine, type **PDT** in any text box, or press Att M, R, T.

Enter the point number of the intersection of the two lines of known bearing.

11.10

1st Base Point

Ρ3

Compute Bearing and Distance

Bng of line #1	Enter the bearing, angle, deflection or azimuth from the first base point to the point on line #1, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.			
Pt on line #1	Enter an identifying point number which will lie on the first line extending from the base point.			
Bng of line #2	Enter the bearing, angle, deflection or azimuth from the first base point to the point on line #2, recall a bearing between any two points in memory, or compute the correct data using the in-line calculator.			
Pt on line #2	Enter an identifying point number which will lie on the second line extending from the base point.			
Req'd Area	Enter the required data in square feet (or square meters if metric).			
What Happens Next	If a solution is possible, "Sight" Survey will print the bearing and distance data. The required area will also be printed.			
Example	Enter & Assign point 1(P1 below). Use Predetermined Area - 2 Lines Through a Point to compute a tract having an area of 43560.00 sq. ft., bounded by Line 1:2 at a Bearing of 34°SW, and by Line 1:3 at a Bearing of 27°SE.			
	Known Point (P1)			
	Known Bearing, Compute Distance Known Area			

P2 🧹

🐺 Text Output						
Point	Direction	Distance	Northing	Easting	Elevation	
Arial	▼ 14 ▼ 🔳		<u>ℤ</u> <u>Ш</u> АВ€ =		Í ¶ Te	
	. <u> 1 </u>			·····	<u> </u>	
Assigned p	ooints				<b>_</b>	
1 ¹		1	0000.0000	20000.00000	0.000	
Predetermi	ined Area					
1		1	0000.0000	20000.00000	0.000	
IN S3	4°00'00.0" W	315.609				
2			9738.34833	19823.51372	0.000	
IN S8	6°30'00.0" E	320.367				
3			9718.79037	20143.28346	0.000	
IN N2	7°00'00.0" W	315.609				
1		1	0000.00000	20000.00000	0.000	
Area = 435	Area = 43560.0000 Sq. Feet or 1.0000 Acres					
			Page 1/1	Line 2	Col 1	

## Measure a Distance (MD)

**FUNCTION:** The <u>Measure a Distance</u> routine is used to compute and report the value of a distance defined by any two points in the **Drawing** window.

To access <u>Measure a Distance</u>, type MD, or press Alt M, M.

<u>Measure a Distance is a Drawing window function, therefore the</u> prompts appear in the Drawing window command line.

Distance .. enter first point (Space bar to exit)




This routine measures the distance between ANY two points, even points that don't actually exist. It actually measures between any two cursor positions. You may want to set your snap mode to Point mode ( $\underbrace{\begin{subarray}{l} \begin{subarray}{l} \begin{subarray}{l}$ 

Click the cursor on the first point. "Sight" Survey prompts:

Second point

Click the cursor on the first point.

"Sight" Survey will respond by displaying an information box What Happens Next containing the measured distance, the difference in Northing, the difference in Easting, and the bearing between the points.



Click **OK**. "Sight" Survey prompts:

Distance .. enter first point (Space bar to exit)

Click the cursor on another point, or cancel this routine by pressing Esc, or the Space Bar .

# Measure an Angle (MA) FUNCTION: The Measure an Angle routine is used to compute and report the value of an angle defined by any three points of known coordinates. This routine may be called as a stand alone routine, or as a computational tool when prompted for an angle or bearing.


11.21

From Point

To access the Measure an Angle routine, type MA in any text box, or press Alt M, M.

This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the From Point is equivalent to running the Go To routine.

	Enter the number of the point theoretically occupied by the instrument. This is the point at which you are measuring the angle. If the entered point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request.
B.S. Point	Enter the backsight point. If the entered point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request.
F.S. Point	Enter the individual foresight point number(s) or a point number string.
What Happens Next	"Sight" Survey will respond to an accepted foresight point(s) by printing the computed angle(s) right. This routine will also report the distance between the occupied point and each foresight point.
Example	<b>Enter &amp; Assign</b> points 1, 2, and 3. Use <u>Measure an Angle</u> to compute the angle 2:1:3 and also the angle 3:1:2.



area Text Output					- 0	×
Point	Direction	Distance	Northing	Easting	Elevation	
Arial			<u>Z U</u> ABC			
······································		- <u></u> 13		<u></u>		
Assigned p	ooints					
l 1 1		1	0000.0000	20000.000	000.0 000	
2			9738.34833	19823.51	372 0.000	
3			9718.79037	20143.283	346 0.000	
	ngle at point 1, b oresighting point			315.609	9	
	ngle at point 1, b oresighting point			315.60	9	•
			Page 1/1	Line !	5 Col 51	

11.22	<u>C</u> oordinate Transformation		
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>Rotation Point &amp; Angle Known</u> is used when the base point and angle of rotation around that base point are known.		
	To access the <u>Coordinate Transformation</u> $\Rightarrow$ <u>Rotation Point &amp; Angle</u> Known routine, type CTR in any text box, or press AttM, C, R.		
Base Point	Enter the number of the point which is to serve as the basis for the transformation option. The specified point will be the point around which other points will be rotated, and the difference between the old and new coordinates of the specified point will serve as the basis for translation.		
New North	If you intend to change the base point coordinates as part of your coordinate transformation proceedings, enter a new Northing.		
New East	If you intend to change the base point coordinates as part of your coordinate transformation proceedings, enter a new Easting.		
New Elev.	If you intend to change the base point coordinates as part of your coordinate transformation proceedings, enter a new elevation.		
Rotation	You can either enter a rotation angle or rotate to a bearing. Rotation angles are entered as turned to the right, but left angles may be entered as negative values.		
	<ul><li>Enter a rotation angle by:</li><li>1. Entering the angle in your chosen angle entry format; or</li><li>2. Recalling a value from the calculator memory; or</li></ul>		
	<ol> <li>You can rotate to a bearing by:</li> <li>Entering the bearing in your chosen angle entry format, including the quad code; or</li> <li>Recalling a bearing by point numbers.</li> </ol>		

Ī

	If you choose to rotate to a bearing, you will also need to supply a <b>Foresight Point</b> number. This point sets the initial (un-rotated) bearing from the base point.
Scale	If you want to enter a scale factor, for example to adjust to a state plane coordinate system, enter the factor.
	If you do not want to enter a scale factor, simply enter <b>1</b> .
	You can also enter a scale factor by using "Sight" Survey's in-line calculator function. For example, suppose you want to rotate a coordinate base and convert your coordinates from a local datum of approx. 600 feet elevation to sea level elevation. Given that the mean radius of the earth at average latitude is $20,906,000$ feet, you could apply a scale factor of $20906000/(20906000+600)$ or $0.999971301$ . To calculate an exact scale factor, you could use the in-line calculator. At the Scale Factor prompt, enter the equation you want to calculate followed by an equal sign (=). For this example you would enter $(20906000/(20906000+600)) =$
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash), and press enter.
What Happens Next	"Sight" Survey prints the translation parameters and transforms the specified points. After the transformation has been completed, you will be returned to the <b>Transform Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).
	Original Pt. 2

Base Pt. 1 (P)

Rotated Pt. 3

## Example #1

**Enter & Assign** points 1, 2, and 3. Rotate points 2 & 3 by 10° (to the right) around point 1 and translate all points to a new basis of 5000, 10000. Use a scale factor of 1.

Text Output				- D ×
Point Direction	Distance	Northing	Easting	Elevation
Arial 💌 14 💌		} <u>7 U</u> ABC		<u>†</u> ¶ <b>1</b>
▶ ↑↑	2 3	<u>3 </u>	<u></u>	<u></u> ↑
Assigned points				
1	1	0000.00000	20000.00000	0.000
2	1	0200.00000	20000.00000	0.000
3	1	0000.00000	20200.00000	0.000
Coordinate Transformat	lion			
Rotate AR 10°00'00.0"				
1	1	0000.00000	20000.00000	0.000
		5000.00000	10000.00000	0.000
Scale Factor = 1.00000	0			
Points 1-3 Transformed				
List/Plot Coordinates				
1		5000.00000	10000.00000	0.000
2		5196.96155	10034.72964	0.000
3		4965.27036	10196.96155	0.000
		Page 1/1	Line 3	Col 1

## Example #2

**Enter & Assign** points 1, 2, 3, and 4. Translate points 1-4 using only a scale factor or **0.999755** with no rotation. Translate around base point 1 and retain your original coordinate basis.

💐 Text Output			
Point Direction	Distance Northing	Easting	Elevation
Arial 🔽 14 💌 🔳	≣≣≣ <mark>₿ℤ</mark> Щм⊮∶		1
- <u> 0</u>  1  2		<u></u>	<u></u>
Assigned points			
1	10000.00000	10000.00000	0.000
2	10100.00000	10000.00000	0.000
3	10100.00000	10100.00000	0.000
4	10000.00000	10100.00000	0.000
Coordinate Transformation	1		
Rotate AR 0°00'00.0"			
1	10000.00000	10000.00000	0.000
	10000.00000	10000.00000	0.000
Scale Factor = 0.999755			
All Points Transformed			
List/Plot Coordinates			
1	10000.00000	10000.00000	0.000
2	10099.97550	10000.00000	0.000
3	10099.97550	10099.97550	0.000
4	10000.00000	10099.97550	0.000
	Page 1/1	Line 9	Col 1

11.23	<u>C</u> oordinate Transformation			
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>Two Points in Each System Known</u> is used to transform points when two corresponding points are known in each system.			
	To access the <u>Coordinate Transformation</u> $\mathbb{T}_{VO}$ <b>Doints in Each</b> System Known routine, type <b>CTT</b> in any text box, or press $\mathbb{AH}_{VO}$ , $\mathbb{C}$ , $\mathbb{T}$ .			
1st Base Pt	Enter the number of the point which is to serve as the basis for the transformation option.			
New North	Enter the Northing for the point in the second system that corresponds to the base point.			
New East	Enter the Easting for the point in the second system that corresponds to the base point.			
New Elev.	Enter the elevation for the point in the second system that corresponds to the base point.			
2nd Base PT	Enter the number of the second known point in the first system.			
New East	Enter the Northing for the point in the second system that corresponds to the first system's second known point.			
New North	Enter the Easting for the point in the second system that corresponds to the first system's second known point.			
New Elev.	Enter the elevation for the point in the second system that corresponds to the first system's second known point.			
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).			

What Happens NextThe rotation angle and scale factor are calculated from the<br/>coordinate values of the four known points. "Sight" Survey prints<br/>the translation parameters and transforms the specified points.<br/>After the transformation has been completed, you will be returned<br/>to the Transform Points prompt. Transformed coordinates may be<br/>viewed by using the List Coordinates routine (LC - page 242) or the<br/>Edit Coordinates window (EC - page 225).

Text Output

Aria

Point

Assigned points 1 2 3 Coordinate Transformation Rotate AR 9°59'54.6" 1 2

Scale Factor = 1.000148 Points 1-3 Transformed List/Plot Coordinates


1

2 3 Direction

2.

Dis

Enter & Assign points 1, 2, and 3. Translate points 1-3 to a new basis where point 1 is at coordinates 5000, 10000, and point 2 is at coordinates 5196.9916, 10034.7296. Use the new point 1 and 2 coordinates for rotation and scale information.



Transformed Pt. 3

5000.00000

5196.99160

4965.27040

1/1

Page |

stanc	e Northing	Easting E	levation
	₿ℤЩ м =		¶ <b>T</b> e
	.  3		
	т.	Т.	т
	40000 00000		⁻
	10000.00000	20000.00000	0.000
	10200.00000	20000.00000	0.000
	10000.00000	20200.00000	0.000
	10000.00000	20000.00000	0.000
	5000.00000	10000.00000	0.000
	10200.00000	20000.00000	0.000
	5196.99160	10034.72960	0.000

10000.00000

10034.72960

10196.99160

Line 3

0.000

0.000

0.000

Col

Example #2

11.24	<u>C</u> oordinate Transformation [®] <u>U</u> S Survey Feet to Meters		
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>US Survey Feet to Meters</u> is used to convert between the two coordinate systems.		
	To access the <u>Coordinate Transformation</u> [®] <u>US</u> Survey Feet to Meters routine, type CTU in any text box, or press AtlM, ⓒ, Ū.		
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).		
What Happens Next	"Sight" Survey transforms the specified points. The conversion factor used is:		
	1m = 39.37" or 1' = 0.304800609601219m		
	After the transformation has been completed, "Sight" Survey will print a message in the Text window that the transformation procedure has been performed.		
	Coordinate Transformation Converting US Survey Feet to Meters Scale Factor = .304800609601219 Points 1-30 Transformed		
	You will be returned to the <b>Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).		
Example	Since this is only a unit conversion, no example is included.		

11.25	<u>C</u> oordinate Transformation � U <u>S</u> Survey Feet to Int'I Feet			
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for U <u>S</u> Survey Feet to Int'l Feet is used to convert between the two coordinate systems.			
	To access the <u>Coordinate Transformation</u> [⇒] U <u>S</u> Survey Feet to Int'I Feet routine, type CTS in any text box, or press AltM, C, S.			
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).			
What Happens Next	"Sight" Survey transforms the specified points. The conversion factor used is:			
	1' (US) = 1.000002000004' (Int'l)			
	After the transformation has been completed, "Sight" Survey will print a message in the Text window that the transformation procedure has been performed.			
	Coordinate Transformation Converting US Survey Feet to International Feet Scale Factor = 1.000002000004 Points 1-30 Transformed			
	You will be returned to the <b>Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).			
Example	Since this is only a unit conversion, no example is included.			

11.26	<u>C</u> oordinate Transformation		
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>Meters to US Survey Feet</u> is used to convert between the two accordinate systems.		
	the two coordinate systems. To access the <u>Coordinate Transformation</u> [™] <u>Meters to US Survey</u> Feet routine, type CTM in any text box, or press Alt M, C, M.		
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).		
What Happens Next	"Sight" Survey transforms the specified points. The conversion factor used is:		
	1m = 39.37" or 3.28083333333333333		
	After the transformation has been completed, "Sight" Survey will print a message in the Text window that the transformation procedure has been performed.		
	Coordinate Transformation Converting Meters to US Survey Feet Scale Factor = 3.2808333333333 Points 1-30 Transformed		
	You will be returned to the <b>Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).		
Example	Since this is only a unit conversion, no example is included.		

11.27	<u>C</u> oordinate Transformation ┺ M <u>e</u> ters to International Feet		
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>Meters to Int'l Feet</u> is used to convert between the two coordinate systems.		
	To access the <u>Coordinate Transformation</u> $\rightarrow Meters to Int'l Feet routine, type CTE in any text box, or press ARM, C, E.$		
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).		
What Happens Next	"Sight" Survey transforms the specified points. The conversion factor used is:		
	1m = 3.28083989501312'		
	After the transformation has been completed, "Sight" Survey will print a message in the Text window that the transformation procedure has been performed.		
	Coordinate Transformation Converting Meters to International Feet Scale Factor = 3.28083989501312 Points 1-30 Transformed		
	You will be returned to the <b>Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).		
Example	Since this is only a unit conversion, no example is included.		

11.28	<u>C</u> oordinate Transformation ३ <u>I</u> nternational Feet to Meters		
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>Int'l Feet to US Survey Feet</u> is used to convert between the two coordinate systems.		
	To access the <u>Coordinate Transformation</u> [™] Int'l Feet to US Survey Feet routine, type CTI in any text box, or press AtlM, C, [].		
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).		
What Happens Next	"Sight" Survey transforms the specified points. The conversion factor used is:		
	1' = 0.3048m		
	After the transformation has been completed, "Sight" Survey will print a message in the Text window that the transformation procedure has been performed.		
	Coordinate Transformation Converting International Feet to Meters Scale Factor = .3048 Points 1-30 Transformed		
	You will be returned to the <b>Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).		
Example	Since this is only a unit conversion, no example is included.		

11.29	<u>C</u> oordinate Transformation		
	<b>FUNCTION:</b> The <u>Coordinate Transformation</u> routine is used to project the coordinates of one plane onto another plane through the use of rotation, translation and/or scaling. The option for <u>Int'l Feet to US Survey Feet</u> is used to convert between the two coordinate systems.		
	To access the <u>Coordinate Transformation</u> $\Im \ln t'$ i Feet to US Survey Feet routine, type CTN in any text box, or press $Att M$ , $\bigcirc$ , $\mathbb{N}$ .		
Points	Enter a single point number or the point numbers between which you wish to transform (separating them with a comma or dash).		
What Happens Next	"Sight" Survey transforms the specified points. The conversion factor used is:		
	1' (int'l) = 0.999998' (US)		
	After the transformation has been completed, "Sight" Survey will print a message in the Text window that the transformation procedure has been performed.		
	Coordinate Transformation Converting International Feet to US Survey Feet Scale Factor = .999998 Points 1-30 Transformed		
	You will be returned to the <b>Points</b> prompt. Transformed coordinates may be viewed by using the <b>List Coordinates</b> routine ( <b>LC</b> - page 242) or the <b>Edit Coordinates</b> window ( <b>EC</b> - page 225).		
Example	Since this is only a unit conversion, no example is included.		

## Pop-Up Calculator (PC)

**FUNCTION:** The **Pop-Up Calculator** is provided as a tool for intermediate computations.

To access the <u>Pop-Up Calculator</u>, type **PC**, or press AltM, P., or click the Calculator icon ( ) in the Main toolbar.

The **Calculator** will appear on your monitor, allowing you to perform intermediate calculations.

The Calculator contains many features, including:

- A four register stack with HP-style Reverse Polish Notation (RPN) data entry;
- Four function math: +, -, * and ÷;
- Reciprocals;
- *x y* register swap;
- Change sign;
- Exponential math including  $y^x$ ;
- Trigonometric functions for Sine, Cosine and Tangent;
- Inverse trigonometric functions for ArcSine, ArcCosine and ArcTangent;
- Squares and square roots;
- The ability to work in various angular formats such as a calculator style D.MMSS format, a decimal degrees format, radians and grads;
- Conversions for radians to and from degrees;
- Angular formatted math including DMS+, DMS-, DMS* and DMS÷.

The keyboard keys are keys are basically organized into two groups: those with *hot keys*; and those without.

The numeric keys and math function keys have not been assigned hot keys, but instead correspond to the numeric keypad on your computer keyboard. In order for these numeric keys to function properly, your keyboard **Num Lock** must be engaged.


层 ZA	K Cal	culato	ır	-	
2.0000 0.8000 1.0000					
dms+	dms-	dms*	dm <i>sl</i>		Deg
<u>S</u> in	<u>A</u> sin		Sgrt	X^ <u>2</u>	<u>1</u> /X
<u>C</u> os	Ac <u>o</u> s	Fix	Cļr	S <u>w</u> р	Drp
<u>T</u> an	At <u>n</u>	Ee <u>x</u>	_	Del	<
<u>R</u> >D	<u>D</u> >R	7	8	9	1
_>D	D-≥	4	5	6	-
<u>E</u> NTER		1	2	3	-
O <u>f</u> f		0	•	±/-	+

### The Keyboard

	The remainder of the keys have been assigned hot keys for an alternate method of access. Normally, you'll simply click your mouse on a key to activate its function, but you can also activate the key by simultaneously pressing Alt and the hot key. The hot key is indicated by an underscore on one of the characters on the key name. For example, the hot key for the <b>Tan</b> (gent) key is <b>T</b> . To activate this key, press Alt T. The <b>ENTER</b> key corresponds to your keyboard's <b>CENE</b> key.
Using Your Mouse	To press any key with your mouse, simply point the mouse cursor at the key and press either the left or right mouse button. To avoid multiple key presses, keep your button presses quick and do not double click.
Correcting Entry Errors	If, while typing in a value, you discover that you have made an entry error and you have not yet pressed $-$ press the $\leftarrow$ key ( $\mathbb{B}^{K}$ Spc) and correct your error. If you have already pressed $-$ lick the <b>Del</b> key, and re-enter your value. (Note: There is no hot key for the <b>Del</b> key.)
Clearing Registers	Clear everything by pressing the $Clr$ key (Attl). You may also use the $Drp$ (Drop) key (AttP) to clear the x register and drop the other registers down.
Setting Decimal Places	Internally, the calculator works with double precision accuracy. The display however, is variable. Set the number of visual decimal places with the <b>Fix</b> key (ARL), preceded by the number of places you want to display. For example, set the display to 6 decimal places by pressing 6 Att.
Manipulating the Stack	In the style of Hewlett Packard calculators, the calculator employs an operating logic known as "Reverse Polish Notation", or RPN. This mathematical logic type was first developed as "Polish Nota- tion" by Polish mathematician Jan Lukasiewicz (1878-1956). Unlike conventional algebra which places operators <i>between</i> vari- ables, Polish notation placed operators <i>before</i> the variables when evaluating algebraic expressions. To optimize calculator entries, HP reversed the process, placing the operators <i>after</i> the variables, thus the term "Reverse Polish Notation". RPN calculators use a four register stack, ( <i>X</i> , <i>Y</i> , <i>Z</i> and <i>T</i> ), to
	manipulate the entry and computation of algebraic data. The


procedure results in the elimination of parenthesis by retaining and displaying the intermediate results of your calculations.

Lifts and Drops When you enter a number into the calculator, your entry is placed into the X register, causing the contents of the registers to lift. The original X value is placed into the Y register, Y is placed into Z, Z is placed into T and T's original contents are lost. This stack lift occurs any time a new value is placed into the X register.



Illustrated above are the "stack drop" and "no lift or drop" operations. Stack drops occur whenever the contents of two registers are combined through an addition, subtraction, multiplication or division. No lift or drop of the stack occurs in operations that act solely upon the X register. These functions include: 1/x;  $x^2$ ;  $\sqrt{x}$ ; and all trigonometric functions.

Drop and SwapWhen you need to access a value that is not in register X, you have<br/>two choices: drop down; or x y swap. Swap, the contents of the X<br/>and Y registers by pressing the Swp key (Art M). Drop the<br/>registers down one level by pressing the Drp key (Art P).



The four register stack lends powerful equation solving capabilities to the pop-up calculator. Through the use of the stack, you have the ability to solve complex equations, with the stack registers

**Solving Equations** 

replacing the parenthesis in your equations. Equations which use the stack to hold intermediate results are called nested equations.

To solve a nested equation, solve the terms in their nested order, beginning with the most deeply nested term. For example, to solve the equation: **145[4+18(9.15/3)]**, you would begin by solving the term (9.15/3), multiply that result by 18, add 4 and multiply by 145. Your keystrokes and register contents would look like:

Keys	X Register
9.15	9.15
←Enter	9.15
3	3.00
	3.05
18	18.00
*	54.90
4	4.00
+	58.90
145	145.00
*	8540.50

The calculator lets you work in one of three formats: Decimal degrees (**Deg**); Degrees-minutes-seconds (**DMS**); or Radians (**Rad**). To cycle through the choices, click the button just below the right corner of the register display. The current choice will appear on the button.





For the purposes of the remainder of this section, we will assume that the chosen format is DMS.

The calculator contains standard trigonometric functions for Sine  $(\underline{\texttt{Sin}})$ , Cosine  $(\underline{\texttt{Cos}})$ , Tangent  $(\underline{\texttt{Tan}})$ , ArcSine  $(\underline{\texttt{Asin}})$ , ArcCosine  $(\underline{\texttt{Acos}})$ , and ArcTangent  $(\underline{\texttt{Atn}})$ . These functions are designed to work in any angular format supported by the calculator, freeing you from the burden of conversions to and from decimal degrees. For example, to find the sine of 45° 37' 52.5", key in 45.37525 and press the  $\underline{\texttt{Sin}}$  key ( $\underline{\texttt{Att}}$ ) to reveal the result of 0.714854. Or, suppose that you have a sine value of 0.428864 and you need to find the angular value. Key in 0.428864 and press the  $\underline{\texttt{Asin}}$  key ( $\underline{\texttt{Att}}$ ) to reveal the result of 25.234376, or 25° 23' 43.76".

**Angular Mathematics** 

**Trig Functions** 

Conversion Functions	The calculator contains conversion functions for decimal degrees to and from the D.MMSS format, and degrees (decimal) to and from radians.
	To convert from decimal degrees to D.MMSS, key in the value and click the $D \rightarrow key$ (Att)). To convert from a D.MMSS format to decimal degrees, key in the value and press the $->D$ key (Att)).
	To convert from radians to degrees in your chosen format, key in the value and press the $\mathbb{R}^{>D}$ key (Att P). To convert from degrees to radians, key in the value and press the $\mathbb{D}>\mathbb{R}$ key (Att D).
Angular Arithmetic	You can add and subtract formatted angles without first converting them to decimal values. You may also multiply and divide angular values by any other (non-angular) value, without conversions. For example, suppose that you have three angular values and you want to find the average value. The values are 75° 13' 52", 75° 14' 07 and "75° 13' 36". Key in the first value of 75.1352 and press Fine. Key in the next value of 75.1407 and press the DMS+ key (F5). You should see an intermediate result of 150.2759. Now key in the final value of 75.1336 and press the DMS+ key (F5). You should see an intermediate result of 225.4135. Now find the average of the three angles by pressing 3 and the DMS+ key (F8) to reveal the average angle of 75.135167 or 75° 13' 51.67".
¥	Do not confuse the angular math functions with regular $\oplus$ , $\Box$ , $\Box$ , and $\oplus$ functions or errors in your calculations will result!
Other Math Functions	In addition to trigonometric, standard and angular math functions, the pop-up calculator offers six other math functions. These are: <i>x squared</i> ; <i>square root</i> ; <i>y to the x power</i> ; <i>reciprocal of x</i> ; <i>change sign</i> ; and <i>exponential math</i> .
x Squared	To obtain the square of the value contained in the X register, press the $X^2$ key (Att2). This operation does not affect the stack.
Square Root of <i>x</i>	To obtain the square root of the value contained in the X register, press the <b>Sqrt</b> key ( $Alt \bigcirc$ ). This operation does not affect the stack.

Section 11

Y raised to the <i>x</i> power	To raise the value contained in the Y register to the X power, type the first value and press $\underbrace{-\text{Enter}}$ to place it into the Y register. Then type in the X value and press $$ key (Alt ). This operation does not affect the stack.
Reciprocal of x	To obtain the reciprocal of the value contained in the $x$ register, press the $1/x$ key ( $\mathbb{R}$ ). This operation does not affect the stack.
Change Sign	To change the sign of the value contained in the <i>X</i> register, press the $\pm$ / - key ( $\bigcirc$ ). This operation does not affect the stack.
Exponential Math	To enter a value raised to any power of 10, type in the value, press the <b>Eex</b> key ( $Alt X$ ), type in the power of 10 and press $\underline{-Enter}$ . This operation does not affect the stack.
Using a Calculated Value	<ol> <li>To insert a value you have calculated into a data entry field in the Data Entry window, follow these steps.</li> <li>Press the Swp key (AttW).</li> <li>Press the Drp key (AttP) to drop the value to the bottom of the calculator window.</li> <li>Double-click the value to select it.</li> <li>Press Ctf(Insert to copy the value.</li> <li>Click the mouse in the desired data entry field.</li> </ol>

6. Press Shift Insert to paste the value into the field.

Page 366 The MISC Menu

This page intentionally left blank.



#### <u>S</u>nap Modes

Select <u>Point</u> (SP) Select <u>D</u>istance (SD) Select <u>B</u>earing (SB) CAD to CO<u>G</u>O

Draw Suppleme<u>n</u>tal Layer O<u>v</u>erride (LV) Label an Angle (AL)

CAD Paper in Landscape Orientation Show Paper Border

## Section 12 The <u>D</u>RAW Menu

The **Draw** menu contains functions relating to the transfer of data from the **Drawing** window to COGO. This menu can be accessed by clicking the right mouse button anywhere on the **Drawing** window.

<u>Snap Modes</u> are used to tell the drawing cursor how to act when clicked near lines, points, etc.

The three "**Select**" items, are used to transfer information from the drawing back into corresponding prompts in the **Data Entry** window.

The **CAD** to **COGO** item contains four "**Get**" items used to pick a drawing object and then enter the coordinates of the object's control points into the data file and also into the **Text Output** window. The drawing objects you may select from are: an arc; a line; and a point; and a point series. Generally, these objects will be manually-created objects, whose control points are not yet part of the COGO file.

Why would you want to use these "Get" functions? Well, suppose you are preparing a site plan for an apartment complex. Your lot corners are already part of the data file, but you have created an outline of the building. Dragging and rotating the outline, you determine where it should be placed. You also add a parking lot, sidewalks, and a pool. Using these routines, you can insert into your data file, the coordinates of the control points for all the manually created objects. You can now generate Radial Stake Out information for all of the building corners, parking lot corners, sidewalks, etc. You'll find this is much faster than manually computing the coordinates and adding the objects to your drawing.

The **Draw Supplemental** menu allows you to add certain "extra" elements to your drawings, including line and curve tables, legends, North arrows, etc.


## 12.01

#### Snap Modes

**FUNCTION:** The <u>Snap Mode</u> function is used to select a snap mode for the **Drawing** window cursor.

To access the <u>Snap Mode</u> function from the Draw menu, press AfD, S.

When you access **Snap Mode**, "Sight" Survey prompts:



To select a Snap Mode, click on the mode you want to use and then click  $\Box K$ .

Snap modes cause the cursor to behave in a particular way each time you click or press *Etile*. Snap modes are discussed in detail in **Section 30.05** in the **Drawing Window Reference Manual**.

12.02

## Select Point (SP)

**FUNCTION:** The **Select** <u>**Point**</u> function is used to pick a point from the drawing to be used as data entry into a point number field. The point that is selected must be an existing COGO point.

To access the **Select** <u>Point</u> routine, type **SP** or press <u>At</u>[S], P. The **Drawing** window command line prompts:

#### Select a point

Using the **Grab All** cursor  $(\Box)$  in the **Drawing** window, click on the point to be picked. You don't have to be exact, but the point must lie within the **Grab All** cursor box or you may not get the point you want.

3

ead)

Before using the Select Point feature, be certain your cursor is located in a point entry field in the Data Entry window.

What Happens Next

The point number of the selected point will be automatically entered into the point field in the **Data Entry** window.

Select Point allows you to choose one point each time you activate the function. If you want to select several points, for example while inversing, use the Quick Pick function as described on page 377.

#### 12.03

## Select Distance (SD)

**FUNCTION:** The **Select Distance** function is used to pick a distance from the drawing which will be used as data entry into a distance field. The distance picked is actually calculated by "Sight" Survey, so you must have two existing COGO points to use this routine.

To access **Select Distance** from the keyboard, use the command **SD** or press Att S, D. The **Drawing** window command line prompts:

Select the starting point for distance calculation

Using the **Grab All** cursor  $(\Box)$  in the **Drawing** window, click on the first point to be used in the calculation.

Select the ending point for distance calculation

Again, using the **Grab All** cursor  $(\Box)$  in the **Drawing** window, click on the ending point to be used in the calculation.

3 *Before using the* **Select** <u>Distance</u> *feature, be certain your cursor is located in a distance entry field in the* **Data Entry** window.

What Happens Next

After you select the starting and ending points of the line to be measured, "Sight" Survey will calculate the distance between the two points, then place the calculated distance into the last occupied text box.

#### 12.04

## Select Bearing (SB)

**FUNCTION:** The **Select Bearing** function is used to pick a bearing from the drawing which will be used as data entry into a bearing field. The bearing picked is actually calculated by "Sight" Survey, so you must have two existing COGO points to use this routine.

To access **Select** <u>Bearing</u> from the keyboard, use the command **SB** or press <u>Att</u><u>S</u>, <u>B</u>. The **Drawing** window command line prompts:

Select the starting point for bearing calculation

Using the **Grab All** cursor  $(\Box)$  in the **Drawing** window, click on the first point to be used in the calculation.

Select the ending point for bearing calculation

Select the ending point for bearing calculation		Again, using the <b>Grab All</b> cursor $(\Box)$ in the <b>Drawing</b> window, click on the ending point to be used in the calculation.
	3	Before using the Select Bearing feature, be certain your cursor is located in a bearing entry field in the Data Entry window.
What Happens Next		After you select the starting and ending points of the line to be evaluated, "Sight" Survey will calculate the bearing between the two points. "Sight" Survey will then place the calculated bearing into the last occupied text box.
12.05		Get an Arc (GA)

**FUNCTION:** The **Get an Arc** function is used to add the coordinates of an arc's end points and radius point into the data file and **Text Output** window.

To access **Get an <u>Arc</u>** from the keyboard, use the command **SB** or press <u>Att</u>S, <u>A</u>. The **Drawing** window command line prompts:

#### Select an arc

What Happens Next

Using the Grab All cursor  $(\Box)$  in the Drawing window, click on the target object.

"Sight" Survey will compute coordinates for the arc's starting, ending, and center point, and offer the point computations for approval through the use of a **Point Information** window.



Starting Point of the Arc		
Point Number	40	
Northing	10112.97142463	
Easting	19773.61188891	
Elevation	0	
Description	Start of Arc	
<u>A</u> ccept	<u>C</u> ancel	

All the data boxes in the **Point Information** window are actually text entry boxes. This means that you can edit any of the text in the boxes. For example you can change the **Point Number**, add a **Description**, and add an **Elevation**.

The **Point Information** window has **three critical fields that must be filled in** before the data will be accepted: the **Point Number** field; the **Northing** field; and the **Easting** field.

The **Cancel** button may be used when you don't want to add a particular point to the COGO file. For example, if you only wanted to keep an arc's center point you can use the **Cancel** button when the **Point Information** window is showing either of the arc's end points.

¥

*While you can edit the actual coordinate values, DON'T DO IT!* Changing the values will not change the object's position on the drawing but it will place incorrect data into your data file.

After you have approved the points, "Sight" Survey will add the points to your COGO file, label the points in the **Drawing** window (if point labeling is active), and add a coordinate listing in the **Text Output** window (if the window is active).

🏺 Text Output				
Point	Direction	Distance Northing	Easting	Elevation
Arial	▼ 14 ▼ ≣			t T Te
- <u>I</u>	<u>.  1 </u>	···· · · · · · · · · · · · · · · · · ·	<u> 4 </u>	<u>1. 16</u>
Points De	termined from CA	AD Window		
2	Start of Arc	10008.7249	0 19750.15230	0.000
6	End of Arc	9729.7904	0 19725.74870	0.000
7	Center of Arc	9794.5430	0 19731.41380	0.000
Resuming	at Point			
9		9997.4144	0 20074.04130	0.000
		Page 1/	1 Line 2	Col 1



1. After examining the points in the Enter and Assign box you may save or discard the points.

- 2. "Sight" Survey's Grab All cursor will automatically snap onto the closest point or intersection enclosed within the cursor box. "Sight" Survey searches within the box in the following order:
  - *A.* If a point (e.g. a point, the end of a line, the end of an arc, an arc or circle center) is found within the box, take the nearest one.
  - *B.* If a geometry intersection is found in the box, take the nearest one.
  - *C.* If any other intersection is found in the box, take the nearest one.
  - D. If none of the above are found, "Sight" Survey will return coordinates for the exact point selected.
- 3. If the point selected is already in the coordinate file, you will be able to edit the properties of the point on file.

12.06

#### Get a Line (GL)

**FUNCTION:** The **Get a** <u>Line</u> function is used to add the coordinates of a line's end points into the data file and **Text Output** window.

## Section 12

What Happens Next


To access **Get a Line** from the keyboard, use the command **GL** or press **Att S**, **L**. The **Drawing** window command line prompts:

#### Select a line

Using the **Grab All** cursor  $(\Box)$  in the **Drawing** window, click on the target object.

"Sight" Survey will compute coordinates for the line's starting and ending point, and offer the point computations for approval through the use of a **Point Information** window (see **Get an <u>Arc</u>)**.

After you have approved the points, "Sight" Survey will add the points to your COGO file, label the points in the **Drawing** window (if point labeling is active), and add a coordinate listing in the **Text Output** window (if the window is active).



2. "Sight" Survey's Grab All cursor will automatically snap onto the closest point or intersection enclosed within the cursor box. "Sight" Survey searches within the box in the following order:

- *A.* If a point (e.g. a point, the end of a line, the end of an arc, an arc or circle center) is found within the box, take the nearest one.
- *B.* If a geometry intersection is found in the box, take the nearest one.
- *C.* If any other intersection is found in the box, take the nearest one.
- D. If none of the above are found, "Sight" Survey will return coordinates for the exact point selected.
- 3. If the point selected is already in the coordinate file, you will be able to edit the properties of the point on file.

#### Get a Point (GP)

**FUNCTION:** The <u>Get a Point</u> function is used to add a point's coordinates into the data file and **Text Output** window.

To activate this function from the keyboard, type **GP** or press **Att**[S], **G**. The **Drawing** window command line prompts:

#### Select a point

Using the **Grab All** cursor  $(\Box)$  in the **Drawing** window, click on the target object.

# What Happens Next"Sight" Survey will compute coordinates for the point, and offer<br/>the point computations for approval through the use of a Point<br/>Information window (see Get an Arc on page 371).

After you have approved the point, "Sight" Survey will add the point to your COGO file, label the point in the **Drawing** window (if point labeling is active), and add a coordinate listing in the **Text Output** window (if printing is active).

1. After examining the points in the Enter and Assign box you may save or discard the points.

2. "Sight" Survey's Grab All cursor will automatically snap onto the closest point or intersection enclosed within the cursor box. "Sight" Survey searches within the box in the following order:

- *A.* If a point (e.g. a point, the end of a line, the end of an arc, an arc or circle center) is found within the box, take the nearest one.
- *B.* If a geometry intersection is found in the box, take the nearest one.
- *C.* If any other intersection is found in the box, take the nearest one.
- D. If none of the above are found, "Sight" Survey will return coordinates for the exact point selected.
- 3. If the point selected is already in the coordinate file, you will be able to edit the properties of the point on file.



- 4. <u>Get a Point can be used to quickly find intersection points</u> between lines and arcs. This is a viable alternative to the intersection routines.
- 5. If the point selected is already in the coordinate file, you will be able to edit the properties of the point on file.

12.08

#### Get a Point Series (GS)

**FUNCTION:** The **Get a Point Series** function is used to compile a string or series of point numbers for use in a data entry box, usually the **To Point** box.

To activate this function from the keyboard, type **GS** or press **AttS**, **S**. The **Drawing** window command line prompts:

#### **Use String**

Using the **Grab All** cursor ( $\boxdot$ ) in the **Drawing** window, click on the target points. When you have select all of the points you want to place in the point series, press <u>-Enter</u> or click the <u>Use String</u> button.

What Happens Next

"Sight" Survey will insert the string you have defined into the data entry window.

1. The Grab All cursor automatically snaps onto the closest point or intersection enclosed within the cursor box, searching within the box in the following order:

- *A.* If a point (e.g. a point, the end of a line, the end of an arc, an arc or circle center) is found within the box, take the nearest one.
- B. If a geometry intersection is found in the box, take the nearest one.
- *C.* If any other intersection is found in the box, take the nearest one.
- D. If none of the above are found, "Sight" Survey will return coordinates for the exact point selected.

**Select Points** 

#### Quick Pick CAD $\rightarrow$ COGO (QP)

**FUNCTION:** The Quick Pick CAD  $\rightarrow$  COGO routine is a toggle which enables or disables the ability to quickly pick points, bearings, or distances off an existing drawing to be used as entry into *any* COGO routine. When Quick Pick is enabled, every mouse click in the Drawing window will input the data found at the mouse cursor into the Data Entry window as the entry for the current text box.

This function waits for you to use your mouse cursor to select an entity from your **Drawing** window. It is extremely useful when inversing between points to draw and annotate lines. You simply start the **Inverse** (**IN** - page 255) routine, and then click on the points or point numbers on the drawing screen to draw the lines and annotate them (based upon the settings for **Text Placement** and **Line Type**).

To run this routine, type QP (or Alt(S), (Q)) or click your mouse on the Quick Pick icon (W) on the Main tool bar. When enabled, the Quick Pick tool bar button will contain the word ON, and any click of the mouse on the Drawing window will attempt to select an entity for input into the current text box in the Data Entry window.

When **Quick Pick** is enabled, click on a **point** or **point number** in the **Drawing** window to use the point number as your input into the **Data Entry** window. Simply position the mouse cursor on or very near a point or point number and click the left button.

If you do not click close enough to a defined point or actual point number, some other drawing entity may be selected and input into the **Data Entry** window. So, if you really wanted to enter a point number of **L1**, you could actually click on an L1 short line label. Then, if a point numbered as L1 has already been assigned coordinates, L1 would be entered into the current point number field.

This is similar to using the **Select Point** (**SP** - page 368) routine, but is quicker and easier to use because it eliminates the need to type a routine code or select a routine from the pull-down menu.

**Select Distances** 

#### **Select Bearings**



Whenever **Quick Pick** is enabled, you can single click on a **line** in the **Drawing** window to use the line length/distance as your input into the **Data Entry** window. Simply position the mouse cursor on or very near a line and click the left button.

This is similar to the **Select Distance** (**SD** - page 369) routine, but is quicker and easier to use because it eliminates the need to type in the routine code or select the routine from the pull-down menu.

Whenever **Quick Pick** is enabled, you can single click on a **line** in the **Drawing** window to use the bearing of that line as your input into the **Data Entry** window. Simply position the mouse cursor on or very near a line and click the left button.

The actual bearing direction is determined by the end of the line that was closest when you clicked on it. For example, the bearing from point 1 to point 2, as shown to the left, is  $25^{\circ}17'43''$  NE. If you click closer to point 2, the bearing will be entered as if you were recalling the bearing *from point 1 to point 2*, or as  $25^{\circ}17'43''$  NE. If you click closer to point 1, the bearing will be entered as if you were recalling the bearing *from point 2 to point 1*, or as  $25^{\circ}17'43''$  SW.

This is similar to using the **Select Bearing** (**SB** - page 370) routine, but is quicker and easier to use because it eliminates the need to type in a routine code or select a routine from the pull-down menu.

 The Quick Pick routine stays active until you shut it off by typing QP or by again clicking the Quick Pick icon ()) on the Main tool bar. If you have trouble selecting items from the Drawing window, check the status of the Quick Pick button.

 If a line is moved a small distance and then a CAD2COGO routine is run on that line, the coordinates of the original points might come in as well as the original point number. The variable CAD2COGORange in the COGO.INI file allows you to set the window size for the CAD2COGO routines. Currently it defaults to 0.5 units (feet or meters). If you wish to change this default, you must use a text editor to do so.

### 12.10

#### Draw Supplemental [®]Short Line Table

**FUNCTION:** The **Short Line Table** routine is used to add a table of linear data to your drawing. "Sight" Survey adds items to the **Short Line Table** whenever the length of a line is too short to support the annotation. The line is marked with an identifier, and the annotation is placed into a table.

To add a <u>Short Line Table</u> to your drawing, type **SL**, or press <u>AHD</u>, <u>N</u>, <u>S</u>. The **Drawing** window command line prompts:

Select the short line table position

Position the **Grab All** cursor  $(\Box)$  in the **Drawing** window where you want to place the table and click your mouse or press  $\blacksquare$ 

The short line table contains the following information: a line identifier Ln where n is an assigned number; the line's bearing; and the line's distance. After you have placed the short line table into your drawing, Sight' Survey prompts:

#### Should this data be saved for the next short line table?

Click  $\underline{Yes}$  to save the table with line numbering continuing from the last used number. If you click  $\underline{No}$ , the table will be deleted from the job file and a new table will begin with the leg L1.

12.11

## Draw Supplemental [®]Curve Table

**FUNCTION:** The <u>Curve Table</u> routine is used to add a table of curve data to your drawing. "Sight" Survey adds items to the **Curve Table** when COGO creates an arc. The arc is identified, and the curve data is placed into a table.

To add a <u>Curve Table</u> to your drawing, type CL, or press <u>Att</u>, <u>N</u>, <u>C</u>. The **Drawing** window command line prompts:

#### Select the short line table position

Position the **Grab All** cursor  $(\Box)$  in the **Drawing** window where you want to place the table and click your mouse or press  $\Box$ .

The curve table contains the following information: a curve identifier Cn where n is an assigned number; the delta angle; the radius, arc, chord, and tangent distances; and the chord bearing. After you have placed the curve table into your drawing, Sight" Survey prompts:

#### Should this data be saved for the next curve table?

Click  $\underline{Yes}$  and the table will be saved with the curve numbering continuing from the last used number. If you click  $\underline{No}$ , the table will be deleted from the job file and a new table will begin with the curve C1.

#### Draw Supplemental ♣Scale Bar

**FUNCTION:** The Scale Bar routine is used to add a scale bar to your drawing. You can choose from a  $\underline{2}$  inch,  $\underline{3}$  inch or 5cm Metric scale bar.

To choose a  $\underline{2}$  inch bar press  $\underline{AttD}$ ,  $\mathbb{N}$ ,  $\mathbb{E}$ ,  $\underline{2}$ . To choose a  $\underline{3}$  inch bar press  $\underline{AttD}$ ,  $\mathbb{N}$ ,  $\mathbb{E}$ ,  $\underline{3}$ . To choose a <u>Metric</u> scale bar press  $\underline{AttD}$ ,  $\mathbb{N}$ ,  $\mathbb{E}$ ,  $\mathbb{M}$ .

The Drawing window command line prompts:

Select the scale bar position

Position the cursor in the **Drawing** window where you want to place the scale bar and click your mouse or press **Finer**.

## 12.12

## 12.13

12.14

## Draw Supplemental [®]North Arrow

**FUNCTION:** The <u>North Arrow</u> routine is used to add a **North arrow** to your drawing.

Add a <u>North Arrow</u> to your drawing by pressing AttD, N, N. The Drawing window command line prompts:

Select the North arrow position

Position the cursor in the **Drawing** window where you want to place the **North arrow** and click your mouse or press *Finer*.

#### Draw Supplemental ♣Coordinate List

**FUNCTION:** The **Coordinate List** routine is used to add a coordinate point listing to your drawing.

Add a **Coordinate List** to your drawing by pressing AttD, N, L. "Sight" Survey will prompt for a list of the coordinate points you want placed in the table.

Type in the point numbers and/or ranges and press Fire or click **OK**. For example, an entry of 1, 3, 5-17, 24, 30-50 would list points 1, 3, 5 *through* 17, 24, and 30 *through* 50.

Coordinate Table	×
Enter the points you would like printed, or	OK
type a for all.	Cancel
A	

After you have entered your points, the **Drawing** window command line prompts:

#### Select the coordinate list position

Position the cursor in the **Drawing** window where you want to place the list and click your mouse or press *Enter*.

The coordinate list is a listing of the point number, Northing, Easting, elevation, and description of selected points in your COGO file.

#### Draw Suppleme<u>n</u>tal ✤ Component <u>T</u>able

**FUNCTION:** The **Component Table** routine is used to add a **symbols legend** to your drawing.

Add a **Component Table** to your drawing by pressing AttD, N, T. The **Drawing** window command line prompts:

Select the component table position

Position the cursor in the **Drawing** window where you want to place the table and click your mouse or press *rener*.

The component table is a legend of all the end point symbols used in your drawing. Graphical representations of each symbol are included, along with a descriptive label.

12.16

12.15

#### Layer Override (LV)


**FUNCTION:** The Layer Override routine is used to establish the current drawing layer.

To access the Layer Override function, press Att D, V.



When you first start off with "Sight" Survey, only one layer, **0**, will appear in this dialog box. To add further layers or to rename layer **0**, see Layer Control. You can save default layers in STARTUP.DRG.

Whatever you draw is placed on the **current layer**. When you select **Layer Override**, the following dialog box appears.



Click on the layer that must become the current layer. The new current layer will be highlighted. Click  $\Box K$  to exit.



"Sight" Survey displays the name of the current layer in the Drawing window title bar. When Layer Override is active, (OVERRIDE) appears after the layer name.



#### 12.17

#### Label an Angle (AL)

**FUNCTION:** The <u>Label an Angle</u> routine is used to dimension an angle in your drawing as defined by three points.

To access the <u>Label an Arc</u> routine, type **AL** in any text box, or press AfM,  $\square$ .

From Point	This is the currently occupied point. If you have an occupied point, this box will automatically be filled for you. Changing the <b>From Point</b> is equivalent to running the <b>Go To</b> routine.
Vertex Point	Enter the vertex, or center point. If the entered point has not been assigned coordinates, the program will prompt for them and you must respond as you would to a standard coordinate entry request.
To Point 1) A 2) O	Enter the foresight point. Enter 1 or A to indicate that the angle is acute (less than 180°/200 grads). Enter 2 or 0 if the angle is obtuse (equal to or greater than 180°/200 grads).
What Happens Next	"Sight" Survey calculates the angular dimension and annotates the angle at a point that bisects the actual angle.
Example	Enter & Assign points 1, 2, and 3. Label the angle 1:3:2.
	2 N.35°00105.5 M.80°00'05.4"W 3
į	This routine requires the use of data points to define the angle and does not add witness (leader) lines and arrowheads. To dimension an angle from within the drawing, using drawing

(see Section 30.11).

and does not add witness (leader) lines and arrowheads. To dimension an angle from within the drawing, using drawing elements only, use the <u>Start</u> [™] <u>Annotate</u> [™] Angular Dimension routine (see Section 27.12) in the Drawing window. Set up your witness (leader) line color, arrowheads, and dimension text font using the <u>Start</u> [™] <u>Settings</u> [™] Dimension Defaults routine



To measure an angle without labeling it, use the Misc  $\Rightarrow$  Measure an Angle routine (MA - page 347).

#### 12.18

#### CAD Paper in Landscape Orientation

**FUNCTION:** The **CAD Paper** in Landscape Orientation function is used as a toggle switch to change the orientation of your drawing paper.

To access the CAD Paper in Landscape Orientation function, press  $Alt \square$ ,  $\square$ , or click the Paper Orientation icon (  $\square$  ) in the Main toolbar.

Your drawing is oriented in one of two ways: portrait; or landscape. In portrait orientation, your paper is taller than it is wide. In landscape orientation, your paper is wider than it is tall.



## Sectior 12

12.19

#### Show Paper Border

**FUNCTION:** The **Show Paper Border** function is used as a toggle switch to show and hide the paper border.

To access the Show Paper Border function, press Alt D, A.

The paper border is represented in the **Drawing** window by a magenta colored dashed rectangle.

🕶 "Sight" Survey	_ & ×
Elle Edit Points Lines Curves Misc Draw Config	∐tilties _∆dd Ins(indowelp
🗑 Traverse 📃 🗖 🗙	Drawing
	Epopentes Start
Enter a Point Number	▶ <del>   </del>
ST GT From Point	
EB EP To Point	
IN IC Bearing 0.0000000000 N	
TR TA Distance 0	নিত
POISS	
TC ED	
PA BP	
BB_DD	
BD DB Accept (PgDn)	
Text Output	
Point Direction Distance	
Arial 12 Y	
- l ⁰ l ¹ l ² l ²	
Database opened: Tuesday, September	
<u> </u>	
44% To delete	an object select it, then press the 'DELETE' key. Press 'INSERT' to undo. N:101.18 E:-333.28



Text Output Configuration Menu

Slope Entry Configuration Menu

CAD Configuration Menu (CM)

Angle Setup Configuration Menu

File Paths Configuration Menu

Customize Side Tool <u>B</u>ar

Adjust Screen Colors

✓ Show Status Bar

Sho<u>w</u> Tool Bar

**Check Boxes** 

**Option Buttons** 

COGO Configuration Menu

Section 13	
The CONFI <u>G</u>	Menu

The **Config** menu contains commands used to tailor the way "Sight" Survey works. There are commands to allow you to work in grads or South azimuth, commands to change the color of "Sight" Survey, and commands to control how information is stored. Nearly every aspect of the operation of "Sight" Survey is controlled from one of the configuration menus.

## 13.01 Config Menu Basics

All of the "Sight" Survey configuration routines use a variety of data entry fields. These fields are:

 $\blacksquare$  Item Active

□ Item Inactive

**Check Boxes** are toggle switches. Check box items are active when the box contains a  $\checkmark$  or an  $\chi$ . If a *group* of check box items is displayed, you may select as many as you need.

#### • Item Active

ve O Item Inactive

**Option Buttons** are toggle switches. Option items are active when the button contains a smaller dot. Option buttons are used to present mutually exclusive options. In other words, if a *group* of option button items is displayed, you may select only one.

## Selection Lists

1

Selection Lists are marked by a very button (or very in Windows 3.1) on the right side of the entry field, which already contains a selection. Click your mouse on the very button, then make your choice by using the 1 or very keys or your mouse. Press very to exit a list without making a choice. Depending upon how you choose an item, you may need to press very.

Scrollable selection lists are indicated by the presence of a scroll bar along the right side of the list. Scrollable lists contain more selections than can be shown in the selection list at one time. You can scroll the list by using your 1 and 1 keys, or by clicking

A 8.5x11"	•
E 34x44"	
D 22x34"	
C 17x22"	
B 11x17"	
A 8.5x11"	-
LGL 8.5x14"	
F 28x40"	
Arch. C 18x24"	-

your mouse on the  $\blacksquare$  and  $\blacksquare$  arrows on the scroll bar. You may also click and hold your mouse on the button in the scroll bar while you slide the button up and down.

Text Entry Boxes	0
	<b>Text Entry Boxes</b> are simply boxes into which you type text. Position the cursor in the box using your mouse or the key. Type the data requested and press with a highlighted value exists in a text entry box, the data you type will replace the existing data.
Response Buttons	Change Response Buttons function as simple push buttons. Activate a
	response button in one of two ways: either by clicking your mouse on the button; or (in this example) by pressing Alt H, where the letter following the Alt key corresponds to the underlined letter on the button. (Occasionally, you may need to press effect after using an Alt key combination.)

13.02

## Text Output Configuration Menu

**FUNCTION:** The <u>Text Output</u> configuration menu controls the **Printed Precision** for "Sight" Survey's **Text Output** window and other printing options.

To access this screen from the keyboard, press AttG, M.

×

Section

	Text Output Slope Entry CAD COGO Angle Setup File Paths									
	Printed Precision       Printing Options         Prin. Prec Agea:       4         Prin. Prec Bigs:       1         Prin. Prec Crds:       5         Prin. Prec Dist:       3         Prin. Prec Elev:       3									
	<u>DK</u> <u>Cancel</u> <u>H</u> elp									
Printed precision	<b>Printed precision</b> is nothing more than the number of places that your printed numerical data will be carried out to, <i>in the text output</i> . (Printed precision in drawings is set elsewhere.) It has nothing to do with internal precision. Your choices are: Area - 0 to 6; Bearings - 0 to 3 (seconds value) in degrees, or 0 to 6 in grads; Coordinates - 0 to 8; Distances - 0 to 6; Elevations - 0 to 6.									
Printing Options	The <b>Printing Options</b> section contains three items which may be enabled or disabled with check boxes.									
Print Input Data	<b>Print Input Data</b> , when checked, includes your exact data entries in your text output. This is often helpful when entering field data for the first time, allowing you to spot data entry errors as they may occur.									
$\succ$	The two-letter code PI can be used to toggle Print Input Data between On and Off.									

**Configuration Screen** 

Print Elevations

**Print Elevations**, when checked, includes point elevations and differences in point elevations in your text output.

13.03

Print Point DescriptionsPrint Point Descriptions, when checked, includes 28 character point<br/>descriptions in your text output. (See also the Prompt for Desc.<br/>setting in the Config To COGO sub-menu.)

#### Slope Entry Configuration Menu

FUNCTION: The <u>Slope Entry</u> configuration menu controls Slope Type, Slope Correction, Horizontal Distance, EDM Options, and/or Stadia options.

To access this screen from the keyboard, press AttG, R, AttS, or CM AttS.

Configuration Screen	×
Iext Output Slope Entry CAD Slope Type Prompt for slope input CEDM	COGO Angle Setup File Paths Slope Correction Curvature and Refraction Horizontal Distance
C Stadja C Simple Slope Angles C Leveling C Total Statio <u>n</u> s C EDM (Mining Option) C Assigned Elevations	<ul> <li></li></ul>
EDM Options Difference in H.I.'s of the EDM and EDM - H.I. of Theod. ) Difference in H.I.'s of the prism and H.I. of Prism - H.I. of Target )	
<u></u> K	<u>C</u> ancel <u>H</u> elp

#### Prompt for slope input

The *check box* option, **Prompt for slope input**, acts to turn on slope reduction automatically. When **Prompt for slope input** is active, every distance you enter will be met with a request for data in accordance with the slope type selected. If you only have an occasional slope distance, leave this item off. You can manually alert

"Sight" Survey to a slope distance by placing a slash (either / or  $\)$  immediately after the typed distance before pressing -Ener, such as 150.55/-Ener. An easy way to remember this is to think of the slash as a *sloping line*.



*The two-letter code* **SA** *can be used to toggle* **Slope Angle Prompting** *between* **On** *and* **Off**.

Slope Type **Slope Type** offers seven *option button* selections and one *check box* selection. The option buttons control the type of slope reduction that "Sight" Survey will use when reducing slope distances to horizontal. Your choices are: EDM; Stadia; Simple Slope Angles (angle only, no instrument values); Leveling; Total Stations; EDM (Mining Option); and Assigned Elevations. Three of the slope type selections, EDM, Stadia, and EDM (Mining **Option**), include additional setup options. **Slope Type - Stadia** If you have selected Stadia as your Slope Type, you may now enter values for: Stadia Interval Constant (K) - Type the stadia interval constant into the text entry box. This value is retained between sessions, and you will not need to re-enter it unless your instrument setup changes. Distance from Center of Instrument to Principal Focus (C) - Type the value for **C** into the text entry box. This value is retained between sessions, and you will not need to re-enter it unless your instrument setup changes. Slope Type - EDM If you have selected EDM or EDM (Mining Option), you may now enter values for: two EDM Options; a Slope Correction option; and a Horizontal Distance option. The EDM Options are: Difference in H.I.'s of the EDM and the theodolite. (H.I. of EDM - H.I. of Theod.) and Difference in H.I.'s of the prism and the target assembly. (H.I. of Prism - H.I. of Target)

13.04

	Simply type in a value for each text entry box. The default value for each is $0$ (zero).
Slope Correction	Next select or de-select <b>Slope Correction</b> by <b>Curvature and</b> <b>Refraction</b> by using the check box provided.
Horizontal Distance	Finally, use the <b>Horizontal Distance</b> option buttons to select the elevation at which your horizontal distance is computed.

## <u>CAD Configuration Menu</u> (CM)

FUNCTION: The <u>C</u>AD configuration menu controls Drawing Scale, Paper Size, CAD Units, Printed Precision on the drawing, Padding Options, Page Center Coordinates, Dimensioning of Short Lines, and the Distance Symbol.

To access this screen from the keyboard, press AHG, C, or type CM.

Configuration Screen	×
Text Output Slope Entry	CAD COGO Angle Setup File Paths
Paper Size / Scale	eet CAD Units Page Center
Arch. D 24x36"	<u>Meters</u> <u>East</u> <u>20000</u>
Cad Background Color —	White
- Printed Prec	Dimensioning of Short Lines
Bng: 1 ▼	C Shrink te <u>x</u> t to fit along line
Cids: 2	Create a short line table
Dist <u>:</u> 2 💌	Padding Option
Elev: 2	Pad with space 💌 Custom Lines
Dist. Smbl. Text Offset	Label Offset
. 3.0	6.0 Reset <u>O</u> S Layers
<u></u> K	<u>C</u> ancel <u>H</u> elp

Section 13

Drawing Scale	The <b>Paper Size / Drawing Scale</b> section is where you set the output scale of your drawing which determines such things as text size and symbol size. Set the scale by entering a value in the text box. Be sure to notice the <b>CAD Units</b> and enter an appropriate value. Scaling is very straight forward, but may be slightly different than what you might be used to. For example, standard engineering scales encourage you to think of 1" = so many feet, let's say 100'. "Sight" Survey's <b>Drawing Scale</b> is shown to be 1 foot = so many feet. Since their are 12 inches to the foot, the correct entry would be $1' = 1200'$ . Likewise for a 60 scale drawing where $1" = 60$ ° The entered scale would be $1' = 720'$ (60° x 12").							
Paper Size	Staying in the <b>Paper Size / Drawing</b> scrollable selection list to select or fers 10 US paper sizes (in inches)	ur paper size. "Sight" Survey of-						
	<b>A</b> - 8 ¹ / ₂ " x 11" <b>Legal</b> - 8 ¹ / ₂ " x 14" <b>B</b> - 11" x 17" <b>C</b> - 17" x 22" <b>D</b> - 22" x 34"	E - 34" x 44" F - 28" x 40" Architectural C - 18" x 24" Architectural D - 24" x 36" Architectural E - 36" x 48"						
	Four metric paper sizes (in mm) and	re also offered. These sizes are:						
	<b>A0</b> - 841mm x 1189mm <b>A1</b> - 594mm x 841mm							
CAD Units	Begin by setting your CAD Units. Feet; Inches; and Meters. Select a the option button next to it. In mo ing small details, your choice will pending upon your choice, two oth menu may change: the units in the Symbol.	unit of measure by clicking on st cases, unless you are prepar- be either <b>Feet</b> or <b>Meters</b> . De- ner elements on the <b>CAD</b> sub-						
Page Center Coordinates	The <b>Page Center Coordinates</b> section lets you set the actual coordinates of the center of the page. Use the text boxes to specify these coordinates. "Sight" Survey uses the specified coordinates to orient the paper border over your drawing.							




The two-letter code **CE** can be used to **Re-Center the Paper** on your drawing.

CAD Background Color	<b>CAD Background Color</b> controls the background color of the <b>Drawing</b> window.
į	Changing the color in the middle of a drawing will render invisible any drawing objects that match the background color. However, while you cannot see them, they will still print, except for white. Remember to set object colors accordingly.
Printed Precision	<b>Printed Precision</b> controls the number of places to which numerical data will be printed <i>on your drawing</i> . It has nothing to do with internal precision, nor does it have anything to do with the <b>Printed Precision</b> portion of the <b>Text Output</b> configuration. Your choices are: <b>Coordinates</b> - 0 to 6; <b>Distances</b> - 0 to 6; <b>Elevations</b> - 0 to 3; and <b>Bearings</b> - 0 to 3 (seconds value) in degrees, or 0 to 6 in grads. If you are using <b>Bearings</b> you may also elect to have your bearings rounded to the nearest <b>Minute</b> , or rounded to the nearest <b>Degree</b> .
Dimensioning of Short Lines	Dimensioning of Short Lines controls text placement on lines that are physically too short to accommodate text. Check an option button to either: Shrink the text to fit along the line; or Create a short line table. If you choose the later, short lines will be marked by an identifier that corresponds to an entry in the short line table. To import the short line table use the menu item Draw ³ → Supplemental ³ → Short Line Table, or enter the two-letter command SL.
Padding Options	The <b>Padding Options</b> section uses a selection list to control the characters placed before any degrees entry that is less than 10. You can <b>Pad with a space</b> (e.g. N 5°E); <b>Pad with a 0</b> (e.g. N05°E); <b>Pad with a space and a 0</b> (e.g. N 05°E); or <b>No Pad</b> (e.g. N5°E). (When you are set for azimuths, the padding option is irrelevant and will not be shown.)
Distance Symbol	The <b>Distance Symbol</b> section is a text box whose initial setting corresponds to the selected <b>CAD Units</b> . You can print any character(s) you want behind the distances in your drawing by changing this entry. For example, you may want to use <b>ft</b> . instead of <b>'</b> or <b>in</b> . instead of <b>"</b> .
Text Offset Distance	The <b>Text Offset</b> box allows you to control the distance that annotations are offset from the lines on your drawings. This

setting is used when text (bearings, distances, etc.) is placed along a line on your drawing. (Point labels are selected in the **Properties** window within the **Label Type** property.)

Each whole number unit represents  $1/100^{\text{th}}$  of an inch on the paper when the drawing is printed at the specified scale. For example, the entry of 3.0 shown in the above screen would place bearings and distances  $3/100^{\text{ths}}$  of an inch from the lines when the drawing is printed at the specified drawing scale of 1:1200 (shown in the **Paper Size / Scale** field). If the drawing is plotted at a scale other than what it was created at, the offset distance will not match the selected setting.



ad

Custom Lines

The two-letter code **EL** (Edit Layers) can also be used to access the Layer Editing Box.

Selecting the <u>Custom Lines</u> button will open the custom line type file, CustomLT.Mac within the Windows Notepad. From here, you can edit, delete, or add custom lines. Each custom line is defined by 16 columns of information. The file is a free format spacedelimited ASCII file. Each column must be separated from the others by one or more spaces.

<u>File E</u> dit <u>S</u> earch																
	on linestyles	for	plo	otter an	d so	reen										
EM																
EM	Name of cus															
EN	1	Cha		er to u												
EM	1		0 t						ace a font c							
EM	1			-1 to					drawing, ot							
EM	1				11				cter, 0 to m		way	s ke	ep ri	eadal	ble	
EM	1					-1 t			racter, 0 to							
EM							Repea		ctor in mm o						epeats e	very N mm.
EM	1						1	Lir	etype to use	to connect	th	e cha	arac	ters		
EM	!						1		Font Name							
EM	!		1				1		1	For	t S:					
ЕМ	1		1		1		1	1	1		SU	rike				
EM	1		1		1		1	1	1			UN	ier1			
REM Rem	1		1		1		1	1	!		1	1	Bo:			
REM	!		1		1	1		1	!		1			10	alic	a
REM	!		1		1			1	!	!					Color Color	0 = Haroon 1 = Red
REM	!		1		1				!						Color	1 = кеа 2 = Olive
REM	!		1		1				1		1			1	Color	2 = 0110e 3 = Yellow
REM	1		1		1	1		1	1		1	1	1	1	COTOP	3 = A61100
SE PI	1		1						1						1	
Ren	Lines that			anonto	for	the	obawao	tow								
SETCUSTOMET	Brickwall	2	A	-1	1	ß	1.5	A	Arial	18	ព	ព	ព	ព	9	
SETCUSTONET	Centerline		â	-1	2	ด	50.8	ĩ	Arial	10	ด	ด	ด	ด	9	
SETCUSTONLT	Chainlink		8	-1	í	1	12.7		Arial	10	8	8	8	8	0	
SETCUSTONLT	Electrical		8	-1	6	i.	25.4		Arial	18	6	6	6	8	0	
SETCUSTONLT	Hydrants	ò	ñ	-1	2	÷.	50.8	i.	Arial	18	ñ	ñ	ñ	ñ	ó	
SETCUSTONLT	Railroad		ñ	-1	2	ĥ	6.35	i	Arial	10	ด	ő	ñ	ø	ó	
SETCUSTONLT	Stonewall	13		-1	ĩ	ด้	2.5	Å	Arial	10	ด	ด้	ด้	ด้	0	
SETCUSTONLT	Treeline	21	ŏ	1200		õ	5.1	ĭ	Arial	6	0	õ	õ	õ	9	
SETCUSTOMLT	Woodfence	23	0	-1	1	1	12.7	1	Arial	10	0	0	0	0	9	
end																
												_				

The custom lines defined here may only be selected through the **Properties** window **for use with COGO routines**. These lines are not accessible when using **Drawing** window commands, nor can they be placed in the Linetype.Mac file. Drawing window linetypes are set using <u>Start</u> **Settings SLine Defaults**.

#### EXCEPTION

There is one exception to this rule. You can use custom line types with the command LI (or click  $\nearrow$ ) which draws a chained line. (Custom line types **do not** work with the <u>Start</u>  $\Rightarrow$  <u>Draw</u>  $\Rightarrow$  Line (Chained) command.)

**Deleting Custom Lines** To delete a custom line, highlight the line and press Delete twice. If you want to keep the line for possible later use, you can prevent it from showing in the Line Type selection list in the Properties window by adding REM followed by a space to the front of the line (i.e. REM SETCUSTOMLT).

Adding Custom Lines To add a new custom line, copy one of the existing lines and modify it to match the desired settings for your new line. Use the normal Windows commands for highlighting, copying, and pasting. Refer to your Windows documentation for assistance. Be sure to save the file when you exit Notepad. You must also exit and restart "Sight" Survey for the new line(s) to be available in the Line Type selection list in the Properties window.

- **Editing Custom Lines** To edit an existing custom line, simply change the columns to match your desired settings for that line. Be sure to save the file when you exit Notepad. You must also change the Line Type selection in the **Properties** window to update "Sight" Survey with the new custom line settings. Let's look at each of the columns individually.
  - Active vs. Inactive Each *active* custom line must have the word SETCUSTOMLT for the first column. Only active custom lines are displayed in the Line Type property of the Properties window. You can keep the Line Type selection list uncluttered by REMarking or deleting custom lines that you do not need (or want). Each *Inactive* line must begin with REM followed by a space (i.e. REM SETCUSTOMLT).
  - Name of LineThe second column contains the name of the custom line. This<br/>name appears in the Line Type selection list in the Properties<br/>window. Do not use any spaces in the name.
  - CharacterThe third column contains the actual alphabetic character (or its<br/>equivalent ASCII character code) or the number of the end point<br/>symbol to place along the line. For example, to place the letter R<br/>along the line, enter either an R or the number 82 into this column.<br/>The actual character format is determined by the entries in the<br/>other column entries such as the font name, size, and color.

To place an **lron_Pin** symbol along the line, enter the number **10**. Symbols are numbered alphabetically, starting at two (**2**). Symbol numbers greater than **23** are invalid unless you have added additional symbols to the **DMCustom.Sym** file (in which case the numbers listed in the following table may be incorrect).

2	푸	Brickwall	13	$\bigcirc$	Manhole
3	q_	Centerline	14	Ô	Power_Pole
4	•	Concrete_Mon ument	15		Solid_Square
5	+	Cross	16		Storm_Inlet
6	•	Dot	17	Т	Telephone_Bo x
7	Ε	Electric_Box	18		Tic_Mark
8	G	Gas_Riser	19		Traverse_Point
9	Ŷ	Hydrant	20		Tree_(Large)
10	lacksquare	Iron_Pin	21	**	Tree_(Small)
11	Ο	Iron_Pipe	22	$\otimes$	Valve_Box
12	Ø	Light_Pole	23		Wood_Stake

match that scale. If you'd like the characters placed twice as large

The pre-defined "Sight" Survey symbols and their equivalent numbers are shown in the following table:

Character TypeThe fourth column identifies the character type shown in column<br/>three. Enter a 0 (zero) if column three contains a symbol number,<br/>or enter a 1 if column three contains a font character. If you enter<br/>a 0 (zero for a symbol), remember that numbers 2 through 23 are<br/>the only valid numbers for column three unless you've added<br/>symbols to "Sight" Survey. If column three contains an invalid<br/>symbol number, you will receive one or more "Symbol not found"<br/>messages when the line is placed.Scale FactorThe fifth column contains the scale factor for the character. Enter<br/>-1 to scale the character to match the drawing scale, otherwise<br/>enter the exact scale (in CAD units) that you'd like to use. For<br/>example, if your drawing scale is 1:1200, enter -1 if you want to

as they would normally be placed, enter 600 as the scale. Likewise, enter 2400 to make them half the size.

Rotation The sixth column contains the desired character rotation. Enter 0 to never rotate the character; enter 1 to rotate the character to match the line angle; or enter 2 to rotate the character to match the line *but to also be readable*. The rotation affects only the symbol, or in this case the character, which is placed along the line. Notice the effect of the three different rotation options on the character P in the sample powerlines in the following diagram.

	A A A A A A A A A A A A A A A A A A A
Trimming	The seventh column contains the desired trimming option. Enter a <b>0</b> (zero) to indicate no trimming, or enter a <b>1</b> to trim all lines under the characters.
Repeat Factor	The eighth column contains the repeat factor or interval, in millimeters, for the character placement. Enter a number based upon how often you want to see the character on the <b>printed output</b> . For example, enter the number <b>15</b> to place a symbol every <b>15</b> millimeters on the printed/plotted output.
Line Type	The ninth column contains the line style to use. Enter the number corresponding to the Line Type you wish to use as the underlying line between the characters. When a custom lines is specified for a rectangle, circle, or random curve, the line type specified in this

column will be placed instead of the custom line.

Line Type are numbered as follows: 0-No Line; 1-Continuous; 2-Dashed; 3-Hidden; 4-Center2; 5-Phantom2; 6-Dot2; 7-Dot; 8-Border2; 9-Border; 10-Divide2; 11-Divide.

į	If column four contains a $0$ (zero for symbol), the remaining seven columns are ignored; however, they must still contain something (anything) to maintain the proper format.
Font Name	The tenth column contains the name of the font to use for the character specified in column three. Enter the exact name of the desired font. Usable fonts are shown in the <b>Text Font</b> property of the <b>Properties</b> window. If the font name has spaces in it, you must either replace the spaces with the underscore character () or enclose the font name in double quotes. For example, enter <b>Courier New</b> as either <b>Courier_New</b> or " <b>Courier New</b> ".
Font Size	The eleventh column contains the font size. Enter the desired size (in points) for the character specified in column three.
Font Strikeout	The twelfth column contains the strikeout setting for the character specified in column three. Enter a $0$ (zero) for a regular character, or enter a $1$ to strikeout the character.
Font Underline	The thirteenth column contains the underline setting for the character specified in column three. Enter a $0$ (zero) for a regular character, or enter a $1$ to <u>underline</u> the character.
Font Bold	The fourteenth column contains the bold setting for the character specified in column three. Enter a 0 (zero) for a regular character, or enter a 1 to <b>embolden</b> the character with a strikeout line.
Font Italic	The fifteenth column contains the italic setting for the character specified in column three. Enter a $0$ (zero) for a regular character, or enter a $1$ to <i>italicize</i> the character.
Color	The last column contains the color setting for the line specified in column nine and the character specified in column three. Enter the number corresponding to the desired color. Colors are numbered as follows: 0-Maroon; 1-Red; 2-Olive; 3-Yellow; 4-Lime; 5-Green; 6-Teal; 7-Aqua; 8-Blue; 9-Navy; 10-Purple; 11-Fuschia; 12-White; 13-Gray; 14-Black; 15-Silver; 16-By Layer.

-

Airplane													
→ → Brickwall	÷	÷	÷	÷	÷	÷	÷	÷	÷	÷	÷	÷	÷
Centerline							G				- G-		
Chainlink													
Electrical	—E		—(E)—		—(E)—		—(E)—		—œ—		—(E)—		
Fenceline X	_x		_x					X					
GasLine	—G—		—G—		— G—		—G—		— G—		—G—		
Guardrail		0	0			•	•	•	0		•	•	
Hydrants													
Powerline	—P—		—p —		— P —		—P—		— P —		—P—		
Railroad						<b></b>							_
Sewerline	_s_		_s_		s		s		s		s		
Stonewall		000000							000000	000000	00000	~~~~	
Telephone			-0-				@		-0-				
Treeline	* * *	* *	* * *	* *	* * *		* * *	* *	* * *	**	* * *	**	*
Waterline	-w		-w										
Woodfence	, 												

Custom lines furnished with "Sight" Survey (Not to scale)

13.05

### COGO Configuration Menu

FUNCTION: The COGO Configuration Menu controls Drawing Save Format, Stations Format, Offsets, Constant Factor, Area Units, Point Overwrite Protection, Automatic Point Numbering, and the Prompting for (point) Descriptions.

To access this screen from the keyboard, press AttG, G.



Configuration Screen	×
Iext Output   Slope Entry   CAD   CO	GO Angle Setup File Paths
Automatic Point <u>Numbering</u> Show     Point Overwrite Protection	Stations Format © <u>0</u> +00.00 © <u>0</u> <u>-</u> 000.00 Offsets (DD) Constant Factor (CF) Defined Figures (DF) Change Cogo Font Restore All Defaults Ild Style Cogo Window Tool Tips e Backup File on Save
<u> </u>	Help

Least Squares	The Least Squares section allows you set the standard deviation values for use within the least squares adjustment procedure. Set the Standard Deviation of Angles and the Standard Deviation of Distances to the exact error values stated in your instrument's manual or as calibrated by your measurement samples. "Sight" Survey uses 30.0 as the default for the Standard Deviation of Angles and 0.050 for the Standard Deviation of Distances, but you will need to change these defaults to appropriate values for your equipment.
Standard Deviation of An <u>gl</u> es	If Angular Units is set to Degrees, the Standard Deviation of Angles must be entered in <i>seconds</i> . If Angular Units is set to Grads, the Standard Deviation of Angles must be entered in <i>grads</i> . The Angular Units setting is shown on the <u>Angle Setup</u> tab of the Configuration Menu.
Standard D <u>e</u> viation of Distances	The <b>Standard Deviation of Distances</b> consists of two parts: a constant error and a proportional error, usually referenced in ppm (parts per million). Your instrument documentation may reference this in a format such as: $\pm(5 \text{ mm} + 4 \text{ ppm})$ . If <b>Area Units</b> is set to
	Acres & Square Feet, the Standard Deviation of Distances must be entered in <i>feet</i> . If Area Units is set to either Cuerdas & Square Meters or Hectares & Square Meters, the Standard Deviation of Distances must be entered in <i>meters</i> .

"Sight" Survey uses the *additive* method to compute standard deviations, so you must add the two error parts together and enter their sum as the **Standard Deviation of Distances**. To determine the correct entry for this field, you must first convert the given values to the units you are working in (feet or meters) if they are different from what the documentation shows. Next, you must multiply the proportional error times an average survey distance for the current COGO job and then add that amount to the constant error.

Using an instrument error of  $\pm$ (5 mm + 4 ppm) as an example, the 5 millimeters constant error converts to 0.016 feet or 0.005 meters. The 4 ppm proportional error for a survey with average distances of 500 feet (roughly 152 meters) equals 0.002 feet (4 ft / 1,000,000 ft * 500 ft) or 0.0006 meters (4 m / 1,000,000 m * 152 m). Adding the constant and proportional errors together gives us a total distance error of 0.018 feet or 0.0056 meters. This is the value that you would enter for the Standard Deviation of Distances.

If you want to display the **Standard Deviation** columns for angles and distances while the **Traverse Adjustment** window is open, enable the **Display Standard Deviations** check box. When these columns are displayed you will be able to edit them, if desired. If you have no need to edit the values, we recommend that you disable this check box to save screen space within the **Traverse Adjustment** window.



When the **Traverse Adjustment** window is open, doubleclicking on the **Bearing** or **Distance** column headings will toggle the display of the **Standard Deviation** columns between on and off.

Section 13

Stations FormatStations Format lets you choose between 0+00.00 (a US stationing<br/>format) and 0+000.00 (a metric stationing format).Area UnitsThe Area Units selection list allows you to choose among three unit<br/>types: Acres & Square Feet; Cuerdas and Square Meters; and Hec-<br/>tares and Square Meters.Close Tips After StartupClose Tips After Startup is a check box option. When checked, the<br/>Tip of the Day window will automatically close after "Sight"<br/>Survey has finished its startup procedures.

Prompt for Point Description	<b>Prompt for Point Description</b> is a check box option. If active, whenever you enter or compute a new point you will be asked to supply a point name or description of up to 28 characters in length. If you leave this option disabled, you may manually enter a point name using the <b>Points Point Point</b> function ( <b>ID</b> ).
$\succ$	The two-letter code <b>NO</b> can be used to toggle the <b>Prompt for</b> <b>Point Description</b> setting <b>On</b> and <b>Off</b> .
Automatic Point Numbering	The Automatic Point Numbering check box will enable or disable automatic point numbering. Use the AN routine code to toggle Automatic Point Numbering between On or Off.
	When Automatic Point Numbering is On, "Sight" Survey will seek out the first available point number beyond the occupied point number, with one exception. If you are setting Side Shots, "Sight" Survey will seek out the first available point number beyond the point number of the last side shot.
Point Overwrite Protection	The <b>Point Overwrite Protection</b> check box will enable or disable automatic protection of already used points.
	When <b>Point Overwrite Protection</b> is <b>On</b> , you are warned when you are about to overwrite an existing point. You may choose to overwrite the point or enter a new point number. You may manually override <b>Point Overwrite Protection</b> by placing an asterisk (*) immediately after the point number, such as $45*$ First. Using the manual override method will suppress the warning message.
Use Old Style COGO Window	The <b>Use Old Style COGO Window</b> check box will enable or disable the 20 user-defined buttons in the <b>Data Entry</b> window. When checked, the user-defined buttons are visible and active. When unchecked, the user-defined buttons disappear and you can reshape the window into a more horizontal format.
	In addition to enabling and disabling the 20 user-defined buttons in the <b>Data Entry</b> window, this setting also controls the mode of resizing for the <b>Data Entry</b> window.
	When this checkbox is unchecked, the text boxes in the <b>Data Entry</b> window always maintain their original size, but fill the window

with the boxes from left to right and from top to bottom. Depending upon how you size the window, you can make your **Data Entry** window into a horizontal entry form, perhaps better utilizing screen space.

When this checkbox is checked, the text boxes grow in proportion to the size of window.

Tool tips are little memo boxes that appear as you hover your mouse above a toolbar item. The memo box tells you what the function the button will perform when clicked. If the button has both left and right mouse click functions, the tool tip will show both options separated by a slash.

For example, in the illustration shown to the left, a left-click would **Save** the job under the current name, while a right-click would let you **Save As** a different job name.

Selecting this setting causes "Sight" Survey to create a backup file of the previous coordinate data. The backup coordinate file will have a .zbk extension. To reload backup file, rename the file to have .zak extension.

Selecting the Offset (OD) button opens an Offset Define window. Using this window, you can add or delete offset values to be automatically used during Traverse with Offset routines (both line and arc).

Offset Define
Offset Distance Description
Add Delete Accept Cancel Help



*The two-letter code* **OD** *can be used to access the* **Offset Define** *routine.* 



**Create Backup File on Save** 

Offsets

_			
2			

The **Offset Define** window will accommodate an unlimited number of offset entries, turning into a scrolling menu as needed. To add an entry, click Add to activate the **Offset Distance** dialog box.

Offset Distance				
O.S. Dist.				
Description	Default			
<u>A</u> ccept	<u>C</u> ancel			

Type a value for the **O.S. Dist.** (offset distance). Positive numbers offset to the right and negative numbers offset to the left, all relative to the foresight direction. Press Table, or <u>-Enter</u> to highlight the **Description** entry. Now type a new description, or leave this entry set to **Default**, and click on <u>Accept</u>

When the description field shows a **Default** setting, your description will read something similar to: OS 25 R @ Pt. ?

You can **replace** the default description by clicking your mouse on the description in the **Offset Define** window and then typing over it. To **erase** the description, press **Space Bar -Enter**. To **edit** the default description, click your mouse on the description, wait a moment and then click again. The text entry cursor will relocate to the beginning of the line and you can edit as you wish.



**Constant Factor** 

Unlike other **Config** items, an **Offset Define** table must be set up for each job on which you want to use it.

Selecting the <u>Constant Factor (CF)</u> button opens a text box into which you may enter a numerical constant that will be applied to each entered distance. Use constant factors for things such as: to convert feet to meters (or any unit to another); to apply correction factors for steel tape measurements; to apply a grid factor, etc. To invoke the constant factor on a particular distance, preface your distance entry with a slash ( / ) or semicolon (;). For example, if the multiplier is 0.90 and the measured distance is 300.00, an entry of /300 or ;300 would yield a distance entry of 270.00, which equals 0.90 * 300.

tection 13

To clear a Constant Factor, issue the CF command and enter a value of **1**.

$\bigcirc$	The	e Constant Factor has two pre-programmed applications.
Y	А.	A multiplier followed by the letter <b>A</b> , signals the computer that you are going to create a correction factor for the at- mospheric effect on distances measured with an infrared EDM. The monitor will accept the first entry as a temper- ature in deg. F., (or deg. C. if working in metric units), and then request a pressure which is in inches of Hg. (or mm. Hg. if working in metric units). The correction factor will be computed as:
		1+(278.45-((10.5P)/(1+(T*0.002175)))) (English units)
		1+(278.45-((0.3865P)/(1+(T*0.003661)))) (Metric units)
		where P is the pressure in inches (or mm.) Hg, and T is the temperature in degrees F, (or deg. C.). Check this factor against the specifications of your EDM before using.
	B.	A value followed by the letter <b>T</b> will cause the correction factor to become a temperature correction for steel tapes. For example, the entry <b>88T</b> will convert to a factor for 88 degrees F. of $1+0.0000065*(88-68)$ , $(1+0.000001161*(T-20)$ in metric units). The number entered may be the temperature in deg. F., or deg. C., (if working in metric units). The formula assumes the tape was standardized at 68 deg. F., (or 20 deg. C.).
٩	1.	<i>The two-letter code</i> <b>CF</b> <i>can be used to access the</i> <b>Constant Factor</b> <i>routine.</i>
	2.	Unlike other <b>Config</b> items, the <b>Constant Factor</b> is not retained between sessions and must be set up for each session in which you want to use it.

**Define Figures** 

I

Selecting the Defined Figures (DF) button activates the Define Figures function. See Section 3.17 on page 249 for information on entering Defined Figures.

13.06

Change COGO Font	Selecting the Change Cogo Font button allows you to change				
	the font used in the Data Entry window. Select a new font using				
	a modified Windows font selection dialog box. You will not be				
	able to set a font color, and any font formatting, i.e. bold, italic,				
	etc., will be ignored. Font colors may be adjusted using the				
	Adjust Screen Colors function described on page 414.				
Restore All Defaults	Selecting the Restore All Defaults button resets all "Sight"				
	Survey settings to the installation defaults.				

# Angle Setup Configuration Menu

	<b>FUNCTION:</b> The <u>Angle Setup</u> configuration menu controls the <u>Default Angle</u> , <u>Angular Units</u> , <u>Angle Output</u> format, <u>Azimuth</u> <u>Direction</u> , and the <u>Angle Code Set</u> .
	To access this screen from the keyboard, press Alt, G, R, Alt, A, or CM Alt, A. (The menu is shown on the next page.)
Default Angle	The <b>Default Angle</b> is the angle format that is applied to your data entry when it does not contain a specific format. For example, if you select <b>Angle Right</b> as the default, you could enter all of your angle right entries as something like <b>47.3325</b> with a still use codes to specify a different type of angle, such as <b>47.3325</b> AL which is the same value, but it is turned to the left. Select the <b>Default Angle</b> through a selection list containing four choices: None; Azimuths; Angle Right; and Deflect Right.
Angular Units	The <b>Angular Units</b> option buttons allow you to choose to have your angular data entered and output in either <b>Degrees</b> or <b>Grads</b> .
Angle Output	The <b>Angle Output</b> option buttons allow you to choose to have your angle output in either <b>Bearings</b> or <b>Azimuths</b> .

Configuration Screen					×
Iext Output Slope Entry	CA <u>D</u>	CO <u>G</u> O	Angle Setup	File <u>P</u> aths	
Default Angle Angle Right					
Angular Units — © Degrees © Grads		⊂ Azim			
← Angle Output ←		⊙ SS	e Code Set 1] Angle Codes 2 Angle Codes		
<u></u> K	<u>C</u> ano	cel	<u>H</u> elp		

Azimuth Direction	The <b>Azimuth Direction</b> option buttons allow you to choose to have your azimuth referenced <b>North</b> or <b>South</b> .
Angle Code Set	The Angle Code Set option buttons allow you to choose between SSI Angle Codes and HP Angle Codes.

# <u>F</u>ile Paths Configuration Menu

13.07

**FUNCTION:** The <u>File Paths</u> configuration sub-menu controls the path names for various files, including: Data Files, Utility Files, LegalEase Files, and Program Files. Section 13

To access this screen from the keyboard, press AHG, R, AHP, or CM AHP.

Iext Output       Slope Entry       CAD       COGO       Angle Setup       File Paths         To Data:       E:\SIGHTSRV       Change
To Data: E:\SIGHTSRVChange
To Data: E:\SIGHTSRV
To Utilities: E:\SIGHTSRV\UTILITY Change
To LegalEase: E:\SIGHTSRV\PROGRAM Change
LegalEase Editor: WINWORD
To CollConn: E:\SIGHTSRV\COLLCONN Change
To Programs: E:\SIGHTSRV\PROGRAM
<u> </u>

"Sight" Survey sets path names during installation. Unless you move files or rename folders (or Windows 3 directories), *DON'T CHANGE THESE PATH NAMES!* If you do change them and "Sight" Survey no longer functions, your path names are incorrect.



*The path* **To Programs** *is not changeable. It is shown only as an informational item.* 

To change a path name, *if you must*, click on the **Change** button next to the path name you want to change. This will open a path selection box.

⊖ c:\
🗭 sightsrv Ĉ collconn Ĉ job Ĉ program Ĉ utility
<b></b> C:
<u>A</u> ccept <u>C</u> ancel

The top portion of the box contains the current path name. The lower selection list shows the current drive.

To Change DrivesClick on the drive selection list, or on the Click on the drive selection list, or on the button. The drop-<br/>down list may or may not be scrollable. Click on the new drive.To Change DirectoriesSet the file path in the upper box by clicking your mouse on<br/>directories and subdirectories until you have located the correct<br/>directory.

When you are done, click on Accept or press Alt A.

13.08

### Customize Side Tool Bar

**FUNCTION:** The **Customize Side Tool Bar** function allows you to assign a command string to each of the 20 buttons on the left side of the **Data Entry** window, which can be used to call up commonly used routines or execute other commands.

Sectio 13

To access this screen from the keyboard, press AttG, S.

You will be presented with a window containing 20 buttons in a row on the left side and 20 text entry boxes on the right. The buttons on the left represent the 20 buttons on the side tool bar of the data entry screen and the text entry boxes contain the commands that will be executed when the button is selected.

🚮 Trav	verse					
	Enter a point number					
ST	GT	From Point	1002			
EB	EP	To Point	907			
IN	IC	Bearing	5.0133 NW			
TR	TA	Distance	107.25			
TS	IS					
PO	SS					
TC	ED					
PA	BP					
BB	DD					
BD	DB	E	Accept (PgDn)			

Data Entry Window showing Side Tool Bar

Customize Toolbar 🛛 🕅				
Enter the text for the buttons and the commands that should be executed when the button is pressed.				
ST	ST			
EB	EB			
IN	IN			
TR	TR			
TS	TS			
PO	PO			
TC	TC			
PA	PA			
BB	BB			
BD	BD			
GT	GT			
EP	EP			
IC	IC			
TA	TA			
IS	IS			
SS	SS			
ED	ED			
BP	BP			
DD	DD			
DB	DB			
	<u> </u>			

The buttons are arranged as follows: The top 10 buttons make up the left column, and the bottom 10 buttons make up the right column.

- 1. Click your mouse on the button for which you would like to change the caption.
- 2. Type the new caption. Any text you type will replace the old text. (Only about 2 or 3 characters will fit on the button's face.)
- 3. The button caption is editable using the arrow keys and the backspace key.
- 4. Click your mouse on the next button which you would like to modify or on a text entry box.

You can click **Cancel** to abort any changes, or click the **OK** button to accept the changes made.

### Changing a Button Caption

Section 13

Changing a	Button Command	1. Click your mouse on the text entry box to the right of the button you wish to modify.
		2. Enter the command (or command string) that should be executed when the button is clicked.
		3. Select a different text entry box or button to modify.
Valid Command Strings		Command strings can contain :
		1. Any number of two letter commands;
		2. Numeric data to be placed into a text box;
		3. A pipe symbol ( " $ $ "), which is interpreted as pressing $\bigcirc$ ;
		<ol> <li>A caret symbol ( "^ "), which instructs "Sight" Survey to clear the current field;</li> </ol>
		5. Extra spaces which are ignored by "Sight" Survey.
Examples	Command:	ST
	Result:	"Sight" Survey will jump into the Start routine
	Command:	ST ^ 2
	Result:	Run the start routine, enter 2 as the starting point, and hit enter.
	Command: Result:	<b>ST 1 in 2 SS 90 -6 65 TA 1 45 I Start</b> at point 1, <b>Inverse</b> to point 2, <b>Side Shot</b> 90° angle left a distance of 65 feet, and <b>Traverse an Arc</b> through center point 1 with a delta angle of 45°
	į	The -6 in the third term: SS ^90 -6, indicates an angle left if you are using the Simplicity Systems, Inc. Angle Code Set. Under the HP Angle Code Set it would be an angle right.

Creating a command string takes time and patience. You need to think how you would do it manually, then recreate the steps.

See page 163 for a discussion on angle codes.

### Adjust Screen Colors

FUNCTION: The <u>Adjust Screen Colors</u> command is used to adjust the background and label colors for "Sight" Survey's **Data Entry** and window.

To access this screen from the keyboard, press AtG, A.

After selecting the **Adjust Screen Colors** routine you will be presented with a window containing three options: Form Color; Label Color; and Text Color.

-

	Customize colors
	Form Color
	Label Color Text Color
	OK <u>C</u> ancel <u>H</u> elp
-	the color of the text used in all text boxes click your the <b>Text Color</b> box.

To change the **Label Color**, the color used for text in all labels or prompts, click your mouse on the raised label.

To change the **Form Color**, the color of the background used in the **COGO**, **Config**, and **Properties** windows, click your mouse on the background of the window (not on the label or text box).

When you select an item to change, a color selection window will appear, allowing you to choose the color to be used for the screen background.

In the color selection window, the current color is outlined for easy identification. To select a new color, you may click on a **Basic Color**, an already defined **Custom Color**, or the **Define Custom Colors** button which allows you to create a new color.

13.09

**Text Color** 


Label Color

Form Color



When you elect to **Define** (a new) **Custom Color**, the **Color** menu expands to include: a **Color Mixing Area**; a **Luminescence Bar**; a **Current Color | Solid** box; **Red**, **Green**, and **Blue** control boxes; and **Hue**, **Saturation**, and **Luminescence** control boxes.

To create a new color, begin by clicking on one of the 16 color boxes in the **Custom Colors** area. The box you choose will be the storage location for your new color.



Color Mixing Area & Luminescence Bar

To create a color in the mixing area, use your mouse cursor to drag the crosshair marker around the mixing area to find the desired shade. As you move the crosshairs, notice the changing values in the **Color Control** boxes as well as the changing colors in the **Current Color | Solid** box. The **Current Color** is the actual shade of the 

 down the Luminescence Bar to control the relative lightness of the pure color.

 Color Control boxes
 To create a color with the control boxes, simply enter the values into the text entry boxes. Red, Green, and Blue control the actual strength of each respective color component. Hue is the actual pure color number and Saturation is a measure of the strength of the Hue. Luminescence controls the relative lightness of the color.

 Saving Custom Colors
 When you have successfully designed your new custom color, click Add to Custom Colors to save it. Now click OK to activate your new color and close the color selection window.



The color you select or create may not always be supported by your video setup. When this occurs, the closest allowable color match will be used.

chosen **Solid Color**. The difference between the two colors is controlled by the **Luminescence Bar**. Slide the • arrow up and

### 13.10

### <u>S</u>how Status Bar

**FUNCTION:** The <u>Show Status Bar</u> item is a toggle switch that displays and hides the status bar at the bottom of the "Sight" Survey screen.

To access this screen from the keyboard, press AltG, H.

Simply click your mouse on the Show Status Bar item to turn it On and Off.

56% To delete an object select it, then press the 'DELETE' key. Press 'INSERT' to undo. N:9501.16 E:20079.59

The status bar contains four areas. On the left is a **System Resources** indicator which reports the percentage of free system resources you have available. When Windows starts, it automatically allocates a portion of memory for system resources. This memory is used by Windows to keep track of open windows, programs in use, icons, program groups, etc. However, Windows doesn't manage this memory very well. When a program is started under Windows, a chunk of system resource memory is used. When the program is closed, the program is supposed to give all the memory back, but almost all programs steal some.

When your free resources drop to below 25% you are skating on thin ice. Proceed at your own risk. We strongly suggest you save your data, exit and restart Windows. When your free resources drop to below 10%, a Windows crash is imminent. Save your data and restart Windows. If Windows crashes, you'll lose all your unsaved work.

The second box consumes the majority of the status bar and contains context sensitive help and tips.

The third and fourth boxes, on the right of the screen, contain the Northing and Easting coordinates at the tip of the drawing cursor. These values are relative to the page center coordinates discussed on page 393.

### 13.11

### Show Tool Bar

¥

**FUNCTION:** The **Show Tool Bar** item is a toggle switch which displays and hides the Main tool bar which lies just under the pull-down menu bar at the top of the "Sight" Survey screen.

Section 13

To show or hide this screen from the keyboard, press Att G, W.

Click your mouse on the item to turn it on and off. (The bar shown below has been split into four sections to enhance detail.)



The tool bar buttons represent routines or commonly used functions. To activate a tool bar button point to it with your mouse and click on it. Many buttons have functions for both left and right clicks. The icons and their functions are described below.

	Left: Exit (quit) "Sight" Survey       2         Right: File Path Configuration       4	
	Left: Save Job	
-	Left: New Job	
?	Left: Status - Display point and backsight bearing. Right: System Information	l60
edit Raw	Left: Edit Original Raw Data2	227
EDIT CRDS	Left: Edit Coordinates	
FIG	Left: Define Figure	249
<b>S</b>	Left: Define Offsets       4         Right: Constant Factor       4	
THIS ?	Left: Query Entity       7         Right: Selection Filter       5	

M	Left: Layer Control839Right: Layer Override849
POINT PLOT	Left: Point Plot
?+	Left: Get Point         375           Right: Get a Point Series (String)         376
V	Left: Select Points
<u> </u>	Left: Measure an Angle347Right: Angle Configuration Menu408
X	Left: Measure a Distance       346         Right: Slope Configuration Menu       390
Þ	Left: CAD Configuration Menu392Right: COGO Configuration Menu392
Q	Left: Auto Scaling of image in Drawing window, X when inactive. Right: Zoom Scaled
<u>N45</u> 100'	Left: Annotate Lines - On/Off toggle, X when inactive 490
Pt	Left: Annotate Points - On/Off toggle, X when inactive
<b>•</b>	Left: Add Symbols - On/Off toggle, X when inactive
/	<b>Left:</b> Draw Lines - Toggle line drawing when computing COGO points. When inactive, <b>X</b> overlays the icon.
	Left: Text Output - Activate/deactivate Text Output window. Right: Text Output Configuration Menu
•	Left: Re-center Paper 803 Right: Show/Hide Paper Border 385

# Section 13

	Left: Portrait/Landscape Paper Orientation	
	Left: Contour It!	449
	Left: Collector Connector: Send Data Right: Collector Connector: Receive Data	
LEGAL EASE	Left: LegalEase Right: Write a Legal File	
	Left: Pop-Up Calculator	

### 13.12

### **Check Registration**

**FUNCTION:** The **Check Registration** command is used to upgrade a demo copy of "Sight" Survey to a full working copy.

The check registration command is only available when "Sight" Survey is currently working as a demo.

If "Sight" Survey is currently a full working copy and you would like to change your registration information, click on the *Change Registration* icon ( ) located in the Simplicity Systems group of the **Program Manager**.

After invoking the **Check Registration** command, "Sight" Survey will load the **Change Registration** program. This program will allow you to add or modify personal information that is used by "Sight" Survey and is also used in the registration form that you should send back to Simplicity Systems, Inc. After the **Change Registration** program is exited, "Sight" Survey will again check to see if it should be running as a demo or a full copy.

To upgrade your program from a demo version to a full working copy, select **Check Registration** and call Simplicity Systems at (218) 773-8917.



<u>Circular Curves</u> (UA) Curve by <u>D</u>eflections (UB) Curve by <u>T</u>an. Offsets (UC) Curve by Chord <u>O</u>ffsets (UD)

<u>E</u>DM Slope Reduction (UE) <u>S</u>tadia Reduction (UF)

Spiral Curve Solution (UG) ⊻ertical Alignment (UH) <u>U</u>niversal Triangle (UI)

# Section 14 The <u>U</u>TILITIES Menu

The **<u>U</u>tilities** menu contains a number of stand-alone programs used in solving field staking problems. Here you'll find various types of solutions for circular and spiral curves, field note reduction, triangle solutions and vertical alignment solutions.

# 3

If you access a utility program from "Sight" Survey's Utilities menu, **DO NOT** print your results. Save them to a file and paste them into "Sight" Survey's **Text Output** window and print them from there.

14.01

### Circular Curve (UA)

**FUNCTION:** The <u>Circular Curve</u> routine will solve a circular curve given any one pair of the 29 possible parameters.



When sending output to an ASCII text file, the name of the file created by this routine is **CIRCULAR.DOC**.

### **Parameters**

*This routine will solve a circular curve when given any one of the 29 possible conditions shown below.* 

- KNOWN Central Angle and: Long Chord; Arc Length; Tangent; Mid Ordinate; External; Sector Area; Radius; Degree of Curve-Arc; or Degree of Curve-Chord.
- **KNOWN Degree of Curve-Arc and:** Long Chord; Arc Length; Tangent; Mid Ordinate; External; or Sector Area.
- **KNOWN Degree of Curve-Chord and:** Long Chord; Arc Length; Tangent; Mid Ordinate; External; or Sector Area.

- **KNOWN Radius and:** Long Chord; Arc Length; Tangent; Mid Ordinate; External; or Sector Area.
- **KNOWN Long Chord &** Tangent
- KNOWN Arc Length & Sector Area

To compute a circular curve solution, type **UA** or press Alt **U**, **C** at any prompt in the **Data Entry** window. If you are not running "Sight" Survey, you may select the **Circular Curve** icon in the Simplicity Systems group.

Select the known parameter by pressing the number denoting the first parameter known, or press () or (10) to exit this routine. You will then be prompted for the value of the chosen parameter. Type in the data requested and press (-Enter).

After an acceptable data entry, the program will issue a menu of the available second parameter entries. Since the exact parameter list is dependent upon the first parameter selected, no secondary parameter listing will be reproduced in this manual. Select the known second parameter by pressing the number denoting the parameter known, or press rot to return to the first parameter menu. You will again be prompted for the value of the chosen parameter. Type the data requested and press return. After your final entry, the program will solve for the remainder of the circular curve data.

**)** 

1. All angles entered must be in a D.MMSS format.

 If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Select: < 1 > Next Problem or < 2 > Return to COGO

**Select First Parameter:** 

< 2 > Radius Known

< 3 > Degree of Curve

Known - Arc < 4 > Degree of Curve

**Known - Chord** 

< 5 > Long Chord Known


< 6 > Arc Length Known

<E> EXIT

<1> Central Angle Known

Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.

Circula	r Curv	e Solution
Central Angle	=	37° 15' 20.0"
Deg. Curve Arc	=	11° 27' 33.0"
Deg. Cur. Chord	=	11 °28' 42.0"
Radius Arc Length Arc by Chd. Def. Long Chord	= = =	500.000 325.116 324.573 319.419
Tangent	=	168.538
Mid Ordinate	=	26.193
External	=	27.641
Fillet Area	=	2990.234
Sector Area	=	81279.014
Segment Area	=	5607.618



Section 14

Í	4.	0	2

### Curve by Deflections (UB)

**FUNCTION:** The **Curve by Deflections** routine will generate staking notes for a circular curve based on the deflection angle from the tangent to each station.



*When sending output to an ASCII text file, the name of the file created by this routine is* **DEFLECT.DOC**.

	To compute a deflection layout for any circular curve, type UB or press Att D, D at any prompt in the Data Entry window. If you are not running "Sight" Survey, you may select the Curve by Deflections icon in the Simplicity Systems group.
Central Angle	Type the central angle (D. MMSS) and press -Enter.
Select Known Item: < 1 > Radius < 2 > Degree of Curve - Arc < 3 > Degree of Curve - Chord	Select the known item by pressing 1, 2 or 3, or press F10 to exit the routine. Type the requested radius or the requested degree of curve and press FEME. If you select <b>Degree of Curve - Chord</b> , the curve calculations will be based on a chord definition.
Offset (Enter = 0.00)	Type the offset value and press <i>enter</i> , or just press <i>enter</i> for a <b>0</b> offset. To offset inside the curve, enter a negative offset value.
Select Option: < 1 > Station of P.I. Known < 2 > Station of P.C. Known	Select the appropriate option by pressing 1 or 2, or press F10 to exit the routine.
Station of PI (or PC)	If you select the PC option, pressing <i>Enter</i> without entering any data will result in a station entry of 0+00 (or 0+000 metric). Otherwise type the station and press <i>Enter</i> .
Stationing Interval	Type the distance between stations and press Enter.
Curving to the LEFT or to the RIGHT? (L/R)	If your curve proceeds to the left, press , otherwise press . Your response sets the proper orientation for the deflection angles. After answering this prompt, the solution is computed for you and displayed on your screen.

From time to time you will see the message **Press < Enter > to Continue** whenever the display screen is full. These delays are programmed at specific intervals to allow you to view the data on the monitor during the running of the program. To continue with the solution, simply press **______**. (These delays do not occur if you have chosen to print directly to the printer.)


### **Additional Stations**

Select: < 1 > Next Problem or < 2 > Return to COGO

•

If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.



The DEFLECTION ANGLES (D1, D2, ...) are the deflection angles for each successive Station and Offset Station

Circular Curve Layout by Deflections						
	Central Angle Degree of Curve - Arc Degree of Curve - Chord			2	5° 45' 30.0" 0° 50' 05.4" 0° 57' 04.9"	
A C T	Radius Arc Length Chord Length Tangent Length Offset Deflection/Foot in Minutes				275.000 363.614 337.699 213.921 3.000 6.250	
	Sub Arc	Do	floction	Chord	Offset	
	Sub Arc 25.000 50.000 75.000 100.000 125.000 150.000 175.000 200.000	2° 3 5° 1 7° 4 10° 2 13° 0 15° 3 18° 1	flection 6' 15.7" 2' 31.3" 8' 47.0" 5' 02.7" 1' 18.4" 7' 34.0" 3' 49.7" 0' 05.4"	Chord 24.991 49.931 74.768 99.450 123.927 148.147 172.062 195.621 Short	25.264 50.476 75.583 100.535 125.279 149.764 173.939 197.755	Offset
Station	Deflecti	on	Chord	Chord		
P.C. 0+72.50 1+00.00 2+00.00 3+00.00 4+00.00 4+36.11 P.T.	0° 00' 00 2° 51' 53 13° 16' 55 23° 41' 58 34° 07' 01 37° 52' 45	.2" .9" 1 .6" 2 .3" 3	0.000 27.489 126.361 221.068 308.487 337.699	0.000 27.489 99.450 99.450 99.450 36.088	27.788 127.740 223.480 311.852	0.000 27.788 100.535 100.535 100.535 36.482

14.03

# Curve by Tangent Offsets (UC)

**FUNCTION:** The **Curve by <u>T</u>angent Offsets** routine will generate staking notes for a circular curve based on the offsets from the tangent to each station.




*When sending output to an ASCII text file, the name of the file created by this routine is* **TANGENT.DOC**.

	To compute a tangent offset layout for any circular curve, type UC or press AttU, 1 at any prompt in the Data Entry window. If you are not running "Sight" Survey, you may select the Curve by Tangent Offsets icon in the Simplicity Systems group.
Station of PI	Type the station of the P.I. and press <i>etenter</i> .
Central Angle	Type the central angle ( <b>D. MMSS</b> ) and press <i>Finit</i> .
Select Known Item: < 1 > Radius < 2 > Degree of Curve - Arc < 3 > Degree of Curve - Chord	Select the known item by pressing 1, 2 or 3, or press 10 to exit the routine. Type the requested radius or the requested degree of curve and press 1 f you select <b>Degree of Curve</b> - <b>Chord</b> , the arc length will be based on a chord definition.
Stationing Interval	Type the distance between stations and press <i>Enter</i> . After answering this prompt, the solution is computed for you and displayed on your screen.
	From time to time you will see the message <b>Press &lt; Enter &gt; to</b> <b>Continue</b> whenever the display screen is full. These delays are programmed at specific intervals to allow you to view the data on the monitor during the running of the program. To continue with the solution, simply press <b>Prese</b> . (These delays do not occur if you have chosen to print directly to the printer.)
Additional Stations	After completion of the problem, you will be given an opportunity to compute curve data for any intermediate station on the curve. To compute any extra stations, type in each desired station and press <i>remer</i> , and the curve data will be computed. At any time you wish to exit the program, press <i>F10</i> .
(i	If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.
Select: < 1 > Next Problem or < 2 > Return to COGO	Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.

Section 14

Circu	llar Curve Layout by	/ Tangent Offsets	
	Central Angle = Curve Radius = Station of P.I. = Sta. Interval =	100.000	
Station	Central Angle	Tangent	Offset
P.C. 4+22.55 4+25.00 4+50.00 4+75.00 4+88.45	0° 00' 00.0" 1° 24' 04.7" 15° 43' 30.9" 30° 02' 57.1" 37° 45' 22.5"	0.000 2.446 27.102 50.074 61.230	0.000 0.030 3.743 13.440 20.938
P.T. 5+54.35 5+50.00 5+25.00 5+00.00 4+88.45	0° 00' 00.0" 2° 29' 29.4" 16° 48' 55.6" 31° 08' 21.8" 37° 45' 22.5"	0.000 4.347 28.929 51.712 61.230	0.000 0.095 4.276 14.409 20.938
External Distance =	26.483		



### Curve by Chord Offsets (UD)

**FUNCTION:** The **Curve by Chord Offsets** routine will generate staking notes for a circular curve based on the offset from the tangent and long chord to each station.



When sending output to an ASCII text file, the name of the file created by this routine is **CHORD.DOC**.

To compute a chord offset layout for any circular curve, type UD or press Att [U], (i) at any prompt in the Data Entry window. If you are not running "Sight" Survey, you may select the Curve by Chord Offsets icon in the Simplicity Systems group.

Central Angle	Type the central angle (D.MMSS) and press -Enter.
Select Known Item: <1> Radius <2> Degree of Curve - Arc <3> Degree of Curve - Chord	Select the known item by pressing 1, 2 or 3, or press F10 to exit the routine. Type the requested radius or the requested degree of curve and press F10. If you select <b>Degree of Curve - Chord</b> , the arc length will be based on a chord definition.
Select Option: <1> Station of P.I. Known <2> Station of P.C. Known	Select the appropriate option by pressing 1 or 2, or press 10 to exit the routine.
Station of PI (or PC)	If you have selected the PC option, pressing <i>Etter</i> without entering

**Stationing Interval** 

If you have selected the PC option, pressing  $\overline{-Enter}$  without entering any data will result in a station entry of 0+00 (or 0+000 metric). Otherwise type the station and press  $\overline{-Enter}$ .

Type the distance between stations and press *end*. The solution is computed for you and displayed on your screen.

From time to time you will see the message **Press < Enter > to Continue** whenever the display screen is full. Delays are programmed at specific intervals to allow you to view the data on the monitor during execution of the program. To continue with the solution, simply press **Enter**. (Delays do not occur if you have chosen to print directly to the printer.)


### **Additional Stations**

After completion of the problem, you will be given an opportunity to compute curve data for any intermediate station on the curve. To compute any extra stations, type in each desired station and press *reference*.



If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Select: <1 > Next Problem or <2 > Return to COGO Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.



	Circular Curve I	Layout by Choro	d Offsets		
Ce	Central Angle		75° 00' 00.0"		
Cu	Irve Radius		250.000	0	
	ation of P.C.		0+00.000	-	
	c Length		327.249	-	
	nord Length		304.38		
Ta	ingent Length		191.832	2	
		Long	Chord		
Station	Deflection	Chord	Offset	Chord	
P.C.					
0+00.000	0° 00' 00.0"	0.000	0.000	0.000	
0+50.000	5° 43' 46.5"	49.917	26.282	42.437	
1+00.000	11° 27' 33.0"	99.335	43.609	89.250	
1+50.000	17° 11' 19.4"	147.760	51.290	138.572	
2+00.000	22° 55' 05.9"	194.709	49.020	188.438	
2+50.000	28° 38' 52.4"	239.713	36.888	236.858	
3+00.000	34° 22' 38.9"	282.321	15.378	281.902	
3+27.249	37° 30' 00.0"	304.381	0.000	304.381	
P.T.					

### 14.05

**Slope Distance** 

### EDM Slope Reduction (UE)

**FUNCTION:** The **EDM Slope Reduction** routine will reduce EDM slope measurements to horizontal and vertical components. Horizontal distances are available for four different elevations: at the EDM; at the target; at an average elevation; and at sea level.



When sending output to an ASCII text file, the name of the file created by this routine is **EDM.DOC**.

To reduce EDM slope data, type **UE** or press Att **U**, **E** at any prompt in the **Data Entry** window. If you are not running "Sight" Survey, you may select the **EDM Slope Reduction** icon in the Simplicity Systems group.

**Leg Number** Type in any numeric designation, 1-999, and press *enter*. The leg number is for identification only and is not required. In fact, you may bypass the leg number entry by simply pressing *enter*.

Angle (1) or Elev. of Inst. & Target (2) known (1 or 2)	Select the known option by pressing 1 or 2. Continue with the appropriate instructions.
	Option 1 - Slope Angle Known
Angle	Type the slope angle ( <b>D.MMSS</b> ) and press <u>-Enter</u> . If you are shoot- ing level, simply press <u>-Enter</u> .
<b>i</b>	This can be either a <b>zenith</b> angle or a <b>vertical</b> angle.
Elevation at the Instrument	Type the elevation at the instrument station and press <i>enter</i> . If this elevation is unchanged from a previous problem, simply pressing <i>enter</i> will re-enter the previous value.
Height of the Distance Meter	Type the height of the distance meter above the elevation of the occupied point and press <i>This is not an elevation!</i>
Height of the Prism Assembly	Type the height of the prism above the elevation of the target station and press <b>.</b> <i>This is not an elevation!</i>
Height of the Theodolite	Type the height of the theodolite above the elevation of the occupied point and press <i>return</i> . <i>This is not an elevation!</i>
Height of the Target	Type the height of the target above the elevation of the target station and press <i>return</i> . <i>This is not an elevation!</i>
	After the required height values have been entered, the results will be shown in a display similar to the first one shown in the example that follows. Skip to the section, <b>Common to Both Options</b> , which follows Option 2.
	Option 2 - Elevations Known
Elevation at the Instrument	Type the elevation at the instrument and press -Enter.

Height of the Distance Meter	Type the height of the distance meter above the elevation of the occupied point and press <i>Finer</i> . <i>This is not an elevation!</i>
Elevation at the Target Station	Type the target station elevation and press -Enter.
Height of the Prism	Type the height of the prism above the elevation of the target sta- tion and press <b>. . . . . . . . . .</b>

**Common to Both Options** 

Compute a Horizontal Distance at an Elevation of ? (Press F1 for Next Shot or F2 to Change Setup)

Select: < 1 > Next Problem or < 2 > Return to COGO Type in any elevation at which you wish to compute the horizontal distance and press *etener*. The computed distances will be printed. You may repeat this sequence for any number of elevations.

To enter another shot from this same setup, press  $F_1$ . To change the setup and continue this routine, press  $F_2$ . To end, press  $F_1$ .


ا

If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Make your selection by pressing 1 or 2. If you choose option < 1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem.

					0j	otion	n 1				
<u>Leg</u>	Slope Distan		Zeni Ang		Eleva at E		EDM Height	Prism Height	Theo Heig		Target Height
1	10582.	880	87°40	44.0"	4462.4	420	5.470	5.400	5.4	70	5.400
	Dist @ EDM		)ist @ irget		ist @ rage		Dist @ a Level	Uncor. @ Tar		-	Curv/Ref orrection
105	573.995	1057	4.213	1057	4.104	10	571.738	4891.0	)94		2.297
Ta	orrected arget Elev 893.392	<u>/_</u>									

	Option 2						
Leg	Slope Distance	Elevation at EDM	Instrument Height	Eleva at Tar		Prism Height	
1	5113.550	551.250	5.510	675.8	80	4.750	
	. Dist. ⁄I Elev.	Horiz. Dist. at Target Elev.	Horiz. Dist. at Average Elev.			iz. Dist. Level Elev.	
5112	2.034	5112.065	5112.04	.9	511	11.899	



14.06

## Stadia Reduction (UF)

**FUNCTION:** The **Stadia Reduction** routine will reduce stadia measurements to horizontal and vertical components.



When sending output to an ASCII text file, the name of the file created by this routine is **STADIA.DOC**.

	To perform stadia reductions, type <b>UF</b> or press Alt <b>U</b> , <b>S</b> at any prompt in the <b>Data Entry</b> window. If you are not running "Sight" Survey, you may select the <b>Stadia Reduction</b> icon in the Simplicity Systems group.	
Stadia Interval Constant K (Default = 100)	Type the stadia interval constant and press <i>-Enter</i> . If the constant is equal to 100, simply press <i>-Enter</i> .	
	If you want to enter measured distances instead of stadia intervals, answer the Stadia Interval Constant prompt by typing M □ energy. The program will skip to the Starting Elevation request. Additionally, instead of requesting an Interval, the program will request a Distance. Type the slope distance and press □ energy at each distance prompt.	
Distance from Center of Instrument to Principal Focus C (Default = 0.0)	Type the value for <b>C</b> and press <u>Fine</u> . If <b>C</b> equals zero, simply press <u>Fine</u> .	
Starting Elevation (Default = 100)	Type the elevation of the instrument station and press <i>enter</i> .	
Height of the Instrument	Type the height of the instrument above the elevation of the occupied point and press -Ener.	
Point Number	Type in a point designation and press <i>end</i> . This designation may be in alphanumeric form, up to 12 characters in length. To continue without entering any designation, just press <i>end</i> .	
Angle	Type the slope angle ( <b>D.MMSS</b> ) and press Fine. If you are shooting level, simply press Fine.	
	This can be either a zenith angle or a vertical angle.	14
Reading	Type the rod reading (middle stadia hair) and press <i>Finer</i> .	
Interval	Type the rod interval (difference between the top and bottom stadia hairs) and press <i>end</i> . The program will respond by printing the point designation, the slope angle, the rod interval, the rod reading, the vertical and horizontal distances and the elevation of each	

point. The program will return to a request for the next point number. To end this routine, press **F10**.



If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

#### Select: < 1 > Next Problem or < 2 > Return to COGO

Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.

Stadia Reduction						
Stadia Interval Constant K100.000Distance from Center of Instrument to Principal Focus C0.000Starting Elevation830.000Height of the Instrument4.330					0.000 830.000	
Point Slope Angle	Interval	Reading	Vertical	H. Dist	Elevation	
1 Z 84°00' 00.0"	5.250	6.340	54.577	519.264	882.567	
2 Z 81°30' 00.0"	4.770	4.850	69.731	466.579	899.211	
Note: Z = Zenith Angle	Note: Z = Zenith Angle					

#### 14.07

Data Entry window

## Spiral Curve Solution (UG)

**FUNCTION:** The **Spiral Curve** routine will generate staking notes for a Euhler spiral curve, either from the Tangent to Spiral or from the PI of the spiral's tangents.



When sending output to an ASCII text file, the name of the file created by this routine is **SPIRAL.DOC**.

To compute a spiral curve layout for any circular curve, type UG (or press ARU, P) at any prompt in the Data Entry window. If you are not running "Sight" Survey, you may select the Spiral Curve Solution icon in the Simplicity Systems group.

Length of Spiral	Type the spiral length and press -Enter.		
Select Known Item: < 1 > Radius < 2 > Degree of Curve - Chord < 3 > Degree of Curve - Arc	Select the known item by pressing 1, 2 or 3, or press F10 to exit the routine. Type the requested radius or the requested degree of curve and press F10. If you select <b>Degree of Curve -Chord</b> , the arc length will be based on a chord definition.		
Select: < 1 > Station of TS Known < 2 > Station of PI Known	Select the known item by pressing 1 or 2, or press F10 to exit the routine.		
Station of PI (or TS)	Type the requested station value and press Enter.		
Stationing Interval on Spiral Stationing Interval on Curve	Type the distance between stations along the spiral and pressEnter. Type the distance between stations along the circular curve and pressEnter. To use a value equaling the spiral interval, just press Enter.		
Intersection Angle of Tangents at P.I.	Type the intersection angle ( <b>D.MMSS</b> ) and press <b>.</b>		
Curving to the LEFT or to the RIGHT? (L/R)	If your curve proceeds to the left, press $\Box$ , otherwise press $\mathbb{R}$ . Your response to this prompt sets the proper orientation for the deflection angles.		
Select: <1> Stake from TS & ST Stations <2> Stake from PI	The curve may be laid out in one of two ways. Option 1, assumes that your transit will be set up twice, once at the TS, or <i>Tangent to</i> <i>Spiral</i> , and again at the ST, or <i>Spiral to Tangent</i> . Both setups assume that you are backsighting the <i>Point of Intersection</i> (PI) of the tangents. Option 2 assumes that your transit will be set up at the <i>Point of Intersection</i> (PI) of the tangents and that you will be backsighting the <i>Tangent to Spiral</i> (TS) and the <i>Spiral to Tangent</i> (ST). Enter the chosen staking method by pressing 1 or 2. After selecting the staking method, the program will compute and display the solution. From time to time you will see the message		


display the solution. From time to time you will see the message **Press < Enter > to Continue** whenever the display screen is full. These delays are programmed at specific intervals to allow you to view the data on the monitor during the running of the program. To continue with the solution, simply press **...** (These delays do not occur if you have chosen to print directly to the printer.) ī

If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Select:

- <1> Next Problem
- < 2 > Return to COGO
- **ReStake from** < 3 > **New Station**

After completion of the problem, you'll be given an opportunity to re-compute the curve data using the other available staking method. Make your selection by pressing 1, 2 or 3. If you choose option 3, the problem solution will be repeated assuming a staking method which is the opposite of the previous solution.



- TS = Tangent to Spiral
- SC = Spiral to Curve
- CS = Curve to Spiral
- ST = Spiral to Tangent
- $\theta_{S}$ = Total Spiral Angle
- = Intersection Angle of Tangents at the PI Δ
- = Central Angle of Circular Curve
- = Tangent Offset at SC
- = Tangent Distance from TS at SC = Radius of Osculating Circle
- $\stackrel{\Delta_{C}}{Y_{S}}$  $X_{S}$  $R_{C}$ P
  - = Offset from Tangent to PC of Osculating Circle
- K = Tangent Distance from TS to Shifted PC
- $T_{S}$ = Total Tangent Distance from the PI to the ST (or TS)

	<b>C</b>	iral Curva I	avout			
Spiral Curve Layout						
Le	Length of Spiral 150.000					
Cu	rve Radius			380.000		
Sta	ation of P.I.			8+50.000		
Sta	ationing Interval of	on Spiral		50.000		
Sta	ationing Interval of	on Curve		100.000		
	ersection Angle		at P.I. 105	° 00' 00.0"		
Ta	ngent Dist from I	PI to TS		573.339		
05	S from TS to PC	of Circle (p)	)	2.464		
	fset to the shifted			74.903		
Dir	ection of Curvati	ure		Right		
Deflections	s from Transit at	T.S. & S.T.	Stations, ba	cksighting t	the P.I.	
Station	Deflection	L.Chord	S.Chord	Tangent	Offset	
T.S.						
2+76.66	0° 00' 00.0"	0.000	0.000	0.000	0.000	
3+00.00	0° 05' 28.5"	23.339	23.339	23.339	0.037	
3+50.00	0° 54' 03.9"	73.332	49.996	73.323	1.153	
4+00.00	2° 32' 53.5"	123.241	49.984	123.120	5.479	
4+26.66	3° 46' 05.6"	149.740	26.656	149.417	9.841	
S.C.						
4+26.66	3° 46' 05.6"	149.740	0.000	149.417	9.841	
5+00.00	8° 03' 06.1"	221.688	73.225	219.503	31.051	
6+00.00	14° 47' 17.0"	316.419	99.712	305.938	80.764	
6+99.85	21° 52' 40.6"	405.588	99.567	376.377	151.134	
S.T. 11+23.05	0° 00' 00.0"	0.000	0.000	0.000	0.000	
11+23.05	0°00'00.0 0°05'20.4"	23.047	23.047	23.047	0.000	
10+50.00	0° 05° 20.4 0° 53' 38.1"	23.047 73.040	23.047 49.996	73.047	1.140	
10+00.00	2° 32' 10.2"	122.951	49.990	122.830	5.441	
9+73.05	3° 46' 05.6"	149.740	26.948	149.417	9.841	
C.S.	5 40 05.0	149.740	20.940	149.417	9.041	
9+73.05	3° 46' 05.6"	149.740	0.000	149.417	9.841	
9+00.00	8° 01' 59.0"	221.406	72.935	219.233	30.940	
8+00.00	14° 46' 03.7"	316.150	99.712	305.706	80.587	
7+00.00	21° 52' 02.8"	405.462	99.712	376.288	151.019	
6+99.85	21° 52' 40.6"	405.588	0.146	376.377	151.134	
Apex Distance = 248.265						

Section 14

## Vertical Alignment (UH)

14.08

	<b>FUNCTION:</b> The <u>Vertical Alignment</u> routine will calculate the stationing and elevations along a combination of vertical curves and uniform grades.
į	When sending output to an ASCII text file, the name of the file created by this routine is <b>VERTICAL.DOC</b> .
3	All <b>Entry</b> and <b>Exit</b> grades are entered as percents. For example, a 0.025 slope would be entered as a percent grade of 2.50 percent, preceded by a minus sign if necessary.
Data Entry window	To calculate vertical alignments, type $UH$ (or press $AHU$ , $V$ ) at any prompt in the <b>Data Entry</b> window. If you are not running "Sight" Survey, you may select the <b>Vertical Alignment</b> icon in the Simplicity Systems group.
Select Mode: <1> Vertical Curve <2> Uniform Grade	Select the type of leg to be calculated by pressing 1 or 2. Proceed with the appropriate instructions for the solution mode chosen.
	Mode 1 - Vertical Curve
% Entry Grade (Default = <i>nn.nnn</i> %)	Type the percent entry grade and press $-Enter$ , or simply press $-Enter$ to accept the default value ( <i>nn.nnn</i> ) displayed in the prompt. If the current segment is a continuation of a prior segment, the default value ( <i>nn.nnn</i> ) will be equal to the last exit grade.
% Exit Grade (Default = 0%)	Type the percent exit grade and press $-$ Enter, or simply press $-$ Enter to accept the default value of 0%.
Select Option: <1 > Station of P.I. Known <2 > Station of P.C. Known	Select the appropriate option by pressing 1 or 2, or press 10 to exit the routine.
Station of PI (or PC)	Type the station and press $\overline{\text{renter}}$ , or accept any default station of- fered by simply pressing $\overline{\text{renter}}$ . If you have selected the PC option, a default response of station $x+xx$ will be offered in the prompt. If

the segment you are now computing is a continuation of a prior segment, the value of the default station (x+xx) will be the value of the final station of the last segment.

Elevation at Pl (or PC)Type the requested elevation and press I find, or accept any default<br/>elevation offered by simply pressing I find. If you have selected the<br/>PC option, a default response of elevation zzz.zzz will be offered in<br/>the prompt. If the current segment is a continuation of a prior seg-<br/>ment, the value of the default elevation (zzz.zzz) will be the value<br/>of the elevation at the final station of the last segment.Select Known Option:

You are now offered a choice of three conditions. Select the known condition by pressing 1, 2 or 3, and proceed with the instructions for the option chosen.

## Mode 1 - Option 1 - Length of Curve Known

Length of Curve	Type the curve length and press <i>-Enter</i> .
Stationing in feet (meters)	Please continue with the instructions for the response to this
	prompt which follow the discussion for <b>Mode 1 - Option 3</b> .

#### Mode 1 - Option 2 - High (or Low) Elevation Known

High (or Low) Elevation The Computed Length is *yyyy.yyy*.

<1> Length of Curve

< 2 > High (or Low) Elevation

< 3 > Station and Elevation

Type the value of the elevation and press *enter*.

The program will now compute a length of curve (*yyyy.yyy*) and display it for your approval. Please continue with the instructions for the response to this prompt which appear in the discussion for **Mode 1 - Option 3**.

Section 14

Mode 1 - Option 3 - Station and Elevation Known

Known Station	Type the known station and press <i>renter</i> .
Elevation at Known Station	Type the known elevation and press <i>etenter</i> . The program will now compute a length of curve and display:
The Computed Length is <i>yyyy.yyy.</i> Press <enter> if correct or enter corrected length</enter>	The program will now compute a length of curve ( <i>yyyy.yyy</i> ) and display it for your approval. If the displayed length is acceptable, press <i>PErter</i> , if not, type the correct value and press <i>PErter</i> .

### Mode 1 - All Options

Stationing in feet (meters)

Type the distance between stations and press — At this point, the vertical curve solution will be generated.

From time to time you will see the message **Press < Enter > to Continue** whenever the display screen is full. These delays are programmed at specific intervals to allow you to view the data on the monitor during the execution of the program. To continue with the solution, simply press **...** (These delays do not occur if you have chosen to print directly to the printer.)

After completion of the problem, you will be given an opportunity to compute data for any intermediate station or elevation along the curve. You will see the message:

Enter a station to compute an elevation, OR enter an elevation (followed by an *, such as 752*) to compute the station(s), OR press key F1 to CONTINUE

You may now enter any station and the elevation will be computed, or you may enter an elevation and compute the station.

Press F1 to continue with another segment in your vertical alignment solution. You will be returned to the **Select Mode** prompt which is described at the beginning of the instructions for this routine. To end the routine, press F10.



If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Select: < 1 > Next Problem or < 2 > Return to COGO	Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.
	Mode 2 - Uniform Grade
% Entry Grade (Default = <i>nn.nnn</i> %)	Type the percent entry grade and press $\underbrace{\text{-Enter}}_{n}$ , or simply press $\underbrace{\text{-Enter}}_{n}$ to accept the default value ( <i>nn.nnn</i> ) displayed in the prompt. If the current segment is a continuation of a prior segment, the default value ( <i>nn.nnn</i> ) will be equal to the last exit grade.
	To enter the <b>beginning</b> and <b>ending elevations</b> instead of a grade, type the beginning elevation followed by an asterisk (*), or simply type * • Enter to accept the last elevation of zzz.zzz. If the current segment is a continuation of a prior segment, the default value (zzz.zzz) will be equal to the ending elevation of the last station. After accepting the beginning elevation entry, the program will ask for the ending elevation. Type the elevation and press • Enter.
Beginning Station (Default = <i>x</i> + <i>xx</i> )	Type the station and press $\bigcirc$ or accept the default station offered $(x+xx)$ by simply pressing $\bigcirc$ . If the segment you are now computing is a continuation of a prior segment, the value of the default station $(x+xx)$ will be the value of the final station of the last segment.
Elevation at Beginning Station (Default = zzz.zzz)	Type the requested elevation and press $-\text{Entrip}$ , or accept the default elevation offered by simply pressing $-\text{Entrip}$ . If the segment you are now computing is a continuation of a prior segment, the value of the default elevation ( <i>zzz.zzz</i> ) will be the value of the elevation at the final station of the last segment.
Length of Segment	Type the segment length and press <i>Enter</i> .

> From time to time you will see the message **Press < Enter > to Continue** whenever the display screen is full. These delays are programmed at specific intervals to allow you to view the data on the monitor during execution of the program. To continue with the solution, simply press **remer**. (These delays do not occur if you have chosen to print directly to the printer.)

> After completion of the problem, you will be given an opportunity to compute data for any intermediate station or elevation along the curve. You will see the message:

Enter a station to compute an elevation, OR enter an elevation (followed by an *, such as 752*) to compute the station(s), OR press key F1 to CONTINUE

You may now enter any station and the elevation will be computed, or you may enter an elevation and compute the station.

Press **F1** to continue with another segment in your vertical alignment solution. You will be returned to the **Select Mode** prompt which is described at the beginning of the instructions for this routine. To end the routine, press **F10**.




If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, < 2 > Exit.

Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.

Select: < 1 > Next Problem or

< 2 > Return to COGO



vertical Aligi	nment Solution
Uniform Grade = 2.500%	Segment Length = 300.000'
STATION	ELEVATION
0+00.00	100.000
0+50.00	101.250
1+00.00	102.500
1+50.00	103.750
2+00.00	105.000
2+50.00	106.250
3+00.00	107.500
Grade In = 2.500% Grade Out =	-3.000% Curve Length = 200.000'
STATION	ELEVATION
4+00.00	110.000 P.I.
3+00.00	107.500 P.C.
3+50.00	108.406
3+90.91	108.636 HIGH POINT
4+00.00	108.625
4+50.00 5+00.00	108.156 107.000 P.T.
5+00.00	107.000 P.I.
Uniform Grade = -3.000%	Segment Length = 300.000'
STATION	ELEVATION
5+00.00	107.000
5+50.00	105.500
6+00.00	104.000
6+50.00	102.500
7+00.00 7+50.00	101.000 99.500
7+50.00 8+00.00	99.500 98.000
0,00.00	30.000


14.09	Universal Triangle (UI)
	<b>FUNCTION:</b> The <u>Universal Triangle</u> routine will solve for the unknown sides and/or angles of a triangle when one set of five possible parameters is known.
	When sending output to an ASCII text file, the name of the file created by this routine is <b>TRIANGLE.DOC</b> .
Parameters	This routine will solve a triangle when given any one of the five possible conditions shown below.
	Three Sides Known (SSS) Two Sides and the Included Angle Known (SAS) Two Sides and the Opposite Angle Known (SSA) Two Angles and the Included Side Known (ASA) Two Angles and the Opposite Side Known (AAS)
	To calculate any triangle, type <b>UI</b> (or press Att <b>U</b> , <b>U</b> ) at any prompt in the <b>Data Entry</b> window. If you are not running "Sight" Survey, you may select the <b>Universal Triangle</b> icon in the Simplicity Systems group.
Select Solution: < 1 > Side - Side - Side < 2 > Side - Angle - Side < 3 > Side - Side - Angle < 4 > Angle - Side - Angle < 5 > Angle - Angle - Side	Select the desired option by pressing any number, 1 through 5, then answer the distance and/or angle queries as they appear on the monitor. Press effer after each data entry.
Select: < 1 > Acute Solution < 2 > Obtuse Solution	If the problem has two solutions, you will also be asked to select the acute solution, or the obtuse solution. Press 1 or 2. An <i>acute</i> solution is one in which all of the included angles are less than 90 degrees. An <i>obtuse</i> solution is one in which one of the included angles has a value lying between 90 degrees and 180 degrees.


"Sight" Survey will now solve the triangle, or report that no solution can be made from the data given.




If you didn't enter this routine from within "Sight" Survey, option 2 in the next prompt will read, <2> Exit.

Make your selection by pressing 1 or 2. If you choose option <1 > Next Problem, this routine will repeat the prompts as previously described, allowing you to compute another problem. If you select option <2 > Return to COGO, you will be returned to "Sight" Survey.







Select: < 1 > Next Problem or < 2 > Return to COGO This page intentionally left blank.



Contour<u>I</u>t! (CI) <u>C</u>ollector Connector LegalEase

۲

۲

# Section 15 The <u>A</u>DD-INS Menu

The <u>Add-Ins</u> menu is your gateway to add-on programs for "Sight" Survey. Currently, the menu contains interfaces to three programs: **Contour It!**, a contouring and volumes module; **Collector Connector**, a data collector interface; and **LegalEase**, a legal description writer.

The modules shown in the menu are not included with your "Sight" Survey program. They must be purchased separately. Once installed on your computer, "Sight" Survey will know they are available, and the item will appear in black print. Any items that appear grayed or washed out are not installed, and therefore are not available.

This section of the manual does not contain instructions for the operation of any of these modules, other than what is needed to activate the module. However, some information regarding these modules appears in this section.

#### 15.01


**About Contour It!** 

## Contour <u>It!</u> (CI)

**FUNCTION:** The **Contour** <u>**!**</u>! module is used to create a contour map of your existing topo data. Additionally, **Contour** <u>**!**</u>! allows you to compute the volume between two contoured surfaces.

To access the **Contour**  $\underline{It}$ ! module, type **CI** (or **MC** for Make Contours) in any text box, or press  $\underline{Att}[\underline{A}]$ ,  $[\underline{I}]$ .

**Contour It!** is a simple, easy to use "Sight" Survey integrated module designed to generate contour maps and surface modeling from coordinate data.



Besides the ease of use and speed of **Contour It!** for general contour mapping and surface modeling, **Contour It!** includes fast, accurate and easy volumetric capabilities. Since volume calculations are direct comparisons between two surface models, intermediate grid cell or cross sections are not required to produce volume calculations and greater accuracy is maintained. Calculated volumes contain no provision for cut/fill ratio or shrink/swell percentage.

Northing, Easting, and elevation coordinates may be entered either by hand or loaded from coordinate files previously stored on disk.

The field surface is modeled using the triangulation method. **Contour It!'s** triangulated digital terrain model is extremely accurate. Nevertheless, breaklines may be defined for any areas on the surface model that require adjustment.

**Contour It!'s** graphics are fast, accurate and flexible. All maps may be previewed on your monitor prior to printing, plotting or transferring to CAD programs.

Contour line smoothing is achieved by the latest advanced algorithm, custom designed to handle the special properties of contour lines, while honoring the actual data points.

#### Contour It! Features...

- Unlimited data point capacity;
- Surface modeling using the Triangulation method;
- Breakline capabilities;
- Ability to calculate the volumetric difference between two surfaces. Output includes the total cut and fill amounts;
- Powerful 2-D and 3-D graphics;
- Advanced contour line smoothing;
- In-line contour labels;
- Support for English or Metric units;
- Output to any printer or plotter supported by Windows;
- DXF file transfer from "Sight" Survey to TrueCAD, AutoCAD, or virtually any other DXF capable CAD;
- DWG file transfer from "Sight" Survey to AutoCAD (using v12 format);
- DRG file transfer from "Sight" Survey to TrueCAD;
- Ability to graph point labels on maps.

### Use Contour It! for:

- Contour maps;
- Digital terrain models;
- Stock pile and pit volumes;
- Site design earthwork volumes;
- Any application needing to compare an existing surface model to a proposed surface model, to calculate the difference in volume between the surfaces.

**Contour It!** is perfect for Land Surveyors, Civil Engineers, Architects, Contractors, Mining Engineers and many others. In fact, if you do only one contour map a year, **YOU NEED CONTOUR IT!** 

Contact Simplicity Systems at 1-800-777-7978

#### **Collector Connector**

**FUNCTION:** The <u>Collector Connector</u> module provides communications between your PC and your data collector.

To access the <u>Collector Connector</u> module, press <u>Alt</u> <u>A</u>, <u>C</u>. This will activate the Collector Connector menu.

This command is only available if you have **Collector Connector** installed on your computer. Instructions for the actual usage of **Collector Connector** are contained in the **Collector Connector** manual.

To send coordinates to the data collector, press S. To receive coordinates from the data collector, press C. To import an existing coordinate file, press I. To configure **Collector Connector**, press N.

**Collector Connector for Windows** is a low cost replacement for high-priced OEM (Original Equipment Manufacturer) software. **Collector Connector** provides you with accurate PC to data collector communications all wrapped up in a quick, convenient, menu-driven, easy to use package.

Send Coordinates to the Collector Receive Coordinates from Collector Import Existing Coordinate File Cogfiguration / Run Full-Screen

15.02

**About Collector Connector** 

File Edit He		for Windows		
Send / R		Configure		About
	<ul> <li>SEND a</li> <li><u>B</u>ECEIM</li> <li>RECEIM</li> <li>CONVER</li> </ul>	er Coordinate File to Data C Raw Data File to Data C E a Coordinate File from D E a Raw Data File from D RT a Coordinate File alrea RT a Raw Data File alrea	ollector Data Collector Vata Collector ady on the PC	
<u>D</u> ata Colle	tor	Lietz/Sokkia SDR 24		-
Port Settin	35	[Current Port Settings ar	e: COM1,960	.0,N,8,1 ) 💌
CO <u>G</u> O File	Туре	Simplicity "Sight" Survey	for Windows	-
COGO File	Name	E:\SIGHTSRV\PROGR	AM\	•
Accept	Ei	e Browse E	žit	Help

**Collector Connector** allows you to easily download/ upload ASCII data from your data collector to your PC, transferring both raw data files and coordinate lists!

Automatically format downloaded coordinate files for use with your favorite COGO program! Convert data collector coordinate files already on your PC into files compatible with your favorite COGO program! Select data collector and file types from a menu!

Compatible with Win 3.1, 95, 98, and NT, **Collector Connector** can run as a stand-alone product, or as an add-on module to **"Sight" Survey**, where it is accessed using the <u>Add-Ins</u> pulldown menu. With **Collector Connector** you can:

- MERGE an incoming file with an existing COGO data file, with full point-overwrite protection;
- Send (export) a RANGE of points to the data collector, instead of the entire file.
- Easily ABORT File Transfers.
- Copy or delete an existing file through pulldown menu options.
- Select files using File Selection fields with full Windows File Browser capabilities.
- Use the serial ports COM 1, COM 2, COM 3, or COM 4, at baud rates up to 115200 (depends upon your data collector's capabilities).

**Collector Connector** also lets you tweak Advanced Communications options to eliminate overflow errors, speed up file transfers, and improve control over file transfers. You can:

- Modify Input & Output Buffer Sizes;
- Modify Hand-shaking or Flow Control of the transfer;
- Enter an SDR Scale Factor for Lietz/ Sokkia data collectors;
- Use an improved SDR CheckSum File Verification algorithm for Lietz/Sokkia file transfers;
- Save temporary files that get created during a Receive or Send;
- Cancel the file transfer if a connection is not made within a specified # of seconds; Automatically end the file transfer if communication stops for a specified # of seconds.

Fast, accurate, flexible and simple to operate. All the qualities you want in your data collector communications software, in a very affordable program!

D'Zign HP48 Survey Packet 1 (NE or NEZD); Lietz/Sokkia SDR 2, 20, 22 & 24; Nikon ^; Pentax SC-5 ^; SMI HP 48 SC/SCE, AC/ACE, or DC/DCE or CVCE; Sokkia SDR 31 or 33 (4 char. numeric point Ids or 14 char. alpha point IDs); SURVcalc HP 48 SX/GX; TDS HP 48; Topcon FC-4; Topcon FC-48; Trimble TDC1, TSC1 (Sokkia emulation); and Wild GRE-3 ^. (^ using Lietz emulation)

Supported File FormatsSimplicity "Sight" Survey for Windows; Simplicity Survey 3.0,<br/>Lite, & 4.0; Simplicity Survey! - Ver. 2; Direct transfer<br/>(send/receive only); ASCII custom formats; Autocogo; Bench-<br/>Mark (ASCII); Bischoff; C & G (ASCII); CivilComp CC-Surv<br/>Version 3 & 4; CivilSoft Cogo PC Plus; Collier Version 4 & older;<br/>DCA (generic import); GEM (SDF format); Generic CADD 6<br/>Batch (receive/convert only); Houseman PC-Cad; Lewis & Lewis;<br/>LI Contour; Maptech; Micromate (send only); MTI 3000; NOAA<br/>State Plane Record; PacSoft; Plus III (ASCII); Simplicity<br/>CogoMate 2.x (receive/ convert only); Simplicity DigiMate (send<br/>only); Star*Net Coordinate File (send only); Surv-A-Soft Version<br/>4 & older; Surveyor II; SurveySoft; Tech-nical Advisors; Traverse<br/>PC; and WildSoft (ASCII).



List of supported collectors and file formats was current as of July 1998, and is subject to change without notice. Call Simplicity Systems at (218) 773-8917 for current information.

15.03

**Supported Collectors** 

## LegalEase The Write a LegalEase File (LF)

**FUNCTION:** The <u>Write a LegalEase File</u> routine is used to create a file that can be used by *LegalEase* to create a legal description.

To access the <u>Write a LegalEase File</u> routine, type LF in any text box, or press Aft[A],  $\Box$ , W.

This command is only available if you have **LegalEase** installed on your computer. Instructions for the actual usage of **LegalEase** are contained in the **LegalEase** manual.

Write a LegalEase File (LF) LegalEase Processor (LE) Process a LegalEase File (PL)

#### About LegalEase

To write a **LegalEase** file, press **W**. To activate the **LegalEase** processor, press **□**. To process a **LegalEase** file, press **P**.

LegalEase is an easy to use legal description processor which runs right inside of "Sight" Survey. It will let you write a completely finished legal description with over 30 calls in as little as five minutes! And, your finished document will be loaded into your favorite word processor and written in your own customary style with no chance of numerical error! LegalEase makes writing a legal description as simple as inversing around the subject property by entering point numbers. *You can even access Defined Figures or select the points right off the "Sight" Survey drawing screen!* 

LegalEase is designed to automatically handle several geometric conditions in both closed and open ended traverses, including:

- ✓ Point of Beginning followed by a tangent leg;
- ✓ Point of Beginning followed by a curving leg;
- ✓ Tangent, non-tangent, reverse & compound curves at the POB;
- ✓ Tangent, non-tangent, reverse and compound curves;
- ✓ Curve-to-line and line-to-curve intersections.

LegalEase is very flexible, offering you several configuration options that work hand in hand with your "Sight" Survey configuration to provide total control over your legal description preparations. LegalEase offers a wide selection of geometric phrases for you to select from and/or edit, as well as a choice of customizable captions and ending phrases. If you wish, you may even write and save the phrases using your own wording. The end result is a perfect legal description every time, in your own customized style that is always consistent with the high standards you set for your work!

In the time you spent reading this page, you could have written your first LegalEase description! If you can write a legal description that fast, what will that do for you and your bottom line? Every time you use LegalEase, you could be freeing up to an hour of your time, maybe more. Use that time to complete other jobs. Or, use that time to take on new jobs and *increase your revenue without putting in more hours.* Take a moment to think about that, but don't take too long. After all, time is money.



Section 16 The <u>WINDOWS Menu</u>



User Arrangement #1 User Arrangement #2 Set User Arrangement #1 Set User Arrangement #2

<u>C</u>ascade <u>T</u>ile

1 Text Output 2 Drawing 3 Add Text 4 COGO Drawing Properties The <u>Windows</u> menu is where you'll find window arrangement options, and immediate access to any "Sight" Survey's windows.

## 16.01 User Arrangement #1 & #2

**FUNCTION:** The **User Arrangement** functions are used to restore the screen display to a user defined window layout.

To access **User Arrangement #1** or **User Arrangement #2**, click the item with your mouse.

When accessed, this functions restore the screen layout saved using the **Set User Arrangement #1** and **#2** items.

#### 16.02

## Set User Arrangement #1 & #2

**FUNCTION:** The **Set User Arrangement** functions are used to restore the screen display to a user defined window layout.

To access **Set User Arrangement #1** or **Set User Arrangement #2**, click the item with your mouse.

When accessed, this functions the current screen layout for later use with the User Arrangement #1 and #2 items.

## 16.03

## <u>C</u>ascade

**FUNCTION:** The **Cascade** function is used to arrange "Sight" Survey's windows in a cascading fashion.

To access the **Cascade** function, press Alt W, C.

"Sight" Survey will cascade the windows similar to the illustration below.

🚾 "Sight" Survey	_ 8 ×
Elle Edit Evints Lines Lurves Misc Draw Config Litikies Addins Window Help	
👰 🖬 🥊 ? 📖 🎟 🖭 🕼 🕼 S 🕬 ?+ 🗸 🏒 🎢 🍳 👑 🖓 🕤 🖉 🔛 📾 📾	
🐐 Text Output	
Traverse I averse	
A Drawing	
Properties_3 Start	
× ×	
442 To delete an object select it, then press the 'DELETE' key. Press 'INSERT' to undo.	N-234.68 E:597.73

16.04

## <u>T</u>ile

**FUNCTION:** The **<u>Tile</u>** function is used to arrange "Sight" Survey's windows in a tiled fashion.

To access the <u>Tile</u> function, press AttW, T.

"Sight" Survey will tile the windows similar to the illustration below.

24 "Sight" Survey	_ 8 ×
Elle Edit Points Lines Quives Misc Draw Config Utilities Add Ins Window Help	
- 🕵 📾 🥐 👷 🐯 🖭 🕲 🎯 🐨 🖉 PANT ?+ 🗸 🏒 🥆 🆋 🍳 🐯 📍 😷	
🖥 Drawing 📃 🖾 🗶	
[Tropeties] Start	Point Direction Distance Northing Easting
** □ <u>+</u>	
	Database opened: Monday, August 24, 1998 4:13 pm.
부엌소	
LEQ ×	
20U	
Ha A NYS	
	-
التجييب والمنابع والمنابع والمنابع والمنابع والمنابع والمنابع والتقار	
	Page 1/1 Line 3 Col 1
Traverse	
Enter a Point Number	
Enter a Fount number	
ST GT From Point	
Dealing	
TR TA Distance 0	
P0 SS	
PA BP	
BU DB Accept (PgDn)	
43%	Text Dutput Window (press "Insert" to edit) N:-288.16 E:609.28

## 16.05

## <u>1</u> Text Output, <u>2</u> Drawing, <u>3</u> Data Entry, <u>4</u> Properties

**FUNCTION:** The numbered window names are used to activate any "Sight" Survey window.

From time to time you may want to minimize or maximize a "Sight" Survey window. Such an action is likely to obscure the window, or other windows. To activate any specific window, press Att W, # where # is the window's identifying number: 1; [2]; 3; or [4].



*The menu name for Item number 3 will vary depending upon the current function of the* **Data Entry** *window.* 

Page 458 The WINDOWS Menu

This page intentionally left blank.



# Section 17 The <u>H</u>ELP Menu



<u>C</u>ontents Current <u>T</u>opic <u>S</u>earch for Help On ... <u>H</u>ow to Use Help The  $\underline{\mathsf{Help}}$  menu is where you'll find access to the on-line help system.

System Information (SI)

17.01

## <u>C</u>ontents

**FUNCTION:** The <u>Contents</u> command is used to list the table of contents for the "Sight" Survey help file.

To access the <u>Help</u> [⇒]<u>Contents</u> window, press Alt H, C.

To access any item in the **Contents** window, double click the item.

You can return to the table of contents while you are using the help file simply by clicking on the button at the top of the help screen that says "Contents".

17.02

## Current <u>T</u>opic

**FUNCTION:** The **Current Topic** command is used to show help for the routine currently being accessed in "Sight" Survey.

To access the Current Topic window, press AtH, T.

Use this command if you are working on a particular routine and are not sure what information "Sight" Survey is asking you for.

#### Search for Help On ...

**FUNCTION:** The **Search for Help On** ... command is used to search the help files index for a particular subject.

To access the Search for Help On ... window, press Att H, S.

You can start a new search while using the help file by selecting the button labeled "Help" located at the top of the help screen.

#### 17.04

17.03

## <u>H</u>ow to Use Help

**FUNCTION:** The <u>How to Use Help</u> command is used to access the Help File help.

To access the **How to Use Help** window, press Att H, H.

The Help File help is a file created by Microsoft in order to acquaint people with the help engine. It contains information about using help files.

17.05

## System Information (SI)

**FUNCTION:** The **System Information** command is used to display information about "Sight" Survey and also about the computer being used.

To access the System Information window, press Alt H, 1.

After selecting this routine, "Sight" Survey will display a window containing information about itself and the system being used.

When first activated, the **About** window is displayed. To access the **System Information** window, click the tab or press **Alt** S.



*Pentium, 686 & 586 users: Do not be alarmed if the CPU type indicates 486.* 

To access the <u>Project Information</u> window, click the tab or press Alt P.

Among other things, this window displays the **serial number** for your copy of "Sight" Survey. This information will become important if you require technical support.



Page 462 The HELP Menu

This page intentionally left blank.



# Section 18 Getting Support

18.01

Help!

Simplicity Systems, Inc., provides support free of charge (but *not* toll-free) for 90 days from date of purchase, provided the user has returned a signed software registration form.

Experience demonstrates that well over 80% of the support calls we receive could be avoided if the caller would first look in the manual. Many long hours have gone into the preparation of this manual in an effort to provide all of the information necessary to the operation of this program. So please check the manual before you call.

Telephone support is available **ONLY** at the following numbers:

Voice:	1-218-773-7966
Fax:	1-218-773-3849
E-mail:	support@simsystems.com

Support hours are 8:00am to 5:00pm (Central time), Monday through Friday, exclusive of holidays. If all incoming support lines are busy, your call will be answered by our answering service and you will be given an option to leave your name and number, or you may wish to simply try your call again later. Messages on the answering service will be returned *collect*, in the order they are received with the exception that customers on an **Unlimited Support Plan** will always be given top priority.

If at all possible, please be at your computer when you call for support. This way a support technician will be able to step you through the procedure in question, which will save you the frustration of trying to remember our instructions at a later time. It will also be helpful for the technician to know the exact procedural steps you were following when you encountered the problem. **Raw Data** files and **Text Output** printouts are especially helpful for this.

If your question or problem does not require an immediate answer, please write down your problem and mail or fax it to the Simplicity technical support department including printouts, data disks, etc. Include your program serial number, your phone and fax numbers, and the hours/days you may be available. A support technician will solve your problem and provide you with the solution by mail, fax, or telephone.

You are encouraged to become as familiar with the operation of your computer as possible. When helping you, we will often ask you to perform certain functions such as: Copying a disk; Formatting a disk; Checking the contents of a disk, directory or folder; and Copying, Renaming, and Moving files. It is not within the scope of our technical support plans to assist you with, or tutor you on the use of Windows. Therefore, it is to your advantage to be familiar with these commands before you call.

If you are having a problem such as constant input/output (I/O) errors, etc., chances are good that the problem is hardware or media related. Please contact your hardware dealer first.

#### 18.02

#### Support Plans

The subject of charging a fee for technical support is a controversial subject across the software industry. However, when you compare the initial product cost, it appears that many of the companies that do *not* charge for technical support have actually built a prepaid support charge into the price of their software package. If you are like most people, you don't want to pay for something that you may never use.

At Simplicity, we pride ourselves on dependable, practical, and perhaps best of all, *affordable* software solutions. We have not "built-in" a prepaid support charge into the price of our software. You get a great program with well-written documentation and up to 90 days of free support. We do not charge you "up front" for software support that you may never need. After the initial period of free support, users who feel they will need additional help are encouraged to subscribe to one of our support plans. A technical support order form was enclosed with the shipment of this program. Please refer to this form for prices and updated information on the following support plans.

	Customers who do not subscribe to a support plan will be automatically transferred to the Basic Service when their 90 days of free support has expired.
Free Support	Simplicity Systems, Inc., provides <b>FREE</b> (but <b>not</b> toll-free) technical support during the software warranty period, provided the user has returned a signed software registration form. <i>Free support is provided with initial purchases of our products; it is not included with revisions or site licenses.</i>
	Customers who do not subscribe to the <b>One Year Unlimited</b> support plan will be automatically transferred to the <b>Basic</b> <b>Support</b> plan when their warranty has expired.
Call Backs	If all support lines are busy when you call for support, you have the option of trying your call again later or leaving a message for a technician to return your call. We will be happy to return the call to your toll-free (800 or 888) number, if you have one. If you do not leave your toll-free number, we will call you back direct, but you will be charged a <b>\$15 call back fee</b> .
Billing Terms	We do not maintain an accounts receivable, and as such, we do not normally allow "on receipt" billing terms. If you absolutely do not have or do not wish to use a credit card for support charges, we will invoice your company under <i>Net 10 Days</i> terms (from invoice date) <b>with the addition of a \$10 processing fee</b> . However, if your account is not in good standing, you may be denied future support unless you bring your account up-to-date and place future charges on a credit card.
Basic Support	The <b>Basic Support</b> plan provides technical support at a flat rate of <b>\$45 per incident</b> . You will be charged once for each support incident, regardless of the time required to solve the problem. This

plan is designed for the user who rarely needs support and can use Visa, MasterCard, or American Express for the billing.

One Year Unlimited The One Year Unlimited plan provides priority technical support for one person for one full year for \$199. A multiple user support plan for one full year is \$279. Any person who calls for technical support who is not covered under the One Year Unlimited plan will be charged the **Basic Support** plan rate, or may be added to the original support plan for \$80.

## **Updates & Upgrades**

It is Simplicity's policy to regularly maintain and update our software programs. Occasionally, (approximately once each quarter), "Sight" Survey may undergo *slight* changes such as minor enhancements, bug fixes, etc. which we refer to as software *revisions* or *updates*.

These changes may or may not result in a change of the internal version number of this program. For example, the first *revision* or *update* of **"Sight" Survey Professional 3.0** after its initial release will most likely be referred to as **Version 3.01**. The next revision/update would most likely be **Version 3.02**, etc. These changes are available either for a nominal fee on disk, or at no charge if downloaded from our web site at **www.simsystems.com**.

Much less frequently, this program may undergo *major* changes such as the addition of new routines, etc., which may or may not require the addition of a manual addendum. These changes will always result in the change of the version number. For example, the next *upgrade* of "Sight" Survey will most likely be referred to as **"Sight" Survey Professional 4.0**. These changes are available for a fee commensurate with the changes that have been made.

Whether you choose to update and/or upgrade this program is strictly optional. Depending on the changes that have been made during each release, you may choose to purchase every update, or you may choose to "skip" any update and purchase the next one when the changes may be more substantial. Either way, the choice is *yours*.

18.03



## Section 19 Troubleshooting

19.01

### **Startup & Loading Problems**

Running "Sight" Survey Across a Network If "Sight" Survey is being run across a local area network (LAN), it is important that all users have read/write access to the Program sub-directory. If users do not have access to this directory, an error will occur when they try to load the program. The most common error to occur under this situation is an "Access Denied" error, but the exact error will vary depending upon your system setup. The user will not be able to run the program until he has access rights to the "Sight" Survey Program sub-directory. The default name that the installation program uses for this directory is:

*Drive*:\SightSrv\Program, where *Drive* is replaced by the drive letter where the program is installed.

Loading "Sight" Survey Without Splash Screen The **Splash Screen** is the graphic (shown below) that displays the program title and copyright statement when "Sight" Survey is being loaded into memory. (The Splash Screen only appears if the **Startup Tips Close after loaded** checkbox is enabled.)



To disable both the Splash Screen and the Startup Tips box in Windows 95/98/NT, you must first create a shortcut to the ZAK.EXE application file in the "Sight" Survey Program subdirectory. You must then edit the **Properties** for the shortcut so that

the command line contains the **/NOTITLE** switch, as shown below in the **Short-cut to Zak Properties** window. Accept the changes and start the program using the new shortcut. These are basic Windows 95/98/NT procedures with which you should already be familiar. Refer to your Windows documentation or on-line help if you need additional information.

Zak 3 Properties ? 🗙
General Shortcut
Zak 3
Target type: Application
Target location: PROGRAM
Iarget: C:\SIGHTSV3\PROGRAM\ZAK.EXE /NOTITLE
Start in: C:\SIGHTSV3\PROGRAM
Shortcut <u>k</u> ey: None
Bun: Normal window
Eind TargetEhange Icon
OK Cancel Apply

To disable only the Splash Screen in Windows 95/98/NT, follow the same procedures as discussed in the previous paragraph, but apply them to the SIGHTSRV.EXE file in the SightSrv directory instead of the ZAK3.EXE file in the SightSrv\Program subdirectory.

To disable only the Splash Screen in Windows 3.1, you must edit the Properties for the "Sight" Survey program icon. Do this by highlighting the program icon and selecting **Properties** from the **File** pull-down menu. Next, add the **/NOTITLE** switch to the end of the **Command Line** box. Accept the changes and use the icon to start the program. This is a basic Windows 3.1 procedure with which you should already be familiar. Refer to your Windows documentation or on-line help if you need additional help.

To disable both the Splash Screen and the Startup Tips box in Windows 3.1, follow the same procedures as discussed in the

previous paragraph, but change the name of the startup executable file to the ZAK3.EXE file in the SightSrv/Program sub-directory before adding the /NOTITLE switch.

"Sharing Violation" Error
If "Sight" Survey issues a Sharing Violation error when it first attempts to load into memory, it is most likely because neither the DOS SHARE.EXE or Windows VSHARE is loaded into memory. If you allowed "Sight" Survey's Setup/Installation program to install the VShare device, you simply need to restart your computer for VShare to be loaded into memory, then restart "Sight" Survey. If you did not allow "Sight" Survey to install VShare, you will either need to install it manually or re-install "Sight" Survey and allow it to load the VShare statement for you. To install VShare manually, you must edit the Windows SYSTEM.INI configuration file located in the Windows directory.

To edit the SYSTEM.INI file when using Windows 3.1, open the Windows File Manager program and double-click on the SYSTEM.INI file located in the Windows directory. To edit the configuration file when using Windows 95, open the Windows Explorer program and double-click on the SYSTEM (.INI) configuration file in the Windows directory.

The file should open up in the Windows Notepad or WordPad editor. Under the [386Enh] section, add the following line:

### DEVICE=VSHARE.386

Save the changes, exit, and restart Windows. You should now be able to run "Sight" Survey.

"Invalid Property Value" Error If "Sight" Survey issues an Invalid Property Value error when it first attempts to load into memory, it is most likely because it is trying to use a text font that is not installed on your computer. To avoid this error, you must force "Sight" Survey to use a different font by manually editing the COGO.INI configuration file located in the "Sight" Survey Program sub-directory. Refer to the sub-section Change COGO Font found on page 408 of this manual.

"Sight" Survey Appears To Hang When It Starts If "Sight" Survey appears to hang or "lock up" when it first loads into memory, there is most likely an error message that is displayed on the screen, but is hidden behind the Splash Screen. The actual problem can't be resolved until the error message can be seen. To see the error message, you will need to start the program with the Splash Screen disabled.

*If you are running "Sight" Survey within Windows 3.1*, use your mouse to select File ⇒ Run (or press Alt)F, P) and then type: C:\SIGHTSRV\PROGRAM\ZAK.EXE /NOTITLE vEnter].

If you are running "Sight" Survey within Windows 95/98/NT, use your mouse to select Start Run... (or press Att S, R), then type: C:\SIGHTSRV\PROGRAM\ZAK.EXE /NOTITLE -Enter.

? ×
Type the name of a program, folder, document, or Internet resource, and Windows will open it for you.
C:\SightSV3\Program\Zak3.exe /NOTITLE
OK Cancel <u>B</u> rowse

Once the error appears, you should be able to resolve the problem based upon the error message that appears. If you need additional help, contact our Technical Support office at (218) 773-7966.

The layer names that appear in the Edit Layers window when "Sight" Survey first loads into memory or when a New Job (NJ) is started are the layers that have been defined and saved in the StartUp.Drg file. The file is located in the ...SightSrv\Program directory. If you define layers and want them to be available for all new jobs, you must store those layers in the StartUp.Drg file. To do this, start a new, unnamed job, define the layers, and then use the Start r File r Save Dawing As routine to export the drawing as StartUp.Drg into the Program sub-directory of the ...SightSrv directory.

Layer Names Disappear

### Helpful LegalEase Information

### Automatic Processing of a LegalEase File

You can run LegalEase completely in the background by using the **Process a LegalEase File (PL)** routine. When running in this automatic/seamless mode, your description is processed "in the background" without the LegalEase screens being displayed on your monitor. When the description has been written, your normal word processor will pop-up on top of the "Sight" Survey screen and your description will be loaded for you to review, edit or format to your preference.

If your word processor is already running when "Sight" Survey issues the command to start your word processor and load the legal file, you may end up with two instances of your word processor loaded into Windows. This may or may not occur, depending upon which word processor you use.

Before you attempt to run LegalEase in "automatic" mode, you must first run LegalEase the "regular" way, using the LegalEase Processor (LE) routine to setup the LegalEase configuration settings, custom phrases and captions to your preferences.

Even though you don't actually see the LegalEase program when you are running in automatic mode, it is still running in the background as a reduced icon. If your computer appears to lockup when running in automatic mode, simply press remerent (once) or double-click on the LGLEASE icon to display the LegalEase screen. The program may be prompting you for the curve direction of an obtuse curve, or an error condition may exist. In addition, if you are running Windows in **Standard** mode (WIN /S), you will need to press e (once) or double-click the icon to give Windows the "jump start" it needs to switch programs. You may or may not need to manually close the LGLEASE window afterwards.

The description file output *(filename.DSC)* from LegalEase can be loaded into the "Sight" Survey **Text Output** window using the <u>File</u> ⇒ <u>Import</u> ⇒ <u>Text</u> menu option.

### Lock-ups

The description file output (filename.DSC) from LegalEase can also be loaded into the "Sight" Survey Drawing window using the <u>Draw</u> **Praw** Supplemental **PASCII Text File** menu option.

19.03	Drawing, Printing, & Plotter Problems
Parts of Drawing Can't be Selected	If you can't select some parts of your drawing, the solution will most likely be found in either the <b>Selection Filter</b> (SF) or <b>Edit Layers</b> (EL) routines.
	The Selection Filter can cause items to be omitted when you try to select them using Select by Polygon, Select All, etc. For example, if Current Color is enabled (checked), only elements in the current color will be selected. If Lines is not enabled, lines will not be selected, etc. Display the Selection Filter by typing SF and check which filters are enabled. If you wish to select <i>everything</i> on your drawing, the Allow All filter should be enabled and the Current Color, Current LineType, and Current Layer filters should be disabled.
	If a drawing layer is locked, you won't be able to select anything on it. Display the <b>Edit Layers</b> dialog box by typing <b>EL</b> and look for the letter <b>L</b> to the left of the sample linestyle. If an <b>L</b> appears in any row, that layer is locked. For help unlocking a layer, refer to the sub-section <b>Editing One Layer</b> which begins on page 843 of the <b>Drawing Window Reference Manual</b> .
	Another reason you may not be able to select drawing entities could be that the (operate on) <b>Current Layer Only</b> option is enabled in the <b>Edit Layers</b> dialog box. When this option is enabled, you can only select items which are actually drawn on the <b>Current Layer</b> . If you wish to select items on other layers, type <b>EL</b> to display the <b>Edit Layers</b> dialog box and enable the (operate on) <b>All Unlocked</b> <b>Layers</b> option instead.
Items Disappear On the Screen	If parts of your drawing are missing or seem to have disappeared, the solution is most likely that one or more drawing layers are not visible. If a drawing layer is not visible, it is considered hidden, and you won't be able to see any of the entities contained on it.

Display the Edit Layers dialog box by typing EL and look for rows that do not have the letter  $\mathbf{v}$  to the left of the sample linestyle. If a  $\mathbf{v}$  does not appear in a row, that layer is not visible. For help making a layer visible, refer to the sub-section Editing One Layer which begins on page 843 of the Drawing Window Reference Manual.

Another reason you may not be able to see drawing entities could be that the entities are the same color as the background color you are using. Try changing the background color to black or to white since they are the most likely colors to ensure you can see the whole drawing. For more information, refer to the sub-section CAD Background Color which begins on page 394 of this manual.

"Sight" Survey's **Drawing** window automatically draws boxes to represent text that is too small to read. If you zoom in on, or magnify your text, you should find that it is there in full detail. This function is performed to speed up drawing redraws.

"Sight" Survey's **Drawing** window automatically draws boxes or lines to represent objects that are too small to see properly. If you magnify the drawing or zoom in on the section of the drawing, you should find that the objects appear in full detail. This function is performed to speed up drawing redraws.

If parts of AutoCAD DWG or DXF drawing are missing when you import it into "Sight" Survey, it is likely that the missing parts are the same color as the background color you are using, so you just can't see them. Try changing the background color to black or to white since they are the most likely ones to ensure you can see the whole drawing. You should also use the <u>Start [™]Settings</u> [™]D<u>X</u>F/DWG Conversion (XG) routine to determine if you properly configured the DXF/DWG Pen to CADControl Pen conversion settings.

When a TrueCAD drawing file (.DRG) is imported into "Sight" Survey using the <u>Start **P**_Eile **P**_Load</u> Drawing routine, the Drawing Scale, Page Center, and Paper Size appear as if they were not imported. This is an "appearance only" problem, and can be resolved by immediately using the <u>File **P**_Save Job</u> routine to save the drawing and create an associated "Sight" Survey (.zak) file. Then, simply reload the "Sight" Survey file using the <u>File **P**_Open</u>

Text Disappears or Displays as Boxes

Small Items on Drawing Disappear

Imported DXF/DWG File is Missing Parts

Imported Drawing File Scale Incorrect Job (LO) routine and the Scale, Page Center and Paper Size will now be correct.

error in When an attempt to plot a drawing results in a Floating Point error in module Truectrl.dll, it is usually caused by a corrupt item in the drawing database. Most often you can fix this error by running the <u>Start</u> [™] <u>File</u> [™] Repair Drawing <u>File</u> (FD) routine.

If you want to permanently change the color of the end point symbols on the **Drawing** window, the following information briefly describes the steps involved in making this change.

- Make a backup copy of the DMCUSTOM.SYM and SYMBOL.DRG files which are located in "Sight" Survey's Program sub-directory.
- 2. Run "Sight" Survey and load the SYMBOL.DRG drawing file.
- 3. Use the <u>Start [™]Settings [™]D</u>rawing Settings and set the Scale Ratio to 1:1.
- Change the colors of all of the symbols in the file: Select everything on the screen then use the <u>Start [™]Settings [™]Line</u> Defaults routine to change the <u>Pen</u> color. After selecting the desired color, click on <u>Apply</u> and then click on <u>OK</u>.
- 5. Save the drawing file: Use the <u>Start</u> ⇒<u>File</u> ⇒<u>Save Drawing</u> routine.

After completing the above steps, the symbols will be placed in "Sight" Survey using the new color.

Floating Point error in Truectrl.dll

How to Permanently Change Symbol Colors



# Section 20 The DRAWING Window

The "Sight" Survey **Drawing** window is where the action is. In this window, your drawing will be constructed as you perform your COGO data reductions and subsequent design. You can also work within this window to add other elements to enhance and complete your drawing.


### 20.01

### The Drawing Window



The illustration shown below is a screen capture of the **Drawing** window and a portion of the **Status Bar** which lies below it. The **Status Bar** area is included because it contains the cursor coordinate display. The screen was captured at a resolution of 800 x 600, the minimum suggested operating resolution for "Sight" Survey.

The Drawing window consists of several areas, as shown below:



20.03

### **The Command Line**

The Command Line displays prompts for Drawing window functions. Typically, these prompts have to do with point location, or they are Yes/No type questions. In the later case,  $\underline{Y}$ es and  $\underline{N}$ o buttons will be made available for you to click. When a Drawing window routine requires a text or numeric answer, a prompt window will be used.

### **Scroll Bars & Sliders**

The Drawing window is scrollable vertically, as indicated by a scroll bar along the right side of the window, and horizontally, as indicated by a scroll bar along the bottom of the window. Scroll the window vertically by clicking your mouse on the **A** and **Y** arrows on the scroll bar. Horizontally scroll the window by clicking your mouse on the  $\checkmark$  and  $\blacktriangleright$  arrows on the scroll bar. You may also click and hold your mouse on the slider button in the scroll bar while you slide the button up and down, or left and right.

### The Status Bar

The Status Bar contains four areas. On the left is a System Resources indicator which reports the percentage of free system resources available. When Windows starts it automatically allocates a portion of memory for system resources which is used to keep track of open windows, programs in use, icons, program groups, etc. However, Windows doesn't manage this memory very well. When a Windows program is started some system resource memory is used. When the program is closed, it is supposed to give all the memory back, but almost all programs steal some.



If your free resources drop to below 25%, proceed at your own risk. If your free resources drop below 10%, a Windows crash is imminent. Save your data and restart Windows!

The second box consumes the majority of the status bar and contains context sensitive help and tips.

20.04

Section 20

The third and fourth boxes, on the right of the screen, contain the Northing and Easting coordinates at the tip of the drawing cursor. These values are relative to the page center coordinates. The **Config Show Status Bar** (Att G, H) item is a toggle switch that displays and hides the status bar at the bottom of the screen.

### The Scale Bar

The **Scale Bar** provides a visual guide to the drawing scale. Toggle the scale bar display **On** and **Off** using the **Ruler** setting in **Start** [™] **Settings** [™] **View Settings** (Att S), (S), (V) - page 799).

### _____ The Drawing Window Toolbar

The **Drawing** window toolbar contains 30 icons (buttons) that activate 52 different functions. Most every button activates two functions, one when left-clicked and another when right-clicked.

You must finish active drawing routines (by pressing so or clicking **Cancel** at the top of the **Drawing** window) before you can select another drawing command from the **Drawing** window toolbar. Snaps and Zooms are always available.

ī.

### Select Cursor

Left: Select single entity	55.
Right: Selection Filters	56
Select Nodes Cursor	
Left: Select Nodes	56
Right: Clear Selection	56
Freehand Cursor	
Left: Freehand mode, no snaps	80
Right: Selection Filters	
Point Cursor	
Left: Snap to Nearest Point mode	80
Right: Snap Point settings menu	

### 20.05

20.06

<u>_h</u>_

 $\times$ 

*

 $\bigcirc$ 

I

P •

Z.

 $\sim$ 

₩.

### Grab All Cursor

Grab All Snap mode Snap Point settings menu	
ar Draw Perpendiculars Dimension Perpendiculars	
ntersection snap mode Snap Point settings menu	
nent earest Element snap mode Snap Point settings menu	
angent snap mode Snap Point settings menu	
e/Arc Fircle Center snap mode Snap Point settings menu	
Pan Long Pan	
Move to a <b>Polar Location</b> Move to <b>Exact Coordinates</b>	
ed) Draw a Chained Line Set Line Defaults	
t) Draw unconnected Line Segments Set Line Defaults	

	Polyline	
$\supset$	Left: Draw a Polyline	10
	Right: Set Polyline Defaults   8	
	Rectangle	
	Left: Draw a Rectangle	88
	<b>Right:</b> Draw a <b>Polygon</b>	11
(+)	Circle	
$\sim$	Left: Draw a Circle by two points	
	Right:    Draw a 3 Point Arc    58	89
$\geq$	Parallel Lines	
11	Left: Draw multiple Parallel Lines	
	<b>Right:</b> Draw single <b>Parallel Line</b>	99
	Trim	
<u>+</u>	Left: Trim 2 lines/arcs	
	<b>Right: Trim</b> one line onto another	38
	Zoom	
L <u></u>	Left: Access a Zoom mode via menun	
	Right:    Zoom All    5'	73
3	Zoom Window	
$\sim$	Left: Zoom into an area, or Window	
	<b>Right: Zoom Last</b> , return to previous zoom	72
8	Refresh Drawing	
R	Left: Redraw the drawing screen	82
	<b>Right: Zoom Sheet</b> , show the whole page	74
	Delete Selected	
$\sim$	Left: Delete Selected items 55	51
	Right: Clear Drawing Window	84
<b>4</b> I	Undo	
$\sim$	Left: Undo up to 1000 previous drawing operations 54	47
	Right: Redo up to 1000 undos	48

11
----

Α

<u>N45</u> 100'

Dimension           Left: Access a Dimension selection menun/a           Right: Set Dimension Defaults           826
Text Left: Add Text from the keyboard
Survey Dimensions           Left: Add Survey Dimensions to the drawing
Save Left: Save the Drawing (not the Job)
Align         Left: Align selected objects
Hatch/Fill Left: Enter Hatch/Solid Fill

20.07

### The Start Menu Button

The **Drawing** window **Start** (SM) button opens the main drawing functions menu. The menu items are described in detail within their own sections of the manual.

<u>S</u> tart	
<u>F</u> ile	۲
<u>E</u> dit	•
⊻iew	•
<u>D</u> raw	
<u>M</u> odify	
<u>A</u> nnotate	
<u>T</u> ools	
<u>O</u> bjects	
<u>S</u> ettings	×

File	Section 22
Edit	Section 23
View	Section 24
Draw	Section 25
Modify	Section 26
Annotate	Section 27
Tools	Section 28
Objects	Section 29
Settings	Section 30

### The Properties Menu Button

3

The **Drawing** window **Properties (PR)** button opens the **COGO Properties** menu. These items that affect the appearance of your drawing *for objects and text placed by COGO operations only!* 

Settings changed here do not change settings made in <u>Start</u> **Settings S**<u>L</u>ine and <u>Start</u> **S**<u>S</u>ettings **S**<u>T</u>ext.

The **Properties** window allows you to tailor "Sight" Survey's drawing options to your own preference. "Sight" Survey uses these settings to create your drawing in the **Drawing** window. For example, when "Sight" Survey draws a line, it creates the line using the values set for the **Object Color**, LineType, Line Width and Line Layer properties. You cannot change or edit existing entities by changing the values in the Properties window. Edit existing entities using the routines on the Start  $\Rightarrow$  Edit menu.

COGO Drawing P	
	14 - Black
Object Color	
LineType	Continuous
Line Width	01
Label Type	Point Number
Label Place	Quad #1
Label Angle	+0* - Horizontal
End Pt. Sym	Dot
Text Place	Dist / Bng
Text Font	Arial
Text Size	10
Text Color	08 - Blue
Text Bold	No
Text Italic	No
Symbols Lyr	SYMBOLS
Coords. Lyr	COORDINATES
Coord. List Lyr	COORDLIST
Elevations Lyr	ELEVATIONS
ASCII File Lyr	ASCIITEXT
Line Lyr	LINES
Pt. Name Lyr	PTNAMES
Pt. Number Lyr	PTNUMBERS
Points Lyr	POINTS
Sup. Table Lyr	SUPTABLES
Line Annot Lyr	LINETEXT
Station Lyr	STATIONS

## Section 20

### **Setting Values**

**Object Color** 

To set a Value for any Property, follow these general instructions:

1. Select a **Property** by clicking your mouse anywhere on the **Property's** name or in its **Value** box. A **Settings box** will replace the **Value box**.

2. Use your 1 and 1 arrows to scroll through the available settings, or click the next to the **Settings box** to pull down a settings menu.

3. Select the desired setting with your mouse, or use your 1 and 1 arrows to highlight the desired setting and then press .

4. When you are done making selections in the **Properties** window, click the **Drawing** window **Properties** (PR) button to close the **Properties** window.



If you prefer, you can leave the **Properties** window open and drag it to another screen location. Use the standard Windows technique for dragging windows to a new location.

The **Object Color** property is used to specify the color of the object (lines, arcs, etc., but not symbols or text) to be drawn.

The actual color shown on your display is governed by your video card; however, the main function of this menu item is to control the pen selection on a multi-pen plotter. For example, color two corresponds to pen number two on the plotter.

If you have already placed a line and/or text in the **Drawing** window and you want to change it, double-click on the line or text to activate an editing dialog box. Follow the instructions for **Line Defaults** on page 810, and **Text Defaults** on page 820.

When the **Object Color** property is set to **BY LAYER**, "Sight" Survey will draw all lines in the pen color associated with the layer that is currently assigned to the line layer. For more information please refer to the sub-section "**BY LAYER**" Layering beginning on page 848 of this manual.

	Attention PLOTTER USERS: Whether you have a single- or multi-pen plotter, you'll get much better results in line quality if you control the width and / or color of lines on your drawings by mapping the object colors to your plotter pens. For example, if you want a thicker line and you have a multi-pen plotter, set the object color to the number of the pen that you use for the desired thickness. When plotting that line, the appropriate pen will be retrieved. (This does not apply to color printers.)
Line Type	The <b>Line Type</b> property is used to specify the type of line to be drawn between points. Several line types are available, ranging from a solid line to various dash, dot, and dash-dot patterns.
	When Line Type is set to BY LAYER, "Sight" Survey will draw all lines in the Line Style associated with the layer currently assigned to the Line Layer. For more information, refer to the sub-section "BY LAYER" Layering beginning on page 848 of this manual.
Custom Lines	"Sight" Survey is distributed with several pre-defined custom lines including a centerline, brick wall, fence line, power line, water line, and more. Custom lines can be drawn using any of the COGO routines and the <b>LI</b> and <b>AC</b> routine codes. Custom Lines are not accessible when using <b>Drawing</b> window commands, with the exceptions of the <b>Draw Chained Lines</b> (?) and <b>Draw 3 Point Arc</b> (right-click ?) icons. Custom lines are selected using the <b>Line</b> <b>Type</b> property of the <b>Properties</b> window. They all appear at the top of the <b>Line Type</b> selection list and are preceded by an asterisk (*).
	Custom lines are not drawn for circles, rectangles, or random curves. If a custom line is selected when one of the aforemen- tioned entities is drawn, the entity will be drawn in the line type assigned to the selected custom line. (Line types are assigned to custom lines in the CustomLT.mac file under the column titled Linetype to use to connect the characters. See Custom Lines in Section 13.04 for information on custom line types.

Custom lines do not appear in the LineStyle selection lists for CAD-related functions such as the <u>Start  $\Im$  Settings  $\Im$  Set Arrow</u>

Defaults, Start P Draw P Parallel Lines, and Start P Settings P Layer Control routines.

The pre-defined custom lines are shown in Section 13.04. To view a drawing containing each of the pre-defined line types, begin a New Job (NJ) and use the <u>Start  $\Rightarrow$  File  $\Rightarrow$  Open Drawing routine (Att[S], [F], [O] - page 510) to import the CustomLT.drg drawing file. This file was installed when you installed "Sight" Survey.</u>

To edit, add, or delete custom lines, refer to the Custom Lines subsection in Section 13.04 and also in Section 33 - Line Types.

The Line Width property is used to specify the width of line that is drawn between points. The available values range from 1 to 10, where the unit is in tenths of a millimeter.

If you have already placed a line in the **Drawing** window and you want to change its type, color, and/or width, double-click on the line to activate the **Line Style** dialog box. Follow the instructions for **Line Defaults** on page 810.

- 1. Instead of specifying a line width greater than 01 (Thin), it is recommended that you map your object and text colors to your plotter pens. You will get much better results in line quality when plotting in this manner.
- 2. If you are using a color printer, you cannot map line widths and colors to pens and you should make these settings within "Sight" Survey, using the Line Width property.

The Label Type property is used to specify how to label the ending point. The available label types are:

- None Coordinates Description Elevation
- Label Point Number PtNum & Elev Station

### Label Type

Line Width

ad

Coordinates	When <b>Coordinates</b> is the selected label, the ending point will be labeled with the Northing and Easting coordinate values for that point. The location of the coordinates is determined by the <b>Label Place</b> item.
Description	When <b>Description</b> is the selected label, the ending point will be labeled with the description or point name for that point, if one has been assigned. The location of the description is determined by the <b>Label Place</b> item.
Elevation	When <b>Elevation</b> is the selected label, the ending point will be labeled with the elevation for that point. The location of the elevation is determined by the <b>Label Place</b> item.
Label	When <b>Label</b> is the selected label, the program will pause to allow you to enter your own text as the point label. The location of the label is determined by the <b>Label Place</b> item.
None	Select <b>None</b> if you do not want to label the ending point.
	To avoid labeling points, click on the Add End Point Labels icon ( [2]) in the Tool Bar. When this icon is deactivated, it will contain a large red X over the image.
Point Number	When <b>Point Number</b> is the selected label, the ending point will be labeled with the point number of that point. The location of the point number is determined by the <b>Label Place</b> item.
Pt. # & Elevation	The <b>Pt. # &amp; Elevation</b> label is provided as a convenient labeling choice for point plots and topo plots. When <b>Pt. # &amp; Elevation</b> is the selected label, the ending point will be labeled with the point number and the elevation for that point, separated by a semi-colon. The location of the label is determined by the <b>Label Place</b> item.

### Station

When **Station** is the selected label, the ending point will be labeled with the station number of that point, if one exists. The location of the station number is determined by the **Label Place** item.

- 1. The label is placed at the ending point only. Thus, in order to label your starting point, you must actually enter that point number as an ending point at one time within the drawing. This can be done either by drawing to that point or by just starting at the point and drawing to the same point number.
  - A label will also be placed at the point whenever the Enter & Assign or Point Plot routines are used with the label active.

The Label Placement property is used to specify where the point label will be placed around the point. The following five locations are available: Quad 1, Quad 2, Quad 3, Quad 4, and Decimal.

Quad 1 refers to the Northeast or upper right corner of the point.

Quad 2 refers to the Southeast or lower right corner of the point.

Quad 3 refers to the Southwest or lower left corner of the point.

Quad 4 refers to the Northwest or upper left corner of the point.

When **Label Placement** is set to **Decimal**, the point label will be placed with the decimal point (if one exists in the label value) at the actual coordinates of the point location. If a label does not contain a decimal point, "Sight" Survey begins the label at the point location, i.e. it left-aligns it.

The actual placement of the decimal point depends somewhat upon the **Text Font** and **Text Size**. You can obtain the best results by using a proportionally spaced font, such as Arial or Times New Roman with a text size of 10 points. Less desirable results occur when using a monospaced font such as Courier.

This option is typically used to create **topo plots** with the decimal point of the elevation in the actual point location. To create this type of topo plot, set the **Label Type** to **Elevation**; the **Label** 

#### Label Place

Placement to Decimal; and the End Point Symbol to Cross, Dot or None. Then run the Point Plot (PP) routine.

The **Label Angle** property is used to vary the rotation angle at which point labels are placed on your drawing. This setting is used each time a point label is placed. The default angle is zero degrees, and the rotation angle increases in a counter-clockwise direction from the 3 o'clock position. The choices are:  $0^{\circ}$  (Horizontal),  $+10^{\circ}$ ,  $+20^{\circ}$ ,  $+30^{\circ}$ ,  $+40^{\circ}$ ,  $+45^{\circ}$ ,  $+50^{\circ}$ ,  $+60^{\circ}$ ,  $+70^{\circ}$ ,  $+80^{\circ}$ ,  $+90^{\circ}$ ,  $-10^{\circ}$ ,  $-20^{\circ}$ ,  $-30^{\circ}$ ,  $-40^{\circ}$ ,  $-45^{\circ}$ ,  $-50^{\circ}$ ,  $-60^{\circ}$ ,  $-70^{\circ}$ ,  $-80^{\circ}$ ,  $-90^{\circ}$ .


The following diagram shows the effect of the Label Angle on labels in the various quadrants selected for Label Placement.

	+ 90°	+ 45°	+ 0°	- 45°	- 90°
QUAD #1	+∞	°+	+8	°+	+∞
QUAD #2	$\infty^+$	+°	+8	~+	+ ~
QUAD #3	$\infty^+$	<del>୪</del> +	8 ⁺	ବ୍	$\infty^+$
QUAD #4	∞_+	ଷ ₊	8_+	୫୍-	∞ ₊

End Point Symbol

The End Point Symbol property is used to specify the symbol that you would like placed at the ending point. When the End Point Symbol property is set to anything other than None, a symbol will be placed at the ending point within most every COGO routine. Symbols can also be placed using the Point Plot routine, with or without trimming, or the <u>Start Draw Dymbol</u> routine which automatically trims. Symbols may also be placed using the PS routine code or the Point/Symbol (PS) item on the Draw pulldown menu. These are the quickest methods. However, placing symbols using <u>Start Draw Dymbol</u> allows you to scale and/or rotate each symbol as it is placed.

The (Add Symbols) tool bar icon allows you to quickly activate and deactivate the placement of symbols at ending points without setting the End Point Symbol property to None. When symbol placement is inactive, a large red X overlays the icon. "Sight" Survey includes 22 pre-drawn symbols as shown on the next page. Four additional symbols also exist: a North arrow; a two inch scale bar; a three inch scale bar; and a five centimeter scale bar. These components are accessed through the <u>Draw</u> Draw Supplemental command as described in Section 12.11 through Section 12.14.



* Large trees plot to a 20 foot scaled diameter. Small trees plot to a 7 foot scaled diameter.



You may notice a dot within **Centerline** symbols on the **Drawing** window. This is actually the center point of the arc that represents the letter **C** within the symbol. The dot shows on the display only and will not appear on the printed or plotted drawing.

Custom SymbolsUsing "Sight" Survey, you can create custom symbols for use<br/>within "Sight" Survey. The following steps briefly describe how to<br/>create symbols and make them accessible to "Sight" Survey.

- Make a backup copy of the DMCUSTOM. SYM and SYMBOL.DRG files which are located in the "Sight" Survey Program sub-directory.
- Start "Sight" Survey and load the SYMBOL.DRG drawing file using <u>Start [®]> File [®]> Open Drawing</u> (AttS, F, O page 510). Under <u>Start [®]> Settings [®]> Drawing Settings</u> (AttS, S, D page 789), set the Scale Ratio to 1:1.
- 3. Draw any new symbols that you want added to the file.
- Group the new symbols as actual "Sight" Survey symbols using the <u>Start [™]Objects [™]Make Symbol</u> routine (AttS, O, M page 774): Group each new symbol separately. When prompted, enter a name for the symbol and then select the entities that make up the symbol. Next, specify the lower left and upper right corners of the trimming region. Finally, enter the coordinates of the hook point.
- Save the drawing file: Use the <u>Start</u> [™] <u>File</u> [™] <u>Save Drawing</u> routine (<u>Att</u> <u>S</u>, <u>F</u>), <u>S</u> page 515).
- List the symbol patterns to disk for use with "Sight" Survey: Type XX and at the TrueCAD command prompt, type ListPat and press Fine. Click on Yes to include all layers, click on Yes to include area and perimeter calculations.
- Save the file as DMCUSTOM. SYM. Use the <u>Start</u> ⇒ <u>File</u> ⇒ Save Drawing <u>As</u> routine (<u>Alt</u> S), [E], <u>A</u> page 515), and be sure that the file is saved into the "Sight" Survey Program sub-directory.

After completing the above steps, the new symbols should be listed in the **End Point Symbol** properties box the next time you load "Sight" Survey.



Symbols do not have to be drawings. You can also save commonly used notes, certificates, etc. as symbols.

Trimming	When a symbol is placed using the <b>Point Plot</b> routine, you can enable or disable the trimming of lines and text under a symbol using the <b>Trim Symbol</b> check box. However, when a symbol is placed using the <b>Draw Point / Symbol</b> ( <b>PS</b> ) routine, "Sight" Survey <i>always</i> automatically trims under the symbol. When a symbol is placed using any of the COGO routines (such as <b>Traverse</b> ( <b>TR</b> ), <b>Inverse</b> ( <b>IN</b> ), etc.), "Sight" Survey <i>never</i> trims under the symbol. This is because trimming is performed when the symbol is actually placed on your drawing. Therefore, if we trimmed symbols within the COGO routines, all incoming lines would be trimmed but outgoing lines would not be trimmed.
Text Place	The <b>Text Placement</b> property is used to specify how you want "Sight" Survey to annotate lines or place text on the drawing. The available options are:
/ Bng	Annotates lines with the bearing below the line.
/ Bng Dist	Annotates lines with both bearing and distance below the line.
/ Dist	Annotates lines with the distance below the line.
/ Label	Annotates lines with a label below the line. After you enter the label, "Sight" Survey will use that label for all lines drawn until a different text placement option is selected.
Bng /	Annotates lines with the bearing above the line.
Bng / Dist	Annotates lines with the bearing above the line and distance below the line.
Bng Dist /	Annotates lines with both bearing and distance above the line.
Dist /	Annotates lines with the distance above the line.

Dist / Bng	Annotates lines with the distance above the line and the bearing below the line.
Label /	Annotates lines with a label above the line. After you enter the label, "Sight" Survey will use that label for all lines drawn until a different text placement option is selected.
None	Shuts off the line and arc annotation.
	<i>To avoid line annotation, click on the</i> <b>Dimension Lines</b> <i>icon</i> ( <i>) in the</i> <b>Tool Bar</b> <i>. When this icon is deactivated, it will</i>

contain a large red X over the image.

to restore all three settings.

× ×

### **(i**

The top and bottom of the text line is determined by the angle of the text, not by the order of the starting and ending points. "Sight" Survey keeps a drawing readable by placing all text facing either left to right or bottom to top. This way, a person reading the drawing can easily read the text when the map is placed normally or when turned to the right. To this end, the cut-off points for text placed left to right is 10° NW and 10° SE.

SUPER SHORTCUT - THREE AT ONCE!!! To draw only points (with no lines, point labeling, or annotation) double-click on any of these Tool Bar icons: Add End Point Labels (P); Dimension Lines (P); or Draw Line Between Points (P). Double-click on any of the icons again

**Text Font** 

The **Text Font** property is used to specify the text style you want to use for the text on your drawing. You may choose from any font installed in Windows.



Double-clicking on the **Text Font** property (or current value) will display a **Windows Font Dialog Box** allowing you to set the font type, style (regular, italic, **bold**, or **bold-italic**),size, color, and effects (<u>underline</u> or strikethrough.). Windows 3.1 and Windows 95/98 are supplied with three types of fonts: **TrueType** fonts, **Screen** fonts and **Plotter** (or Stroke) fonts.

If you are going to obtain output using a printer, you should use **TrueType** fonts, or **Printer** fonts that are native to your particular printer.

If you are going to obtain output using a plotter, you should use **Plotter** fonts, such as the **Stroke Font** collection (for Windows NT & 95/98) available from Simplicity Systems. *Call 1-800-777-7978 for details*.

¥

If you are outputting to a vector (pen) plotter, you should use one of the plotter fonts, **Modern, Roman, Script**, or some type of **stroke font** for your text and dimensions. (**HPGL Users -** if you use any other font on your drawing it will be converted for the plotter but all your text will be plotted horizontally, regardless of its orientation on the drawing.)

**TrueType** fonts are preceded by a r or r icon in the list of fonts in the **Font Dialog Box**. They look the same on your screen as they do when they are output to your printer. TrueType fonts scale smoothly to any size on almost any Windows-supported screen and printer (but not daisy-wheel printers or plotters). Extra TrueType fonts can be purchased, and those supplied with other packages can be used.

Screen fonts (if they appear at all) are preceded by an icon representing a screen and usually have the suffix **WN** on the list of fonts in the **Font Dialog Box**. These are the fonts that Windows uses for the text that appears in dialog boxes on the screen, among other things. The font that you see on the screen will be approximated by your printer, so text written using screen fonts may look slightly different on the screen than when printed. **Plotter** fonts are not preceded by an icon. They are vector fonts (i.e. they are made up of lines) and are the fonts you should choose if you are going to output to a plotter.

**Printer** fonts are usually preceded by a printer icon (**E**). These fonts are installed to Windows when you install a new printer.

The **Text Size** property is used to specify the size of the text to be placed on your drawing. Sizes range from 1 to 72 points, where a point equals  $1/_{72}$  of an inch.

The actual plotted text size is determined entirely by the final scale that the drawing is plotted at. If you plot the final drawing at a scale that is different from what you entered for a final scale when you started the drawing in "Sight" Survey, your text size will not be correct. For example, if you enter the final scale as 100 within "Sight" Survey, but you actually plot the drawing within CAD at a 50 scale, your text (and components) will be double their expected size.

When a line being annotated is too short to support the text being placed on it, "Sight" Survey will react in one of two ways: text will either be squished to fit on the line; or a label will be assigned to the line and placed above the line. The label will begin with the letter "L" and follow with a number that represents that line in the Short Line Table which can later be placed on your drawing.

"Sight" Survey's course of action depends upon the **Dimensioning** of Short Lines setting in the CAD Configuration menu (page 392.)

The **Text Color** property is used to specify the color of the text to be drawn. **Text Color** operations are basically identical to setting the **Object Color** (see page 482).

When the **Text Color** property is set to **BY LAYER**, "Sight" Survey will place all text in the Pen color associated with the layer that is currently assigned to the layer for the type of text being placed. For example, **Point numbers** are placed in the color assigned to the **Point Numbers Layer**; **Bearings** are placed in the color assigned to the **Line Annotation Layer**, etc.)

**Text Size** 

**Text Color** 

	Specific text entities and the layer that they are associated with are shown in the table on page 849 of this manual.		
	For more information please refer to the sub-section <b>"BY LAYER"</b> <b>Layering</b> beginning on page 848 of this manual.		
Text Bold	The <b>Text Bold</b> property is used to specify whether or not you want the drawing text to be placed in a bold typeface. When <b>Text Bold</b> is <b>On</b> , text will be placed in a darker, bold typeface. When <b>Text</b> <b>Bold</b> is <b>Off</b> , the text will be placed in a regular typeface.		
Text Italic	The <b>Text Italic</b> property is used to specify whether or not you want the drawing text to be placed in an italic typeface. When <b>Text Italic</b> is <b>On</b> , text will be placed in an italic typeface. When <b>Text Italic</b> is <b>Off</b> , the text will be placed in a regular typeface.		
Symbols Layer	The <b>Symbols Layer</b> property is used to specify the name of the layer for the end point symbols, component table, North arrow, and scale bar. (Symbols drawn as part of a custom line are placed on the <b>Lines Layer</b> .) The default name for this layer is <b>SYMBOLS</b> .		
<b>i</b>	For any of the Layer properties, if the layer you wish to use has not yet been defined, add it by selecting the <new layer=""> option and then entering the new layer name. New layers that are added in this manner (versus using Edit Layers) are only created and saved in the drawing file if they contain data or are set as the current value for a layer property when the file is closed. Layering is discussed in detail, beginning on page 839.</new>		
Coords. Layer	The <b>Coordinates Layer</b> property is used to specify the name of the layer for Northings & Eastings when <b>Coordinates</b> is the selected <b>Label Type</b> . The default name for this layer is <b>COORDINATES</b> .		

Coord. List Layer	The <b>Coordinate List Layer</b> property is used to specify the name of the layer for the coordinate list containing point numbers, Northings, Eastings, elevations and descriptions. The default name for this layer is <b>COORDLIST</b> .
Elevations Layer	The <b>Elevations Layer</b> property is used to specify the name of the layer for Elevations when they are the selected <b>Label Type</b> . The default name for this layer is <b>ELEVATIONS</b> .
ASCII File Layer	The <b>ASCII File Layer</b> property is used to specify the name of the layer for imported ASCII text files. The default name for this layer is <b>ASCIITEXT</b> .
Line Layer	The <b>Line Layer</b> property is used to specify the name of the layer for lines, arcs, random curves, circles, rectangles, and custom lines (including text and symbols placed along custom lines). The default name for this layer is <b>LINES</b> .
Pt. Name Layer	The <b>Point Name Layer</b> property is used to specify the name of the layer for point Descriptions and labels when they are the selected <b>Label Type</b> . The default name for this layer is <b>PTNAMES</b> .
Pt. Number Layer	The <b>Point Number Layer</b> property is used to specify the name of the layer for Point Numbers and Pt # & Elevations when they are the selected <b>Label Type</b> . The default name for this layer is <b>PTNUMBERS</b> .
Points Layer	The <b>Points Layer</b> property is used to specify the name of the layer for dots and crosses. The default name for this layer is <b>POINTS</b> .
Sup. Table Layer	The <b>Supplemental Table Layer</b> property is used to specify the name of the layer for the curve and short-line tables. The default name for this layer is <b>SUPTABLES</b> .

### Section 20

Line Annot Layer	The Line Annotation Layer property is used to specify the name of the layer for bearings, distances, curve lengths, curve labels, and short-line labels. (Text characters drawn as a part of a custom line are placed on the Lines Layer.) The default name for this layer is LINETEXT.
Station Layer	The <b>Station Layer</b> property is used to specify the name of the layer for Stations when they are the selected <b>Label Type</b> . The default name for this layer is <b>STATIONS</b> .
(	Some drawing entities do not have a special layer property and are instead drawn on the <b>Current Layer</b> at the time of placement. They are: <b>Parallel Lines</b> ; <b>Leader Lines &amp;</b> <b>Arrows</b> ; <b>Text Lines</b> ; and <b>Angle Labels</b> ; as well as most items placed from within the <b>Drawing</b> window such as: <b>Dimensions</b> ; (any type) <b>Hatches</b> ; <b>Fills</b> ; <b>Bitmaps</b> ; <b>Arc &amp; ASCII Text</b> ; etc.

### 20.09

### The Right-Click Draw Menu

When you right-click the mouse anywhere in a blank area of the **Drawing** window, "Sight" Survey's **Draw** menu appears. This is the same menu that appears when you select the **Draw** menu from the menu bar that lies across the top of the program screen.

<u>S</u> nap Modes
Select <u>P</u> oint (SP) Select <u>D</u> istance (SD) Select <u>B</u> earing (SB) CAD to CO <u>G</u> O ►
Draw Suppleme <u>n</u> tal ► Layer O <u>v</u> erride (LV) Label an Angle (AL)
CAD Pape <u>r</u> in Landscape Orientation ✓ Show P <u>aper</u> Border

You can select functions from this menu while you are working in the **Drawing** window.



## Section 21 Accurate Placement

Section 21

"Sight" Survey contains features that make it easy to produce accurate drawings. These features include: Jumps; Precise Cursor Movements; Grids; Ortho Snaps; and Calculations.

### 21.01

### Jumps & Snaps

**FUNCTION: Jumps** and **Snaps** are used to quickly move the cursor to a precise existing location.

"Sight" Survey has two ways of moving exactly onto an existing part of a drawing: Jumps and Snap Modes. Drawing jumps and snap modes can only be issued while "Sight" Survey's Drawing window is prompting you for a point. (i.e. The prompt bar at the top of the Drawing window must be prompting for a point.) These commands will not work when the Drawing window shows the default Select cursor ( $\triangleright$ ).

A Jump moves your cursor exactly onto an existing part of the drawing, for example onto the end of a line. If you want to accept the point that you have jumped to, such as for the first point of a line or as a point through which a traverse line must pass, you must first enable the Quick Pick (QP) toggle or use one of the following Select routines: Select Point (SP), Select Bearing (SB) or Select Distance (SD). Usually, you must press Fener or click the left mouse button to actually set the point at the jump location. By combining jumps with the Quick Pick (QP) routine, an accurate "move and accept" is performed each time you press Fener or click your left mouse button. However, if you move your mouse before you press Fener or click the left mouse button, the point will be lost and you will have to perform the jump again.

Within "Sight" Survey, when you implement a **Snap Mode**, it sets the cursor snap mode for the next selected point. Changing the default snap mode is useful when you must exactly snap onto a point or other entity in a congested part of the drawing. The snap mode overrides the jump mode and allows more accurate entity selection. For example, if you jump to a point where a cross has been placed, the default **Grab All** cursor (  $\boxdot$  ) will jump to the nearest entity within the cursor box. By enabling a **Nearest Intersection** snap mode, it forces the center of the cross to be selected instead of an end point of one of the lines of the cross.

The quick reference guide below lists jumps and snap modes. More detailed information on jumps follows the guide.

J	JUMPS & SNAP MODES - QUICK REFERENCE			
Locks	Locks & Toggles			
K	<b>Locks</b> cursor to the <b>exact bearing/angle</b> of an entity.			
Ð	Toggles Ortho (parallel/perpendicular). Mode on and off.			
Curson	r Snap Modes			
Shift F	Enables <b>Freehand</b> cursor ( <b>Cancels Jump/Snap</b> mode.			
Shift A	Enables Grab All cursor ( 🖸 ) snap mode.			
Shift J	Enables Nearest Point cursor ( +++) snap mode.			
Shift N	Enables Nearest Line/Arc cursor ( $\downarrow^{\ltimes}$ ) snap mode.			
Shift Y	Enables Nearest Intersection cursor ( $_{+}^{\times}$ ) snap mode.			
Shift E	Enables Nearest Center Point cursor $( + \bigcirc )$ snap mode.			
Precisi	on Jump Codes			
A	Jumps to any point in the cursor box.			
J	Jumps to the <b>nearest point</b> . (Identical to clicking your mouse while a point lies within the cursor box.)			
N	Jumps to the nearest line or arc.			
$\mathbf{Y}$	Jumps to the nearest intersection.			
E	Jumps to the center point of the nearest arc or circle.			
Ξ	Jumps to the <b>midpoint of a line</b> .			
O	Jumps an exact distance and bearing.			
C	Jumps to an exact coordinate location.			
Η	Jumps to the center of the Drawing window.			

Directi	onal Jump Codes			
1	Jumps <b>upwards</b> a set number of vertical units.			
[Shift] ↑				
I.	Jumps <b>downwards</b> a set number of vertical units.			
Shift I	-			
E C	Jumps to the <b>left</b> a set number of horizontal units.			
	1			
	Jumps to the <b>right</b> a set number of horizontal units.			
Shift →				
	units.			
Home	Jumps diagonally up and left a set number of units.			
Page Up	Jumps diagonally up and right a set number of units.			
End	Jumps diagonally down and left a set number of units.			
Page Dn	Jumps diagonally down and right a set number of units.			
CtrlT	Jumps to an exact <b>ratio distance</b> such as 0.5.			
Duant				
	ng Zoom Shortcuts (These work anytime)			
CtrlM	Magnify the drawing at the cursor location.			
CtrlD	<b>De-Magnify</b> the drawing at the cursor location.			
CtrlA	Zoom All of the drawing onto the screen.			
CtrlW	Initiates the <b>Zoom Window</b> command.			
	Initiates the Split Window command when used within			
	the Zoom Window command.			
	Closes <b>Split Windows</b> when used <i>within</i> the <b>Zoom Window</b> command.			


3

Jumps only position the cursor. Jumps do not accept the point jumped to for use in drawing routines. After you jump to a point, you must press *enter* to accept (or fix) the point.

The available jump codes and jumps are:

- A Jump to Grab All: Jump to any point in the cursor box. This jump is only operational when you are in the Grab All snap mode.
- J Jump Point: (Also, clicking your mouse while a point lies within the Grab All snap mode cursor box will cause "Sight" Survey to jump to that point.)
- **N** Jump Near Element: Jumps to the nearest line or arc.
- Y Jump Intersection: Jumps to the nearest intersection.
- **E** Jump Circle Center: Jumps to the nearest circle (or arc) center point.
- T Midpoint Jump: Jumps to the midpoint of a line.
- **G** Jump Grid: Jump to the nearest grid point.
- X Last Fixed Jump: Jumps to the last *fixed* point, accepted by pressing *energy* or clicking the mouse.
- Ctrl T Ratio Jump: Jumps to a particular distance along a line or between two points. Prompts for a ratio, for example 0.33 to jump a third of the way.

To illustrate the usage of jumps, consider the illustration below:



In a new "Sight" Survey session, type **LI** to draw a line from **1** to **2** to **3**. "Sight" Survey will prompt (in the **Drawing** window command line):

### Enter first point of line

Click your cursor at the location for point 1.

### Enter next point of line

Click your cursor at the location for point **2**. The line is "rubberbanded" so you can see it as you draw.

### Enter next point of line

Click your cursor at the location for point 3.

### Enter next point of line

Press **Esc** to cancel line drawing.

Type **AC** to draw a three point arc. "Sight" Survey prompts:

### Enter first point of arc

Move the **Grab All** cursor ( $\bigcirc$ ) near point **3** and press **J**-Ener to jump to the nearest point and mark it as the first point. "Sight" Survey prompts:

### Enter point on arc

Move the cursor to a point on the arc and click. (This is shown as point 6 in the example drawing on page 500). "Sight" Survey prompts:

### Enter last point of arc

Move the cursor to the end point on the arc and click. (This is shown as point 4 in the example drawing). The arc will be drawn. Press  $\boxed{Esc}$  to cancel arc drawing.

### Section 21

Now we'll use a jump to identify the arc center point and draw a line to it from point **4**. Type **LI** to draw a line. "Sight" Survey prompts:

#### Enter first point of line

Press X - Ener to jump to the last fixed point and mark it as the first point. "Sight" Survey prompts:

### Enter next point of line

Press Event to jump to the arc center point and mark it as the next point. A line will be drawn from point 4 to point 5 and "Sight" Survey prompts:

### Enter next point of line

Now we'll try a few other jumps, but we won't draw the lines. Move the cursor to a point near  $\text{Line}^{2-3}$  and press  $\square$  (but not  $\stackrel{\text{reme}}{=}$ ) to jump to the midpoint of  $\text{Line}^{2-3}$ . Now move the cursor a little bit toward point 2 and press  $\square$  (but not  $\stackrel{\text{reme}}{=}$ ) to jump to the intersection point of  $\text{Line}^{1-2}$  and  $\text{Line}^{2-3}$ . Now move the cursor to point 1 and press  $\square$   $\stackrel{\text{reme}}{=}$  to set  $\text{Line}^{5-1}$ . Press  $\stackrel{\text{Esc}}{=}$  to cancel line drawing.

### **Precise Cursor Movements**

**FUNCTION:** Precise cursor movements are used to quickly move the cursor to a precise new location.

"Sight" Survey is capable of several types of precise cursor movements. To make a precise cursor movement, just press the corresponding arrow or key at any **Drawing** window command line prompt for a point.

### 21.02

3 you move to a point, press *rest to accept (or fix) the point.* Precise cursor movements cannot be issued unless "Sight" Survey's Drawing window command line is prompting you for a point. Precise cursor movements are jumps of a specified number of units; jumps to exact coordinates; and jumps established by angle and distance. As with the previously described set of jumps, you can use any of these jumps whenever "Sight" Survey's Drawing window command line is prompting you for a point. After performing each movement, you must press et actually set the point at the new location. of units. You will be asked to specify the number of units up, down, left, or right that you want to move. Move Up: How far ? × 11.5 0K Cancel Type in a value and press ere or click **OK**. The value is in the drawing units specified in **Start Settings Unit Settings** (Att S), **S**, **U** - page 797). Shift [Left, Right, Up, Down] Press Shift (or Shift 1) to jump up (or down) the last set number of vertical units. Press Shift (or Shift) to jump left (or right) the last set number of horizontal units.

> Press Home, Page Up, Page Dn, or End to jump diagonally up and left, up and right, down and right, or down and left a set number of units. You must specify the number of units you want to move.

### Left, Right, Up, Down

Diagonals

Press  $\uparrow$ ,  $\Box$ ,  $\ominus$ , or  $\ominus$  to jump up, down, left, or right a set number


Precise cursor movements only position the cursor. They do not accept the point location for use in drawing routines. After

Move to Exact Coordinates

Move Right and Up: How far ?	×
40.000 65.000	
OK	

Type both values separated by a space and press —Enter or click OK

Press C or right-click the **Polar Move** icon ( ) to jump to an exact coordinate location. You will be asked to specify the **Northing** and **Easting** that you want to jump to.



Type both values separated by a space and press Fine or click **OK**.

3


The order in which coordinates are displayed and entered depends on the way you have set up Northings and Eastings in the Surveyor Setup section of Start ⇒ Settings ⇒ Drawing Settings (Att) S, S, D - page 789).

### Move to a Polar Location

Press  $\bigcirc$  or click the **Polar Move** icon ( $\checkmark$ ) to jump to an exact location specified by a distance and angle. You will be asked to specify the distance and angle that you want to jump to.

Enter distance to move			×
30.000			
-	ОК	Cancel	

Type in a distance value and press - Enter or click **OK**.



Section 21

Type in a bearing value (in the format shown) and press *The or click The DMS*. For faster data entry, you may separate the DMS values with spaces or periods, for example: **41°42'38**" may be entered as **41 42 38**, or as **41.42.38**.

#### To a Ratio Distance

Press **CHT** to jump to an exact ratio distance such as 0.5, 0.33, etc. You will be asked to specify the defining points and ratio that you want to jump.

Enter division ratio for jump 🛛 🗙		
138		
OK Cancel		

Type in a ratio value and press Firer or click **OK**. "Sight" Survey prompts:

Would you like to jump to a ratio point on line, (else between two points).

Click  $\underline{Yes}$  or press  $\underline{e_{\text{Enter}}}$  or  $\underline{Y}$  if you want to set a point at the ratio distance and on a line connecting two other points.

If you want to set the point between two unconnected points, click **No** or press **N**. "Sight" Survey prompts:

#### Enter first point

Click on (or jump to and set) a point. "Sight" Survey prompts:

Enter next point

Click on (or jump to and set) the next point. "Sight" Survey moves to a point at the ratio distance. Press <u>"Enter</u> to set the point.

21.03	Outho Snono
21.03	Ortho Snaps         FUNCTION: Ortho Snaps are used to construct lines and/or
	text parallel and/or perpendicular to an existing object.
	Using <b>Ortho Snaps</b> , it is easy to construct lines or write text parallel or perpendicular to a reference direction. The reference direction is set by identifying the line and pressing $\mathbb{K}$ . ( $\mathbb{K}$ stands for loc $\mathbb{K}$ .)
Drawing Lines	For example, suppose you have just drawn a line at a bearing of S 10° E. Now you want to draw a line parallel to the last line. Position the cursor near one of the end points of the line. Type <b>LI</b> to draw a line. At the prompt,
	Enter first point
	position the cursor near the midpoint of the line and press $\boxed{1}$ to jump to the actual midpoint. Press $\boxed{K}$ to lock in the angle, then press $\textcircled{+}$ to activate the <b>Ortho</b> mode.
	3 Use the 🕂 key from the numeric keypad.
	Move the cursor to the desired distance from the first line and click or press <i>etenter</i> . "Sight" Survey prompts:

#### Enter next point of line

Press 🛨 again. Now as you move the cursor, notice that the line can only be drawn perpendicularly through the point, or through the point on a path parallel to the first line. Draw your line and click or press *etemer*.

To turn the **Ortho** mode off, press Esc to exit the line drawing mode.

When you access the <u>Start  $\Rightarrow$  Annotate  $\Rightarrow$  Text Line Entry</u> function (AttS, A, Y - page 659), "Sight" Survey prompts:

#### Enter text position

Position the cursor on the line to which you want to align text. **DO NOT click the cursor.** Instead, press  $\ltimes$  to lock the cursor to the angle of the line. Now move the cursor to the desired text location and click. Then enter text just as before.



If you want text perpendicular to the line, press  $\bigcirc$  after you have pressed  $\ltimes$ .

Text will stay locked at the angle until you exit the **Text Line Entry** function. The next time you enter the function, text will default to horizontal.

#### 21.04

**Placing Text** 

#### Grids

**FUNCTION: Grids** serve as guideline functions for precise movement.

**Grids** allow you to place a user-defined grid onto the screen. The grid points can be snapped to using the **Grid Snap** mode or **Jump Grid**. The grid may also be turned on and off.

Grids are discussed in Section 9.14 - <u>Start [™]</u>Tools [™] Grid (AttS), T, D - page 747).

	2
<u> </u>	9

#### Calculations

**FUNCTION: Calculations** may be entered when "Sight" Survey prompts for a distance.

3

The calculations referred to in this section apply only to prompts that appear during Drawing window functions. This section does not apply to data entered into COGO's Data Entry window.

Whenever "Sight" Survey prompts you to enter a distance, be it diameter, radius, length etc. you can enter that distance as an arithmetic expression, for example (518-212)/3.

This expression is evaluated when you click OK, or press  $\overrightarrow{-Enter}$  after typing the expression, resulting in the correct distance being used.

You can use the following functions:

- * multiply (use the * on the numeric keypad).
- / divide (use the / on the numeric keypad).
- minus (use the on the numeric keypad).
- + plus (use the + on the numeric keypad).
- $^{\circ}$  power, e.g. 10² (ten to the power of two).

**sqrt(x)** square root, for example: sqrt(100) (square root of 100).

The functions sin(x), cos(x), tan(x), asin(x), acos(x), atan(x), atan2(y:x), int(x), abs(x), log(x) and ln(x) are also available.

Standard mathematical hierarchy applies, and brackets can be used to force the sequence of operations. The correct use of brackets when using + and - in combination with * and / is essential.



New Drawing

Open Drawing

Load Drawing

Save Drawing

Save Drawing <u>A</u>s Sa<u>v</u>e Settings

Load Symbol File Import ASCII <u>T</u>ext Import <u>B</u>itmap

Export ASCII Text

Repair Drawing File (FD)

Purge Redundant Elements

Print

Zoom Print

Print Setup

Execute <u>M</u>acro Load Title Bloc<u>k</u>

## Section 22 <u>S</u>tart Menu - <u>F</u>ILE

The **FILE** menu accessed from the **Start** button in the **Drawing** window is where you'll find commands relating to the loading, saving, and plotting of drawings. The menu also contains commands for importing and exporting ASCII text, drawing repair, and for loading of custom title blocks.

#### 22.01 <u>New Drawing</u>

**FUNCTION:** The <u>New Drawing</u> function is used to erase the current drawing and start a new drawing.

To select the <u>New Drawing</u> function, press Att S, F, N, or click the File Open icon ( $\square$ ) on the Drawing window tool bar.

If you select <u>New Drawing</u> and you have not saved the drawing that is currently on the screen, a dialog box appears asking you whether you want to save the current drawing.

l	Choice Computing Inc. CADControl						
	Drawing E:\SIGHTSRV\DAKW00DS.DRG has changed. Do you wish to save it?						
	Yes <u>N</u> o Cancel						

To save your drawing, click <u>Yes</u>. To continue loading a new drawing without saving, click <u>No</u>.

The **Drawing** window screen will be cleared and the new drawing will be loaded.

## Section 22

#### **Open Drawing**

FUNCTION: The Open Drawing function is used to load a new *drawing* into the **Drawing** window. The drawing may be a "Sight" Survey or TrueCAD drawing, an AutoCAD drawing (version 10-12, including LT), or a DXF file.

To access the Open Drawing function, press AttS, F, O.

When you select **Open Drawing**, the Windows **Load** dialog box is activated.




The default drawing type, the format "Sight" Survey uses, is CADControl DRG. To choose a different type of drawing file, DWG or DXF, use the Select Files of Type list box at the bottom left of the dialog box. Select the drawing you want, then click OK

#### **Missing Bitmaps**

When you save a drawing containing bitmaps, the bitmaps are not stored with the drawing. Only a reference to them is stored. If you delete or rename a bitmap or move it to another directory, "Sight" Survey will not be able to find the referenced bitmap the next time the drawing is loaded.

22.02





If you have moved the bitmap to another directory, click <u>Browse File Directory</u> >>> in the dialog box to locate the bitmap so "Sight" Survey will be able to find it. Then click <u>Iry Again</u>

If you click **Ignore Reference**, "Sight" Survey loads the drawing without the missing bitmap. If you click **Delete Reference**, "Sight" Survey deletes the reference to the bitmap and loads the drawing.

DWG and DXF Support	"Sight" Survey supports all AutoCAD 10, 11 and 12 DXF and				
	DWG data except Shapes, 3D Faces, X-References or anything in				
	Paper Space. If you bring 3D information into "Sight" Survey, the				
	z coordinates may be dropped.				

To get an AutoCAD 13 or 14 drawing into "Sight" Survey, save it as an AutoCAD 12 file from within AutoCAD 13 or 14.

DXF and DWG colors appearing in "Sight" Survey are controlled by the **DXF/DWG Conversion Settings** dialog box (Att S, S, X page 835).

FontsAutoCAD does not use standard Windows fonts, but "Sight"Survey does. Therefore, you need to convert DXF and DWG fonts<br/>to CADControl equivalents. Fonts are controlled by the DXF/DWG<br/>Conversion Settings dialog box box (Att S, S, X) - page 835).

Pen colors

į	1. If you are using a pen plotter you should use DXF/DWG Conversion Settings to translate DXF and DWG fonts into the equivalent Windows pen plotter fonts. These are Modern, Roman, and Script.		
	2. If the DXF or DWG file you are converting contains an AutoCAD font you don't know the name of, use the UNKNOWNNAME setting in the For DXF Font section of the DXF/DWG Conversion Settings dialog box. Then select the CADControl font you want to convert it to in the Use TrueCAD section.		
	3. If the fonts you want to convert to or from do not appear in the list of fonts in the DXF/DWG Conversion Settings dialog box, you can add more fonts by loading the TRUECAD.INI file into a word processor and adding the required font names to the existing listing.		
Line Types	By default, DXF and DWG line types should appear correctly in "Sight" Survey. However, the way that DXF and DWG line types appear in "Sight" Survey is controlled by the editable <b>LINETYPE.MAC</b> file. See Section 33 - Line Types.		
Part of the drawing is missing	If you have loaded a DXF or a DWG file and part of your drawing seems to be missing, use <b>Start S Settings View Settings</b> (Art <b>S</b> ), <b>S</b> , <b>V</b> - page 799) and change the background color of your drawing. It is possible that the missing portions of the drawing are simply the same color as the background.		
Drawing Origin	Since AutoCAD's origin point (0, 0) is at the bottom left and "Sight" Survey's is at the center of the paper, you may have to use <b>Start </b> $\Rightarrow$ <b>Settings</b> $\Rightarrow$ <b>Re-center Paper</b> (click $\bullet$ or press Alt(S), S), A - page 803) to center your drawing on the paper.		
Scale	AutoCAD usually functions at a scale of 1:1. You may want to change the scale in "Sight" Survey to a more normal setting, for example 1:50, using <u>Start [™]Settings [™]Drawing Settings</u> (Att S, S, D- page 789).		

Section 22

Attributes	AutoCAD attributes are converted to "Sight" Survey as follows. AutoCAD has two types of attribute: <b>Attdef</b> (attribute definition, only found inside blocks) and <b>Attribute</b> (solidified Attdef, produced when you insert a block). An Attdef has three text strings: prompt, tag and default. These are stored in a TrueCAD data item as <b>prompt:tag=default</b> . An Attribute has two text strings: tag and value. These are stored in a TrueCAD data item as <b>tag=value</b> . The TrueCAD data items are converted back to Attdefs and Attributes when you save the drawing as a DWG file.
Dimensions	AutoCAD has two ways of putting text into a dimension: either blank or some text. If the AutoCAD dimension is blank, "Sight" Survey inserts its own text, based on the current dimension settings. If the AutoCAD dimension has text in it, "Sight" Survey copies it exactly.
Slow Loading DXF or DWG	DXF and DWG drawings often contain unreferenced blocks which can slow them down drastically. You can purge these blocks using <b>Start</b> $\Rightarrow$ <b>File</b> $\Rightarrow$ <b>Purge Redundant Elements</b> (Att S, F, G - page 544).

22.03

#### Load Drawing

**FUNCTION:** The <u>Load Drawing</u> function is used to load or merge a new *drawing* into the <u>Drawing</u> window. The drawing may be a "Sight" Survey or TrueCAD drawing, an AutoCAD drawing (version 10-12, including LT), or a DXF file.

To access the <u>Load Drawing</u> function, press <u>Alt</u>  $\mathbb{S}$ ,  $\mathbb{E}$ ,  $\mathbb{L}$ , or rightclick the File Open icon ( $\mathbb{P}$ ) on the Drawing window tool bar.

**Load Drawing** operates in the same manner as **Open Drawing** (ArtS, F,  $\Box$  - page 510) except that the new drawing is merged into the existing drawing.

When loading a DWG or DXF file into an existing drawing, the new drawing is positioned on the existing drawing according to its

coordinates, for example a point at coordinate 1000, 2000 on the new drawing will be placed at coordinate 1000, 2000 on the existing drawing. This also occurs when loading a "Sight" Survey or TrueCAD drawing into an existing drawing while working in the **Surveyor** coordinate system.

If you are using the **Cartesian** coordinate system when loading a "Sight" Survey or TrueCAD drawing, "Sight" Survey prompts:

#### Enter new reference point position

Position the cursor at that position in the existing drawing where you want the new drawing to be loaded and click the mouse, or press  $\boxed{-Enter}$ . The origin point (0, 0) of the new drawing will be placed at the specified point and will assume the coordinates of the existing drawing. "Sight" Survey prompts:

Drawing s	cale and rotation		×
1200 0			
	ОК	Cancel	

Type a scale and rotation for the drawing you are loading, separated by a space, and click  $\Box K$ . For example, if you type **1200 0**, the new drawing will be loaded at 1" = 1200" (or 100') with no rotation.



When scaling a drawing, the number you enter is a multiplier. For example, a scale entry of 1 will load the drawing at the same size as it was created. An entry of 2, doubles the size of the drawing, etc.

If your drawing contains bitmaps you may be required to enter additional information, such as the path to the bitmap, etc. See **Missing Bitmaps** on page 510 for more information.

#### Save Drawing

**FUNCTION:** The <u>Save Drawing</u> function is used to save a *drawing*. The drawing will be saved as a CADControl or TrueCAD drawing, "Sight" Survey's native drawing format.

To access the <u>Save Drawing</u> function, press AHS, F, S., or click the <u>Save Drawing</u> icon (F) on the <u>Drawing</u> window tool bar.

If the drawing has been previously saved, selecting <u>Save Drawing</u> will use the drawing's existing filename.

If the drawing has not been previously saved, <u>Save Drawing</u> will function like the <u>Save Drawing As</u> command as described in the next section.

#### 22.05

#### Save Drawing As

**FUNCTION:** The **Save Drawing** <u>As</u> function is used to save a *drawing* under a new filename, or as an AutoCAD drawing (version 10-12, including LT) or DXF file.

To access the Save Drawing As function, press Att S, F, A., or right-click the Save Drawing icon ( $\Box$ ) on the Drawing window tool bar.

If the drawing has been previously saved, selecting <u>Save Drawing</u> will use the drawing's existing filename.

If the drawing has not been previously saved, <u>Save Drawing</u> will function like the <u>Save Drawing As</u> command as described in the next section.

Under most conditions, you should save drawings as CADControl (TrueCAD) DRG files. This is "Sight" Survey's native format. To transfer a drawing to AutoCAD, save your drawing as a DWG file. To transfer a drawing to any other CAD program, save your drawing as a DXF file.

## Section 22



DXF is a standard AutoCAD file format. "Sight" Survey's DXF is designed to read and write this standard. Compatibility between "Sight" Survey and other CAD programs depends on whether those programs can read and write standard DXF files correctly.

#### **DWG and DXF Conversion**

If you are saving a drawing as a DWG or DXF file, you can select which version of AutoCAD the DWG or DXF file should be compatible with: 10, 11 or 12. Use the **To DXF/DWG Conversion Settings** dialog box (ARS), S), X) - page 835) to make this selection. This dialog box also controls the appearance of colors and fonts in AutoCAD or DXF files. Line type is controlled by the LINETYPE.MAC file. See Section 33 - Line Types.

#### Save Drawing As

When you select **Save Drawing <u>As</u>**, the Windows **Save** dialog box appears.

Save As		? ×
File <u>n</u> ame: c:\sightsrv\oakwoods.zak cox.zak oakwoods.zak	Eolders: c:\sightsrv c:\ sightsrv program utility	OK Cancel
Save files of <u>type:</u> "Sight" Survey Files 💌	Drives:	

Choose the type of file you want to save (**DRG**, **DWG** or **DXF**) and specify the drive and directory for the file location. Type a filename (without and extension) and click **OK**.

If the file already exists...

If a drawing with the file name you have chosen already exists, you will be warned. You may then choose to proceed or cancel the save operation.



Section 22

Click Yes to continue the operation. Click No or press Finer to cancel the save operation.

If you are saving an AutoCAD DWG file or a DXF file, "Sight" Saving an AutoCAD file Survey prompts: Write everything? (else just selected) Click Yes to save the whole drawing as a DWG or DXF file. To save only those items on the drawing that have been selected, click No **DWG and DXF Conversion** If you are saving a drawing as a DWG or DXF file, you can select which version of AutoCAD the DWG or DXF file should be compatible with: 10, 11 or 12. Use the To DXF/DWG Conversion Settings dialog box (AltS, S, X - page 835) to make this selection. This dialog box also controls the appearance of colors and fonts in AutoCAD or DXF files. Line type is controlled by the LINETYPE.MAC file. (See page 877.) Fonts "Sight" Survey uses standard Windows fonts, AutoCAD does not. You'll need to convert "Sight" Survey 's fonts to AutoCAD equivalents. Use the To DXF/DWG Conversion Settings dialog box (AltS, S,  $\times$  - page 835) to make this selection. If the fonts you want to convert to or from do not appear in the and list of fonts in DXF/DWG Conversion Settings, you can add further fonts by loading the **TRUECAD**. INI file into a word processor and adding the required font names to the existing listing.

Bitmaps	Older versions of AutoCAD do not support bitmaps. If your drawing contains bitmaps, AutoCAD may crash when the DXF or DWG file is loaded into it.		
3	When you save a drawing that contains a bitmap, <b>the bitmap is</b> <b>not stored in the drawing</b> . Only a reference to the bitmap is stored. It is therefore important that you do not delete the <b>bitmap</b> . If you delete the bitmap or move it to another directory, an error message will appear next time you try to load any drawings containing the bitmap.		
Scales	If you have layers at different magnifications on your drawing, AutoCAD may crash when the DXF or DWG file is loaded into it.		
Backup Copies	When you save a "Sight" Survey drawing, a backup copy of the drawing (with a <b>.BAK</b> extension ) is automatically created in the same directory that the drawing is saved in.		
The Drawing <u>O</u> ffice Manager	If the Use Drawing Office Manager box is checked in the Save Settings (AttS, F, $\bigtriangledown$ - page 523), the Drawing Office Manager file will be updated each time you save.		
	The <b>Drawing Office Manager</b> ( <b>DOM</b> for short) allows you to keep track of each drawing: its description; the name of the draftsperson drawing it; the department it is being drawn in; the paper size, scale and units used; the number of hours spent on it; the date it was last updated; the date it was last plotted; etc. (See table for full details of information stored).		
	All this information is stored in an ASCII file called <b>DOM.TXT</b> every time you save your drawing. <b>DOM.TXT</b> resides in your <b>SightSrv</b> directory and is updated each time you save a drawing. It can be loaded into any database that reads a comma delimited ASCII file, and can also be edited in any text editor such as Windows Notepad or the DOS Editor.		

Each record in the file refers to a particular drawing and is stored on a single line, with fields separated by commas. It looks something like this (but all on one line):

"SAMPLE","\SIGHTSRV\JOBS\","C:","MFLOAN", "SAMPLE SUBDIVISION","","A1",100,1000.0, "SOUTH", 2538.093,17971.396,"","200", 19880929,19880929,,,"","","","","","","","EKKE", , 0.12,,,,,,,0.033,,,,

All fields included in the **DOM** are listed below, together with:

- The type of field (Type): Text (C); Numbers (N); Date (D).
- The number of characters allocated to the field (Len.).
- The number of decimals allocated to the field (Dec.).
- Whether the field is automatically filled in by CADControl. Fields that are automatically filled in by CADControl are marked with a *. You can fill in the non-automatic fields yourself using any text editor, provided that each field is separated by commas and that text character fields are enclosed in double quotes.

Field Name	Туре	Len.	Dec.	Auto	Comments
FILE_NAME	С	8	0	*	Drawing name.
DIRECTORY	С	40	0	*	Directory drawing is stored in, for $example \langle Ally \rangle$ .
DRIVE	C	4	0	*	Drive directory is on, for example C:.
DISK_VOL	С	12	0	*	Disk volume label.
DESCRIPTN	С	40	0	*	Drawing description entered automatically from TrueCAD, for example CONCRETE RESERVOIR.
MORE_DESCR	С	40	0		You can type extra descriptive information into this field if you wish.
PAPER_SIZE	С	4	0	*	Paper size, for example A1.
SCALE	Ν	8	1	*	Scale, for example 100. This would mean that the scale was 1:100.

Field Name	Туре	Len.	Dec.	Auto	Comments
UNITS	N	9	2	*	Units, represented in mm. If the drawing units are mm, this figure is 1; if they are inches, this figure is 25.4; if they are meters, this figure is 1000 etc.
COORD_SYS	С	10	0	*	Coordinate system. SOUTH for Southern Hemisphere; NORTH for Northern Hemisphere.
DRG_ORIG_Y	Ν	12	3	*	Y coordinate of drawing origin.
DRG_ORIG_X	Ν	12	3	*	X coordinate of drawing origin. If you are using Cartesian coordinates, this is 0. If you are using Surveyor coordinates it is the Surveyor Origin you enter into the Drawing Settings dialog box in the Settings Menu.
DEPARTMENT	С	10	0	*	Department responsible for the drawing.
CHOI_VERSN	С	6	0	*	Version of TrueCAD used.
DATE_START	D	8	0	*	Date the drawing was started.
LASTUPDATE	D	8	0	*	Date the drawing was last updated.
LASTPLOT	D	8	0	*	Date the drawing was last plotted.
DATE_DUE	D	8	0		Date the drawing is due to be finished.
CUSTOMER	С	20	0		Customer.
JOB_NO	С	20	0		Job Number.
CATEGORY	С	10	0		Drawing category.
DRAWING_NO	С	15	0		Drawing number.
DRG_NO_B	С	15	0		Another drawing number.
STATUS	С	5	0		Drawing Status
DRAUGHTSM1	С	10	0		Another Draughtsman
COST_HOUR	Ν	7	2		Cost charged per hour of drawing.
TOT_TIME	Ν	7	2	*	Total time spent on drawing in decimal hours, for example 0.5 is half an hour.
JAN	Ν	6	2	*	Time spent on drawing per month.
FEB	Ν	6	2	*	
MAR	Ν	6	2	*	
APR	Ν	6	2	*	
MAY	Ν	6	2	*	
JUN	Ν	6	2	*	

Field Name	Туре	Len.	Dec.	Auto	Comments
JUL	Ν	6	2	*	
AUG	Ν	6	2	*	
SEP	Ν	6	2	*	
OCT	Ν	6	2	*	
NOV	Ν	6	2	*	
DEC	Ν	6	2	*	

#### **Drawing Description**

This screen only appears if you have checked Use Drawing Office Manager in Save Settings. It only appears the *first time* you save a drawing.

Drawing Descrip	tion	×
<u>D</u> escription	Sample Drawing	×
Dr <u>a</u> ftsperson	M.Floan	
Department		
Date Started	19980521 Last Plotted	
	<u>E</u> ntity Statistics	
	Block Statistics	
	OK Cancel	

The information that you type into the box will be added to the **Drawing Office Manager** (see page 518), allowing you to keep track of the number of hours you work on the drawing, the date you last plotted it etc.

You can type a **Description**, and the name and **Department** of the **Draftperson**.

The date the drawing was started is automatically entered into the **Date Started** box in the order year, month, day. It cannot be edited.

In the example shown, the drawing was started in 1998 (1998), in May (05), on the twenty-first (21).

Similarly, you cannot edit the Last Plotted box. This box will automatically be updated with the date each time you plot.

#### **Entity Statistics**

This button displays the number of primitives, objects and layers on your drawing. It also shows the number of blocks (including unreferenced blocks) and the number of block inserts. Blocks and block inserts are only relevant to drawings that have been imported from AutoCAD.

Statisti 7	cs Objects	13	Layers	0	Blocks
5	Lines	0	Arcs	0	Polylines
3	Text	0	Dims	0	Inserts
0	Arrows	0	Bitmaps		
1	Points	0	Data		
		[			

**Block Statistics** 

This button is only relevant to drawings that have been imported from AutoCAD. It displays statistics about AutoCAD blocks hidden within the drawing structure. The numbers of different primitives shown are not the numbers of primitives on the drawing but the number of primitives contained within the AutoCAD blocks, some or all of which may be unreferenced. The insert figure shows the number of blocks inserts. The reason why there may seem to be a lot of CAD objects among the blocks is that CADControl automatically gives each block an object name.

Block S	tatistics				×
Statisti					
0	Objects	13	Layers	0	Blocks
0	Lines	0	Arcs	0	Polylines
0	Text	0	Dims	0	Inserts
0	Arrows	0	Bitmaps		
0	Points	0	Data		
			ОК		

## Section 22

If you use **Start** [™] **File** [™] **Purge Redundant Elements** (Att S), **F**, **G** - page 544) the number of blocks shown will probably decrease dramatically, as will the file size of your drawing. If you use **Start** [™] **Objects** [™] **Explode Objects** (Att S), **O**, **Esc** - page 770) to explode all the block inserts on the drawing, all the blocks will become unreferenced and can be removed using **Purge Redundant Elements**.

#### 22.06

#### Save Settings

**FUNCTION:** The **Save Settings** function is used to set drawing save parameters and autobackup intervals for drawings.

To access the Save Settings function, press Atts, F, V.

Save Settings				
AutoBackup Options				
✓ Backup drawing every 15 minutes				
✓ Ask User Before Backing Up				
Backup Path C:\Temp				
Save Options				
✓ Get Drawing <u>R</u> eference point				
✓ Save <u>G</u> eometry with each drawing				
✓ Use Drawing Office Manager				
OK Cancel				

From this screen you can select **AutoBackup Options** and other save options. To select or deselect an option, simply click the mouse on the check box associated with the option.



Autobackup is only used for saving your drawing. "Sight" Survey actively saves your data as you work, so a data backup is not needed.

Backup drawing every ? minutes

This selection tells "Sight" Survey how often to automatically backup your drawing. To use this option, click the selection box first. Then press and type in the autobackup interval in minutes.


3

When you save a drawing that contains a bitmap, the bitmap is not stored in the drawing. Only a reference to the bitmap is stored. It is therefore important that you do not delete the bitmap. If you delete the bitmap or move it to another directory, an error message will appear next time you try to load any drawings containing the bitmap.

"Sight" Survey will store the drawing in the file **ABACKUP1.DRG**. At the same time, it will copy the old **ABACKUP1.DRG** into a file called **ABACKUP2.DRG**. This means you will always have two backups of your work: an older backup called **ABACKUP2.DRG** and a newer backup called **ABACKUP1.DRG**.

<u>Ask User Before Backing Up</u> This selection tells "Sight" Survey to ask permission before each automatic backup. If you check the <u>Ask User Before Backing Up</u> box, "Sight" Survey will warn you when it is about to backup. When the warning appears, click <u>OK</u> to backup, or on <u>Cancel</u> to abort the backup.

Section 22



Backup <u>P</u> ath	This selection tells "Sight" Survey where to save the backup files <b>ABACKUP1</b> and <b>ABACKUP2</b> . Type in a drive and directory such as <b>C:\Temp</b> or <b>C:\SightSrv\Backups</b> . Note there is <b>no</b> <b>backslash</b> at the end of the path. The directory must exist whenever an autobackup takes place or an <b>Invalid Backup Path</b> error message will result.
Get Drawing <u>R</u> eference point	This selection is a TrueCAD setting and is not used by "Sight" Survey. <i>This item should be selected</i> .
Save <u>G</u> eometry with each drawing	This selection is a TrueCAD setting and is not used by "Sight" Survey. <i>This item should be selected</i> .

22.07	Load Symbol File
	<b>FUNCTION:</b> The Load Symbol File function is used to load a new symbol file for use in the Drawing window.
	To access the Load Symbol File function, press Atts, F, Y.
	Symbol construction is covered in Section 29.06, Make Symbol, on page 774.

Before any symbol may be used, the library file containing the symbol must be loaded. A symbol file is simply a drawing containing symbols (objects) that may be used repeatedly.

When you select **Load Symbol File**, a standard Windows **Load** dialog box appears.

Select new symbol file		? ×
File name: symbol.drg compass.drg scale.drg startup.drg symbol.drg	Folders: c:\sightsrv\program c:\ c:\ c:\ c:\ c: c:\ c: c:\ c: c: c: c: c: c: c: c: c: c:	OK Cancel N <u>e</u> twork
List files of type: Drawing Files	Dri <u>v</u> es:	

Select the symbol file you need and click **OK**.

You must specify if the symbols should be loaded at their absolute size, or to scale.

Do you want symbols to be absolute (else to scale)

In almost every case the drawings you will be working on will be drawn to scale. The symbols furnished with "Sight" Survey are drawn at actual size and are meant to be drawn to scale, not to their absolute size. If you create your own symbols library, you should create your symbols in the same manner. To load symbols to be plotted to scale, click <u>No</u>.

**Symbol Attributes** 

One more question remains before you can use your symbols. "Sight" Survey prompts:

Convert Attributes to text during load?

If you click  $\underline{Yes}$ , any attributes attached to the symbols you want to insert will be written as text next to the symbols. If you click  $\underline{No}$ , attributes will remain invisible.

Symbol Scaling

#### Import ASCII Text

**FUNCTION:** The **Import ASCII Text** routine is used to import any ASCII text file into "Sight" Survey's **Drawing** window. The imported text file becomes an actual part of the "Sight" Survey drawing.

To access the Import ASCII <u>Text</u> function, press AltS, F, T.

You can also import text by pasting it in from another Windows application using the <u>Paste</u> function in the <u>Start</u> **⇒Edit Menu** (AttS, E, P - page 550).

Ę

The appearance of the imported text is determined by the settings in the <u>Set</u> Text Defaults dialog box in the <u>Start</u> ⇒ <u>Settings Menu</u> (right-click A or press Att S, S, E - page 820).

**Import ASCII** <u>Text</u> begins with a standard Windows Load dialog. Select the ASCII file you want to import, then click <u>OK</u>. "Sight" Survey prompts:

#### Enter position textblock should start

Position the cursor on the drawing at the position where the text should appear and click or press *end*. The ASCII file will be imported and the text will appear.

Where the text will appear in relation to the cursor position you specify depends on where you have set the position of the text label origin. See <u>Start ⇒ Settings</u> ⇒ Set Text Defaults (Att S, S, E) - page 820).

## Section 22

22.09

#### Import Bitmap

**FUNCTION:** The **Import Bitmap** routine is used to import a bitmap (**BMP**) file into "Sight" Survey's **Drawing** window. This powerful feature can be used to insert aerial photos, area maps, pictures, etc. into your drawing.

To use the **Import Bitmap** function, press AHS, F, B. The **Open** dialog box will appear, titled as **Select file to load**. Following the usual methods for opening a file, select the bitmap file you wish to import and click **OK** or **Open**. "Sight" Survey will display the **Set Bitmap parameters** box.

Set Bitmap param	eters 🛛 🗙		
Real World Pixel	Size (in current units)		
Width: 1	Height: 1		
Placeholder for bitmap			
<u>R</u> esample Mode	Preserve Black		
ОК	Cancel		

#### **Real World Pixel Size**

Each bitmap is made up of small squares or **pixels**. You need to type the width and height that each pixel should be into the dialog box. Width and height are measured in the units you have set up in <u>Start  $\Rightarrow$  <u>Settings</u>  $\Rightarrow$  <u>Drawing</u> Settings (Att S), S, D - page 789).</u>

For example, if you have scanned in a map that represents an area measuring  $1200' \times 1200'$  on the ground, and in its bitmap form this map measures 600 x 600 pixels, then the real world pixel size is 2' in both width and height.

If you need to change the **Real World Pixel Size** of a bitmap once you have loaded it into your drawing, double click on the bitmap. This brings up the **Set Bitmap Parameters** dialog box again, which can then be edited.

# Placeholder for BitmapIf you check the Placeholder for Bitmap box, the bitmap will not<br/>appear on the screen and on your printouts, but instead will be<br/>marked with a placeholder. The placeholder appears as a purple<br/>cross-hatched rectangle with the name of the bitmap written across<br/>it. Displaying bitmaps as placeholders speeds up redraws.

If the <u>Placeholder for Bitmap</u> box is unchecked, the bitmap will be displayed in full detail.

You can change a bitmap from a placeholder to full detail or vice versa at any stage after loading by double clicking on it, which brings up the **Set Bitmap Parameters** dialog box for editing. You can also view all the bitmaps on your drawing as placeholders, or all of them in full detail. See <u>Start  $\Rightarrow$  Settings</u>  $\Rightarrow$  <u>View Settings</u> (<u>Att</u>S, (S), (V) - page 799).

#### Resample Mode

The resample mode dictates how your bitmap will be displayed on the screen when you demagnify the screen or scale the bitmap to make it smaller.

*The* **<u>Resample Mode</u>** *option affects the way your bitmap appears on the screen, but does not affect the way it is printed.* 

**Preserve Black** - "Sight" Survey will display fewer pixels than previously. Black pixels will be displayed at the expense of other pixels.

**Preserve White** - "Sight" Survey will display fewer pixels than previously. White pixels will be displayed at the expense of other pixels.

**Thin Pixels** - All the pixels in your bitmap will be displayed, but they will be smaller than previously.

The default setting, **Preserve Black**, seems to work best for most images. However, for scanned maps and photographs you might want to try the **Thin Pixels** setting. Experiment with the settings to see how they affect your bitmaps as you zoom in and out.

To change the **<u>Resample Mode</u>** after loading the bitmap, double click on the bitmap. This will bring up the **Set Bitmap Parameters** dialog box so you can edit it.

When you have finished setting the parameters, click **OK**. "Sight" Survey prompts:

#### Select position for upper-left corner of bitmap

Use your mouse to position the **Freehand Cursor**  $(\uparrow \uparrow \uparrow \uparrow)$  at the desired insertion point and click your mouse to insert the bitmap.

Once you have loaded the bitmap, you can select and drag it, move it, stretch it, scale it, copy it, rub it out etc. However, you cannot edit the pixels within it. You can print bitmaps, but you cannot plot them (unless your plotter is an inkjet type, raster-image plotter).



1. The number of pixels across the bitmap must be a multiple of 8, otherwise the bitmap may fail to load.

 If you need to move the bitmap so it is behind other elements on the drawing, use <u>Start</u> ⇒ <u>Edit</u> ⇒ Move to <u>Back</u> (ARS, E, B - page 570).

3

When you save a drawing that contains a bitmap, the bitmap is not stored in the drawing. Only a reference to the bitmap is stored. It is therefore important that you do not delete the bitmap. If you delete the bitmap or move it to another directory, an error message will appear next time you try to load any drawings containing the bitmap.

22.10

#### Export ASCII Text

**FUNCTION:** The **Export ASCII Text** function is used to export text from a *drawing* into an ASCII text file.

To access the Export ASCII Text function, press Alt S, F, etc.

$\boldsymbol{\times}$	You can also export text by using the <b>Copy</b> (AttS, E, C - page 549) or Cut (AttS, E, $\square$ - page 548) functions in the <b>Start Sedit Menu</b> to copy text onto the Windows Clipboard, from where it can be pasted into other Windows applications.
	When you <b>Export ASCII Text</b> , a standard Windows <b>Save</b> dialog box appears. Type a name for your ASCII file, then click $\Box \kappa$ . "Sight" Survey prompts:
	Enclose text that should go to file
	Draw a polygon around the text you want to export into the ASCII file. Once you have enclosed the text, "Sight" Survey will write the ASCII file.
<b>i</b>	<ol> <li>If you have enclosed several pieces of text in the polygon, the order in which these will appear in the ASCII file is dependent on their position in the drawing. The topmost text item will be transferred to the file first, followed by the second-topmost item, etc.</li> <li>If text is not horizontal it will not transfer properly.</li> <li>If the text is part of an object or group, such as text that has been imported, the entire group must be contained within the selection polygon or none of the text will be included.</li> </ol>

22.11

#### Print

**FUNCTION:** The **Print** function is used to print or plot a *drawing*.

To access the  $\underline{Print}$  function, press  $\underline{Att}$ ,  $\underline{F}$ ,  $\underline{P}$ .



For information on how to install printers and on how to select the default printer, see the documentation that came with your copy of Windows.

## Section 22

3

and

If you are outputting to a plotter, you should use one of the plotter fonts, **Modern**, **Roman** or **Script** for your text and dimensions. If you use any other font on your drawing it will be converted for the plotter but all your text will be plotted horizontally, regardless of its orientation on the drawing.

You can output bitmaps to printers and ink-jet plotters, but not to pen plotters.

When you select **Print**, the **Print** dialog box appears.

Print	? ×
Printer: HP DraftMaster II on LPT1:	ОК
Print range	Cancel
• All	<u>S</u> etup
C Selection	
C Pages	
Erom: Lo:	
Print guality: 203 dpi	<u>C</u> opies: 1
	🗹 Collate cop <u>i</u> es



The appearance of the **Print** dialog box may vary depending upon the version of Windows you are running.

Edit the dialog box settings if necessary, then click **OK**. The **Printer Defaults** dialog box appears.

Printer Defaults	×	
Printer Profile PRINT		
Delete Save New		
X offset (mm) 0 Y offset (mm) 0		
Minimum Pen 1 Maximum Pen 1	j j	
$\bullet$ Use <u>Plotter Arcs</u> $\diamond$ Make arcs from <u>Lin</u>	es	
Zoom Print Scale Hatch Scale Fat lines		
All Colors to <u>B</u> lack Pen <u>Mappings</u>		
OK Cancel Help		

X and Y Offset
 The X and Y Offset boxes allow you to offset the drawing on the paper. The offset is measured in mm. The X offset displaces the drawing to the right if a positive value is input, and to the left if a negative value is input. The Y offset displaces the drawing downwards if a positive value is input and upwards if a negative value is input.
 Minimum and Maximum Pen
 The Minimum and Maximum Pen boxes allow you to specify the

The **Minimum and Maximum Pen** boxes allow you to specify the range of colors that will be used when you are outputting to a plotter. The minimum pen is 1 and the maximum pen is 15.

If you are using a plotter with less than 15 pens, for example if your plotter has six pens, but you have used more than the first six colors in the **Pen Selection Area** (red, olive, yellow, lime, green and teal counting downwards from the top), you should specify minimum and maximum pens 1 and 15. If you do not, the parts of your drawing drawn with other colors will not be plotted.



These options are disabled if you are using a printer.

Use Plotter Arcs / Make Arcs from Lines	If the <b>Use Plotter Arcs</b> option is checked, "Sight" Survey will plot arcs created by your plotter driver. If the <b>Make Arcs from Lines</b> option is checked, "Sight" Survey will plot arcs made out of very small lines.
	If no arcs appear when you try to plot, or if arcs are plotted incor- rectly, use the <b>Make Arcs from Lines</b> option.
Zoom Print - Scale <u>H</u> atch Scale <u>F</u> at Lines	Selecting either the Scale Hatch or Scale Fat Lines options under the Zoom Print heading tells "Sight" Survey to scale line weight and/or hatch patterns accordingly when you change the scale on your drawing. <i>These boxes may be grayed out if they are not</i> <i>applicable to your setup.</i>
All Colors to Black	If your printer prints colors as different shades of grey, meaning that some colors are printed very faintly, check this option. All colors will then be printed as black.
Pen Mappings	This function allows you to use a printer such as an inkjet or laser printer as though it was a pen plotter. It does this by letting you map each color on the screen to a different line width on the printer. For example you could make red lines print at 0.3 mm, green lines print at 0.7 mm etc.
	When you click on the <b>Pen Mappings</b> button, the <b>Pen Width Mappings</b> dialog box appears.

Pen Width Mappings		
<u>P</u> en Number	Generated: Wi	dth Color
0	0	
1	0	
2	0	
3	0	
4	0	
5	0	
2 3 4 5 6 7	0	
7	0	
89	0	
9	0	•
<u>E</u> dit Pen 0	0	Color
ОК		Cancel

The pens are listed on the left hand side of the box and are numbered from 0 to 15. Zero (0) is the top color in the **Pen Selection Area** at the right of the screen and 15 is the bottom color. Click on a pen to which you want to assign a width. The pen's number appears in the **Edit** part of the dialog box. Type a width (measured in mm) into the white part of the dialog box.

Now click on another pen to which you want to assign a width. The width associated with the first pen you edited appears next to that pen's number in the dialog box, and the second pen's number appears in the **Edit** area. Assign a width to the second pen and repeat until you have assigned a width to each pen. Click OK.

Pen mappings only affect those lines with a width of 0. For example, if you map the red pen to print at 0.3 mm, and there is a red line on the drawing that you have given a width of 0.7 mm using the Line Defaults dialog box, then that red line will print at 0.7 mm even though you have mapped the red pen to print at 0.3 mm.

This function is very useful for thickening dimension witness lines (see page 826) which often print very faintly on modern high resolution inkjet printers. To thicken witness lines, set aside one color and draw all your witness lines in that color. Then map that color to the desired thickness.



Busy printing	When you click $\Box \kappa$ , the message <b>Busy printing</b> appears while your drawing is printed or plotted.
Change Pens in Plotter	If you specified a maximum pen greater than the number of pens your plotter driver provides for, you will get the message <b>Change</b> <b>Pens in Plotter</b> . Simply click on <b>OK</b> after changing them.

22.12

#### Zoom Print

**FUNCTION:** The **Zoom Print** function is used to print a selected part of your drawing at a selected scale.

Section 22

To access the  $\underline{\text{Zoom Print}}$  function, press  $\underline{\text{AHS}}$ ,  $\underline{\text{F}}$ ,  $\underline{\text{Z}}$ . The Print dialog box appears.

? ×
OK
Cancel
<u>S</u> etup
<u>C</u> opies: 1
🗹 Collate copies



The appearance of the **Print** dialog box may vary depending upon the version of Windows you are running.

Edit the dialog box settings if necessary, then click **OK**. The **Printer Defaults** dialog box appears.

"Sight" Survey now checks the paper size and orientation of your output device. This may be different from the paper size and orientation of your drawing. For example, you may be doing a rough print of all or part of an A1 drawing on an A4 printer, prior to producing a final plot. A pink dotted rectangle representing the paper size and orientation of your output device appears on the screen. "Sight" Survey prompts:

#### Plot to Fit? (else at exact scale)

If you click Yes, "Sight" Survey will read the paper size and orientation of your printer or plotter and will print your drawing so that it fits onto the paper exactly. You'll be given an opportunity to enter a border width, after which you should press Fine. Continue at the prompt "Satisfied with zoom?" on the next page.

If you click <u>No</u>, you can specify the exact scale at which your drawing will be printed.

Enter scale to plot at	>
1200	
ОК	Cancel

The default scale that appears is the scale specified in the **Config** CAD **Configuration Menu** as discussed on page 392. Accept the default scale by clicking OK, or by pressing Enter. To enter a new scale, type the value and click OK, or press Enter. "Sight" Survey prompts:

#### Enter center of zoom box

A gray box, the **zoom box**, appears. This box represents the area of your drawing that will be printed or plotted, given the paper size and orientation, and the scale you entered. As you move your mouse, so moves the box around your drawing.

Position the zoom box around the drawing or part of the drawing you want to print or plot and press *etenter* or click your mouse. "Sight" Survey prompts:


#### Would you like to rotate plot?

If you would like to rotate the plot, for example because your paper is oriented one way and your drawing the other, click <u>Yes</u>. "Sight" Survey prompts:

#### Enter angle from keyboard?

If you would like to enter an exact angle of rotation from the keyboard, click <u>Yes</u>. If you would like to rotate the drawing around using the cursor, click <u>No</u>.

If you elected to enter an exact angle of rotation from the keyboard, "Sight" Survey prompts:



Type the angle you want to rotate your drawing by, then click **OK** or press **Ener**. The message: **Standby while transforming plot** appears. Click **OK**. The drawing is rotated by the specified angle, which is measured in a counter-clockwise direction. Skip the next prompt.

If you elected to rotate the drawing using the cursor, "Sight" Survey prompts:

#### Drag till rotate satisfactory

Move your cursor. The zoom box rotates around the part of the drawing you want to plot or print. Once the zoom box fits nicely around the part of the drawing you want to plot or print, click  $\Box K$  or press  $\blacksquare Enter.$  The message Standby while transforming plot appears. Click  $\Box K$ . The drawing is rotated so that it fits onto the paper as specified. After the rotation prompts, "Sight" Survey continues with:

#### Satisfied with zoom?

## Section 22

The part of your drawing that will be printed or plotted appears on the screen enclosed by dashed lines indicating the edges of the paper. If you are satisfied with what is to be printed or plotted, click Yes. If you are not satisfied, click <u>No</u> button. "Sight" Survey prompts:

#### Enter new center of zoom box

Move the zoom box to a new position and press *end* or click your mouse. You will again be asked:

#### Satisfied with zoom?

Continue until you are satisfied with the plot, or abort **Plot Drawing Fit to Page** by pressing the **Space Bar**.

After you are satisfied with the orientation of the drawing, "Sight" Survey prompts:

#### Enter point for compass insertion (space bar for no compass)

Press the Space Bar if you do not want a North arrow on your drawing. If you want a North arrow, position your cursor at the chosen location and press *Letter* or click your mouse.

When you respond to the compass insertion prompt, "Sight" Survey will respond with the **Printer Defaults** dialog box. Continue with the instructions for the **Printer Defaults** dialog box found on page 533.



If you have rotated your print/plot, the message **Transforming** plot back again will appear. Click OK. Your drawing will return to the orientation it was at prior to rotation.

## Section 22

### 22.13

#### Print Setup

**FUNCTION:** The **Print Setup** function is used to change the output device, settings, or orientation.

To access the **Print Setup** function, press **Att S**, **F**, **R**.

When you select **Print Setup**, a standard Windows **Print Setup** dialog box appears.

Print Setup		? ×
Printer		OK
Default printer		Cancel
(currently AccelaWriter 8	100 on LPT1:)	
O Specific printer:		Options
AccelaWriter 8100 on L	PT1:	
Orientation	Paper	
• Portrait	Size: Letter 8 1/2 x 11 in	
A <u>L</u> andscape	Source: AutoSelect Tray	

્

The appearance of the **Print Setup** dialog box may vary depending upon the version of Windows you are running.

3

Windows 3.1 Users

The Paper Size indicated here must be set to match the Paper Size in the CAD Configuration Menu. Otherwise, your drawing may not plot correctly.

In order to set up your output device fully in Windows 3.1 you may have to go to **Printers** in the **Control Panel**. Click on your printer or plotter in the list of installed printers that appears. Then click on the <u>Setup...</u> button.

Windows 95 or 98 UsersIn order to set up your output device fully in Windows 95 or 98<br/>you may have to go to Start, then Settings, then Printers. Click<br/>on the icon corresponding to the device. Select Properties from<br/>the Printers File Menu.

#### Repair Drawing File

**FUNCTION:** The **Repair Drawing** <u>File</u> function is used to rebuild and repair a drawing file which has somehow become corrupted, or which is an older file format than the one currently used by "Sight" Survey. It attempts to clean up the drawings by writing them out to disk as a temporary CAD macro (.MAC) file, and then reloading the macro into the **Drawing** window.

To access the Repair Drawing File function, press AltS, F, F.



This routine may also be accessed by using the two-letter command FD, for Fix Drawing.

If for some reason you have a drawing that has become corrupted, the **Repair Drawing File** function may be able to recover your drawing.

Examples of corrupted drawings are those on which you get messages like FP Error, Application Error, This Program has performed an Illegal Operation, Object too long, Object extends off the edge of the world, MainCAD caused a General Protection Fault etc., or drawings that simply won't load at all. Sometimes "Sight" Survey will warn you that it has detected a corrupted drawing and will tell you to run the Repair Drawing <u>File</u> function.

Before you run **Repair Drawing File**, try save the drawing under a different name from the name it was previously saved under.

**Repair Drawing File** must be run from a clean drawing screen. Press AttS, F, N to select Start  $\Rightarrow$  File  $\Rightarrow$  New Drawing. Then press AttS, F, F to access the Start  $\Rightarrow$  File  $\Rightarrow$  Repair Drawing File function.

A dialog box headed **Select drawing to repair** appears. This is a standard Windows Load dialog box. If you do not know how to use a Windows Load dialog box, see the documentation that came with your copy of Windows.

The **Open** dialog box will appear to allow you to enter the name of the drawing file that you wish to repair and click OK (or OF), or simply double-click on the filename. If the repair function was completed successfully, the prompt bar at the top of the **Drawing** window will display:

#### Repair Successful! Delete temp Macro file?

Click  $\underline{Yes}$  to delete the temporary macro file which was created by the **Repair Drawing File** routine. If you wish to save the macro file, click  $\underline{No}$ .

If the drawing on your screen looks correct, which it should, you will want to save it. However, you will need to decide if you want to overwrite the original drawing file, or if you want to give the file a new name. Each method has its own unique caveat, as you will see within the next few paragraphs.

After repairing the drawing, "Sight" Survey will automatically prompt you to save the repaired drawing file. Type in a name for the file including the **.DRG** filename extension, and press e or click **OK** (or **Save**). If you enter the same name as the original drawing file, you will be prompted:



If you really wish to overwrite the existing drawing file, press  $\mathbb{N}$ , otherwise press  $\mathbb{N}$  and enter a different name for the drawing.

*If you save the drawing over the top of the original drawing by giving it the same name, you lose the original drawing.* Caveat: If you later find that something is missing from the repaired drawing, you will have to re-create that part of the drawing.

If you save the drawing as a new drawing file by giving it a different name than the original drawing, you will preserve the original drawing file intact. *Caveat:* The drawing that is associated with the COGO job file, is the original drawing file because it has the same main filename as the COGO file. You will need to work around this by renaming the original file to something else (but **DO NOT** give it a **.BAK** extension, as this extension is used internally), and then renaming the repaired drawing file to the original filename. This is really not as confusing as it may sound, and the **Windows 3.1 File Manager** or the **Windows 95/98 Explorer** will allow you to rename the files.

If you are not familiar with the **File Manager** or **Explorer** programs, please refer to your Windows documentation or online help for additional information.

There is another way to repair drawing files, but you should be very careful if you use it. The method is to simply load the COGO job file for the drawing you wish to repair, erase the drawing part of it (using the DX command), then run the **Repair Drawing File** routine and type in the name of the current COGO job file followed by a .DRG extension. If the drawing repair is successful you can simply re-save the whole COGO job file under the same name, or preferably, a new name. This method eliminates having to rename drawing files after the drawing has been repaired.



If **Repair Drawing File** was unable to fix the drawing, copy it onto a floppy disk and send it to:

Simplicity Systems, 1621 Second Avenue NE, East Grand Forks MN 56721-0556

Please include a brief explanation of what has happened.

### Purge Redundant Elements

**FUNCTION:** The **Purge Redundant Elements** function is used to load eliminate unwanted redundancies in a "Sight" Survey or TrueCAD drawing.

To access the **Purge Redundant Elements** function, press Alt S, F, G.

The Purge Redundant Elements routine consists of three options:

**Remove Duplicate Entries?** 

If you want to delete duplicate entities, click <u>Yes</u>, otherwise click <u>No</u>. "Sight" Survey will only remove entities that have been duplicated on the same layer.

#### **Remove Unreferenced Blocks?**

If you want to delete unreferenced blocks, click <u>Yes</u>, otherwise click <u>No</u>. This has the same effect as using the **Purge** command in AutoCAD.

#### **Remove Unreferenced Layers?**

If you want to delete unused or empty layers, click  $\underline{Yes}$ , otherwise click  $\underline{No}$ .

"Sight" Survey will examine the drawing and purge unwanted elements. A report of all elements purged will be issued. Be patient. Large drawings may a substantial amount of time to purge.

22.17

#### Execute Macro

**FUNCTION:** The **Execute** <u>Macro</u> function is used to run a CAD macro file.

To access the Execute Macro function, press Att S, F, M.

Marcos are routines consisting of small number of actual CAD commands. "Sight" Survey uses macros for things such as **Arc Text** and **Title Block** loading. From time to time, additional macros may be made available, and this is the command you will use to run them.

When you select **Execute Macro**, a standard Windows **Load** dialog box entitled **Select macro name to run** appears.

To run a macro, select the macro file you want to run and click on  $\Box K$ . The macro is executed immediately. You can abort a running macro at any time by pressing Esc.

#### Load Title Bloc<u>k</u>

**FUNCTION:** The Load Title Block function is used to add a pre-drawn title block to your existing "Sight" Survey drawing.

To access the Open Drawing function, press Alt S, F, O.

Load Title Block inserts a title block or border into your drawing at the correct scale, regardless of the scale of your drawing.

Before using Load Title Block, you must draw a title block to load. Draw it at a scale of 1:1, using Cartesian coordinates. You can include certificates, bitmaps of company logos, etc. When you have drawn the title block, select it by dragging a rectangle around it (see <u>Start bEdit bSelect</u> (AttS, E, S - page 552) in the Menu), and group it into an object (see <u>Group Into Object</u> (AttS, O, G - page 767) in the <u>Start bObjects Menu</u>). Then save your title block drawing. Section 22



*Title Block construction is covered in greater detail in* **Section 31 - Title Blocks**.

You should create a title block drawing for each paper size you are likely to use. For example, a 24" x 36" drawing could be named **TB24x36.drg**.

When started, Load Title Block activates a standard Windows Load dialog box. Select the title block drawing you want to use and click  $\bigcirc K$ . The title block appears on your drawing at the correct scale, regardless of the scale of your drawing. Since the title block is a grouped object, you can select the title block and position it around your drawing as desired.

3

When you save a title block that contains a bitmap, **the bitmap is not stored in the drawing**. Only a reference to the bitmap is stored. **It is therefore important that you do not delete the bitmap**. If you delete the bitmap or move it to another directory, an error message will appear next time you try to load the title block.



<u>U</u> ndo (00)
<u>R</u> edo (RE)
Cut
Сору
Paste
<u>S</u> elect
Select by Polygon
Selection <u>Filters</u> (SF)
Clear Selection
Select <u>N</u> ormal
S <u>e</u> lect Nodes
Move to Fr <u>o</u> nt
Move to <u>B</u> ack

## Section 23 <u>Start Menu - EDIT</u>

The **EDIT** menu accessed from the **Start** button in the **Drawing** window is where you'll find commands for editing your drawing. Commands include various cutting and pasting functions, Undo and Redo, and several selection functions useful for choosing objects and other drawing elements.

## 23.01 <u>U</u>ndo

**FUNCTION:** The <u>Undo</u> function is used to erase the current drawing and start a new drawing.

To select the <u>Undo</u> function, press <u>Alt</u>  $\mathbb{S}$ ,  $\mathbb{E}$ ,  $\mathbb{U}$ , or click the <u>Undo</u> icon ( $\mathbb{U}$ ) on the **Drawing** window tool bar.

**Undo** undoes the last thing you did in the drawing, whether this was deleting something, moving something, drawing a line etc.

For example, suppose you:

- Draw a line.
- Draw a circle.
- Move the line and circle from point *a* to point *b*.
- Rub out the line and circle.

When you click <u>Undo</u>, the rubbed out line and circle re-appear. If you click <u>Undo</u> again, the line and circle move back from point *b* to point *a*. If you click <u>Undo</u> a third time, the circle disappears. And, if you click <u>Undo</u> again, the line disappears.

**Undo** will undo the last 1000 objects that have been changed. This is not the same as the last 1000 operations. For example, if you moved 100 objects at once and then click **Undo**, you would have used up 100 of the 1000 undos even though you had only undone one move.

If you click  $\underline{U}$ ndo something by accident, you can replace it using the **Redo** function.

<u>Undo</u> will **not** undo changes made by the <u>Start</u>  $\bigcirc$  <u>Objects</u>  $\bigcirc$  Update Objects function (AttS),  $\bigcirc$ ,  $\bigcirc$  - page 785). It will partially undo detailed views created by the <u>Start</u>  $\bigcirc$  <u>Tools</u>  $\bigcirc$  <u>Expand</u> function (AttS),  $\bigcirc$ ,  $\bigcirc$  - page 760).

23.02	<u>R</u> edo
	<b>FUNCTION:</b> The <b><u>R</u>edo</b> function replaces the things you have undone.
	To select the <b>Redo</b> function, press $Atts, E, R$ , or right-click the <b>Redo</b> icon ( 1) on the <b>Drawing</b> window tool bar.
	<b><u>R</u>edo</b> undoes the last action performed in the drawing, whether this was deleting something, moving something, drawing a line etc.
	<ul><li>For example, suppose you:</li><li>Draw a line.</li><li>Draw a circle.</li></ul>
	When you click $\underline{U}$ ndo, the circle disappears. If you click <u>Redo</u> , the circle reappears.

Cu<u>t</u>

**FUNCTION:** The **Cut** function is used to delete selected items and place them on the Windows Clipboard.

To select the Cut function, press Atts, E, T.



You can also access Cut by pressing Ctrl X or by pressing the Shift Delete keys on your keyboard at the same time.

**Cut** deletes selected items and places them on the Windows Clipboard. The item last placed on the Clipboard can then be pasted back into "Sight" Survey or into another Windows application using that application's **Paste** command.

Before using Cut, choose the items you want to cut using Select or Selection Filters. If you have not selected anything, the Cut command prompts:

#### Select single entity (Shift for multiple selection)

Use your mouse to select objects to cut. If you have multiple items to select, press Shift while clicking the mouse on the objects. You can also enclose the target objects in a selection rectangle. To do that, click and hold the mouse on one corner, then drag the selection window open and release the mouse button. When you have all your target objects selected, press the Space Bar bar.



If you cut something by accident, use  $\underline{U}$ ndo (AttS, E, U - page 547) to replace it.

3

*The difference between* **Cut** *and* **<u>Delete</u>** *is that* **<b>Cut** *sends deleted items to the Clipboard, and* **<u>Delete</u>** *does not.* 

Occasional problems have been experienced with cutting from "Sight" Survey and pasting into other applications, particularly when the drawing contains arcs. The target applications are almost always older programs, and the problems have been resolved in newer versions.

23.04	<u>С</u> ору
	<b>FUNCTION:</b> The <b>Copy</b> function is used to copy selected

To select the **Copy** function, press Att S, E, C.

items and place them on the Windows Clipboard.



You can also **Copy** items by pressing Ctrl C or by pressing the Ctrl Lisent keys on your keyboard at the same time.

The **Copy** command is exactly the same as the **Cut** command, except that selected items are not deleted. Instead, a copy of them is placed on the Clipboard, from where it can be pasted into "Sight" Survey or other applications.

#### <u>P</u>aste

**FUNCTION:** The **Paste** function is used to paste or insert items from the Windows Clipboard into a "Sight" Survey drawing.

To access the **Paste** function, press AltS, E, P.



You can also **Paste** items by pressing  $Ctrl \lor$  or by pressing the Shift Inset keys on your keyboard at the same time.

**Paste** inserts text and graphics cut or copied from "Sight" Survey or other programs into a "Sight" Survey drawing, via the Clipboard.

Before you can paste, you must have cut or copied something to the Clipboard from "Sight" Survey or another program. If there is nothing in the Clipboard to be pasted, the **Paste** command will simply not function.

When you select **Paste**, "Sight" Survey prompts:

#### Enter paste position

Click the cursor where you want the contents of the Clipboard to appear on the screen.

If you are pasting graphics, or a mixture of text and graphics, the top left hand corner of the contents of the Clipboard will be placed at the cursor position you specify.

If you are pasting text only, where the text appears relative to the cursor position will depend on the **text label origin** that is set at the time of pasting. For example, if the text label origin is 1, the text will be placed above and to the right of the cursor position. See **Start**  $\Rightarrow$  **Set Text Defaults** (ARS, S, E) - page 820).

The font and text size of text pasted into "Sight" Survey is determined by the defaults set in **Set Text Defaults** at the time of pasting.

When pasting in drawings on several layers that have been cut or copied from another "Sight" Survey drawing, the layers will appear as follows:

- If the layers that the items were cut or copied from exist in the drawing the items are being pasted into, they are pasted to the correct layers.
- If the layers that the items were cut or copied from do not exist in the drawing the items are being pasted into, they are pasted to the current layer.

You cannot paste bitmaps into "Sight" Survey. To load a bitmap, use <u>Start [®] File [®] Import Bitmap</u> (AttS, F, B - page 528).

23.06

#### <u>D</u>elete

**FUNCTION:** The <u>Delete</u> function is used to delete selected items. The deleted items are *not* placed on the Windows Clipboard.

To select the <u>Delete</u> function, press <u>Alt</u>(S),  $\Box$ ,  $\Box$ , or click the <u>Delete</u> icon ( $\bigcirc$ ) on the Drawing window tool bar.



You can also access **Delete** by pressing **Delete**.

Delete erases selected items but does not place them on the Windows Clipboard. Before you use Delete, you should select the items you want to cut using the Start ⇒ Edit ⇒ Select command (AttS, E, S) - page 552) or Start ⇒ Edit ⇒ Selection Filters (AttS, E, F) - page 560). If you have not selected anything, the Delete command will prompt you:

#### Select single entity (Shift for multiple selection)

Use your mouse to select objects to delete. If you have multiple items to select, press Shift while clicking the mouse on the objects. You can also enclose the target objects in a selection rectangle. To do that, click and hold the mouse on one corner, then drag the selection window open and release the mouse button. When you have all your target objects selected, press the Space Bar bar.



If you delete something by accident, use  $\underline{U}$ ndo (AttS, E, U - page 547) to replace it.

3

*The difference between* **Cut** *and* **<u>Delete</u>** *is that* **<b>Cut** *sends deleted items to the Clipboard, and* **<u>Delete</u>** *does not.* 

### Select

**FUNCTION:** The <u>Select</u> function is used to select items; stretch, scale and rotate; drag, copy; edit text, lines, dimensions, arrows, polylines and bitmap parameters.

To access the <u>Select</u> function, press AHS, E, S, or click the <u>Select</u> icon ( $\square$ ) on the <u>Drawing</u> window tool bar.

The <u>Select</u> function is active whenever the cursor is arrow-shaped  $(\triangleright)$ . This cursor is called the <u>Select Cursor</u> and it can be used for the following.

Selected items are termed the **selection set**, and may be edited, moved, mirrored, scaled, copied, rotated, deleted etc., using functions in the <u>Start</u> [™] <u>Modify Menu</u> and the <u>Start</u> [™] <u>Edit Menu</u>. They can also be **nudged** by precise increments using the **arrow keys**.

Once selected using the **Select Cursor** ( $\triangleright$ ), eight handles ( $\blacksquare$ ) and a rotate icon ( $\overset{\blacksquare}{\cdot}$ ) appear around the selection set.



Section 23

For more information on handles, see the subheadings **Handles** on page 555.

Handles may be used to **scale** or **stretch** the selection set. See the subheading **Stretching and Scaling** on page 556.

The rotate icon  $(\bullet_{\bullet})$  is used to rotate the selection set. See the subheading Rotating on page 556.

To **drag** and to **copy** the selection set, see the subheadings **Dragging** and **Copying** on page 557.

To **edit** line style, text, dimensions, arrows and bitmap parameters, see the subheading **Double Click Editing** on page 558.

S

Select Single Primitives

**Selection Set** 

Select a single primitive (line, arc, piece of text, dimension, arrow etc.) by clicking on it with the **Select Cursor** ( $\triangleright$ ). The primitive

The <u>Start</u>  $\Rightarrow$  <u>Edit</u>  $\Rightarrow$  <u>Selection Filters</u> function offers additional methods of selection. See <u>Selection Filters</u> on page 560

To add a single primitive to a group of items that have already been selected, press shift and click on the primitive at the same time.

will become highlighted and handles will appear around it.

Sometimes primitives have been grouped so that when you click on one primitive, the whole group is selected. To return the group to primitives, use <u>Start</u> O <u>Objects</u> O <u>Explode</u> Objects (Att S, O, X - page 770). Once the group is exploded, you will be able to select a single primitive within the group.

Select Single Objects Whenever you create an object manually using Begin New Object (Art)S, ⊙, B - page 765), Group Into Object (Art)S, ⊙, G - page 767), or Make Symbol (Art)S, ⊙, M - page 774) in the Start Sobjects Menu, the primitives in the object are grouped. This means that when you click on the object with the Select Cursor ( ) ) all the primitives within it are selected at once, making selection quicker and easier.

> Some CAD functions that automatically create objects also group the primitives within these objects. For example, when you draw a rectangle using **Rectangle** (AttS, D, X - page 588) in the <u>Start</u> ⇒ <u>Draw Menu</u>, the four lines making up the rectangle are grouped. Similarly, symbols entered using <u>Start</u> ⇒ <u>Draw</u> ⇒ <u>Symbol</u> (AttS, D, M - page 613) are grouped, and sketches produced using <u>Start</u> ⇒ <u>Draw</u> ⇒ <u>Sketch</u> (AttS, D, K - page 615) are grouped.

> Select a single object by clicking on it with the **Select Cursor** ( $\triangleright$ ). The object will be highlighted and handles will appear around it.

To add a single object to a group of items that have already been selected, press **Shift** and click on the object at the same time.




To select a primitive from an object, use  $E_x$  plode Objects (AttS, O, X - page 770) in the Start  $D_0$  Dijects Menu. Once exploded, you may select a single primitive within the group.

#### Select everything in a rectangle

To select everything within a rectangle, position the **Select Cursor**  $(\triangleright)$  at one corner of the rectangle. Click and hold your mouse button, then drag your cursor to the diagonally opposite corner of the rectangle. The outline of the rectangle appears as the cursor is dragged. When the rectangular outline encompasses everything you want to select, release your mouse button.



If what is selected is not what you expected, check the **filters** you have selected. See Selection Filters (AltS, E, F - page 560).



default, replace the line that reads **USEHANDLES** 0 with **USEHANDLES** 1.

## **Stretching and Scaling**

When you have selected items, eight handles ( $\blacksquare$ ) appear around them. When you pass the **Select Cursor** ( $\triangleright$ ) over one of the handles, the cursor changes shape:  $\leftrightarrow$  if it is a left or right handle,  $\ddagger$ if it is a top or bottom handle, and  $_$  or  $_$  if it is a corner handle. The arrows show the directions in which you will be able to scale the selection set if you click on that handle. If you click on the left or right handles, you can only stretch the selection set horizontally. If you click on the top or bottom handles, you can only stretch the selection set vertically, while corner handles let you stretch the selection set diagonally.

Text objects may only be stretched diagonally.

For alternative and more accurate methods of stretching and scaling, see Stretch (ARS, M, E - page 623) and Scale (ARS, M, A - page 629) in the Start  $\mathbb{R}$  Modify Menu.

Rotating


When you have selected items, eight handles  $(\blacksquare)$  will appear around them, together with a rotate icon () just to the left of the top right handle.

When you pass the **Select Cursor** ( $\triangleright$ ) over the rotate icon, the cursor changes to a circular arrow (S). While the cursor is in the shape of a circular arrow, click your mouse and a **Freehand Cursor** ( $\overset{\frown}{+}$ ) will appear. The **Drawing** window prompt bar prompts:

#### Enter point to rotate to

(and)

Move your mouse to move the **Freehand Cursor**  $(f_{+}^{\circ})$  around. As you move it, a "ghost" image or outline of the selection set rotates about its center, as shown in the following illustration.



When you are satisfied with the rotation, click your mouse again to set the position.



For alternative and more accurate method of rotating, see <u>Start</u>  $\mathbb{P}$ <u>Modify</u>  $\mathbb{P}$ <u>Rotate</u> (AttS, M, O - *page 636*).

Use the **Select Cursor** to drag the selection set from one place to another. To do this, move the cursor onto some element of the selection set and press your left mouse button, holding it down. Move your mouse. The selection set moves with your mouse.

If you hold down the **Shift** key while you are dragging, you will only be able to drag the selection set **horizontally** or **vertically**.



and

For an alternative and more accurate method of moving, see <u>Move</u> (AltS, M, M - page 625) in the <u>Start</u>  $\mathbb{P}$ <u>M</u>odify Menu.

If you press the Ctrl key while you drag, the selection set will not be moved. Instead, a copy of the selection set will be made and the copy will be dragged. See the previous section, **Dragging**.

If the **Select Cursor** has a small box around the tip, you will be able to place the copy accurately, because the cursor will snap exactly onto any point within the box.



For alternative methods of copying, see <u>Drop</u> (AttS, M, D - page 634) and <u>Repeat</u> (AttS, M, R - page 631) in the <u>Start</u>  $\Rightarrow$  <u>Modify Menu</u>.

## Dragging

Copying

Double Click Editing

If you double click on a line or arc with the Select Cursor (  $\triangleright$ ), the Line Style dialog box appears. See Start S Settings L Line Defaults (AftS, S,  $\Box$  - page 810).

If you double click on a piece of text, the **Text Entry** dialog box appears. See <u>Start</u>  $\Rightarrow$  <u>Settings</u>  $\Rightarrow$  <u>Set</u> Text Defaults (ArtS), S, E - page 820).

If you double click on a horizontal, vertical, ordinate or slope dimension, you enter the Edit Dimension Properties function. See Start  $\mathbb{P}$  Annotate  $\mathbb{P}$  Edit Dimension Properties (Att S, A, P - page 705).

If you double click on an arrow, the Arrow Defaults dialog box appears. See <u>Start</u>  $\Rightarrow$  <u>Settings</u>  $\Rightarrow$  <u>Set Arrow</u> Defaults (<u>Att</u>S, S, <u>W</u> - page 832).

If you double click on a polyline or bezier curve, the **Polyline Defaults** dialog box appears. See <u>Start</u> **⇒**<u>Settings</u> **⇒Polyline Defaults** (AttS, S, E - page 812).

If you double click on the edge of a bitmap with the **Select Cursor**  $(\triangleright)$ , the **Set Bitmap Parameters** dialog box appears. See **Start**  $\Rightarrow$  **File**  $\Rightarrow$  **Import Bitmap** (Att S, F, B - page 528).

#### Select by Polygon


**FUNCTION:** The **Select by Polygon** function is used to select the drawing entities by creating a box or irregular polygon around those entities.

To access the Select by Polygon function, press AltS, E, Y.

A large crosshair will appear with the **Freehand Cursor**  $(\uparrow \uparrow \uparrow \uparrow)$  at the center, and "Sight" Survey prompts:

Enter polygon about elements to be selected

#### 23.08



Draw a polygon around the elements to be selected. The polygon can be either a rectangular box, or it can be irregularly shaped. An irregularly shaped polygon is extremely useful to maneuver around entities in a cluttered drawing.

To select items within a rectangular box, position the Freehand Cursor ( $\uparrow^{\sim}$ ) at one corner of the rectangle. Click your mouse button and release it. The prompt bar at the top of the Drawing Window prompts:

#### Enter next point of polygon (hit space bar for a box)

## Section 23




Move the cursor to the diagonally opposite corner of the rectangle. As you move the cursor, you will see the outline of a rectangular box with a diagonal line through it. When the rectangular outline encompasses everything you want to select, press [Space Bar].

#### Enter next point of polygon (hit space bar for a box)

Move the cursor to the next vertex on the polygon boundary. As you move the cursor, you will see the outline of a rectangular box with a diagonal line through it. When positioned properly, click your mouse button, or press Fine. The prompt bar at the top of the **Drawing Window** will again prompt:

#### Next point of polygon (space bar to close)



Move the cursor to the next vertex on the polygon boundary and click your mouse button or press Fere. You will continue to be prompted for the next point of the polygon until you close the polygon. Continue to enter the polygon vertices. When you have entered the last vertex, move the cursor close to the first point that you entered and press g to automatically close the polygon.



- 1. If what is selected is not what you expected, check the filters you have selected. See Selection Filters (ARS, E, E below.
- 2. To deselect everything, use Clear Selection (AttS, E, L) page 567), or click your mouse on an open section of the drawing.

#### **Selection Filters**

**FUNCTION:** The **Selection Filter** dialog box allows you to control, or filter, the selection of entities within your drawing.

📲 Selection	×
Clear	Clos <u>e</u>
<u>S</u> elect All	
Select by	Polygon
0 <u>bj</u> ect	<u>N</u> ame
<u>H</u> atch	Layer
Filters	∠ All <u>o</u> w All
🗹 L <u>i</u> nes 🗹	Arro <u>w</u> s
<u>⊮</u> <u>A</u> rcs ⊮	Bitmaps
🗹 Text 🗹	PolyLines
🖌 <u>P</u> oints 🖌	Data Ite <u>m</u> s
🗹 <u>D</u> ims 🗹	Bloc <u>k</u> Inserts
🗌 Current (	Colo <u>r</u>
Current line <u>t</u> ype	
🗌 🗌 Current I	ayer

To access the **Selection** <u>Filter</u> dialog box type SF, or press <u>Att</u>, [E], [E].

Perhaps you want to change **all** the text and/or lines in your drawing to a different color, text size or line style. Using the **Selection Filter**, you can do this easily. (For other methods of selecting objects, see <u>Select</u> (Att S, E, S - page 552).

Once objects are selected, the group of selected items (or primitives) is called the selection set, and can be edited, moved, scaled, copied, rotated, deleted, etc. It is highlighted and surrounded by eight **handles** ( $\blacksquare$ ).

If you run this routine **after** selecting any object(s), the selected object(s) will stay selected unless you select to **Clear** clear them. When you run this routine, the **Selection** dialog box (as shown to the left) appears:

Drawing Selection Filter Quick Reference		
<u>Clear</u> Clos <u>e</u> <u>S</u> elect all	Clears the selection set (deselects everything). Closes the Selection window. Selects everything matching the selected Filters.	
Select by		
Polygon	Selects everything within a polygon.	
0 <u>bj</u> ect	Selects grouped objects by clicking on any item.	
<u>N</u> ame	Selects objects by name.	
Hatch	Selects hatches.	
Layer	Selects layers.	
Filters	Controls what is selected. You can select one,	
	two, or any combination of objects, including all	
	objects.	
Current Color	Selects objects matching the Current Color.	
Current LineTy	Current LineType Selects objects matching the Current Line	
	Туре.	
Current Layer	Selects objects on the Current Layer.	

The dialog box remains open until you click **Close**. This allows you instant access to the **Selection Filter** while you are doing other things. While the dialog box is open, it will float on top of all other "Sight" Survey windows. If you find this to be obtrusive, you can move it to a more preferred location, or simply close the box between uses.

*The filter settings are saved between uses within the current job file.* When you load a new or different job the filter settings are reset to Allow All.

The Filters control what gets selected on your drawing when the <u>Select all</u>, <u>Polygon...</u>, <u>Object...</u>, <u>Name...</u> and <u>Layer...</u> buttons are used. For example, if you have set up the filters to select only <u>A</u>rcs and you click on <u>Select all</u>, only **arcs** and **circles** will be selected. If you click on <u>Polygon...</u> instead, only **arcs** and **circles** within the **polygon** (that you draw) will be selected. If <u>Arcs</u> and <u>Current</u> <u>Color</u> are the only filters checked, then only **arcs** and **circles** of the **current color** will be selected. The current color is the color that was last used in your drawing. It most likely will be the color that is shown in the <u>Object Color</u> setting of the <u>Properties</u> window, but may vary depending upon the last entity placed onto your drawing.

Filters

#### Allow All

To select absolutely everything on your drawing, enable the Allow All filter. This will enable all of the "entity" filters and disable all of the "current type" filters. The "entity" filters are: Lines, Arcs, Text, Points, Dims, Arrows, Bitmaps, PolyLines, Data Items, and BlockInserts. The "current type" filters are: Current Color, Current LineType, and Current Layer. The following table shows which entities each filter references:

This Selection	
Filter option	Refers to these drawing entities:
L <u>i</u> nes	Lines, Crosses, Symbols ⁺ , Rectangles, Leader
	Lines not attached to the Arrow, Line portions
	of Custom Lines
Arcs	Arcs, Circles, Symbols+
Te <u>x</u> t	Point Labels, Bearing & Distance Annotations,
	Curve & Line Tables, Coordinate Lists, Text/
	Font portions of Custom Lines
<u>P</u> oints	Dots
<u>D</u> ims	Dimensions*
Arro <u>w</u> s	Arrows, and the attached leader line
Bitmaps	Inserted Bitmap Drawings
PolyLines	PolyLines*
DataIte <u>m</u> s	Data Items*
Bloc <u>k</u> Inserts	Blocks* (And any Symbols which were inserted as
	Blocks)
Current Colo <u>r</u>	Any entities matching the Current Color
Current	Any entities matching the Current Line Type
Line <u>t</u> ype	
Current Layer	Any entities contained on the Current Layer

* Imported from TrueCAD or other CAD's.

i

**Symbols** are made up of lines and arcs, therefore, when the Lines and/or Arcs options are enabled, the lines and/or arcs within the end point symbols will also be selected. This applies to End Point Symbols as well as Symbols which are drawn as part of a Custom Line. For instructions on changing the color of **ONLY** the End Point Symbols, see the Hands-on Instruction section on page 565.

To select portions of a grouped drawing entity by selecting a portion of the object, click on **Object...**. The prompt bar at the top of the **Drawing** window prompts:

#### Select whole object (Shift for multiple selection)

Position the **Freehand Cursor** ( $_{+}^{\infty}$ ) on any part of the grouped object (i.e. symbol or custom line) you want to select and click your mouse button. All entities grouped into that object (within the enabled filters) will be selected. For example, if you click on a symbol, but have only the Arc filter enabled, only the arcs and circles *within that symbol* will be selected. To select more than one object, hold down the s key while clicking on each object.

To cancel object selection, press Space Bar or click on **Cancel**.

To select the drawing entities by typing in the name of the object, click on <u>Name...</u>. You will be prompted:



Type in the parent name, press g, then type the object name. If you do not know the parent or object names of an object, you can find out by using the **Query Entity** (**QE** or **Att**(**S**), **T**, **Q**- page 751) routine. Type in the names and press <u>reme</u> or click **OK**.

All drawing entities with the name you type (and within the enabled filters) will be selected. For example, if you type Symbol Pipe, all objects named Pipe, with the parent name Symbol, will be selected. Wildcards are allowed. For example, if you type Symbol *, all objects with the parent name Symbol, such as Symbol Pipe, Symbol Pin, Symbol Water, Symbol ConcMon, etc., will be selected. If you type * Water, all objects called Water, such as Symbol Water, Line Water, etc., will be selected.

To select additional items with a different name, click again on **Name...** and then enter another name.

#### Select by Name...

Select by Object...



Names are case-sensitive. You must type them using upperand lower-case letters exactly as stored in the object.

Select by <u>H</u> atch…	To select the drawing entities by selecting a hatch pattern off your drawing, click on <u>Hatch</u> . The prompt bar at the top of the <b>Drawing</b> window prompts:
	Select a hatch perimeter
	A cross (+ or x) appears at one location along the perimeter of each hatch. Position the Freehand Cursor ( $_{+}^{\sim}$ ) on the perimeter cross, or on the hatch itself, and then click the mouse button. The perimeter of the hatch area becomes highlighted. The prompt bar at the top of the Drawing window will again prompt:
	Select a hatch perimeter
	Select another hatch perimeter or cancel the hatch selection by pressing g or by clicking on the <b>Cancel</b> button in the prompt bar at the top of the <b>Drawing</b> window.
Select by <u>L</u> ayer…	To select the drawing entities on a specific layer or layers, click on <b>Layer</b> A layer selection window will appear.
	A         SYMBOLS         COORDINATES         COORDINST         ELEVATIONS         ASCIITEXT         LINES         PTNUMBERS         POINTS         SUPTABLES         LINETEXT         SUPTABLES         LINETEXT         STATIONS

0K

Click on the desired layer and then click **OK**, or just doubleclick on the desired layer. To select additional items on a different layer, click again on **Layer**... and then choose another layer.

Cancel

All drawing entities on the layer(s) you choose (and within the enabled filters) will be selected.

An idiosyncrasy exists when using the Select by Layer... button: The setting for the Current Layer filter is ignored, and the entities on the layer(s) you choose will be selected, whether or not the chosen layer is the Current Layer.

ead

# Section 23

## **HANDS-ON INSTRUCTION: Changing Colors of Objects** The following procedure changes all the green parts of a drawing to black. (Can be applied to any two colors.) *Step 1. Set the* Current Color to green. To do this, change the **Object Color** *property value in the* **Properties** *window* to 05 -Green Step 2. Select all the green parts of your drawing. To do this, type **SF** to display the **Selection Filter**. If it is not already enabled, enable the Allow All filter by clicking on the check box to the left of it. Next, enable the **Current Color** *filter by clicking on its check box, and* ensure that the Current LineType and Current Layer filters are disabled. Now, click on the Select all button and all the green entities on your drawing will become selected. *Step 3. Disable the* Current Color *filter, and close the window. To do this, click on its check box to remove the* $\checkmark$ *or* X, then click on the Close button. If you do not do this step, you will only be able to select objects of the Current Color the next time you try to select anything. Step 4. If you have any green text, change it to black. To do this, type **XT**. (If the Apply button in the Set Text **Defaults** *dialog box is dimmed, you don't have any* green text.) If you do have green text, click the Pen button, change the color to black, and click Apply. When the Attributes to Apply dialog box appears, disable the All option, enable the Pen option, and click OK . Click OK

- *Step 5.* If you have any green **objects**, change them to black. To do this, type **XL**. Click the **Pen** button, change the color to black, and click **Apply** Click **OK**.
- Step 6. If you have any green arrows, change them to black. To do this, type XA. Click the Pen button, change the color to black, and click Apply. Click OK
- *Note:* You may not be able to see changes immediately because items will still be selected. After making all desired changes, deselect the items to see the changes.

(

If your green lines and arcs have different line types and/or line widths, Step 5 of the previous procedure will change all the line types and widths to one line type and one line width. To retain the different line types/widths, in Step 1 you must change the LineType property value in the Properties window to the desired line type. Then, in Step 2, you should enable the Current LineType filter in addition to the Current Color filter.

and

#### HANDS-ON INSTRUCTION: Changing the Color of End Point Symbols

The following procedure outlines steps to change the color of End Point and Custom Line Symbols within your drawing, without changing the color of other parts of your drawing.

- Step 1. Select all the symbols on your drawing. To do this, type SF to display the Selection Filter. If it is not already enabled, enable the Allow All filter by clicking on the check box to the left of it. Also ensure that the Current Color, Current LineType and Current Layer filters are disabled. Next, click on the Layer... button and select the layer which contains your end point symbols. (Most likely, this layer would be called SYMBOLS.)
  Step 2. Change the symbols to the desired color. To do this,
- type XL. Then click the Pen button and select the desired color. Next, click Apply, and then click

ectiol 23

Step 3.	Deselect the selected items	. To do this, click on the
	<u>Clear</u> button in the Sele	ection window.
Step 4.	Close the Selection Filter.	To do this, click on the
	Clos <u>e</u> button.	

23.10

## **Clear Selections**

**FUNCTION:** The **Clear Selections** function is used to deselect, or clear, any current selections.

To access the Clear Selections function, press Att S, E, L.

A faster way to deselect is to simply click your mouse in an unused portion of your drawing. Before doing so, you must turn off any active snap modes.

23.11

### Select Normal

X

**FUNCTION:** The **Select Normal** function is used to reset the method of selection when "Sight" Survey has been using **Select Nodes.** 

To access the Select Normal function, press At S, E, N.

If an object is currently selected by nodes when you activate the **Select Normal** function, the object will be *selected normally*, i.e. surrounded by eight **handles** ( $\blacksquare$ ) will appear around them, together with a **rotate icon** ( $\textcircled{}_{1}$ ) just to the left of the top right handle.

23.1	2

#### Select Nodes

**FUNCTION:** The **Select Nodes** function is used to select items; reshape items; drag, copy; edit text, lines, dimensions, arrows, polylines and bitmap parameters.

To access the <u>Select Nodes</u> function, press Alt [S], [E],  $\overline{Elevel}$ , or click the <u>Select Nodes</u> icon ( $\blacksquare$ ) on the <u>Drawing</u> windows toolbar. The <u>Select Nodes</u> function is active whenever the cursor is cross-shaped ( $\rightarrow$ ). This cursor is called the <u>Nodes Cursor</u>, which can be used to select items. Selecting with the <u>Nodes Cursor</u> is exactly the same as selecting with the <u>Select Cursor</u> ( $\triangleright$ ).

Once selected using the **Nodes Cursor**, all the nodes in the selection set (points, ends of lines and arcs, arc and circle centers, text and dimension origins etc.) are marked by a small square. These nodes can be used to reshape the selection set.

If you click on the **Select** icon ( $\square$ ) on the **Drawing** window toolbar while the nodes are displayed, the nodes will be replaced by **handles**. To return to the nodes, click on the **Select Nodes** icon ( $\blacksquare$ ) in the toolbar.

Like the **Select Cursor**, the **Nodes Cursor** can also be used to drag and copy the selection set (although it cannot be used for accurate dragging) and for double click editing.

When you have selected items using the **Nodes Cursor**, all the nodes in the selection set (points, ends of lines and arcs, arc and circle centers, text and dimension origins etc.) are marked by a small square.

If you click on one of the small squares marking a node, it will become highlighted. To highlight more than one node, click on the nodes you want to highlight while pressing down the Shift key. When you pass the **Nodes Cursor** over one of the highlighted nodes, the cursor changes to four arrows:  $\Rightarrow$ . While the cursor is in the shape of four arrows, press your left mouse button and hold it down. The cursor reverts to the cross shape ( $\Rightarrow$ ).

Nodes

As you move the cursor around, all the highlighted nodes, together with any lines, arcs etc. attached to them, move. When you have finished moving the node or nodes, release your left mouse button.

#### Moving nodes accurately

You can move a single, highlighted node accurately by using <u>Start</u> ⇒ Modify ⇒ Move Point (AttS, M, P - page 626).

To do this, press the  $\bigcirc$ ,  $\bigcirc$ ,  $(\uparrow)$ , or  $\bigcirc$  keys to move the node left, right, up or down. "Sight" Survey will prompt you to enter the distance to be moved. When you have typed the distance, click  $\bigcirc K$  or press  $\bigcirc F$ . The highlighted node will move.

### Move to Front

**FUNCTION:** The **Move to Front** function is used to move elements to the front of other elements on your drawing.

To access the Move to Front function, press AttS, E, O.

Move to Front moves elements to the front of other elements on your drawing. It is especially useful if there is a solid fill or bitmap on your drawing and you need lines or text to appear on top of the solid fill or bitmap. When you select Move to Front, "Sight" Survey prompts:

Select item to move to the front

Click on the element that you want to move to the front. The prompt is repeated until you press the Space Bar, or click on **Done**.



The elements you have moved to the front may not appear to have been moved to the front until you redraw the screen. If you can't see the element you want to move to the front because it's behind something else, select the area containing the element by dragging a rectangle over it or by using <u>Start</u>  $\Rightarrow$  Edit  $\Rightarrow$  Select by Polygon (AttS, E, O - page 558). When it is selected, the hidden element will be visible.

### Move to **B**ack

**FUNCTION:** The Move to Back function is used to paste or insert items from the Windows Clipboard into a "Sight" Survey drawing.

To access the Move to Back function, press AttS, E, B.

Move to <u>Back</u> moves elements behind other elements on your drawing. When you select Move to <u>Back</u>, "Sight" Survey prompts:

Select item to move to the back

Click on the element that you want to move to the back. The prompt is repeated until you press the Space Bar, or click on **Done**.



The elements you have moved to the back may not appear to have been moved to the back until you redraw the screen.



Zoom <u>W</u>indow (ZW) Zoom Last (ZL) Zoom <u>N</u>ext (ZN) Zoom <u>A</u>II (ZA) Zoom <u>S</u>heet (ZS) (ZP) Zoom S<u>c</u>aled Zoom S<u>c</u>aled Zoom View (Z0-9) <u>D</u>efine Zoom View (DZ)

<u>M</u>agnify (MG) Demagnify (DM)

<u>P</u>an (PN) Long Pan (LP)

<u>R</u>edraw (RD)

Spli<u>t</u> Window Join Window

Clear Drawing Window (DX)

## Section 24 <u>Start Menu - VIEW</u>

The <u>VIEW</u> menu accessed from the <u>Start</u> button in the **Drawing** window is where you'll find commands for zooming and panning your drawing. Commands include various drawing related functions, including multiple viewport management.

## 24.01 Zoom Window



**FUNCTION:** The **Zoom** <u>W</u>indow function is used to define an area to zoom by drawing a box around it.

Access the **Zoom Window** function in any one of these ways:

- Type **ZW**.
- Press AltS, V, W.
- Click the Zoom <u>Window</u> icon on the Drawing window toolbar.
- Through the Zoom Icon ( 📳 ) menu.

#### Enter a corner of zoom box

A large cross hair appears on the screen with the cursor at the cross center. Position the cursor at one corner of the area you want to zoom, click or press <u>"Enter</u>].

#### Enter second corner of rectangle

As you move the cursor, you will notice it is attached to a box. Position the cursor so that the box surrounds the area you want to zoom, then click or press <u>-Enter</u>.

The area within the box will now be enlarged to occupy the whole drawing area.



There are three ways to return your drawing to the previous view: type **ZP**; use **Zoom Last** in the **Zoom Icon** menu (P); or right-click the **Zoom Window** icon (N). To return your drawing to an unzoomed view, use **Zoom Sheet**.

24.02

#### Zoom <u>L</u>ast

**FUNCTION:** The **Zoom Last** function is used to move backward through sequence of zooms.

Access the **Zoom Last** function in any one of these ways:

- Type ZL.
- Press AltS, V, L.
- Right-click the Zoom <u>Window</u> icon on the Drawing window toolbar.
- Through the Zoom Icon ( 🖃 ) menu.

**Zoom Last** moves you backward through up to 10 previous zooms. For example, suppose you perform a sequence of three zooms: Zoom 1; Zoom2; and Zoom 3.

If you select **Zoom Last** while you are in Zoom 3, you will return to Zoom 2. If you then select **Zoom Last** while you are in Zoom 2, you will return to Zoom 1. If you then select **Zoom Last** while you are in Zoom 1, you will return to your original view.



The last ten zooms you have used are stored with your drawing when you save it. So next time you load the drawing, you can still use **Zoom Last** to step backwards through your zooms.

### Zoom <u>N</u>ext

**FUNCTION:** The **Zoom** <u>Next</u> function is used to move forward through sequence of zooms.

Access the **Zoom <u>Next</u>** function in any one of these ways:

- Type **ZN**.
- Press AltS, V, N.
- Through the Zoom Icon ( 🔳 ) menu.

Zoom <u>Next</u> moves you forward through up to 10 zooms. For example, suppose you perform a sequence of three zooms: Zoom 1; Zoom2; and Zoom 3. Using the <u>Zoom Last</u> command three times, you have returned to the unzoomed, original view.

If you select **Zoom <u>Next</u>** while you are in the unzoomed view, you will return to Zoom 1. If you then select **Zoom <u>Next</u>** while you are in Zoom 1, you will return to Zoom 2. If you then select **Zoom** <u>Next</u> while you are in Zoom 2, you will return to Zoom 3.



The last ten zooms you have used are stored with your drawing when you save it. So next time you load the drawing, you can still use **Zoom Next** to step forwards through your zooms.

## 24.04

#### Zoom <u>A</u>ll

**FUNCTION:** The **Zoom** <u>All</u> function is used to show the whole drawing at the maximum possible size.

Access the **Zoom** <u>All</u> function in any one of these ways:

- Type ZA.
- Press AltS, V, A.
- Right-click the Zoom lcon ( 🗊 ) menu.
- Through the Zoom Icon ( 🔳 ) menu.

Zoom <u>All</u> displays your whole drawing. If the drawing is larger than the paper size, the paper is shown as a pink dotted rectangle.



There are three ways to return your drawing to the previous view: type **ZP**; use **Zoom Last** in the **Zoom Icon** menu (**P**); or right-click the **Zoom Window** icon (**N**). To return your drawing to an unzoomed view, use **Zoom Sheet**.

## Zoom <u>S</u>heet

**FUNCTION:** The **Zoom Sheet** function is used to show the entire sheet of paper and its contents. (This routine is interchangeably referred to as **Zoom Page**, or **ZP**.)

Access the **Zoom Sheet** function in any one of these ways:

- Type **ZS** (or **ZP**).
- Press AltS, V, S.
- Right-click the Redraw lcon ( 🎤 ) menu.
- Through the Zoom Icon ( 🔳 ) menu.

When selected, only that part of the drawing within the paper extents represented by the pink dotted rectangle is shown.

24.06

24.05

#### Zoom Scaled

**FUNCTION:** The **Zoom Scaled** function is used to show your drawing at a specified scale.

Access the **Zoom Scaled** function in any one of these ways:

- Type ZC.
- Press AltS, V, C.
- Through the Zoom Icon ( 🗾 ) menu.



Type in the scale at which you want to see your drawing and click **OK** or press **Ener**. For example, if you type 10, your drawing will appear on the screen at the size it would be at if its scale was 1:10.

#### Enter zoom box

A box representing the amount of the drawing that will fit on the screen after scaling appears as the cursor. Position this box around the part of your drawing you want to zoom into and click or press . Enter

If you specified a scale greater than the scale at which you are currently viewing your drawing, you will not be able to see the box as the box will be larger that the screen. The cursor (which you will be able to see) represents the center of the box.

#### Zoom Selected

FUNCTION: The Zoom Selected function is used to zoom everything that has been selected to the maximum possible size to fit on the screen.

To access the **Zoom Selected** function, press Alt S,  $\nabla$ , E, or use the **Zoom Icon** ( 🗾 ) menu.

Before using this zoom you must select everything that you want zoomed using the Select (AttS, E, S - page 552) or Selection Filters (AttS, E, F - page 560) functions in the Start > Edit Menu.



24.08	<u>Z</u> oom View
	<b>FUNCTION:</b> The <u>Zoom View</u> function is used to zoom to one of 10 views as defined by the <u>Define Zoom View</u> function (ArtS, V, D - page 577).
	Access the <b>Zoom View</b> function in any one of these ways:
	• Type <b>Z</b> #, where <b>#</b> is the number of the desired view.
	• Press Alt S, V, Z.
	• Through the <b>Zoom Icon</b> ( 😰 ) menu.
	The operation of this function differs depending upon how it has been accessed. Use the appropriate instructions below:
Z#	When you access the <b>Zoom View</b> function by typing <b>Z#</b> (where <b>#</b> is the number of the desired view), "Sight" Survey automatically zooms to the requested view.
<u>S</u> tart ₹ <u>&gt;</u> View ₹> <u>Z</u> oom View	When you access the <b>Zoom View</b> function through the <b>Start</b> menu, or by pressing Alt $S$ , $V$ , $Z$ , a sub-menu appears:
	Zoom Number:0 1 2 3 4 5 6 7 8 9 9

Click on the number corresponding to the view you want to zoom. "Sight" Survey will zoom to the requested view.

If you have not defined any views using the **Define Zoom View** function, the program will zoom to a default view.

Zoom Icon ( 🕑 )

When you click on the **Zoom lcon** ( **P**) on the **Drawing** window toolbar, a sub-menu appears:

Zoom <u>W</u>indow Zoom <u>L</u>ast Zoom <u>N</u>ext Zoom <u>All</u> Zoom <u>P</u>aper Zoom <u>S</u>elected Zoom <u>V</u>iew <u>D</u>efine Zoom View

Press  $\mathbf{V}$  or click on **Zoom** <u>V</u>iew. Another sub-menu appears:



Click on the number corresponding to the view you want to zoom. "Sight" Survey will zoom to the requested view. If you have not defined any views using the **Define Zoom View** function, the program will zoom to a default view.

# 24.09

## Define Zoom View

**FUNCTION:** The <u>Define Zoom View</u> function is used to define up to 10 different zoom or view areas.


Access the **Define Zoom View** function in any one of these ways:

- Type **DZ**.
- Press AltS, V, D.
- Through the Zoom Icon ( 📳 ) menu.



The operation of this function differs slightly depending upon how it has been accessed. Use the appropriate instructions below:

DZ or When you access the <u>Zoom View</u> function by typing DZ, or through the <u>Start</u> menu, or by pressing Alt S, ♥, D, a sub-menu appears:



Click on the number corresponding to the zoom view you want to define.

 $\operatorname{\mathsf{Zoom}}\nolimits(\operatorname{\hbox{\rm I\!\! C}})$ 

When you click on the **Zoom lcon** ( 🕑 ) on the **Drawing** window toolbar, a sub-menu appears:

Zoom <u>W</u> indow
Zoom <u>L</u> ast
Zoom <u>N</u> ext
Zoom <u>A</u> ll
Zoom <u>P</u> aper
Zoom <u>S</u> caled
Zoom S <u>e</u> lected
Zoom <u>V</u> iew
<u>D</u> efine Zoom View

Press D or click on **Define Zoom View**. Another sub-menu appears:



Click on the number corresponding to the zoom view you want to define.

**Common to all methods** 

"Sight" Survey prompts:

Enter a corner of zoom window



Position the cursor at one corner of the area you want to zoom into and click or press Finer. "Sight" Survey prompts:

## Enter second corner of rectangle

As you move the cursor, a rubber-band box opens. Position the cursor so that the box surrounds the area you want to define and click or press *end*. The box you enter will be numbered and marked by green lines.

If you accessed **Define Zoom View** through the **Zoom Icon** (**P**), the menu of numbers will reappear. You can click on another number to define another zoom, or exit the function by pressing **Soc** or by clicking on the screen somewhere outside the number menu.

The zooms you define are stored with your drawing.



When you have finished defining zoom areas, you can clean up the Drawing window and remove the zoom region lines by using the Redraw (RD - page 582) command.

## 24.10

### <u>Magnify</u>

**FUNCTION:** The <u>Magnify</u> function is used to magnify your drawing at the cursor position.

To access the <u>Magnify</u> function, type MG, or press AltS, V, M.

Magnification will occur centered on the current position the cursor. Your drawing is magnified by a factor of 3. To change this magnification factor, use <u>Start</u>  $\Im$  <u>Settings</u>  $\Im$  <u>Change</u> Magnify Factor (AttS, S, C) - page 810).



Since magnification occurs at the current cursor position, do not use your mouse to select this item from the menu. Instead, position your mouse first, then type MG, or press Att[S], V], M.

# 24.11

# Demagnif<u>y</u>

**FUNCTION:** The **Demagnify** function is used to demagnify your drawing at the cursor position.

To access the **Demagnify** function, type **DM**, or press Alt S, V, Y.

Demagnification will occur centered on the current position the cursor. Your drawing is demagnified by a factor of 3. To change this demagnification factor, use <u>Start</u>  $\Rightarrow$  <u>Settings</u>  $\Rightarrow$  <u>Change</u> Magnify Factor (ARS, S), C) - page 810).



Since demagnification occurs at the current cursor position, do not use your mouse to select this item from the menu. Instead, position your mouse first, then type DM, or press Att S, V, Y.

24



# <u>P</u>an

**FUNCTION:** The **Pan** function is used to redraw the screen centered at the cursor position.

To access the <u>Pan</u> function, type **PN**, or press  $\overline{AHS}$ ,  $\overline{V}$ ,  $\overline{P}$ . "Sight" Survey prompts:

### Center display at point

Click the cursor at the desired center point. Panning will occur centered on the cursor position.



Since panning occurs at the current cursor position, do not use your mouse to select this item from the menu. Instead, position your mouse first, then type **PN**, or press Alt(S, V), P.

# 24.13

### Lon<u>g</u> Pan

**FUNCTION:** The **Long Pan** function is used to place a pan box around a part of the drawing to zoom into.

To access the Long Pan function, press Alt S,  $\nabla$ , G.

When you select **Long Pan**, a small dotted square representing your sheet of paper appears, with your drawing inside it. "Sight" Survey prompts:

Enter pan box (Space bar for expanded view)

When you move your mouse, you will see that the cursor is attached to a box. Place this box around the part of your drawing you want to zoom into and click or press *returner*.

Alternatively, press the Space Bar. You will be returned to the view you were working in when you selected Long Pan. The cursor will still be attached to the box, although you may not be able to see the box. Move the cursor to the area of the drawing you want to pan to and click or press **-**Enter.

### 24.14

## <u>R</u>edraw

**FUNCTION:** The <u>Redraw</u> function is used to refresh (clean up) the drawing.

Access the **<u>Redraw</u>** function in any one of these ways:

- Type RD.
- Press  $\overline{\text{Alt}}$   $\overline{\text{S}}$ ,  $\overline{\text{V}}$ ,  $\overline{\text{R}}$ .
- Click the **Redraw lcon** ( ) on the **Drawing** window toolbar.

After several drawing operations have been performed, especially if they include changes and deletions, you may need to "clean up" the display. **<u>Redraw</u>** refreshes the screen to eliminate extraneous clutter.

24.15

### **Split Window**

**FUNCTION:** The **Spli<u>t</u> Window** function is used to open multiple viewing ports. Each view can be of a different portion of the drawing, and at a different zoom factor.

For those times when you would benefit by being able to zoom two or more locations simultaneously, "Sight" Survey allows you to split the **Drawing** window into any number of sub-views.

To access the Split Window function, press AHS, V, T. "Sight" Survey prompts:


Split display at point

Click the cursor at a point in the **Drawing** window where you want to split the display. "Sight" Survey prompts:

### Split vertically? (else horizontally)

Press  $\heartsuit$  or click  $\checkmark$  to split the window vertically, or press  $\aleph$  or click  $\checkmark$  to split the window horizontally.

The screen will be split horizontally or vertically at the cursor position. Horizontal splits are marked by the presence of a scale bar. Vertical splits are indicated by a heavy dashed line. In the example below, the screen has been split in both directions.



Select the active viewport by placing the cursor somewhere inside it. Then use **Zoom** commands to define the view in the viewport.

3

Viewports are activated/deactivated by the cursor passing through them. If you want to use a toolbar function in a particular viewport, you cannot pass the cursor through another viewport on the way to the toolbar. Move the cursor out of the **Drawing** window and around the **Drawing** window to the toolbar. For example, say you want to draw a line in viewport 3. Move the cursor out of viewport 3 to the right or down, then to the toolbar without entering any other viewports.

# 24.16

24.17

### Join Window

**FUNCTION:** The <u>Join Window</u> function is used to combine split windows.

Viewports must be removed in the same order in which they were created. For example, if you split a window horizontally, then split one of the horizontal windows vertically, you must remove the vertical split before removing the horizontal split. Using the screen illustration shown on the previous page, you must join viewport 2 and viewport 3 before you can join viewport 1 and viewport 2.

To access the <u>Join Window</u> function, press AHS, V, J.

### Click on border to join

Click the cursor on the border separating viewports to be joined.

## Clear Drawing Window (D<u>X</u>)

**FUNCTION:** The **Clear Drawing Window** function is used to erase the entire contents of the **Drawing** window.

To access the **Clear Drawing Window** function, type **DX**, or press Ait(S), (V), (X).

¥

When you issue a Clear Drawing Window command, the onscreen drawing is lost and cannot be recovered using Undo. This routine does not delete a saved drawing from your hard disk. After clearing the screen, you may reload a saved drawing using the Load Drawing routine.

3

Use the DX keyboard command to clear drawings containing Short Line (Curve) Tables to allows proper clearing of the table data. See page 90 in the Quick Start manual.


-



Line (Chained) (LI) Lines (Pt to Pt) Point Rectangle (DR) Arc 3 Point (AC) Arc Radius Circle (DC) Circle Diameter Circle 2 Point Line Arc Line Parallel Line (DP) 1 Parallel Element Around a Perimeter (PU) Ellipse Dat Ellipse

Part <u>E</u>llipse Circular Spline Cu<u>b</u>ic Spline (RC) Polyline Polygon S<u>ym</u>bol S<u>k</u>etch

Draw Building Location



# Section 25 Start Menu - DRAW

The **DRAW** menu accessed from the **Start** button in the **Drawing** window is where you'll find commands for drawing construction. Commands include various functions for construction of lines, arcs, and circles. Drawing elements are placed on layers as indicated in the discussion for each element.

# 25.01 Line (Chained) (LI)

**FUNCTION:** The Line (Chained) function is used to construct a line consisting of segments where the end of one line automatically marks the beginning of the next.

Access the Line (Chained) function in any one of these ways:

- Type **LI**.
- Press AltS, D, H.
- Click the Line (Chained) icon ( ) on the Drawing window.

### Enter first point of line

Position the cursor where you want the start point of a line to be and click or press *etener*.

### Enter next point of line

As you move the cursor, a rubber-band line follows it. Position the cursor where you want the end point of the line to be and click or press *returner*. This point also marks the start of the next line.

Enter next point of line

# Section 25

Enter the end point of another line, or cancel line drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.

 To draw a line of an exact length or at a given angle see Accurate Placement on page 497.
 To change line color or type while you are drawing see


<u>Start [™]Settings [™]Line Defaults (AllS, S, L - page 810).</u>

	į
~~~	

Lines (Pt to Pt)

easy

FUNCTION: The Lines (Pt to Pt) function is used to draw separate lines.



Access the Lines (Pt to Pt) function in any one of these ways:

- Type LI.
- Press AltS, D, P.
- Click the Lines (Pt to Pt) icon (1/2-) on the Drawing window.

Enter first point of line

Position the cursor where you want the start point of a line to be and click or press *Enter*.

Enter next point of line

As you move the cursor, a rubber-band line follows it. Position the cursor where you want the end point of the line to be and click or press *eterer*.

Enter first point of line

Enter the first point of another line, or cancel line drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.



- 1. To draw a line of an exact length or at a given angle see Accurate Placement on page 497.
- 2. To change line color or type while you are drawing see <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Line Defaults</u> (Alt S, S, L) - page 810).

25.03

P<u>o</u>int

Points are drawn on the layer specified in Properties (PR) Points Lyr, unless Layer Override is active. FUNCTION: The Point function is used to draw points.

To access the **Point** function, press **AltS**, **D**, **O**.

Enter position of point

Position the cursor where you want a point to be and click or press <u>Enter</u>.

Enter position of point

Enter another point, or cancel point drawing by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.





To position the cursor accurately see **Accurate Placement** *on page* 497.

Section 25

Rectangle (DR)

FUNCTION: The **Rectangle** function is used to draw rectangles by two diagonally opposite corners.

Rectangles are drawn on the layer specified in <u>Properties (PR)</u> Line Lyr, unless Layer Override is active.

Access the **Rectangle** function in any one of these ways:

- Type **DR**.
- Press AltS, D, T.
- Click the Rectangle icon () on the Drawing window.

Enter first rectangle corner

Position the cursor where you want one corner of a rectangle to be and click or press *Enter*.

Enter second corner of rectangle

Move the cursor to a diagonally opposite corner. The cursor is rubber-banded, so you can see the rectangle as you draw it. When you have positioned the cursor, click or press <u>without</u>.

Enter first rectangle corner

Enter a corner of another rectangle, or cancel rectangle drawing by pressing E_{SC} or the $S_{PACO Bar}$, or by clicking on \underline{C}_{ancel} .



1. To position the cursor accurately see Accurate Placement on page 497.

2. To change line color or type while you are drawing see <u>Start</u> [¬]Settings [¬]→ Line Defaults (AltS, S, L) - page 810).



When you draw a rectangle, the lines of the rectangle are automatically grouped so you can select the whole rectangle by clicking on it once with the Select Cursor (\triangleright). To select a single line in the rectangle, you must first **explode** it using <u>Start</u> \Rightarrow <u>Objects</u> \Rightarrow Explode Object (ARS, \bigcirc , \boxtimes - page 770).

Arc 3 Point (AC)

FUNCTION: The <u>Arc 3 Point</u> function is used to draw an arc as defined by three points.

Arcs are drawn on
the layer specified in
Properties (PR) Line Lyr,
unless Layer Override is
active

To access the <u>Arc 3 Point</u> function, type AC, or press <u>Att</u> (D, A), or right-click the <u>Circle</u> icon ((O)) on the <u>Drawing</u> window.

Enter first point of arc

Position the cursor where you want one end of the arc to be located and click or press *eterer*.

Enter point on arc

As you move the cursor, you can see the arc being drawn. Position the cursor at any point on the arc between its two ends and click or press *rener*.

Enter last point of arc

Position the cursor where you want the other end of the arc to be and click or press -Enter.

Enter first point of arc

Enter one end of another arc, or cancel arc drawing by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.



1. To position the cursor accurately see Accurate Placement on page 497.

2. To change line color or type while you are drawing see <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Line Defaults</u> (AHS, S, L - page 810).

2	5	0	6
		-	-

Arc <u>R</u>adius

FUNCTION: The Arc <u>Radius</u> function is used to draw an arc as defined by two end points and a radius.

Arcs are drawn on the layer specified in <u>Properties (PR)</u> Line Lyr, unless Layer Override is active.

To access the <u>Arc 3 Point</u> function, type AC, or press <u>Alt</u>S, D, A.

Enter start point of arc

Enter end point of arc

Position the cursor where you want the other end of the arc to be and click or press *-Enter*.

Enter radius (negative for ClockWise arc)	×
150	
OK	

Type the radius of the arc and click or press File. If you do not know the radius and need to calculate it, you can type the necessary arithmetic expression, for example (518-212)/3 instead of the radius (see Calculations in Accurate Placement - page 508).



To change line color or type while you are drawing see <u>Start</u> ⇒ <u>Settings</u> ⇒ Line Defaults (AHS, S, L) - page 810).

Enter a **positive** radius value to construct an arc in an **counterclockwise** direction between the start and end points you have defined. Enter a **negative** radius value to construct an arc in a **clockwise** direction between the start and end points you have defined. The radius that you enter must be at least as long as half the distance between the start and end points of the arc. If the radius you enter is too short, the message...

Information 🛛 🛛
Radius too small setting it to L/2
OK)

will appear. "Sight" Survey will automatically set the radius to L/2 - half the distance between the two points - and draw the arc.

If you want to measure the distance between the two points, use the **<u>Start</u> <u>></u><u>Tools</u> <u>></u><u>Measure</u> command. (<u>Att</u><u>S</u>, T**, **M** - page 748).

Enter start point of arc

Enter one end of another arc, or cancel arc drawing by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.

25.07

<u>C</u>ircle (DC)

FUNCTION: The <u>Circle</u> function is used to draw a circle by placing a center point and a point on the circle's circumference.

Access the <u>Circle</u> function in any one of these ways:

- Type DC.
- Press AltS, D, C.
- Click the <u>Circle</u> icon () on the Drawing window.

Enter center point of circle

Circles are drawn on the layer specified in Properties (PR) Line Lyr, unless Layer Override is active. Section 25 Position the cursor where you want the center point of a circle to be and click or press *Enter*.

Enter point on circle

As you move the cursor away from the circle center, the circle will appear. When it is the correct size, click or press *etenter*.

1. To position the cursor accurately see Accurate Placement on page 497.

2. To change line color or type while you are drawing see <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Line Defaults</u> (AltS, S, L) - page 810).

Enter center point of circle

Enter the center point of another circle, or cancel circle drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.




eady

Regardless of which point on the circle circumference was initially specified, only the center point and the point that lies on the circumference at the 3 o'clock position are stored.

25.08

Circle Diameter


FUNCTION: The **Circle Diameter** function is used to draw up to five concentric circles.



To access the Circle Diameter function, press AttS, D, D.

Circle center point

Position the cursor where you want the center point of the circle or circles to be and click or press *etcale*.



a

1.	To position the cursor accurately see Accurate Placemen	nt on
	page 497.	

2. To change line color or type while you are drawing see <u>Start</u> [¬]Settings [¬]Line Defaults (AltS, S, L) - page 810).

Enter up to 5	i diameters separated	by spaces	×
20 70 80			
	ОК	Cancel	

Type in up to five diameters separated by spaces and click **OK** or press **-Enter**.

For example, to produce these three circles shown to the left, you would type: **20 70 80**

Circle center point

Enter the center point of another circle or circles, or cancel concentric circle drawing by pressing Esc or the Space Bar, or by clicking on Cancel

25.09

active.

Circles are drawn

on the layer specified in <u>Properties (PR)</u> Line Lyr, unless Layer Override is

Circle 2 Point

FUNCTION: The **Circle 2 Point** function is used to draw a circle defines by two points on the circle's circumference.

To access the Circle Diameter function, press AltS, D, 2.

Enter first point on circle

Position the cursor where you want one point on the circle's circumference to be and click or press *enter*.

Section 25



- 1. To position the cursor accurately see Accurate Placement on page 497.
- 2. To change line color or type while you are drawing see <u>Start</u> ⇒ <u>Settings</u> ⇒ Line Defaults (Alt S, S, L) - page 810).
- 3. To place the circle tangent to another entity (line, arc or circle) at the first point, change to Tan Snap mode () before entering the point. See Tan Snap mode in Start
 Settings Sap Modes (ARS, E, O page 804).

Enter point on circle

As you move the cursor, you will notice it moves as a rubberbanded circle attached to the first point. Position the cursor where you want the other point on the circle's circumference to be and click or press *Enter*.

If you were in **Tan Snap** mode () when you entered one of the points, "Sight" Survey prompts:.

Tangent Circle by two points: Enter diameter	×
25	ו
OK Cancel	

Enter a diameter for the circle, then click **OK** or press **Enter**.

The routine will repeat itself until you cancel the function by pressing Esc or the Space Bar, or by clicking on **Cancel**.

Line Arc Line

FUNCTION: The Line Arc Line function is used to draw a line-arc-line sequence.

To access the Line Arc Line function, press Alt S, D, 1.

Line Arc Line radiuses corners while you are drawing to produce a smooth sequence of lines and arcs. Nothing is drawn until you have entered the first three points.

To produce a sequence of parallel lines and arcs, see the **Parallel Line** function (AttS, D, N - page 597). For an alternative method of producing a line arc line sequence, see the **Circular Spline** (AttS, D, (L - page 607)).

 $\begin{bmatrix} \mathbf{R2} \\ \mathbf{b} \\ \mathbf{c} \\ \mathbf{R1} \end{bmatrix} = \begin{bmatrix} \mathbf{R2} \\ \mathbf{c} \\ \mathbf{c} \\ \mathbf{c} \end{bmatrix}$

Lines and arcs are

drawn on the layer

Override is active.

specified in Properties (PR)

Line Lyr, unless Layer

It is sometimes helpful to use COGO functions to determine and set the corner points you will be using (b and c on the diagram) before you start.

When you access Line Arc Line, "Sight" Survey prompts:

Enter first point

Position the cursor where you want the first point of the first line in the line arc line sequence to be (*position a*). Click or press -




i

To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter corner point

Position the cursor at a corner that will be radiused (*position b*) and click or press \bigcirc Nothing is drawn yet.

Section 25



Type the radius for the corner (*R1*) and click $\bigcirc K$ or press $\neg Enter$. If you do not know the radius and need to calculate it, you can type the necessary arithmetic expression, for example (518-212)/3 instead of the radius (see Calculations in Accurate Placement - page 508).

Enter next corner point (enter two points the same to end with a line)

When this question is asked, you can either enter another radiused corner (*as at c on the diagram*), or you can end the line-arc-line sequence, (*as at d on the diagram*).

Enter corner radius	×
5	
ОК	Cancel

To enter another radiused corner, simply repeat the process you have used so far.

To end the line-arc-line sequence, press $\boxed{\text{Esc}}$ to close the **Enter corner radius** prompt and then press $\boxed{\text{Enter}}$ to accept *position d* again. You have now selected *position d* twice and the line-arc-line sequence will be terminated.

Parallel Li<u>n</u>e

FUNCTION: The **Parallel** Line function is used to draw parallel lines.

To access the **Parallel Line** function, press Att S, D, N, or click the **Parallel Line** icon ($\boxed{2}$) on the **Drawing** window.

The way that the parallel lines are drawn is dependent on the parallel line defaults, which are set using <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow <u>Parallel Defaults</u> (AttS, S, P - page 814).

When you access the **Parallel Line** function with **Parallel Defaults** set for **Around Existing Perimeter** you get the **Perimeter Menu**. This is a multi-purpose menu, containing more items than you need for this function. Choose one of the top five items around or along which you want to place a parallel line: **Enter perimeter: Auto**; **Line**; **Rectangle**; **Arc**; or **Circle**. To select an item, press the underlined letter, or click the item.

Enter Perimeter: <u>Auto</u> If you select this option, you will be asked to click the cursor inside the desired perimeter. You will then be asked if you are satisfied with the perimeter. Click <u>Yes</u> and the parallel line(s) is (are) drawn.

Line If you select this option, the prompts that you get will be exactly the same as for <u>Start</u> \rightarrow <u>Draw</u> \rightarrow <u>Line (Chained)</u> (LI or <u>Alt</u>S, D, H - page 585). When you have completed drawing the line, press <u>Esc</u> or <u>Space Bar</u> and "Sight" Survey will return you to the **Perimeter Menu**. Select <u>Done Perim</u> and the parallel line(s) is (are) drawn.

Rectangle If you select this option, the prompts that you get will be exactly the same as for **Start** ²→ **Draw** ²→ **Rectangle** (DR or Att S), D, T - page 588). When you have completed drawing the rectangle, press **Esc** or **Space Bar** and "Sight" Survey will return you to the **Perimeter Menu**. Select **Done Perim** and the parallel line(s) is (are) drawn.

Lines are drawn on the layer specified in Properties (PR) Line Lyr, unless Layer Override is active.

Around Existing Perimeter

Enter perimeter: <u>A</u> uto
Line
R <u>e</u> ctangle
A <u>r</u> c
<u>C</u> ircle
Intersections
O <u>bj</u> ect
Do <u>n</u> e Perim
<u>S</u> how Perim
<u>D</u> el Previous
Dash T <u>og</u> gle
<u>T</u> olerance
<u>Q</u> uit

Draw Fresh

Arc If you select this option, the prompts that you get will be exactly the same as for **Start** ⇒ **Draw** ⇒ Arc 3 Point (AC or AttS), D, A - page 589). When you have completed drawing the arc, press Esc or Space Bar and "Sight" Survey will return you to the **Perimeter Menu**. Select **Done Perim** and the parallel line(s) is (are) drawn.

<u>Circle</u> If you select this option, the prompts that you get will be exactly the same as for <u>Start</u> [™] <u>Draw</u> [™] <u>Circle</u> (DC or <u>Aft</u> <u>S</u>, <u>D</u>, <u>C</u> page 591). When you have completed drawing the circle, press <u>Ess</u> or <u>Space Bar</u> and "Sight" Survey will return you to the **Perimeter Menu**. Select <u>Done Perim</u> and the parallel line(s) is (are) drawn.

If you checked the **Draw Fresh** box in **Parallel Defaults**, the prompts that you get when you select **Parallel Line** will be exactly the same as for **Line (Chained) (LI** or **AttS**, **D**, **H** - page 585).

If you checked the <u>Line Arc Line</u> box in <u>Parallel Defaults</u>, the prompts that you get when you select <u>Parallel Line</u> will be exactly the same as for <u>Line Arc Line</u> (<u>Atts</u>, D, <u>1</u> - page 595).

3

1. When specifying radii in a line arc line sequence, make sure they are larger than the inside offset defined in Parallel Defaults.

2. If the corner points in a line-arc-line sequence are too close together and the radii are too large, your parallel lines will cross over and change sides.

While only one line will appear as you are drawing, all the parallel lines you specified will appear once you finish line drawing, finish defining the perimeter, or finish drawing the line arc line sequence.



If your parallel lines are unexpectedly drawn on the wrong side of the line, perimeter, or line arc line sequence, use Undo (OO or AttS, E, U - page 547) to delete them and check your offsets in Start O Settings O Parallel Defaults (AttS, S, P page 814).

1 Parallel Element

FUNCTION: The <u>1</u> **Parallel Element** function is used to draw a single line, arc, or circle parallel to an existing line, arc, or circle. It can also be used to draw multiple lines parallel to an existing line.

To access the <u>1</u> Parallel Element function, press AHS, D, 1, or right-click the Parallel Line icon (\swarrow) on the Drawing window.

Parallel elements by spacing? (else through a given point)

Click Yes to set parallel elements by entering the spacing between elements. Click No to have the parallel element pass through a given point. Continue with the appropriate instructions.

This option places a parallel element(s) by specifying a distance between the existing element and the parallel one, along with the number of parallel elements to create.

Enter parallel spacing and number of lines	×
30 1	
OK Cancel	

Type the spacing value and the number of elements you want to create, separating them with a space, and click OK or press --Enter.



Elements containing arcs and circles are only copied once, regardless of the number of copies you specify in the prompt.

If you are going to use <u>1</u> Parallel Element to draw more than one parallel line at once, the lines will be evenly spaced at the distance you type here.

Automatic trimming of consecutive parallel lines?

Lines are drawn on the layer specified in <u>Properties (PR)</u> Line Lyr, unless Layer Override is active.

Parallel Elements by Spacing

Click <u>Yes</u> to turn on line trimming, or <u>No</u> to leave the line trimming off. Trim will **not** work if the number of lines you have specified is greater than 1.



If you elect to use line trimming, each succeeding line will be trimmed to fit the previous one.



If you do not use line trimming, succeeding lines will not be trimmed.

The beginning of the first line and the end of the last line selected will not be trimmed. If you require a closed perimeter, use **Start №Modify %Trim** (AttS, M, **T** - page 638) to join the first and last lines together.

Select element to be parallel copied

Click on the element you want to copy and the copy will appear. This prompt will repeat until you cancel the function by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.



Polylines cannot be duplicated with this routine. You must first explode the polyline, then duplicate the segments. See **Start** O **Dipects** O **Explode Objects** (Alt S, O, X - page 770).

Parallel Elements through a Point This option places a parallel element(s) through whatever point you specify.

Enter number of parallel lines		×
1		
ОК	Cancel	

Automatic trimming of consecutive parallel lines?

Click \underline{Yes} to turn on line trimming, or \underline{No} to leave the line trimming off. Trim will **not** work if the number of lines you have specified is greater than 1.

(

The beginning of the first line and the end of the last line selected will not be trimmed. If you require a closed perimeter, use **Start Nodify Notify Trim** (ARS, M, T - page 638) to join the first and last lines together.

Section 25

Select element to be parallel copied

Click on the element you want to copy and the copy will appear. This prompt will repeat until you cancel the function by pressing Esc or the Space Bar, or by clicking on **Cancel**.

Enter point parallel line (arc) should pass through

Click your mouse at the desired position and the parallel element will be constructed through that point. The position that you choose defines the distance between all the parallel lines.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Select element to be parallel copied

This prompt will be repeat, allowing you to continue copying parallel elements. Cancel the function by pressing Esc or the Space Bar, or by clicking on **Lancel**.

25.13

Around a Perimeter (PU)

Lines are drawn on the layer specified in Properties (PR) Line Lyr, unless Layer Override is active.

Multiple Parallel Line defaults			
◆ Draw <u>F</u> resh ☐ Line-arc-line ◇ Around <u>E</u> xisting Perimeter			
Number of Parallel Lines 1			
Defaults for line number 1			
Type Width point Offset Pen 0 -5			
Close off ends Fillet corners Starting angle 90 Ending angle 90			
OK Cancel <u>H</u> elp			

FUNCTION: The Around a Perimeter function is used to draw a parallel line around an existing perimeter.

To access the Around a Perimeter function, type PU, or press Atts, E, O.

The way that the parallel lines are drawn is dependent on the parallel line defaults, which are set using Start > Settings [₽]Parallel Defaults (AttS, S, P - page 814).

The distance that the parallel line will be placed away from the perimeter is controlled by the **Offset** setting. If you set the offset to a negative number, the parallel perimeter will be constructed inside the existing perimeter. If you use a positive offset value, the parallel perimeter will be constructed outside of the existing perimeter.

This function also works with polylines, except that no element will be constructed parallel to the last segment of the polyline.

Place Cursor inside perimeter and near a line

Click your mouse somewhere inside the perimeter, but close to one of the sides of the perimeter. The perimeter will be automatically selected.

Satisfied with perimeter?

Click Yes if the perimeter has been correctly selected, or No to exit the routine. If you accept the perimeter, the parallel perimeter is automatically drawn, and the routine ends.

2	5	F	Δ	

active.

Ellipses are drawn


on the layer specified in <u>Properties</u> (PR) Line Lyr,

unless Layer Override is

Ellip<u>s</u>e

FUNCTION: The Ellipse function is used to draw ellipses.

To access the Ellipse function, press AttS, D, S.



Enter ellipse center point

Position the cursor where you want the center point of an ellipse to be and click or press - Enter.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter major	axis		×
10			
	ОК	Cancel	

Type in the length of the major axis (see diagram) and click **OK** or press **WENE**. If you do not know the length of the major axis and need to calculate it, you can type the necessary arithmetic expression, for example (518-212)/3 instead of the radius (see **Calculations** in **Accurate Placement** - page 508).

Enter aspect	ratio and angle		×
2 30			
	ОК	Cancel	

The aspect ratio is the length of the major axis divided by the length of the minor axis (see the diagram on the previous page). To get an ellipse that is twice as long as it is wide, use an aspect ratio of 2. To get an ellipse three times longer than it is wide, use an aspect ratio of 3, etc.

The angle is measured counter-clockwise from the 3 o'clock position.

Type the aspect ratio and the angle of the ellipse, separated by a space. Then click $\Box K$ or press \blacksquare An ellipse is drawn.

Enter ellipse center point

Enter the center point of another ellipse, or cancel ellipse drawing by pressing Esc or the Space Bar, or by clicking on Cancel.



In order to snip, hatch or snap to an ellipse, you must first change it to a sequence of 12 arcs using <u>Start</u> \mathbb{R} <u>Modify</u> \mathbb{R} Ellipse<u>2</u>Arcs (AtS, M, 2 - page 658).


25.15

Part <u>E</u>llipse

FUNCTION: The **Part Ellipse** function is used to draw a portion of an ellipse.

To access the Part Ellipse function, press AttS, D, E.

Ellipses are drawn
on the layer specified in <u>Properties</u> (PR) Line Lyr,
unless Layer Override is active.



Enter ellipse center point

Position the cursor where you want the center point of an ellipse to be and click or press *rener*.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter major axis	×
10	
ОК	Cancel

Type in the length of the major axis (see diagram) and click **OK** or press **PERE**. If you do not know the length of the major axis and need to calculate it, you can type the necessary arithmetic expression, for example (518-212)/3 instead of the radius (see **Calculations** in **Accurate Placement** - page 508).

Enter aspect ratio and angle	x
2 30	
ОК	Cancel

Section 25

The aspect ratio is the length of the major axis divided by the length of the minor axis (see the diagram on the previous page). To get an ellipse that is twice as long as it is wide, use an aspect ratio of 2. To get an ellipse three times longer than it is wide, use an aspect ratio of 3, etc.

The angle is measured counter-clockwise from the 3 o'clock position.

Type the aspect ratio and the angle of the ellipse, separated by a space. Then click $\Box K$ or press e E here. An ellipse is drawn.

Enter first snip point on ellipse (ellipse goes round ccw)

Position the cursor at a point on the ellipse boundary where you want one end of the ellipse part to be and click or press *etail*.

The ellipse is drawn in an counter-clockwise direction. If you want to achieve the result illustrated here, you must choose the first snip point as indicated. To retain the other portion of the ellipse, reverse the first and second snip points.

Enter 2nd snip point

Position the cursor at a point on the ellipse boundary where you want the other end of the ellipse part to be and click or press *-Enter*. The unwanted parts of the ellipse are cut away.

Enter ellipse center point

Enter the center point of another part ellipse, or cancel ellipse drawing by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**



Part ellipses created using this function cannot be hatched or snapped to. Ellipse2Arcs DOES NOT WORK on part ellipses.

If you need a part ellipse that can be snapped to and hatched, create an ellipse using the Ellipse function and convert it to 12 arcs using <u>Start \gg Modify \Rightarrow Ellipse2Arcs (AttS), M, 2 - page 658).</u>

First snip point

Second snip point Ellipse before snipping

Ellipse after

snipping

After converting the ellipse to arcs, delete the unwanted parts using <u>Start \mathbb{P} Modify \mathbb{P} Cut and Rub (Att S, M, B - page 650) and <u>Start</u> \mathbb{P} <u>Edit \mathbb{P} Delete</u> (DS or Att S, E, D - page 551).</u>

25.16

Circular splines

are drawn on the layer

Line Lyr, unless Layer

Override is active.

specified in Properties (PR)

Circular Spline

FUNCTION: The **Circular Spline** function is used to draw a randomly curving line, called a spline. A spline can be composed of arcs (Circular Spline) or line segments (Cubic Spline).

To access the Circular Spline function, press AltS, D, L.

This function draws a spline composed of arcs. Each new point enters another arc tangent to the previous one and through the point. This function also allows a line-arc-line sequence to be entered. The spline is rubber-banded to enable you to see exactly what will be drawn.

The first three points that you enter define an arc, as in the Arc 3 Point function.

Circular spline ... enter first point

Position the cursor where you want the first point in the circular spline to be and click or press *enter*. This represents the first point of an arc.

Enter second point of spline

Position the cursor at another point on the spline and click or press . This represents a point on an arc between its two ends.

Enter next point of spline

The arc that you are drawing appears, and is rubber-banded so that you can see exactly what you are drawing. Position the cursor at

25

another point on the spline and click or press — This represents the end point of an arc, and the arc is drawn.

Enter next point of spline - or [Ctrl End] to change arc to line

From here, each new point will enter an arc tangent to the previous arc and through the point. Lines may also be entered.

To draw another **arc**, position your cursor at another point along the spline, and click or press **Enter**.

To draw a **line**, press the Ctrl and End keys together. Then position your cursor and click or press <u>rener</u>.

This prompt repeats until you terminate spline drawing by pressing **Esc** or the **Space Bar**, or by clicking on clicking **Cancel**.



To close a perimeter created using this function the first and second points of the spline must be entered again as the penultimate and last points of the spline.

25.17

Cubic Spline (RC)


FUNCTION: The **Cubic Spline** function is used to draw a randomly curving line, called a spline. A spline can be composed of arcs (Circular Spline) or line segments (Cubic Spline).

To access the **Cubic Spline** function, type **RC** or press **AttS**, **D**, **B**. This function fits a cubic spline, composed of small lines, through points.

Three points are required before a spline can be drawn between the first two points. No spline will be drawn to the last point entered.

Enter number of divisions per spline segment

Cubic splines are			
drawn on the layer			
specified in Properties (PR)			
Line Lyr, unless Layer			
Override is active.			



The spline is reduced to straight line segments. This number dictates how many segments are produced between entered points. Numbers between 5 and 10 are useful. Larger numbers will result in smoother curves, they will consume more memory. Type a number then click **OK** or press **.**

Cubic spline curve ... enter first point

To position the cursor accurately see **Accurate Placement** *on page 497.*

Enter second point

Section 25

Position the cursor at another point on the spline and click or press <u>Enter</u>.

Next spline point

Position the cursor at another point on the spline and click or press . A cubic spline is fitted between the first and second points.

Next spline point

Add another point to the spline or cancel spline drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.



ad

The spline is always drawn between the third last and second last points you entered.

25.18

Polyline

FUNCTION: The Polyline function is used to draw a polyline or a 3 point or 4 point Bezier curve.

Polylines are drawn on the layer specified in Properties (PR)

Line Lyr, unless Layer Override is active.







To access the **Open Drawing** function, press Alt S, D, Y, or click the **Polyline Icon** () on the **Drawing** window toolbar.

Polylines look exactly the same as lines drawn using **Start >Draw** ▶ Line (Chained) (LI or AltS, D, H - page 585). The difference is that when you click on a polyline to select it with the Select Cursor (\triangleright) , the whole polyline is selected, not just one line segment.

A polyline is defined by its vertices, i.e. the beginnings and ends of the line segments within it. To select just one line segment in a polyline, you must first explode the polyline. See Start > Objects \Rightarrow Explode Object (AltS, O, X - page 770).

You can also use the **Polyline** function to draw 3 point and 4 point Bezier curves. 3 point Bezier curves are drawn between every three polyline vertices.

4 point Bezier curves are drawn through every four polyline vertices.

i

To hatch or fill an object constructed by a polyline, you must first explode the object. See **Start Dbjects Explode Object** (AltS, O, X - page 770).

Poly LineStyle			
Pen No Spline 🗸			
Width .5 points 💽 🗆 Closed			
♦ Empty ♦ Hatch ♦ Solid Fill			
net			
OK <u>T</u> ake From <u>Apply</u> Cancel			

Whether a polyline, 3 point Bezier or 4 point Bezier curve is drawn by the **Polyline** function, and whether or not it is closed and hatched depends on the options you have selected in Start Settings ⇒ Polyline Defaults (right-click) or press Atts, S. **F** - page 812).

Once drawn, a polyline can be converted to a Bezier curve or a Bezier curve can be converted to a polyline simply by doubleclicking on it with the Select Cursor (\triangleright). You can also change the hatch status of a polyline by double clicking on it.

When you select the **Polyline** function, "Sight" Survey prompts:

Enter first point of polyline

Position the cursor where you want the first polyline vertex to be and click or press *-Enter*.



To position the cursor accurately and to draw a line of an exact length or at a given angle see Accurate Placement on page 497.

Enter next point of polyline

As you move the cursor, a line follows it. Position the cursor for the second polyline vertex to be and click or press *energed*.

If you are drawing a polyline, the first line segment will be drawn. If you are drawing a Bezier curve, nothing will be drawn until you have entered the fourth vertex.

Enter next point of polyline

Enter another polyline vertex, or cancel polyline drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.




Once you have drawn a polyline or Bezier curve, you can use the function <u>Start</u> B<u>Edit Menu</u> S<u>Select Nodes</u> (ARS, E, E page 568) to stretch the line or curve by its vertices.

25.19

Poly<u>g</u>on

FUNCTION: The **Polygon** function is used to draw polygons.

Section 25



To access the **Polygon** function, press Alt S, D, G, or right-click the **Draw Rectangle Icon** (\Box) in the **Drawing** window toolbar.

Number of	sides for polygon		×
6			
	ОК	Cancel	

Type the number of sides you want the polygon to have, then click $\bigcirc K$ or press $\bigcirc Enter$.

Enter center point of polygon

Position the cursor where you want the center point of the polygon to be and click or press *rener*.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter polygon enclosing circle

Position the cursor on the circumference of a circle enclosing the polygon and click or press with the polygon.

Enter center point of polygon

Position the cursor at the center point of another polygon or cancel polygon drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.



When you create a polygon, the lines making up the polygon are automatically grouped so that you can select the whole polygon by clicking on it once with the **Select Cursor** (\triangleright). To select a single line in the polygon, you must first **explode** it using **Start Objects Explode Object** (ARS, O, X - page 770). Symbols are

specified in Properties (PR)

Selecting the symbol to use

drawn on the layer

Symbols Lyr, unless

Layer Override is

active.

Sy<u>m</u>bol

FUNCTION: The Symbol function is used to enter into your drawing a symbol from the symbol file.

To access the **Symbol** function, press AttS, D, M.

Before you can use the Symbol function, you must use Start \rightarrow File \rightarrow Load Symbol File (AltS, F, Y - page 525) to load the drawing containing the symbols you want to use. Otherwise, "Sight" Survey wouldn't know where to find the symbols.

If you have not loaded a symbol file, "Sight" Survey will automatically enter the Load Symbol File function.

When you enter the symbol function, you are presented with a menu from which to choose your symbol. Use the vertical scroll bar to scroll up and down the symbol list, and click on the desired symbol.




Alternatively, click <u>View</u>. Thumbnail sketches of the symbols appear on the screen. Click on the symbol you want.

After you have selected the desired symbol, "Sight" Survey prompts:

Enter position for symbol (will rotate onto nearest line if in graball mode)

ad

The symbol's *hook point* is positioned at the cursor position. Position the cursor where you want the symbol to appear and click or press *energy*.



Enter symbol scale & rotation	×
110	
ОК	Cancel
UK	

Enter the symbol scale in the X and Y directions, and the symbol rotation angle. Separate the values with spaces. Click $\Box K$.


Would you like to snip around symbol

If your symbol is being placed on top of another drawing element, you can elect to have the area under the symbol snipped, or cut away. This is useful to avoid confusion that might be caused by having lines running through and obscuring symbols. Click **Yes** to clip under the symbol, otherwise click **No**.

If you are entering a symbol that has had attributes attached to it, you will be prompted for the value of attribute once you have specified the position of the symbol. For example, suppose the symbol you are entering has an attribute called **COLOR** attached to it. "Sight" Survey prompts:

		×
ОК	Cancel	
	ОК	OK Cancel

The default value of the attribute **COLOR** will appear in the command line, where you can edit it.





Attributes

If you answered Yes to the Convert attributes to text during load? prompt when you loaded the symbol library, the value that you type into the command line will be written as text next to the symbol. It will be written using the currently selected text defaults. If you need to edit this text once it is on the drawing, double click on it. If you need to move the text, you must first explode the object it is attached to using Start \Rightarrow Objects \Rightarrow Explode Objects (ARS, \bigcirc , \boxtimes - page 770).

If you answered **No** to the **Convert attributes to text during load?** prompt when you loaded the symbol library, a diamond will appear at the attribute position. This diamond will disappear when you redraw the screen.

Once "Sight" Survey has prompted for the value of each attribute attached to the symbol, the symbol will be drawn on the screen.

Enter position for symbol (will rotate onto nearest line if in graball mode)

Enter another symbol, or cancel by pressing E_{SC} or the $S_{Pace Bar}$, or by clicking on \underline{C}_{ancel} .

25.21

S<u>k</u>etch

FUNCTION: The **Sketch** function is used to draw in a freehand mode.

To access the Sketch function, press Alt S, D, K.

"Sight" Survey begins by prompting you for a minimum distance between points, i.e. the minimum length of any individual line segment.

Sketches are			
drawn on the layer			
specified in Properties (PR)			
Line Lyr, unless Layer			
Override is active.			

OK Cancel	Enter minimum distance (in curren	nt units=feet) between freehand d 🗙
	ОК	Cancel

Type an interval from 1 to 2 mm and click **OK** or press **Fine**.

Freehand sketches are composed of many small line segments. While smaller intervals will result in smoother lines, more memory will be consumed and redraw time will be significantly slowed. You should keep the number of sketches on any drawing to a minimum.

Enter start of freehand drawing

Position the cursor where you want the sketch to begin and click or press <u>rener</u>. As you move the mouse, a continuous line will be drawn on the screen until you click or press <u>rener</u>.

Because it is difficult to move the mouse smoothly, the usual result of using **Sketch** is a wobbly squiggle. You may want to use <u>Start</u> **N**<u>Tools</u> **N**<u>Tidy</u> Polygons (AttS), **T**, **T** - page 754) to clean up erratic lines. Sketching will yield the best results when done with a digitizer stylus.

Enter start of freehand drawing

Position the cursor to start another sketch or cancel sketching by pressing Esc or the Space Bar, or by clicking on **Cancel**.



The small lines making up the sketch are automatically grouped enabling you to select the whole sketch by clicking on it once with the Select Cursor (\triangleright). To select a single line in the sketch, you must first explode it using Start O Objects Explode Object (Alt) \fbox{O} , \fbox{O} , \fbox{O} - page 770).

Large sketches may contain too many lines to be grouped into one object. Such sketches will be grouped into several objects.

Draw a Building Location

dimension Text Height.

FUNCTION: The **Draw** a **Building Location** function is used to locate and draw a structure when you know the structure dimensions and tie-distances from two structure corners to two property corners.

Before beginning this routine, you might wish to set the dimension <u>Text Height</u> to a value more compatible with the small point-tie dimensions you'll be placing on the drawing. Right-click the Dimension icon (<u>L</u>) in the Drawing window toolbar to activate the Dimension Settings and change the


Buildings are drawn on the layer specified in Properties (PR) Line Lyr, unless Layer Override is active.


To access the Draw a Building Location function, press \overline{AHS} , D, \overline{W} .

If the setting for **Surveying Dimensions** is not set to **Distance Only**, "Sight" Survey will suggest that you change the setting. In the **Drawing** window command line, you are prompted:

For best results, set Survey Dimension Format to Distance Only.

Since you have measured only distances to tie the lot corners to the building corners, the bearings of the tie lines to the corners are irrelevant and should not be printed. Therefore, you should instruct "Sight" Survey to print only the distances. To change the setting for Surveying Dimensions, click Yes. The Survey Dimensions Setup dialog box appears:





Under the **Survey Dimension Format** section, click the option **Distance only**. Click $\Box \kappa$ to close the dialog box. In the **Drawing** window command line, you are prompted:

Select 1st Lot Corner


3

The cursor has changed to the **Grab All** cursor (\Box) . Move the cursor so the first lot corner (C1) is in the box and click.

Choosing the correct starting corner is crucial because the Draw a Building Location function requires distance-distance intersections to be performed in a clockwise direction. For example, assume your lot line runs Southwesterly with point C1 on the North end, and point C2 on the South. Starting at point C1 and going to point C2 will locate the structure on the East side of the line. Starting at point C2 and going to point C1 will locate the structure on the West side of the line.

In the **Drawing** window command line, you are prompted:

Enter distances to Near & Far corner separated by a space



Type the known distance (D1) from the first lot corner (C1) to the *near* corner of the building (A) followed by a space, followed by the distance (D2) from the first lot corner (C1) to the *far* corner of the building (B) and press \bigcirc . In the Drawing window command line, you are prompted:

Select 2nd Lot Corner

Move the **Grab All** cursor (\bigcirc) cursor so the second lot corner (C2) is in the box and click. In the **Drawing** window command line, you are prompted:


Enter distances to Far & Near corner separated by a space

Type the known distance (D3) from the second lot corner (C2) to the *far* corner of the building (A) followed by a space, followed by the distance (D4) from the second lot corner (C2) to the *near* corner of the building (B) and press $\overline{-Enter}$.

3


Notice that in this prompt you are asked for the Far & Near distances while in the previous distance prompt you were asked for Near & Far distances. The order of distance entry is crucial to the success of this macro. Distances must be properly paired. The first distance in both entries must go to the first point, and the second distance in both entries must go to the second point.

Upon successful data entry, an option menu appears in the **Drawing** window.



This menu governs how the ties and tie distances are to be shown on the drawing. The options are: <u>1</u>. Continue - continue without drawing lines or distances; <u>2</u>. Lines and Dimensions - draw dashed lines and label the distances; <u>3</u>. Dimensions Only - label the

Section 25



distances without drawing dashed lines; and $\underline{4}$. Quit - quit the macro. To select an option, press the corresponding number or click on the option.

"Sight" Survey performs two distance-distance intersections and locates the building corners. If selected, dashed lines are drawn from the lot corners to the building corners, and the tie distances are labeled. In the **Drawing** window command line, you are prompted:

Set Building Starting Corner

Move the cursor somewhere into an open area of the **Drawing** window and click or press -Enter. At this time, the location is unimportant. (For this example, we'll refer to the starting point as **B**.) In the **Drawing** window command line, you are prompted:

Set Next Corner

You will now draw the building outline using the arrow keys to move the cursor measured distances. Press an arrow key (\boxdot, \boxdot) , (1), (1) and a distance prompt box appears:

<u>م</u>
Cancel

Type in the distance and press <u>"Enter</u>. (The first <u>"Enter</u> moves the cursor, the second <u>"Enter</u> sets the point.) A line is drawn. In the **Drawing** window command line, you are prompted:

Enter next point of polyline

Press another arrow key and a distance prompt box appears. Type in the distance and press <u>"Enter"</u>. (The first <u>"Enter</u> moves the cursor, the second <u>"Enter"</u> sets the point.) A line is drawn. This sequence continues until you have reached your starting point. When your building has been drawn, press **Esc** to cancel the building drawing operation.



You can move diagonally using arrow keys in combination. For example to move up 4 feet and to the right 6 feet, press 1 4 • Enter • 4 • Enter • Enter • You may also enter polar dimensions such as a dimension and a particular bearing. To enter a polar dimension, press • instead of an arrow key. When you have moved the cursor, don't forget to press • Enter a second time to set the point.

Enter point that must move

Move the **Grab All** cursor (\Box) so building corner **B** is in the box and click. In the **Drawing** window command line, you are prompted:

Enter point it should move to

Move the **Grab All** cursor (\bigcirc) to the points computed by the tie distances **D2** and **D4** and click. The building moves to the new location. In the **Drawing** window command line, you are prompted:


Enter point about which to rotate

The point we are at is the point around which we want to rotate. Without moving the **Grab All** cursor (\bigcirc), press \bigcirc or click. In the **Drawing** window command line, you are prompted:

Enter angle from keyboard (else from cursor)

Since we are going to be using the other computer building corner to set our building rotation, we will not be entering the angle from the keyboard. Press \mathbb{N} or click \mathbb{N}° . In the **Drawing** window command line, you are prompted:

Enter point that must rotate



Move the **Grab All** cursor (\Box) so building corner **A** is in the box and click. In the **Drawing** window command line, you are prompted:

Enter point it must rotate to

Move the **Grab All** cursor (\Box) to the point computed by the tie distances **D1** and **D3**, and click. The building rotates to the new location. In the **Drawing** window command line, you are prompted:

Enter point that must move

Press **Esc** to end the macro.

25.23

Draw Perpendiculars +

FUNCTION: The **Draw Perpendiculars** <u>+</u> function is used to place multiple perpendicular lines to a baseline.

To access the Draw Perpendiculars + function, press AttS, D, +.

Select the baseline

Move the cursor onto (or near) the baseline and click. "Sight" Survey prompts:

Select a point

Move the **Grab All** cursor (\bigcirc) cursor so the point from which you want to draw the perpendicular line is in the box and click. "Sight" Survey will place the perpendicular line on the drawing. This prompt repeats until you press **Esc** or **Cancel** to quit this routine.

Perpendiculars are drawn on the layer specified in <u>Properties (PR)</u> Line Lyr, unless Layer Override is active. Section 25



Str <u>e</u> tch	
<u>M</u> ove	
Move <u>P</u> oint	
Mirror Image	
Sc <u>a</u> le	
<u>R</u> epeat	
<u>D</u> rop	
R <u>o</u> tate	
<u>I</u> rim	
<u>F</u> illet	
C <u>h</u> amfer	
Di <u>v</u> ide/Extend (BL)	
<u>J</u> oin Lines	
Cut and Ru <u>b</u>	
<u>S</u> nip	
Move Selected to New L	.ayer (XY)
<u>C</u> opy Selected to New L	ayer

Ellipse<u>2</u>Arcs

Section 26 <u>S</u>tart Menu - <u>M</u>ODIFY

The **MODIFY** menu accessed from the **Start** button in the **Drawing** window is where you'll find commands for modifying drawing elements. Commands include various functions for resizing and moving elements, functions for specialized copying and pasting, and functions for joining and trimming lines and arcs.

26.01 Stretch

FUNCTION: The **Stretch** function is used to move that part of a drawing enclosed within a polygon.


To access the **Stretch** function, press AHS, M, E, or click the **Stretch** icon (\mathbb{P}_{P}) on the **Drawing** window toolbar.

In this function you move only that part of a drawing that you enclose within a polygon. The rest of the drawing remains stationary.

You can also stretch parts of your drawing using Start E Edit E Select (AttS, E, S - page 552) or Start E Edit E Select Nodes (AttS, E, E - page 568), and also Start E Modify E Scale (AttS, M, A - page 629).

Any lines crossing the polygon boundary act like rubber-bands. They enlarge, shrink or rotate depending on the amount and direction of movement.

If previously dimensioned, linear dimensions will adjust automatically when **Stretch** is used, although tolerances will be lost. Hatching and filling will also be updated automatically.



Before stretching.

After stretching.

Ç

It is best to be in **Freehand** mode $(f^{(n)})$ when you use **Stretch**. If you are in a snap mode, the cursor sometimes jumps from the point you select to move to, back to the point you selected as the point to move, resulting in no stretching. To enter **Freehand** mode, click on the **Freehand** mode (for) in the **Drawing** window toolbar.

Stretch everything? (else just selected)


Click Yes to stretch everything within the user-defined polygon. If you click No only those elements within the polygon that have been selected using the Select (AttS, E, S - page 552) or Selection Filters (AttS, E, F - page 560) functions will be moved.

Enter polygon about points to be moved

Draw a polygon around the elements to be stretched. Do not put the polygon around the whole shape or it will be moved, not stretched.

Enter point that must move

Position the cursor on a point and click or press *end*. This point is a reference point used to define the movement of the part of the drawing that you enclosed in the polygon. The polygon that you drew will disappear.





To position the cursor accurately see **Accurate Placement** *on page 497.*

Enter point it must move to

Move the cursor to indicate the position the point will be stretched to. A square representing the part of the drawing to be stretched appears. Press *refer* or click to accept the position, and the drawing is stretched.

26.02

<u>M</u>ove

FUNCTION: The <u>Move</u> function is used to move a selection set. You can also move the selection set using the <u>Start</u> \Rightarrow <u>Edit</u> \Rightarrow <u>Select</u> function (<u>Alt</u> \bigcirc , \bigcirc , \bigcirc - page 552).

To access the Move function, press Alt S, M, M.



It is best to be in Freehand mode (\bigcap) when you use Move. If you are in a snap mode, the cursor sometimes jumps from the point you select to move to, back to the point you selected as the point to move, resulting in no movement. To enter Freehand mode, click on the Freehand mode (\bigcap) in the Drawing window toolbar.

The <u>Move</u> function moves everything that has been selected. Before you use the command, you must select the primitives you want to move using the <u>Select</u> (AHS, \Box , \Box , \Box - page 552) or <u>Selection Filters</u> (AHS, \Box , \Box - page 560) commands.

If you haven't selected anything when you choose <u>Move</u>, you will automatically enter the <u>Select</u> function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the entities you want to move. When you have finished, press the Space Bar or click **Cancel**.

Enter point that must move

Position the cursor on a point on the selection set and click or press . This point is a reference point used to define the movement.

end

To position the cursor accurately see Accurate Placement on page 497.

Enter point it should move to

Move the cursor to indicate the position the selected point must move to. A ghosted selection set moves as you move the cursor. Press Free or click when you are satisfied. The selection set is drawn at the new position.

26.03	Move <u>P</u> oint
	FUNCTION: The Move Point function is used to move a point and everything attached to it.
	To access the Move Point function, press AIRS, M, P.
	You can also move a point using the <u>Start Selit Select</u> Nodes (ARS, E, E - page 568) function.
	Select point to move

The cursor has switched to **Point** mode $\begin{pmatrix} \downarrow \downarrow \downarrow \downarrow \\ \downarrow \end{pmatrix}$. Position the cursor close to the point you want to move and click or press \bigcirc . The cursor jumps exactly onto the point because it is in **Point** mode.

Enter point it should move to

The cursor has switched to **Grab All** mode (\bigcirc). Move the cursor to where the point should move to and click or press \bigcirc The point is moved.

Select point to move

Select another point to move or cancel point moving by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.

26.04

Mirror Image

FUNCTION: The Mirror Image function is used to create a mirror image of the selection set.

To access the Mirror Image function, press AttS, M, G.

Section 26

The Mirror Image function mirrors everything that has been selected. Before you use the command, you must select the entities you want to mirror using the <u>Start → Edit → Select</u> (Att S, E, S - page 552) or <u>Start → Edit → Selection Filters</u> (Att S, E, F - page 560) commands.

Mirror Image lets you choose to mirror vertically about a horizontal axis, horizontally about a vertical axis, or about an arbitrarily axis.



Select the axis orientation with your mouse, or by pressing \mathbf{V} , \mathbf{H} , or \mathbf{A} .

If you haven't selected anything when you choose Mirror Image, you will automatically enter the <u>Select</u> function as soon as you choose this routine. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the entities you want to mirror. When you have finished, press the Space Bar or click **Cancel**.

Enter point about which to mirror

Position the cursor at a point about which to mirror. The mirror axis will pass through this point.

Keep old half

If you want to retain the original selection set after performing a Mirror Image, click \underline{Yes} . To discard the original image, keeping only the new mirrored image, click <u>No</u>.

If you have chosen to mirror horizontally or vertically, the selection set is mirrored. If you have chose to mirror arbitrarily, "Sight" Survey prompts:

Enter other point on mirror axis

Position the cursor at the second point defining the axis and click or press *etener*. The selection set is mirrored.



To position the cursor so the selection set is mirrored at a specific angle, press () to perform a Polar Move. See Accurate Placement on page 497.

When text is mirrored it remains readable because only the label origin is mirrored. The label origin of text that is not centered is changed. For example, if the * denotes the label origin of the text and the word **TEXT** denotes a piece of text, ***TEXT** mirrors to **TEXT*** during a vertical mirror.

When you mirror objects, the mirrored half is a new object with the same name and parent name as the original. This means that if you have drawn, for example, half of an object and have mirrored it to get the other half, you will have to unite the two halves into a single object. You can do this using **Start** Objects Objects Object **Group Into Object** (Att) Object, O, O - page 767).

26.05

Sc<u>a</u>le

FUNCTION: The **Scale** function is used to alter the scale of the selection set.

To access the Scale function, press Alt S, M, A.

You can also scale the selection set using <u>Start</u> \Rightarrow <u>Edit</u> \Rightarrow <u>Select</u> (AttS, E, S - page 552).

Section 26

The **Scale** function scales everything that has been selected. Before you use the command, you must select the entities you want to scale using the **Start** E **Edit** E **Select** ((AttS), [E], (S) - page 552) or **Start** E **Edit** E **Selection Filters** ((AttS), (E), (F) - page 560) commands. The selection set can be scaled differently in the horizontal and vertical directions.

If you haven't selected anything when you choose **Scale**, you will automatically enter the <u>Select</u> function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the entities you want to scale. When you have finished, press the Space Bar or click **Cancel**.

Enter point about which to scale


Position the cursor at the point around which the increase or decrease in scale is to take place. This point will remain stationary while the rest of the selection set is scaled. Click or press **.**



To position the cursor accurately see **Accurate Placement** *on page 497.*

Enter scale from cursor (else from keyboard)

You can use the cursor to indicate where the selection set must be scaled to. For example, if you indicate that this point ...




must be

scaled to here ...



... the selection set will be scaled like this.



If you want to indicate the scaling by cursor, click \underline{Yes} and go to Scaling by Cursor. Otherwise, click \underline{No} and continue at Scaling by the Keyboard.

If you don't scale by using the cursor, you can type specific horizontal and vertical scaling factors from the keyboard. For example, typing 2 1 will scale the selection set by a factor of 2 in

the horizontal direction and by a factor of **1** in the vertical direction.

Scaling by Cursor





Enter point to be scaled

Position the cursor on a point to be moved during the scale. Press <u>-Enter</u> or click to accept the point to be scaled.

Enter point it must scale to

Move your cursor to the desired position. As you move your cursor, you can see the selection set being scaled. To retain the horizontal and vertical proportions of the selection set as you scale it, press the Shift key as you move the cursor.



To position the cursor exactly on the point it must scale to, see Accurate Placement on page 497.

Click or press . The selection set is scaled.

Section 26

Scaling by the Keyboard


×
Cancel

Type in horizontal and vertical scaling factors separated by a space, then click OK or press -Enter. The selection set is scaled.

26.06

<u>R</u>epeat

FUNCTION: The <u>Repeat</u> function is used to make rectangular (linear) or polar (radial) copies of the selection set.



Rectangular Repeat

Polar Repeat To access the **<u>Repeat</u>** function, press <u>Atts</u>, <u>M</u>, <u>R</u>.

The **Repeat** function copies everything that has been selected. Before you use the command, you must select the entities you want to repeat using the **Start** \Rightarrow **Edit** \Rightarrow **Select** (AttS, E, S - page 552) or **Start** \Rightarrow **Edit** \Rightarrow **Selection Filters** (AttS, E, F - page 560) commands.

If you haven't selected anything when you choose <u>Repeat</u>, you will automatically enter the <u>Select</u> function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the entities you want to copy. When you have finished, press the Space Bar or click **Cancel**.

Repeat h	ow many times		×
1			
	ОК	Cancel	

Type in the number of *additional* copies required and click **OK** or press **-Enter**. For example, if you type 2 you will end up with three copies of the selection set: the original and two copies.

Rectangular repeat? (else polar)

To repeat along a line, click <u>Yes</u> and go to **Rectangular Repeat**. To repeat in a circle, click <u>No</u> and go to **Polar Repeat**.

Rectangular Repeat

Enter point on original set

Position the cursor at a point on the selection set and click or press . This point acts as a reference point.



To position the cursor exactly on a specific point, see **Accurate Placement** *on page 497.*

Enter point on repeated set

Position the cursor at the place where the first copy should be positioned. This position defines the distance between copies. All subsequent copies will be positioned at equal distances from each other. Click or press *LETER*. The selection set is repeated.

Polar Repeat

Enter point about which to rotate

Position the cursor at the center of the circle around which the copies will be placed and click or press *energed*.

Enter rotation angle	tion I
60	Sec [
OK Cancel	

The default angle required to copy the selection set evenly around a circle will appear. Accept this default by clicking OK or pressing -Enter. Alternatively, type an angle of your choice and click OK or press -Enter. The selection set is repeated.

For example, to produce the polar repeat diagram at the beginning of this section you would have had to answer 5 to the question, Repeat how many times, and type 60 in answer to this question, for the number of degrees (6 copies multiplied by 60 degrees is 360 degrees - a complete circle).

The angle you type is measured counter-clockwise. If you do not know the angle and need to calculate it, you can type the necessary arithmetic expression, for example 360/4 instead of the angle. See **Calculations** in **Accurate Placement** on page 508.

Each copy produced by **<u>Repeat</u>** is a new object, with the same name and parent name as the original. For example, if you started off with one tree, which you repeated five times, you would end up with six trees. If you draw one part of an object and then use <u>**Repeat**</u> to complete the object, you have to group the repeated parts into a single object. You can do this using <u>**Start**</u> \Rightarrow <u>**Objects**</u> \Rightarrow <u>**Group Into Object**</u> (<u>Att</u>)<u>S</u>, \bigcirc , \bigcirc - page 767).

26.07	<u>D</u> rop
	FUNCTION: The Drop function is used to copy the selection set.
	To access the <u>D</u>rop function, press $Alt S$, M , D .
$\left.\right>$	You can also copy the selection set using the <u>Start</u> \rightarrow <u>Edit</u> \rightarrow <u>Copy</u> (AttS, E, C - page 549) and <u>Start</u> \rightarrow <u>Edit</u> \rightarrow <u>Paste</u> (AttS, E, P - page 550) functions.
	Unlike <u>Repeat</u> , <u>Drop</u> does not assume a regular interval between copies of the selection set. Copies are positioned individually.
	The Drop function copies everything that has been selected. Before you use the command, you must select the entities you want to repeat using the Start → Edit → Select (AftS, E, S - page 552) or Start → Edit → Selection Filters (AftS, E, F - page 560) commands.
	If you haven't selected anything when you choose \underline{D} rop, you will automatically enter the \underline{S} elect function as soon as you choose the

Select Single Entity (Shift for multiple selection)

command. "Sight" Survey prompts:

Select the entities you want to copy. When you have finished, press the Space Bar or click **Cancel**.

Enter a point on selection set

pagh

Position the cursor on a point and click or press *etail*. This point is a reference point that you will use to define where the copy will be placed.

To position the cursor exactly on a specific point, see **Accurate Placement** *on page 497.*

Enter point where you would like to copy selection set

As you move the cursor, you will see an image of the selection set moving with it. Position this image and click or press *werearter*. The copy will be drawn.

Enter point where you would like to copy selection set

As you move the cursor, you will see another image of the selection set moving with it. Position this copy and press *-Enter* or click, or cancel copying by pressing *Esc* or the *Space Bar*, or by clicking on *Cancel*.

Each copy produced by **Drop** is a new object, with the same name and parent name as the original. For example, if you started off with one tree, which you repeated five times, you would end up with six trees. If you draw one part of an object and then use **Drop** to complete the object, you have to group the repeated parts into a single object. You can do this using **Start** \Rightarrow **Objects** \Rightarrow **Group Into Object** (Artis, O, O - page 767).

26.08

Rotate

FUNCTION: The **Rotate** function is used to rotate the selection set.

To access the **Rotate** function, press Alt S, M, O.

You can also scale the selection set using <u>Start</u> \Rightarrow <u>Edit</u> \Rightarrow <u>Select</u> (AttS, E, S - page 552).

The **Rotate** function rotates everything that has been selected. Before you use the command, you must select the entities you want to rotate using the <u>Start **Select**</u> (Att S, E, S - page 552) or <u>Start **Selection**</u> Filters (Att S, E, F - page 560) commands.

If you haven't selected anything when you choose **Rotate**, you will automatically enter the **Select** function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the entities you want to rotate. When you have finished, press the Space Bar or click **Cancel**.

Enter point about which to rotate

Position the cursor at the point about which the selection set will be rotated and click or press <u>-Enter</u>.



To position the cursor exactly on a specific point, see **Accurate Placement** *on page 497.*

Enter angle from keyboard (else from cursor)

If you know the angle of rotation, click <u>Yes</u> and go to **Rotating** by Angle.

If you want to rotate the selection set by dragging it with your cursor, click **No** and go to **Rotating by Cursor**.

Rotating by Angle

Enter angle			×
75			٦
	ОК	Cancel	

Type the rotation angle and click **OK** or press **Ener**. The selection set is rotated.

The rotation angle is measured counter-clockwise from the three o'clock position regardless of how you have set up the Angular Format in Start $\$ Settings $\$ Drawing Settings (AttS, S, D - page 789).

If you do not know the angle and need to calculate it, you can type the necessary arithmetic expression, for example 360/4 instead of the angle. See **Calculations** in **Accurate Placement** on page 508.

Enter point that must move

You are now given the option to move the rotated selection set (see <u>Start > Modify > Move</u> (Att >, M, M - page 625)). If you do not want to move the rotated selection set, cancel by pressing Esc or the <u>Space Bar</u>, or by clicking on <u>Cancel</u>.</u>

Rotating by Cursor

Enter point that must rotate

Position the cursor at the point you want to use to drag the selection set around with and click or press *etater*.

To position the cursor exactly on a specific point, see **Accurate Placement** *on page 497.*

Enter point it must rotate to

Position the cursor at a point to indicate the new inclination of the selection set, and click or press *etement*. You will see the selection set rotating as you move the cursor.

Enter point that must move

You are now given the option to move the rotated selection set (see <u>Start $\rightarrow Modify \rightarrow Move$ (AttS, M, M</u> - page 625)). If you do not want to move the rotated selection set, cancel by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u>Cancel</u>.

```
26.09
```

<u>T</u>rim

FUNCTION: The **Trim** function is used to automatically trim or extend a line or arc to join another one exactly.

To access the <u>Trim</u> function, press \overline{Att} , M, $\overline{}$, or click the <u>Trim</u> icon (\underline{I}) on the **Drawing** window toolbar.


When you select the <u>Trim</u> function, the cursor switches to Freehand mode $\begin{pmatrix} & & \\ & & \end{pmatrix}$ and you are prompted:

Update both original elements, just the first or neither (2/1/0)	×
2	
OK Cancel	


"Sight" Survey needs to know how many elements you want to update. Type 2, or 1, and click $\Box \kappa$. The 0 option is irrelevant in this option.

Update

If you choose First Line, one line or arc will be trimmed or extended to meet another line or arc.



If you choose Both Lines, two lines or arcs will be trimmed or extended to meet each other.






After Trim

Use


You need to tell "Sight" Survey how many points you want to use when selecting the elements to be trimmed.

Select fillet/trim with two points (else single point)	×
No	
OK	

Click **OK** to choose **Single Point**, and you will be able to select the lines or arcs to trim with one mouse click.



If you have chosen to update the **First Line**, you must click on the element you want to trim or extend. If you are trimming an element rather than extending it, ensure that you click on that part of the element to be retained after the trim.



If you have chosen to update **Both Lines**, you must click inside the corner made by the two elements.

If you choose **Two Points**, you must select the lines or arcs to trim with two mouse clicks.



If you have chosen to update the **First Line**, you must click on the element you want to trim or extend *first*. If you are trimming an element rather than extending it, ensure that you click on that part of the element to be retained after the trim.



Then click on this line

Once you have clicked on the element to trim or extend, click on the element that it must be trimmed or extended to.



If you have chosen to update **Both Lines**, you must click on one of the elements you want to trim or extend, then on the other.



If you are trimming an element rather than extending it, ensure that you click on that part of the element to be retained after the trim.

When you have finished trimming, select another element to trim or extend or cancel by pressing Esc or the Space Bar, or by clicking on <u>Cancel</u>.



26.10

<u>F</u>illet

FUNCTION: The **Fillet** function is used to insert radiused corners between elements or edits elements to join exactly.

To access the **Fillet** function, press Att S, M, E, or right-click the **Trim** icon (**I**) on the **Drawing** window toolbar.

The elements to be filleted may be arcs or lines. It doesn't matter whether they join, cross, or do not intersect at all. However, if you are going to fillet two elements that cross and you are going to update both elements (see **Update** in this section), you may need to divide the elements at the intersection to give four lines before filleting. For example:

Two lines that cross like this ...



... will fillet like this if you update both elements...



unless you divide them at the intersection using the function Start \mathbb{Z} Modify \mathbb{Z} Divide/Extend (AttS, M, \mathbb{V} - page 647).

When you select the **Trim** function, the cursor switches to Freehand mode $\begin{pmatrix} \uparrow & \uparrow \\ + & \uparrow \end{pmatrix}$ and you are prompted:

Update both original elements, just the first or neither (2/1/0)	×
OK Cancel	

"Sight" Survey needs to know how many elements you want to update. Type 2, 1, or 0 and click **OK**

Update


If you choose to update neither elements, a fillet will be inserted between two elements, but the elements will not be updated.

> If you choose to update just the first element, a fillet will be inserted between two elements and one of the elements will be updated.

If you choose to update both elements, a fillet will be inserted between two elements and both of the elements will be updated.


Use

You need to tell "Sight" Survey how many points you want to use when selecting the elements to fillet.



Click $\bigcirc K$ to choose **Single Point**, and you will be able to select the lines or arcs to trim with one mouse click.

If you have chosen to update the **first element**, you must click near the element you want to update but *inside* the corner made by the two elements.




Before Fillet

ction

If you have chosen to update **neither** or **both elements**, you must click *inside* the corner made by the two elements.

After Fillet



Before Fillet After Fillet

Two Points

If you choose **Two Points**, you must select the elements to fillet with two mouse clicks.

If you have chosen to update the **first element**, you must click near the element you want to update *first*. You must click *inside* the corner made by the two elements.

Single Point




Once you have clicked near the element to update, click near the other element. Again, you must click on the inside of the corner made by the two elements.




Then click here

If you have chosen to update **neither** or **both elements**, you must click near to one of the elements to fillet between, then click near the other. You must click on the *inside* of the corner made by the two elements.



Radius



You now need to specify the radius to be used for filleting. "Sight" Survey prompts:

Enter fillet radius (0 to trim)	×
30	
ОК	Cancel

Type the fillet radius. If you type 0, the <u>Fillet</u> function will operate in exactly the same way as the <u>Trim</u> function.



If your fillet is "inside out", you probably clicked outside the corner made by the elements being filleted, not inside. Undo (click \bigcirc or type OO - page 547) the fillet and try again, clicking on the inside of the corner.

26.11

C<u>h</u>amfer

FUNCTION: The **Chamfer** function is used to draw a third, sloping line between two existing lines.

To access the **Chamfer** function, press **AttS**, **M**, **H**.

However, if you are going to chamfer two elements that cross and you are going to update both elements (see **Update** in this section), you may need to divide the elements at the intersection to give four lines before filleting. For example:


Two lines that cross like this ...

... will chamfer like this...

unless you divide them at the intersection using the function <u>Start</u> \mathbb{P} <u>Modify</u> \mathbb{P} <u>Divide/Extend</u> (<u>AttS</u>, <u>M</u>, <u>V</u> - page 647).

When you select the **Chamfer** function, the cursor switches to **Freehand** mode $(\uparrow \circ \circ)$ and you are prompted:

Section 26



You can either specify a chamfer by angle and one distance or by two distances. Specify the chamfer method by typing **A** (by angle) or **D** (by distances, and clicking $\Box K$.

Distances are measured from the intersection point of the two lines even if they do not meet, and are applied to the lines in the order in which they are selected.

Select first line to be chamfered



ĩ

Position the cursor on or near the first line to be chamfered and click or press *Enter*.


Second line



Position the cursor on or near the second line to be chamfered and click or press *-*Enter.

Chamfer by Angle and Distance

Second line selected for chamfering



First line selected for chamfering

Enter chamfer distance and angle	×
30 45	
OK Cancel	

Type in a chamfer distance and a chamfer angle, separated by a space, and click $\bigcirc K$ or press $\neg Enter$. In the example shown above, the distance is **30** drawing units, and the angle is **45** degrees.


After specifying the units, the chamfer will be drawn. "Sight" Survey prompts:

Select first line to be chamfered

Click on another line to be chamfered, or cancel chamfering by pressing Esc or the Space Bar, or by clicking on **Cancel**.

Chamfer by Two Distances

Second line selected for chamfering



First line selected for chamfering

Enter first and second chamfer	distances 🛛 🗙
50 50	
ОК	Cancel

Type in the two chamfer distance and a chamfer angle, separated by a space, and click $\bigcirc K$ or press \bigcirc In the example shown above, both distances are 50 drawing.

After specifying the units, the chamfer will be drawn. "Sight" Survey prompts:

Select first line to be chamfered

Click on another line to be chamfered, or cancel chamfering by pressing Esc or the Space Bar, or by clicking on **Cancel**.

26.12

Divide/Extend (BL)

FUNCTION: The **Divide/Extend** function is used to split or extend a line or arc.

To access the **Divide/Extend** function, type **BL** (for Break Line) or press AttS, M, ∇ .

This function has two purposes.

• Splitting a line or arc. When a line or arc is split, the two split ends form a point that can be snapped to exactly. Also, once a line or arc has been split, one part of it can be rubbed out or edited.

• Extending a line or arc. For example, extending a line to meet another line.

When you select Divide/Extend, "Sight" Survey prompts:

Select line or arc to be divided or extended

Position the cursor on the line or arc to be divided or extended and click or press *etcher*.

Enter point where you want to divide element (or point to extend it to)

If you want to divide the line or arc, position the cursor at the point where the split must take place and click or press *Enter*. If the point is not exactly on the line or arc, the split will take place at the nearest position on the line or arc.

If you want to extend the line or arc, position the cursor at the point you want to extend it to and click or press *Enter*. If the point does not lie exactly on the extended line or arc, the line or arc will be extended to the nearest position.



26.13

To position the cursor exactly on a specific point, see **Accurate Placement** *on page 497.*

Join Lines

FUNCTION: The <u>Join Lines</u> function is used to join the ends of two lines.

To access the <u>Join Lines</u> function, press <u>Atts</u>, <u>M</u>, <u>J</u>.




Some lines are deleted when you use <u>Join Lines</u>. This function is therefore described using two examples which show the action of <u>Join Lines</u> in two different instances. •

When using <u>Join Lines</u> you should be in Freehand mode ($\uparrow \circ \circ$). Click the Freehand icon ($\frown \circ$) in the Drawing window toolbar.


Before using Join Lines, you must have two lines.

Select first line to be joined

Position your cursor at the end of one of the lines and click or press . The end of the line that you position your cursor close to will be deleted.




Position your cursor at the end of the other line and click or press . The end of the line that you position your cursor close to will be deleted.



The two lines are joined and the original lines are deleted.

26.14



... to give this line

Lines 1 and 2 have been joined

If the two original lines disappear and no new line is produced, click **Undo** (1) and try again. Ensure that you are in **Freehand** mode ($\overset{\frown}{+}$), and that you click at the ends of the lines that are to be deleted.

Select first line to be joined

Position the cursor near the end of another line and click or press <u>-Enter</u>, or cancel the function by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u>Cancel</u>.


Cut and Ru<u>b</u>

FUNCTION: The **Cut and Rub** function is used to rub out (erase) part of a line.


To access the Cut and Rub function, press Alt S, M, B.

Do you want to cut one place (else two places)

If you want to rub out the end of a line, and therefore only have to cut the line in one place, click \underline{Yes} . Go to Cutting in one place.



cut the line in two places, click $\boxed{N_0}$. Go to Cutting in two places.



Cutting in one place



Position your cursor between the cut point and the end of the line. Click or press <u>rener</u>.

Select line to cut (between cut point and end)

Section 26

Select cut point



Notice that the cursor has switched from Freehand mode $(\begin{array}{c} & & \\ & & \\ & & \\ \end{array}$) to Grab All mode ($\begin{array}{c} & \\ & \\ \end{array}$). By switching into Grab All mode, the Cut and Rub function assumes the piece of line you want to cut away is bounded by an intersection that must be snapped to exactly. If this is not the case, switch back to Freehand mode by clicking on the Freehand ($\begin{array}{c} & \\ & \\ \end{array}$) in the Drawing window toolbar.

The unwanted section of line disappears.

Cut another line (else exit)

If you want to cut another line, click \underline{Yes} , otherwise click \underline{No} .

Cutting in two places



Select line to cut (between cut points)

Position your cursor between the two intersections. Click or press <u>Enter</u>.

Enter first cut point

Notice that the cursor has switched from Freehand mode $(\begin{array}{c} & & \\ & & \\ & & \\ \end{array}$) to **Grab All** mode ($\begin{array}{c} \\ & \\ \end{array}$). By switching into **Grab All** mode, the **Cut and Rub** function assumes the piece of line you want to cut away is bounded by an intersection that must be snapped to exactly. If this is not the case, switch back to Freehand mode by clicking on the Freehand ($\begin{array}{c} \\ \\ \end{array}$) in the Drawing window toolbar.



Position the cursor so that one of the intersections bounding the piece of line you want to rub out is within the cursor box and click or press *wEnter*.

Enter second cut point




Position the cursor so that the other intersection bounding the piece of line you want to rub out is within the cursor box and click or press *letter*.

The unwanted section of line disappears.

Cut another line (else exit)


If you want to cut another line, click <u>Yes</u>, otherwise click <u>No</u>.



Before snip. Everything inside this box will be snipped out.

To delete that portion of the snipped entity outside a box or circle, click $\boxed{N_0}$.

After snip.



Move the cursor diagonally away from the first corner you entered and click or press *Enter* to delete elements inside or outside the box.

Enter new corner of snip box

When you move the cursor the snip box you have just defined moves with it. Place the snip box at another position and click or press Fine. The elements inside or outside the box will be deleted. Cancel **Snip** by pressing **Esc** or the **Space Bar**, or by clicking **Lancel**.

Snipping inside or outside a circle

Enter center point of snip circle

Position the cursor at the center of the snip circle and click or press -Enter.

and

To position the cursor exactly on a specific point, see **Accurate Placement** *on page 497.*

Enter point on radius

Position the cursor at a point on the snip circle's circumference and click or press to delete elements inside or outside the circle.

Enter new center point of snip circle

When you move the cursor the snip circle just defined moves with it. Place the snip circle at another position and click or press *rener*. The elements inside or outside the circle will be deleted. Cancel **Snip** by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.

26.16

Move Selected to a New Layer (XY)

FUNCTION: The **Move Selected to a New Layer** function is used to move selection set to a particular layer.

To access the **Move Selected to a New Layer** function, type XY or press Att, M, Y.

Before using this function, you must have created a layer to move the selection set to. See <u>Start ⇒ Settings</u> ⇒ Layer Control (, EL or <u>Alt</u>(S), S), Y - page 839).



1. The layer containing items to be selected must be visible and unlocked.

- 2. The target layer does not need to be visible or unlocked.
- *3. Use* **Undo** *to restore items accidentally selected or moved to the wrong layer.*
- 4. To move a copy of an object, use **Copy** and **Paste** before using this routine. This leaves the original item unchanged.
- 5. If an object that originally came from the **Drawing** window is pasted back into the **Drawing** window, it is placed onto its original layer.
- 6. If an object that did not originally come from the Drawing window is pasted into the Drawing window, it is placed onto the current layer.

The **Move Selected to a New Layer** function moves everything that has been selected. Before you use the command, you must select the primitives you want to move using the <u>Select</u> (AltS, E, S - page 552) or <u>Selection Filters</u> (AltS, E, F - page 560) commands.

If you haven't selected anything when you choose **Move Selected to** a New Layer, you will automatically enter the <u>Select function</u> as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Move to layer?	X
A	
SYMBOLS	
COORDINATES	
COORDLIST	
ELEVATIONS	
ASCIITEXT	
LINES	
PTNAMES	
PTNUMBERS	
POINTS	
SUPTABLES	
LINETEXT	
STATIONS	
ОК	Cancel

Select the entities you want to move to a new layer. When you have finished, press the Space Bar or click **Cancel**.

Once you have selected something to move into another layer, a layer name dialog box (as shown to the left) appears.

Click on the layer that the selection set must be moved to. The new layer that the selection set has been moved to is highlighted.

26

Copy Selected to a New Layer

FUNCTION: The <u>Copy Selected to a New Layer</u> function is used to copy selection set to a particular layer.

To access the <u>C</u>opy Selected to a New Layer function, press AltS, M, C.

Before using this function, you must have created a layer to move the selection set to. See <u>Start \Rightarrow Settings</u> \Rightarrow Layer Control (\blacksquare , EL or Alt(S), (S), (Y) - page 839).


The <u>Copy</u> Selected to a New Layer function moves everything that has been selected. Before you use the command, you must select the primitives you want to move using the <u>Select</u> (Alt S, E, S - page 552) or Selection Filters (Alt S, E, F - page 560) commands.

If you haven't selected anything when you choose <u>Copy Selected to</u> a New Layer, you will automatically enter the <u>Select</u> function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the entities you want to copy to a new layer. When you have finished, press the Space Bar or click **Cancel**.

Once you have selected something to move into another layer, a layer name dialog box appears.



Click on the layer that the selection set must be moved to. The new layer that the selection set has been moved to is highlighted.

26.18 Ellipse2Arcs FUNCTION: The Ellipse2Arcs function is used to convert ellipses into 12 arcs so that they can be snipped. To access the Ellipse2Arcs function, press [Att]S, M, [2]. Image: This function will not operate on part ellipses drawn using the Start ™ Draw ™ Part Ellipse function (Att]S, D, E - page 604). Enter polygon about ellipses to be converted to arcs Draw a polygon around the ellipses to be converted. Enter polygon about ellipses to be converted to arcs

Either draw a polygon around more ellipses to be converted to arcs, or cancel ellipse conversion by pressing Esc or the Space Bar, or by clicking on **Cancel**.



Text Line Entry (TL) Arc Text]

<u>E</u>dit Text

<u>M</u>ove Text Scale Te<u>x</u>t Change <u>T</u>ext Parameters

Set <u>A</u>lignment Align <u>=</u>

Horizontal Dimension Vertical Dimension Slope Dimension Angular Dimension Badial Dimension Survey Dimension Ordinate Dimension Dimension Arc Perpendicular Dimension +

Edit Dimension <u>Properties</u> Cut Dimension <u>Line</u> Alter Dimensio<u>n</u>

Add Arrow -≥ Add <u>B</u>alloon Add/Rem Text Bubble

Enter Hatch/Solid <u>Fill</u> Adjust Existing Hatch <u>D</u>raw All Hatch Dra<u>w</u> Selected Hatch <u>H</u>atch -> Lines

Label <u>C</u>oordinates

Section 27 <u>Start Menu - ANNOTATE</u>

The <u>ANNOTATE</u> menu accessed from the <u>Start</u> button in the **Drawing** window is where you'll find commands for adding text to your drawing. Commands include various functions for adding text lines and around arcs. Commands for editing and scaling text are also found here, along with several options for dimension various aspects of your drawings. Finally, the Annotate menu also includes commands for hatching and filling, as well as for setting object alignment.

All annotation, hatches and fills placed by routines accessed through this menu are written to the current layer!

27.01

Text Line Entry (TL)

FUNCTION: The **Text Line Entry** function is used to write text to your drawing.



Access the Text Line Entry function in any one of these ways:

- Type **TL**.
- Press AltS, A, Y.
- Click the **Text** icon (A) on the **Drawing** window.

Before entering text, use <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow <u>Set</u> <u>Text Defaults</u> (AttS, S, E - page 820) to set the text parameters. You can also change the text parameters as you are entering the text into the <u>Text</u> Entry dialog box, or change the parameters of text that has already been entered using the <u>Set Text Defaults</u> function or the <u>Start</u> \Rightarrow <u>Annotate</u> \Rightarrow <u>Edit Text</u> (AttS, A, E - page 664).

Text Line Entry allows you to type text directly into a "Sight" Survey drawing. You can also import text from a word processor

as an ASCII file using **Start >File >Import ASCII Text** (Att**S**, **F**, **T** - page 527), or paste text into the drawing from a Windows word-processor or desk top publishing program using **Start >Edit >Paste** (Att**S**, **E**, **P** - page 527).

This routine normally places text on a horizontal line. To place text along a line oriented at an angle, see **Placing Text at an Angle** on page 662.

When you access the **Text Line Entry** function, "Sight" Survey prompts:


Enter text position

Position the cursor where you want the text to appear and click or press where the text will appear relative to this position depends on the *text label origin* you have set using <u>Start</u> Settings Set Text Defaults.



To position the cursor accurately see **Accurate Placement** *on page* 497.

A warning message appears:




The **Text Entry** dialog box (shown on the next page) allows you to enter and/or edit text and set **Text Defaults** (i.e. change font, color, bold, etc.) at the same time. Some users experience sporadic problems when they have combined these operations. To date, we have been unable to consistently and remedy this problem.

١	/

To avoid a program crash, if you have entered or edited text in the **Text Entry** dialog box, **DO NOT** click the **Text Defaults** >> button. Close the dialog box, then doubleclick the text to re-open the **Text Entry** dialog box, after which you can click the **Text Defaults** >> button and change your text settings.

Click **OK** to erase the warning message and the **Text Entry** dialog box appears. Type the text, which will appear in the white area of the dialog box at the position of the black vertical cursor.



Section 27

If you check the Accept Return box, you can enter a new line of text by pressing the etcal key on its own. Otherwise you must press the Ctrl and etcal keys at the same time to enter a new line of text.

If you want to change the text parameters from this dialog box, click on the Text Defaults >> button. You will enter Start Settings Set Text Defaults (Att S, S, E) - page 820). DO NOT do this if you have entered or edited text – see the warning message above!

If you want to change text height, you can type a new text height into the text height box. If you want to use different height units from those displayed, you must click **Text Defaults** >>> to enter **Start >> Set Text Defaults**.

When you have finished typing the text, click **OK**.

Enter text position

Position the cursor where you want another piece of text to appear and click or press *enter*. Cancel text entry by pressing *Esc* or the *Space Bar*, or by clicking on *Lancel*.

If you need to edit text content after you have entered it, for example because you have made a spelling mistake, double click on the text with the **Select Cursor** (\triangleright). The text will appear in the **Text Entry** dialog box for editing. You can also use <u>Start</u> \Rightarrow <u>Annotate</u> \Rightarrow <u>Edit Text</u> (<u>Att</u><u>S</u>, <u>A</u>, <u>E</u> - page 664).

To place text along a line see Accurate Placement on page 497.



Placing Text at an Angle

When you access the **Text Line Entry** function, "Sight" Survey prompts:

Enter text position

Position the cursor on the line to which you want to align text. **DO NOT click the cursor.** Instead, press \ltimes to lock the cursor to the angle of the line. Now move the cursor to the desired text location and click. Then enter text just as before.



If you want text perpendicular to the line, press \square after you have pressed \mathbb{K} .

Text will stay locked at the angle until you exit the **Text Line Entry** function. The next time you enter the function, text will default to horizontal.

Arc Text)

FUNCTION: The **Arc Text** function is used to place text around an arc.

To access the Arc Text function, press Att S, A, D.

Select arc to place text on

Position your cursor on the arc you want to place the text around and click or press -Enter.

Enter Text			×
	ОК	Cancel	

Type the text you want to place around the arc and click OK or press -Enter.

The text is placed around the arc, centered between the ends of the arc.

Section 27



If you are placing text around a circle, the text will be centered on the 3:00 o'clock position. You may rotate the text around the circle to the desired position using **Start** \mathbb{R} **Modify** \mathbb{R} **Rotate** (Att S, M, \mathbb{O} - page 636).



Arc Text is actually drawn one character at a time, after which it is grouped into a single object. Therefore, if you doubleclick to edit the text properties, you will only be able to edit one letter at a time. If you want to delete or move the text, it will perform as a single object. However, if you want to delete only a portion of the text, you must first explode the text object using <u>Start</u> \rightarrow <u>Objects</u> \rightarrow <u>Explode</u> Object (Aft S, O, X - page 770).

THIS IS TEXT MONG AN ARC

27.03

<u>E</u>dit Text

FUNCTION: The **Edit Text** function is used to edit existing text.

To access the Edit Text function, press AltS, A, E.

You can also edit text content by double clicking on the piece of text you want to edit with the Select Cursor (\triangleright).

¥

Some users experience sporadic problems when they edit text and then try to change **Text Defaults** at the same time. To date, we have been unable to consistently and remedy this problem. **To avoid a program crash,** if you have entered / edited text in the **Text Entry** dialog box, **DO NOT** click the **Text Defaults** >> button. Close the dialog box, then double-click the text to reopen the **Text Entry** dialog box, after which you can click the **Text Defaults** >> button and change your text settings.

The **Edit Text** function edits all the text that has been selected. Before you use the command, you must select the text you want to edit using the **Select** (AttS, E, S - page 552) or **Selection Filters** (AttS, E, F - page 560) commands.

If you haven't selected anything when you choose **Edit Text**, you will automatically enter the **Select** function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the text you want to edit. When you have finished, press the Space Bar or click **Cancel**.

The text you have selected will appear inside the **Text Entry** dialog box (see page 661), where it can be edited.

If you have selected several pieces of text to edit, only one will appear at one time. The next will appear when you have finished editing the first piece of text and have clicked **OK**.

If you want to change the text parameters from this dialog box, click on the Text Defaults >> button. You will enter Start Settings Set Text Defaults (Aft S, S, E - page 820). DO NOT do this if you have entered or edited text – see the warning message on the previous page!

If you just want to change text height, you can type a new text height into the text height box. If you want to use different height units from those displayed, you must click Text Defaults >> to enter <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow <u>Set</u> Text Defaults.

When you have finished editing the text, click **OK**

27.04

<u>M</u>ove Text

FUNCTION: The <u>Move Text</u> function is used to move all text that has been selected.

To access the Move Text function, press AttS, A, M.

X

You can also move text using the **Select Cursor** (\triangleright). Select the text you want to move, then drag it to a new location using your mouse.

Section 27

The <u>Move Text</u> function moves all the text that has been selected. Before you use the command, you must select the text you want to move using the <u>Select</u> (AltS, [E], [S] - page 552) or <u>Selection Filters</u> (AltS, [E], [E] - page 560) commands.

If you haven't selected anything when you choose <u>Move Text</u>, you will automatically enter the <u>Select</u> function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the text you want to move. When you have finished, press the Space Bar or click **Cancel**.

Enter point on text that must move

Position the cursor at a point on the text and click or press *Finer*. This point is a reference point that you will use to define the movement.

Enter new text position

Position the cursor to indicate the position the selected point must move to and click or press *Enter*.



To position the cursor accurately see **Accurate Placement** *on page 497.*

27.05

Scale Te<u>x</u>t

FUNCTION: The **Scale Text** function is used to change the scale of selected text.

To access the Scale Text function, press Alt S, A, E.

The **Scale Text** function scales all the text that has been selected. Before you use the command, you must select the text you want to scale using the **Select** (AttS, E, S - page 552) or **Selection Filters** (AttS, E, F - page 560) commands.

If you haven't selected anything when you choose **Scale Text**, you will automatically enter the **Select** function as soon as you choose the command. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the text you want to scale. When you have finished, press the Space Bar or click **Cancel**.

	×
Cancel	
	Cancel

Type the text scale factor. For example, if you want the text to be twice as big, type **2**. Then click OK or press \overline{Pinter} .

Scaling takes place about the text label origin as set in <u>Start</u> [¬]Settings [¬]Set Text Defaults (AttS, S, E - page 820).

27.06

Change <u>Text</u> Parameters

FUNCTION: The **Change <u>Text Parameters</u>** function is used to alter the characteristics of the text.

To access the Change Text Parameters routine, press AttS, A, T.



You can edit the text parameters of a single piece of text by double clicking on it with the Select Cursor (\triangleright). The text you have selected will appear inside the Text Entry dialog box. Click on the Text Defaults >> button to enter Start \Rightarrow Settings \Rightarrow Set Text Defaults (Att S, S, E - page 820). Section 27

Change Text Parameters allows you to change the text parameters of all text that has been selected. Before you use the command, you must select the text whose parameters you want to change using the <u>Select (Att S, E, S</u> - page 552) or <u>Selection Filters</u> (<u>Att S, E, F</u> - page 560) commands.

If you haven't selected anything when you choose **Change Text Parameters**, you will automatically enter the <u>Select</u> function as soon as you choose the command. "Sight" Survey prompts:



Select Single Entity (Shift for multiple selection)

Select the text whose parameters you want to change. When you have finished, press the Space Bar or click **Cancel**. The **Set Text Defaults** dialog box will appear. Complete instructions for the available settings are discussed beginning on page 820.

When you have edited the parameters, you can exit the dialog box by clicking **OK** or **Apply**. The parameters of all the selected text will be updated.

27.07

Set <u>A</u>lignment

FUNCTION: The **Set** <u>Alignment</u> function is used to define how the selection set should be aligned, or align the selection set horizontally or vertically.

To access the Set <u>Alignment</u> function, press <u>Alt</u> S, A, A, or click the Align Objects icon (E) in the Drawing window toolbar.



"Grid lines" are referred to in this section. When you use <u>Start</u> ⇒ <u>Tools</u> ⇒ <u>Grid</u> to create a grid in "Sight" Survey, only the dots representing the intersections between the horizontal and vertical grid lines are displayed.

Use **Set** <u>Alignment</u> to determine how the selection set will be aligned next time you use <u>Start</u> \Rightarrow <u>Annotate</u> \Rightarrow <u>Align</u> (<u>Att</u>S, <u>A</u>, <u>=</u> page 671). The selection set is all the items that have been selected using the <u>Select</u> (<u>Att</u>S, <u>E</u>, <u>S</u> - page 552) or <u>Selection Filters</u> (<u>Att</u>S, <u>E</u>, <u>F</u> - page 560) commands.

To align or distribute the selection set, use <u>Select</u> or <u>Selection</u> <u>Filters</u> to select the items you want to align. Then select <u>Set</u> <u>Alignment</u>. Edit the dialog box to your satisfaction and click <u>Apply</u>.

When you select **Set** <u>A</u>lignment, the Align dialog box appears.



Align: To Each Other or To Grid If you check To Each Other in the Align dialog box, the selection set will be aligned with itself. In the example below, the selection set has been left aligned. The items in the selection set have been aligned with the left hand edge of the square, because this was the left most thing in the selection set before alignment.



Alignment

The align **To Each Other** *and* **To Grid** *options are only relevant to* **Align**, *not to* **Distribute**.

If you check **To Grid**, the selection set will be aligned to the nearest grid line There must be a grid on the screen before you align using **To Grid**, or nothing will happen. See **Start** [®]→**Tools** [®]→**Grid** (Att)^S, **T**, **D** - page 747).

The **Vertical** section of the **Align** dialog box allows the items in the selection set to be aligned to the **Top**, **Center** or **Bottom**. The **Horizontal** section of the **Align** dialog box allows the items in the selection set to be aligned to the **Left**, **Center** or **Right**.

Items in the selection set can be aligned both horizontally and vertically at the same time.

DistributionDistribution refers to the practice of placing selected objects at
equal spacing to one another
Before you distribute items, they
must be *approximately* positioned. Distribute will not work on
randomly placed items.



The align **To Each Other** *and* **To Grid** *options are only relevant to* **Align**, *not to* **Distribute**.

Vertical Distribution

Distribution may take place vertically or horizontally. When you select **Vertical Distribution** you must specify **Top**, **Center**, or **Bottom**. For example: If you specify **Top**, selected objects are repositioned so that their tops are equally spread between the top of the top object and the top of the bottom object.




Horizontal Distribution	When you select Horizontal Distribution you must specify Left , Center , or Right . For example: If you specify Left , selected objects are repositioned so that their left sides are equally spread between the left side of the left-most object and the left side of the right- most object.
	Before Distribution After Distribution
Combining Distribution and Alignment	 You can combine alignment and distribution into one operation. The possible combinations are: Vertical Alignment & Horizontal Alignment
	• Vertical Alignment & Horizontal Distribution

- Vertical Distribution & Horizontal Alignment
- Vertical Distribution & Horizontal Distribution

27.08	Align <u>=</u>
	FUNCTION: The Align function is used to align and/or distribute the selection set.
	To access the Align function, press ARS , A , \equiv ., or click the Align icon (E) on the Drawing window toolbar.
	The Align function aligns everything that has been selected. Before you use the command, you must select the entities you want to align using the <u>Select</u> (Alt S, E, S - page 552) or <u>Selection Filters</u> (Alt S, E, F - page 560) commands, or nothing will happen.
	One item cannot be aligned with itself. You must select at least two items to align or three to distribute, or nothing will happen.
	The way that the selection set is aligned and/or distributed depends on the way you have set up the Align dialog box. See <u>Start</u> [™] Annotate [™] Set Alignment (AltS, A, A - page 668).
Aligning Text	Text may not look as though it has been aligned with the other items in the selection set. This is because the text characters are enclosed in a "cell" with a space above them and below them. For example, when aligning text to the top, it is not the top of the character that is aligned, but the top of the "cell".
	The text label origin associated with a piece of text does not affect the way that text is aligned using Align. See <u>Start \Rightarrow Settings \Rightarrow Set Text Defaults (AltS, S, E - page 820)).</u>
	Each piece of text is associated with a text alignment, defined in <u>Start \Rightarrow Settings \Rightarrow Set Text Defaults</u> . If you have a piece of text comprised of several lines, this <i>does</i> affect the way that text is aligned using Align.
	For example, the text alignment of the piece of text has been set to

For example, the text alignment of the piece of text has been set to "right" in the <u>Set Text Defaults</u> dialog box.



27.09

When you use **Align** to left align it with another item, the left-hand edge of the piece of text is aligned, but the lines remain right justified.

To align all the text to the left, you must change the text alignment associated with the piece of text to "left". Do this by double clicking on the piece of text with the **Select Cursor** (\triangleright). The selected text you have will appear inside the **Text Entry** dialog box. Click on the **Text Defaults** button to enter the **Set Text Defaults** dialog box. Change **Text Alignment** to **left**, then click **OK**.

Horizontal Dimension


FUNCTION: The Horizontal Dimension function is used to place horizontal dimensions on the drawing.

To access the Horizontal Dimension function, press AHS, A, Z, or click the Dimension icon (\square_2) on the Drawing window toolbar and press \square .


Dimension appearance (text height, arrow size, number of decimals, etc.) is set using <u>Start</u> \Im <u>Settings</u> \Im <u>Dimension Defaults</u> (Att \Im , \Im , N - page 826). The settings in <u>Dimension Defaults</u> will affect *all* the dimensions on your drawing (except those placed while doing COGO), including previously drawn ones. This means that if you are not satisfied with the way your dimensions look, you can change them at any stage.

You can change the text content, arrow type and witness line color of individual dimensions using <u>Start</u> \Rightarrow <u>Annotate</u> \Rightarrow Edit Dimension <u>Properties</u> (AttS, A, P - page 705).

Horizontal dimensions are fully *associative*. This means that if you change the size of a dimensioned object using, for example, **Stretch**, **Scale** or **Move Point**, the dimensions will automatically update to reflect the new size. You can also change horizontal dimensions to cause a change in the size of dimensioned object. See <u>Start \Rightarrow Annotate \Rightarrow Alter Dimension (ARS), A, N - page 705).</u>



For example, this object has been dimensioned *x*.



If you replace the x with 50, for example, using the Alter Dimension function, the object will change size so that it is 50 units long.


Horizontal dimensions need not dimension horizontally aligned points, although horizontal distances will be measured. If you do not want to measure horizontal distances, use <u>Start Annotate</u> <u>Slope Dimension</u> (AttS, A, S - page 679).


Mechanical Style

If you have checked the **Mechanical Style** button in **Start Settings Dimension Defaults**, "Sight" Survey prompts:

Do you want ru	nning, chained o	free dimensions (R/C/F)	×
Running			
	ОК	Cancel	


Type **R** for Running, **C** for Chained, or **F** for Free. Click OK or press $\overline{e_{\text{Enter}}}$.





Dimensions may be running,

or they may be chained,



or they may be free (just one isolated dimension).

Enter text position

The cursor switches to **Freehand** mode $(\uparrow \uparrow \uparrow)$. Position it and click or press \neg Enter).

The text and dimension line will be positioned at the cursor position.


The text will automatically be centered between the witness lines. If you do not want the text centered, you can move it to the desired


position after you have drawn the dimension, using the <u>Start</u> \mathbb{N} <u>Modify</u> \mathbb{N} Stretch (<u>Att</u>S, <u>M</u>, <u>E</u> - page 623).



To position the cursor accurately see **Accurate Placement** *on page 497.*


If you are drawing **running** or **chained** dimensions and you position the cursor close to an existing dimension, the new dimension text and line will be drawn relative to this existing dimension regardless of the cursor position. For example: If you position the cursor as shown below to the left,





the new dimension text and line will be positioned as shown above to the right.

If you position the cursor as shown below to the left,



The new dimension text and line will be positioned as shown above to the right.

The spacing between subsequent dimensions is determined by the Linefeed option in <u>Start</u> [™]><u>Settings</u> [™]><u>Dimension</u> Defaults.

Enter first point



The cursor will switch to **Point** mode $\binom{4+4}{2}$. Position it close to the first point to be included in the dimension and click or press **Fine**. The cursor will automatically jump onto the point. If you do not want to jump onto the point you can change cursor modes, for example by clicking on the **Freehand lcon** (**F**) in the **Drawing** window toolbar.

Enter next point



Position the cursor close to the next point to be included in the dimension and click or press *referer*.

Enter text of dimension		×
415.38'		
ОК	Cancel	

The distance between the two points is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click **OK** or press **Enter** to accept the dimension as it is.
- Edit the dimension. For example, if your convention is to show dimensions to the nearest 10 or 50 you might overtype a dimension of 2134 with 2150. This will not update the positions of the points it refers to and should thus be entered as **2150 NTS** (not to scale) so that someone else taking over the drawing will know that the exact measured dimension is not in fact 2150.
- Add notes to the dimension.
- Replace the dimension. For example, you might be dimensioning a generic object. In this case, you could overtype the dimension that is displayed with a variable letter such as X. You could later use the Alter Dimension function to assign an exact value to X. See Start → Annotate → Alter Dimension (Alts), (A, N page 705). Alter Dimension only works on horizontal and vertical dimensions.

When you are satisfied with the text in the prompt, click $\bigcirc K$ or press \bigcirc Enter.

Text cramped. Enter vertical movement: <u>Up</u> <u>D</u>own <u>S</u>ame

This menu only appears if your text is too large to fit comfortably in the available space. Choose one of the options. If you select Up or **Down** the text will be moved in the relevant direction.

Text cramped. Enter new horizontal position: <u>L</u>eft <u>R</u>ight <u>S</u>ame

This menu only appears if your text is too large to fit comfortably in the available space. Choose one of the options. If you select Left or Right the text will be moved in the relevant direction.

(B)

If you have checked the Architectural Style button in <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Dimension Defaults</u>, go to the Enter Next Point prompt on page 678.

If you are drawing **Running** or **Chained** dimensions, "Sight" Survey prompts:

Enter next point

Position the cursor close to the next point to be included in the dimension and press *weiter* or click. Or you may cancel dimension drawing by pressing *Esc* or the *Space Bar*, or by clicking on *Cancel*.

If you are drawing Free dimensions, "Sight" Survey prompts:


Enter text position

Enter the text position for another dimension, or cancel dimension drawing by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.

Mechanical Style

If you have checked the Architectural Style button in <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Dimension Defaults</u>, "Sight" Survey prompts:

Enter text position



18





3

and

The cursor will switch to **Freehand** mode $(\uparrow \uparrow \uparrow \uparrow)$. Position it and click or press \bigcirc

The text and dimension line will be positioned at the cursor position.

The text will automatically be centered between the witness lines. If you do not want the text centered, you can move it to the desired position after you have drawn the dimension, using the <u>Start</u> \mathbf{W} <u>Modify</u> \mathbf{W} <u>Stretch</u> (<u>Alt</u> **S**, **M**, **E** - page 623).


To position the cursor accurately see **Accurate Placement** *on page 497.*

Enter position leader lines should extend to

Position the cursor where you want the leader lines to extend to and click or press *energy*.

To position the cursor accurately see **Accurate Placement** *on page 497.*

The next four prompts are the same as those beginning with the Enter First Point prompt on page 675.



Enter next point

Position the cursor close to the next point to be included in the dimension and click or press <u>-Enter</u>. Or you may cancel dimension drawing by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u>Cancel</u>.

	T .	1	ſ
<i>4</i> / .			

Vertical Dimension

FUNCTION: The <u>Vertical Dimension</u> function is used to write vertical dimensions to your drawing.

To access the <u>Vertical Dimension</u> function, press AHS, A, V, or click the Dimension icon () on the Drawing window toolbar.

This function works in exactly the same way as **Horizontal Dimension** (page 672) except that vertical dimensions are produced instead of horizontal ones.

27.11

Slope Dimension

FUNCTION: The <u>Slope Dimension</u> function is used to write slope dimensions to your drawing.


To access the <u>Slope Dimension</u> function, press <u>Att</u> (A, S), or click the <u>Dimension</u> icon ((B_{ac})) on the <u>Drawing</u> window toolbar and press S.

Dimension appearance (text height, arrow size, number of decimals, etc.) is set using **Start Settings Dimension Defaults** (Att **S**, **S**, **N** - page 826). The settings in **Dimension Defaults** will affect *all* the dimensions on your drawing (except those placed while doing COGO), including previously drawn ones. This means that if you are not satisfied with the way your dimensions look, you can change them at any stage.


You can change the text content, arrow type and witness line color of individual dimensions using <u>Start</u> \Rightarrow <u>Annotate</u> \Rightarrow Edit Dimension <u>Properties</u> (AttS, A, P - page 705).

Slope dimensions are fully *associative*. This means that if you change the size of a dimensioned object using, for example, **Stretch, Scale** or **Move Point**, the dimensions will automatically update to reflect the new size.

Section 27 There are three sloping dimension options: A dimension **parallel** to the line being dimensioned (below left); A dimension at a **fixed angle** that you type in (below right). In this example, 45 degrees has been typed;



And an **isometric dimension** where the witness lines are angled at 60 or 120° to the line being dimensioned. If you want to enter an isometric dimension, the **Isometric Grids** box in the **Start** \Rightarrow **Settings** \Rightarrow **Drawing Settings** dialog box must be checked.



Do you want dimension at fixed angle, (else take angle from points)


If you want to draw a dimension **parallel** to the line being dimensioned, click **No** and go to **Parallel sloping dimensions**.

If you want to draw a dimension at a **fixed angle** that you type in, click **Yes** and go to **Dimensions at fixed angles**.

If the **Isometric Grids** box in the <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow <u>Drawing</u> Settings dialog box is checked and you want to draw an isometric dimension, click <u>Yes</u> and go to <u>Isometric dimensions</u>.

Parallel sloping dimensions





The cursor will switch to **Point** mode $(\downarrow \downarrow \downarrow)$.

Enter first point

Position it close to the first point to be included in the dimension and click or press *enter*. The cursor will automatically jump onto the point. If you do not want to jump onto the point, you can change cursor modes.

Enter next point

Position the cursor close to the next point to be included in the dimension and click or press *Enter*.

Enter text of dimension			×
415.38'			
0	к	Cancel	

The distance between the two points is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click **OK** or press **Ener** to accept the dimension as it is.
- Edit the dimension. For example, if your convention is to show dimensions to the nearest 10 or 50 you might overtype a dimension of 2134 with 2150. This will not update the positions of the points it refers to and should thus be entered as **2150 NTS** (not to scale) so that someone else taking over the drawing will know that the exact measured dimension is not in fact 2150.
- Add notes to the dimension.
- Replace the dimension.

When you are satisfied with the text in the prompt, click OK or press -Enter.

Text cramped. Enter vertical movement: <u>Up</u> <u>D</u>own <u>S</u>ame

This menu only appears if your text is too large to fit comfortably in the available space. Choose one of the options. If you select **Up** or **Down** the text will be moved in the relevant direction.

> Text cramped. Enter new horizontal position: <u>L</u>eft <u>R</u>ight <u>S</u>ame

This menu only appears if your text is too large to fit comfortably in the available space. Choose one of the options. If you select Left or Right the text will be moved in the relevant direction.



Enter text position

Place the cursor where you want the text to appear and click or press $\boxed{-Enter}$. Note that the cursor mode has changed back to **Freehand** mode $\binom{\sim}{+}$.

The text will automatically be centered between the witness lines. If you do not want the text centered, you can move it to the desired position after you have drawn the dimension, using the <u>Start</u> ² Modify ² Stretch (Alt) S, M, E - page 623).



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter first point

Enter the first point of another dimension or cancel dimensioning by pressing Esc or the Space Bar, or by clicking on **Cancel**.

Dimensions at fixed angles

Enter bearing in form Nd*m's"₩	' (Use spaces or decimals between) 🗙
N 45°00'0" E	
ОК	Cancel

Type in the angle at which want the dimension to be drawn. If you are working in decimal angles, you will be asked to enter the bearing in the form dd.dddd (for example 45.5 degrees). If you are working in degrees, minutes and seconds, you will be asked to enter the bearing in degrees, minutes and seconds. When you have entered the angle click **OK** or press **.**

The way that angles are measured (for example counter-clockwise from 3 o'clock) depends on the way you have set up the Angular Format in Start \Im Settings \Im Drawing Settings.

Running			
	ОК	Cancel	
			_

27

Ĩ

This question, and the remaining questions are the same as for **Horizontal Dimensions**. *Please continue on page 673.*

Isometric d	imensions
-------------	-----------

Enter bearing in form Nd*m's"W	(Use spaces or decimals between) 🗙
N 45°00'0'' E	
ОК	Cancel

Type in the angle at which you want the dimension to be drawn and click $\bigcirc K$ or press $\underbrace{-Enter}$. This will be the same angle as the line you are dimensioning: 30, -30 or 90 degrees if you are doing an isometric drawing and have set up the **Angular Format** to measure counter-clockwise from the 3 o'clock position. The way that angles are measured depends on the way you have set up the Angular Format in Start $\sqrt[3]{S}$ Ettings $\sqrt[3]{D}$ rawing Settings.


Do you want witness lines to be at angle +60 (else at angle +120)

Click Yes if you want the witness lines to be angled at 60 degrees to the line being dimensioned, or No if you want the witness lines to be angled at 120 degrees (see diagram below).

Do you want running, chaine	d or free dimensions (R/C/F)
Running	
ОК	Cancel

()

This question, and the remaining questions are the same as for **Horizontal Dimensions.** *Please continue on page 673.*



27.12

Angular Dimension

FUNCTION: The **Angular Dimension** function is used to dimension angles or arc lengths.

To access the Angular Dimension function, press AtS, A, G, or click the Dimension icon (\blacksquare) on the Drawing window toolbar and press A.

Dimension appearance (text height, arrow size, number of decimals, etc.) is set using <u>Start **Settings Solimension Defaults**</u> (ArtS, S, N - page 826). The settings in <u>Dimension Defaults</u> will affect *all* the dimensions on your drawing (except those placed while doing COGO), including previously drawn ones. This means that if you are not satisfied with the way your dimensions look, you can change them at any stage.

Angular dimensions are not affected by the Witness Gap and Witness Overshoot options in <u>Start **Settings**</u> **Dimension** Defaults.

You can change the text content of individual dimensions using **Start Annotate Edit Dimension Properties** (AttS, A, P - page 705). However, you *cannot* change angular dimension witness line or dimension arrow colors once you have drawn the dimension.

Angular Dimension gives four options:

- 1. Dimensioning an angle between two existing lines;
- 2. Dimensioning an angle between three points;
- 3. Dimensioning an existing arc length; and
- 4. Dimensioning an arc length between three points.

When you access the **Angular Dimension** function, "Sight" Survey prompts:


Do you want angle (else arc length)

If you want to dimension an angle (below left), click **Yes** and go to **Dimensioning Angles** below.

If you want to dimension an arc length (below right), click **No** and go to **Dimensioning Arc Lengths** on page 690.




Dimensioning Angles



Dimensioning Angles Between Two Existing Lines

Witness line start



Is this dimension between two existing lines?

If there are two **intersecting** lines you want to dimension, click **Yes** and go to **Dimensioning Angles Between Two Existing Lines** on page 686. (The lines must actually intersect.)

If you want a dimension between three points, click **No** and go to **Dimensioning Angles Between Three Points** on page 688.


Select first line

Position the cursor near one of the two lines to be dimensioned and click or press *end*.

Select second line

Enter witness line start

Position the cursor where you want the witness lines to start and click or press -Enter.



Enter witness line end

Position the cursor at the place where you want the dimension arrow to be and click or press *enter*.

Enter text part of angular dimension	×
37.39°	
OK	

The angle between the two lines is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click **OK** or press **Enter** to accept the dimension as it is.
- Edit the dimension.
- Add notes to the dimension.
- Replace the dimension.

When you are satisfied with the text, click **OK** or press **Enter**.



To obtain a degree symbol, type Att 0176. Hold down the Att key while you type in the four numbers on the numeric keypad.

Satisfied with arc radius?

If you are satisfied with the position of the arc indicating the measurement (the position of the dimension arrow), click <u>Yes</u> Otherwise, click <u>No</u>.

Drag till satisfied with arc radius

This question is only asked if you answered <u>No</u> to the previous prompt.

As you move the cursor, you will see a circle expanding and shrinking. This circle represents the position of the dimension

arrow. Once the position of the arrow is satisfactory, click or press $\overline{\mathbf{rentr}}$.

Satisfied with text position?

If you are satisfied with the position of the text, click Yes. Otherwise click No.

Enter new dimension text position

This question is only asked if you answered **No** to the previous prompt.

•

ead

When you reposition text, it will always be horizontal and not at an angle around the arc.

Use the cursor to drag the dimension text (represented by a box) to a new position and click or press Fire.

Dimensioning Angles Between Three Points



Enter center point

Position the cursor at the center point of the three and click or press *renter*.

To position the cursor accurately see **Accurate Placement** *on page* 497.






Enter first angular point (defines witness line start)

Position the cursor at one of the other points and click or press . This first angular point will also define the witness line start.

Enter second angular point (defines text radius)



Position the cursor on the last point and click or press *end*. This point also defines the **position of the dimension arrow**.

Enter text part of angular dimension	×
37.39°	
OK Cancel	

The angle between the two lines is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click **OK** or press **Ener** to accept the dimension as it is.
- Edit the dimension.
- Add notes to the dimension.
- Replace the dimension.

When you are satisfied with the text, click **OK** or press **Fine**.



To obtain a degree symbol, type Att 0176. Hold down the Att key while you type in the four numbers on the numeric keypad.


Satisfied with arc radius?

If you are satisfied with the position of the arc indicating the measurement (the position of the dimension arrow), click <u>Yes</u> Otherwise, click <u>No</u>.

Drag till satisfied with arc radius

This question is only asked if you answered **No** to the previous prompt.

As you move the cursor, you will see a circle expanding and shrinking. This circle represents the position of the dimension arrow. Once the position is satisfactory, click or press Fine.



If you are satisfied with the position of the text, click \underline{Yes} and go to Dimensioning Arc Lengths. Otherwise click \underline{No} .


Enter new dimension text position



When you reposition text, it will always be horizontal and not at an angle around the arc.

Use the cursor to drag the dimension text (represented by a box) to a new position and click or press *enter*.

Dimensioning Arc Lengths



First point

Dimension an Existing Arc

Is this dimension of an existing arc?

If the arc you want to dimension already exists, click **Yes** and go to **Dimension an Existing Arc**.

Otherwise, you must define an arc by three points - the arc center and two points that define the arc radius to be measured and the position of the dimension arrow. Click <u>No</u> and go to Dimension an Arc Between Three Points on page 692.

Select arc

Position the cursor on the arc you want to dimension and click or press *rentrance*.

Enter text part of angular dimension	×
37.39°	
OK Cancel	

The angle between the two lines is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click OK or press Fine to accept the dimension as it is.
- Edit the dimension.
- Add notes to the dimension.
- Replace the dimension.

When you are satisfied with the text, click **OK** or press **PEnter**.

To obtain a degree symbol, type All 0176. Hold down the All key while you type in the four numbers on the numeric keypad.

Satisfied with arc radius?

If you are satisfied with the position of the arc indicating the measurement (the position of the dimension arrow), click <u>Yes</u> Otherwise, click <u>No</u>.

Drag till satisfied with arc radius

This question is only asked if you answered **No** to the previous prompt.

As you move the cursor, you will see a circle expanding and shrinking. This circle represents the position of the dimension arrow. Once the position is satisfactory, click or press *etement*.

Satisfied with text position?

If you are satisfied with the position of the text, click <u>Yes</u>. Otherwise click <u>No</u>.

Enter new dimension text position

This question is only asked if you answered **No** to the previous prompt.




When you reposition text, it will always be horizontal and not at an angle around the arc.

Use the cursor to drag the dimension text (represented by a box) to a new position and click or press -Enter.

Dimension an Arc Between Three Points

Enter center point




Position the cursor at the first point and click or press *etenter*. Bear in mind that the arc will be measured in an counter-clockwise (ccw) direction between the two points you enter.

The point you enter here also defines the actual arc radius that will be measured.

Enter second angular point (defines text radius)

Position the cursor at the second point and click or press — Internet. The point you enter here also defines the position of the dimension arrow.





The arc length between the two lines is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click OK or press enter to accept the dimension as it is.
- Edit the dimension.
- Add notes to the dimension.
- Replace the dimension.


When you are satisfied with the text, click **OK** or press **-**Enter.



To obtain a degree symbol, type Att 0176. Hold down the Att key while you type in the four numbers on the numeric keypad.

Satisfied with arc radius?

If you are satisfied with the position of the arc indicating the measurement (the position of the dimension arrow), click <u>Yes</u> Otherwise, click <u>No</u>.



This question is only asked if you answered **No** to the previous prompt.

As you move the cursor, you will see a circle expanding and shrinking. This circle represents the position of the dimension arrow. Once the position of the arrow is satisfactory, click or press

Satisfied with text position?

If you are satisfied with the position of the text, click Yes. Otherwise click No.

Enter new dimension text position

This question is only asked if you answered **No** to the previous prompt.



When you reposition text, it will always be horizontal and not at an angle around the arc.

Use the cursor to drag the dimension text (represented by a box) to a new position and click or press Fire.

27.13

<u>R</u>adial Dimension


FUNCTION: The <u>Radial Dimension</u> function is used to dimension arcs or circles.

To access the <u>Radial Dimension</u> function, press <u>At</u>[S], <u>A</u>, <u>B</u>, or click the <u>Dimension</u> icon (\blacksquare_{2}) on the <u>Drawing</u> window toolbar and press <u>R</u>.

This function enters a radial dimension onto an arc or circle. In the case of arcs, the radius is measured and is indicated by an **R**. In the case of circles, the diameter is measured and is indicated by a \emptyset (the diameter sign).

Dimension appearance (text height, arrow size, the number of decimals, etc.) is set using <u>Start</u> <u>Settings</u> <u>Dimension Defaults</u> (<u>Att</u><u>S</u>, <u>S</u>, <u>N</u> - page 826). The settings in <u>Dimension Defaults</u> will affect *all* the dimensions on your drawing (except those placed while doing COGO), including previously drawn ones. This means that if you are not satisfied with the way your dimensions look, you can change them at any stage.

You can change the text content of individual radial dimensions using <u>Start</u> ⇒ <u>Annotate</u> ⇒ <u>Edit Dimension</u> <u>Properties</u> (<u>Att</u>S, <u>A</u>, <u>P</u> page 705). However, you *cannot* change angular dimension witness line or dimension arrow colors once you have drawn the dimension.



When you access the **<u>R</u>adial Dimension** function, "Sight" Survey prompts:

Radial dimension .. select arc or circle

Position the cursor close to the arc or circle you want to dimension and click or press *Enter*.



This cursor position affects the way that the dimension will be drawn. See the prompt **Do you want text on radius arrow?** below.

Enter text of radial dimension	×
R 15.25	
OK Cancel	

The radius of an arc or the diameter of a circle is measured and is displayed on the screen as text in the prompt. To accept the dimension as it is, click $\bigcirc K$ or press $\boxed{-Enter}$. Alternatively, you can add tolerances to the dimension, add notes to it or edit it. When the dimension text is to your satisfaction, click $\bigcirc K$ or press $\boxed{-Enter}$.

•

To obtain a diameter symbol (\emptyset) , type Alt **0216**. Hold down the Alt key while you type in the four numbers on the numeric keypad.

Do you want text on radius arrow?

If you want text along the radius arrow (arc) or along the diameter arrow (circle), click <u>Yes</u>.

The radius or diameter arrow will be drawn. It will be drawn through the point where you positioned the cursor in the first prompt and through the arc or circle center. Thus, for a horizontal arrow you must position the cursor at the extreme left or right edge of the arc or circle indicated in the first prompt.

If you do not want text on the arrow, click **No** and skip the next prompt.

Enter text position

This question is only asked if you answered **No** to the previous prompt.


Position the cursor where the text should appear and click or press <u>Enter</u>. The radius or diameter arrow will be drawn. It will be drawn through the **text position** you have specified and through the **arc or circle center**.

٩

<u>Ø 20</u>

When you reposition text, it will always be horizontal and not aligned along the dimension line.

Radial dimension .. select arc or circle



Position the cursor close to the arc or circle you want to dimension and click or press *Etter*, or cancel dimensioning by pressing *Esc* or the *Space Bar*, or by clicking on *Cancel*.

27.14

Survey Dimension

FUNCTION: The **Survey Dimension** function is used to place bearing and/or distance dimensions on your drawing.

To access the **Survey Dimension** function, press Att(S), A, U, or click the **Dimension** icon (\blacksquare) on the **Drawing** window toolbar and press U. You may also enter the routine by clicking the **Surveying Dimension** icon (\blacksquare) in the **Drawing** window toolbar. (**Not** the dimension icon on "Sight" Survey's **Main** tool bar.)

Dimensions placed into your drawing using this function are similar to those placed automatically by COGO functions. **Survey Dimension** offers you a very quick, convenient method for placing bearing and/or distance dimensions on your drawing, simply by snapping to points. You will find it most useful in replacing the COGO **Inverse** function when adding extraneous dimensions to your drawing.

Since **Survey Dimension** places only text, without drawing a line like **Inverse**, it is perfect for dimensioning parking spaces, road right-of-ways, offsets, etc.

Dimension appearance are controlled by various settings. Text style and number of decimals are set using <u>Start</u> → <u>Settings</u> → <u>Dimension Defaults</u> (AttS, S, N - page 826). Dimension format and angular decimals are controlled by using <u>Start</u> → <u>Settings</u> → <u>Surveying Dimension</u> (AttS, S, G - page 826).



The settings in **Dimension Defaults** will affect **all** the dimensions on your drawing (except those placed while doing COGO), including previously drawn ones.

Surveying Dimensions do not use arrows and witness lines.

Surveying dimensions are not associative. This means that if you change the size of a dimensioned object using, for example, **Stretch, Scale** or **Move Point**, the dimensions will *not* automatically update to reflect the new size. You must delete the dimensions and then redimension the object.



For ease of use, you should be in **Point** w or **Grab All** □ snap mode prior to using this function. Click the appropriate icon on the **Drawing** window toolbar. See Start Settings S. Snap Mode (AttS, S, S, S - page 804).

When you access the **Surveying Dimension** function, "Sight" Survey prompts:

Enter first point

Enter next point

If you want to jump to a new first point press the Space Bar. Otherwise, position the cursor at the next point and click or press renter. The dimension will be written.

Enter next point

The most recent point becomes the new first point, and his prompt will repeat until you jump to a new first point or press **Esc** or **Cancel** to exit the routine.

27.15

Ordinate Dimension

FUNCTION: The **Ordinate Dimension** function is used to enter ordinate dimensions.

To access the <u>Ordinate Dimension</u> function, press <u>Att</u>, <u>A</u>, <u>O</u>, or click the <u>Dimension</u> icon (\blacksquare_{a}) on the <u>Drawing</u> window toolbar and press <u>O</u>.

Dimension appearance (text height, arrow size, number of decimals, etc.) is set using **Start Settings Dimension Defaults** (Att **S**, **S**, **N** - page 826). The settings in **Dimension Defaults** will affect *all* the dimensions on your drawing (except those placed while doing COGO), including previously drawn ones. This means that if you are not satisfied with the way your dimensions look, you can change them at any stage.

You can change the text content, arrow type and witness line color of individual dimensions using <u>Start</u> $\xrightarrow{\mathbb{P}}$ <u>Annotate</u> $\xrightarrow{\mathbb{P}}$ Edit Dimension <u>Properties</u> (AttS, A, P - page 705).

Ordinate dimensions are fully *associative*. This means that if you change the size of a dimensioned object using, for example, **Stretch**, **Scale** or **Move Point**, the dimensions will automatically update to reflect the new size. You can also change ordinate dimensions to cause a change in the size of dimensioned object. See <u>Start</u> [®] <u>Annotate</u> [®] <u>Alter Dimension</u> (<u>Alt</u>S], <u>A</u>, <u>N</u> - page 705).

When you access the **Ordinate Dimension** function, "Sight" Survey prompts:


Section 27

X Ordinate (Else Y Ordinate)

Click Yes if you want ordinate dimensions along the x axis (as shown below to the left). Click No if you want ordinate dimensions along the y axis (as shown below to the right).



Enter first (base) point




This is the point from which the ordinate dimensions will be measured.

The cursor switches to **Point** mode $\begin{pmatrix} \downarrow \downarrow \downarrow \end{pmatrix}$. Position it close to the base point and click or press $\boxed{\text{remin}}$. The cursor will automatically jump onto the point. If you do not want to jump onto the point you

can change cursor modes, for example by clicking on the Freehand icon (\square) in the Drawing window toolbar.

Enter text position




This defines where the dimension text will be positioned.

The cursor switches to **Freehand** mode $(\downarrow \uparrow \uparrow \uparrow)$. Position it where you want the dimension text to be and click or press \neg Enter. The dimension text will appear in line with the position you enter.

To position the cursor accurately see **Accurate Placement** *on page 497.*

Enter next point



The cursor switches back to **Point** mode $\begin{pmatrix} 4 & 4 \\ + & - \end{pmatrix}$. Position it close to a point to be dimensioned and click or press -Ener. The cursor will automatically jump onto the point.


n text		×
ОК	Cancel	

The distance between the base point and the point you have just entered is measured and is displayed on the screen as text in the prompt. At this point you can:

- Click **OK** or press **Ener** to accept the dimension as it is.
- Edit the dimension.

- Add notes to the dimension.
- Replace the dimension.

When you are satisfied with the text, click **OK** or press **Ener**. The dimension appears on the drawing.



Enter next point

The cursor switches back to **Point** mode $(\frac{1}{4}, \frac{1}{4})$. Position it close to a point to be dimensioned and click or press <u>refree</u>. This prompt will be repeated until you cancel the function by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u>**Lancel**</u>.


27.16

Dimension Arc

FUNCTION: The **Dimension Arc** function is used to dimension an arc.

To access the **Dimension Arc** function, press Alt S, A, I.

Dimension Arc is used to place the delta angle, arc length, and radius along an arc. You are given the



option of using a witness arrow and placing the dimensions away from the arc.

Dimension appearance are controlled by various settings. Text style, arrow style, and number of distance decimals are set using **Start ⇒ Settings ⇒ Dimension Defaults** (AttS, S, N - page 826). The number of angular

decimals is controlled by using <u>Start</u> \Rightarrow <u>Surveying</u> Dimension (AttS, S, G - page 826).

Dimensions placed using Dimension Arc are not associative. This means that if you change the size of a dimensioned object using, for example, **Stretch**, **Scale** or **Move Point**, the dimensions will **not** automatically update to reflect the new size. You must delete the dimensions and then re-dimension the object.

When you access the **Dimension Arc** function, "Sight" Survey prompts:

Select arc to dimension

Position the cursor near the arc you want to dimension and click or press *[emer]*. This position may affect the placement of the arc text. See the discussion for the next prompt.

Text along the arc? (else apart)

Click \underline{Yes} to place the text at point you clicked in the first prompt. Click \underline{No} to place the text at a different location and connect the text to the arc with a witness line and arrowhead.

Enter text position

This prompt, as well as the next three prompts, will only appear if you answered \underbrace{No} to the previous prompt. Position the cursor where you want the to be and click or press $\underbrace{-Enter}$.

Enter arrow tail

Position the cursor where you want an arrow tail to be and click or press <u>refer</u>.

Enter next point of arrow (exit = [Space Bar] to enter arrow head)

Position the cursor where you want the arrow head or a bend in the arrow tail to be. To place a bend in the line, click or press <u>Finer</u>. To place an arrowhead, press <u>Space Bar</u>.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter arrow head

Position the cursor where you want the arrow head to be and click or press *energy*. The dimension line is drawn.

Select arc to dimension

Position the cursor near the arc you want to dimension and click or press <u>-Enter</u>, or cancel this routine by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u>Cancel</u>.

27.17

Dimension Perpendicular +

FUNCTION: The **Dimension Perpendicular** function is used to compute and annotate (on the drawing) the perpendicular dimension from a baseline to a point.

Before beginning this routine, you might want to set the dimension <u>Text Height</u> to a value more compatible with the small perpendicular dimensions you'll be placing on the drawing. Right-click the Dimension icon (\blacksquare) in the Drawing window toolbar to activate the Dimension Settings and change the dimension <u>Text Height</u>.

Section 27

To access the **Dimension Perpendicular** function, press Alt S, A, \oplus ., or right-click the **Snap Perpendicular** button (p) on the **Drawing** window toolbar.

If the setting for **Surveying Dimensions** is not set to **Distance Only**, "Sight" Survey will suggest that you change the setting. In the **Drawing** window command line, you are prompted:

For best results, set Survey Dimension Format to Distance Only.

Since you are measuring only distances from a baseline to a point, the bearing of the line to the point is irrelevant and should not be printed. Therefore, you should instruct "Sight" Survey to print only the distances. To change the setting for **Surveying**

Dimensions, click <u>Yes</u>. The Survey Dimensions Setup dialog box appears:

Survey Dimension Setup	×
Survey Dimension Orientation	
\diamond Text follows bearing direction	
Text is always upright	
Survey Dimension Format	-
\diamond Bearing on top, Distance on bottom	
\diamond Distance on top, Bearing on bottom	
\diamond Both Bearing and Distance on top	
Distance only	
Bearing direction is counter-clockwise	
Round to 0 Seconds.	
(0 uses default angular decimals)	
<u>O</u> K <u>C</u> ancel	

Under the **Survey Dimension Format** section, click the option **Distance only**. Click **OK** to close the dialog box. In the **Drawing** window command line, you are prompted:

Select the baseline

Move the cursor onto (or near) the baseline and click. "Sight" Survey prompts:



To label with only a dimension, press 1 or click **Dimension Only**. To label with a dimension and draw a dashed line from the baseline to the point, press 2 or click **Line and Dimension**. To quit this routine, press 3 or click **Quit**.

If you select option 1 or 2, "Sight" Survey prompts:

Select a point

Move the **Grab All** cursor (\Box) cursor so the point to which you want to dimension is in the box and click. "Sight" Survey will place the dimension on the drawing. This prompt will repeat until you press **Esc** or **Cancel** to quit this routine.

27.18

Edit Dimension Properties

FUNCTION: The **Edit Dimension Properties** function may be used to: edit the text of an individual dimension; change a dimension arrow head; and/or edit the color of the witness lines and dimension arrows.

To access the **Edit Dimension** <u>Properties</u> function, double click on the dimension you want to edit. This short cut only works on **horizontal**, **vertical** and **slope** dimensions.



You cannot use Edit Dimension Properties to edit survey dimensions.

Section 27

This function does three things:

- 1. Edits the text of an individual dimension. For example, you can add tolerances, add notes, change the text etc.
- 2. Changes a dimension arrow head into a blob (horizontal, vertical and slope dimensions only).
- 3. Edits the color of the witness lines and dimension arrows (horizontal, vertical and slope dimensions only).


To change dimension parameters (for example text size, number of decimals etc.), use <u>Start [™]>Settings</u> [™]>Dimension Defaults (ARS, S, N - page 826).

To move dimension text, use <u>Start</u> \mathbb{R} <u>Modify</u> \mathbb{R} <u>Stretch</u> (<u>Att</u><u>S</u>, <u>M</u>, <u>E</u> - page 623). To cut out portions of witness lines, use <u>Start</u> \rightarrow <u>Annotate</u> \rightarrow Cut Dimension Line (Att S, A, L) - page 707).

When you access the **Edit Dimension** <u>Properties</u> function, "Sight" Survey prompts:

Select dimension to be edited

Position the cursor anywhere on the dimension to be edited and click or press *etcher*.



Select the editing option from the menu shown by clicking on the desired item.

Editing Text

Enter new text		× • • • • • • • • • • • • • • • • • • •	<
221.9780'			
	ОК	Cancel	

The existing dimension text is displayed in the prompt. Edit it, then click $\bigcirc K$ or press \bigcirc .

Select dimension to be edited

Select another dimension to edit and click or press —Enter, or cancel dimension editing by pressing Esc or the Space Bar, or by clicking on **Cancel**.

Editing Arrow Heads

Place cursor near arrow head to change

Position the cursor near the arrow head you wish to change and click or press *etage*. The arrow head is changed into a blob.

Select dimension to be edited

Select another dimension to edit and click or press —Enter, or cancel dimension editing by pressing Esc or the Space Bar, or by clicking on **Cancel**.

Editing Pen

Enter new witness line pen

Select dimension to be edited

Select another dimension to edit and click or press *Enter*, or cancel dimension editing by pressing *Esc* or the *Space Bar*, or by clicking on **Cancel**.

27.19

Cut Dimension Line


FUNCTION: The **Cut Dimension** <u>Line</u> function is used to cut the witness lines of **horizontal** and **vertical** dimensions.

To access the Cut Dimension Line function, press AltS, A, L.

Select dimension whose line must be cut

Position the cursor on the dimension text of the dimension whose witness line you are going to cut and click or press *rener*.

Enter snip box for cutting line



Position the cursor at one corner of the snip box and click or press

Enter second corner of rectangle

Move the cursor diagonally away from the first corner you entered and click or press *-Enter*.

The portion of the witness line inside the snip box is deleted.

Select dimension whose line must be cut

Position the cursor on another dimension and click or press —Enter, or cancel witness line cutting by pressing Esc or the Space Bar, or by clicking on <u>Cancel</u>.

27.20

Alter Dimension

FUNCTION: The **Alter Dimension** function physically changes the size of part of a drawing when the dimension text associated with that part is changed.

To access the Alter Dimension function, press AltS, A, N.



Alter Dimension only works on horizontal and vertical dimensions.

Access the **Alter Dimension** function when you want to change the size of a drawing element by changing its dimension. For example, if you change the dimension text shown here from 17.3 to 40, the dimensioned object will lengthen (or shorten) to fit the new dimension text.



40

L

This enables *"drawing by number"*, where you draw the generic outline of a part and dimension it with variables such as *A*, *B*, *C*, *X*, etc.

You can enter dimension variables as you dimension the object when "Sight" Survey prompts Enter text of dimension. You can also enter these variables using Text in Start \Rightarrow Annotate \Rightarrow Edit Dimension Properties.


You can then use Alter Dimension to change the dimension text. For example, if you change the dimension text shown here from x to 40, the dimensioned object will lengthen (or shorten) to fit the new dimension text.



Each dimension should be assigned a different variable name. "Sight" Survey will not know which dimension you wish to change if there are more than one with the same name.

Prompt # 1	Select dimension to be altered with cursor (else search for text)
	If you want to select the dimension text to be altered by clicking on it with your mouse, click Yes and go to Prompt # 2 .
	If you want to type the dimension text to be altered, click No and go to Prompt # 3 .
	Selecting the dimension text to change by clicking on it if you answered $\boxed{\underline{Yes}}$ to Prompt # 1.
Prompt # 2	Select dimension to be altered with cursor
	Click on the dimension you want to alter and go to Prompt # 4 .
	Type the dimension text to change if you answered No to Prompt # 1 .

Prompt # 3



Type the text you want to alter. It is important that you type the dimension text **exactly** as it appears on the drawing, including decimal points or commas and any trailing spaces or zeros. Click **OK** or press **ener**.

Enter new dimension text (will cause dimension to alter)	×
<mark>391.76'</mark>	
OK Cancel	
OK Cancel	

Type in the numeric value that the dimension text must change to and click $\bigcirc K$ or press \bigcirc The dimension and dimensioned part will shrink or stretch to match the new value.


Alter a whole area, along witness line, or at witness point	(A/L/P) 🛛 🗙
Area	
OK Cancel	

The answer you type here determines what will be affected by the new dimension. Type **A** for **Area**, **L** for along witness **Line**, or **P** for **Point**. Then click \bigcirc or press $\underbrace{\text{--Enter}}$.


If you type A to alter the Area, the whole drawing will be updated.

Prompt # 4


Prompt # 5




If you type **L** to alter **along a witness Line**, all points that lie on a witness line will be altered, but the rest of the drawing will not change.



If you type **P** to alter a **Point**, only the dimensioned line will be altered. The rest of the drawing will not change.





Before Alter Dimension.

After Alter Dimension. X has been dimensioned 28. Only the dimensioned line has been altered.

Prompt # 6	Keep left/lower point fixed? (else right/upper)
	If you click <u>Yes</u> , the left most point of the dimension will remain fixed if you are altering a horizontal dimension and the lowest point of the dimension will remain fixed if you are altering a vertical dimension. Alterations will take place about this point.
	If you click <u>No</u> , the right most point of the dimension will remain fixed if you are altering a horizontal dimension and the highest point of the dimension will remain fixed if you are altering a vertical dimension. Alterations will take place about this point.
Prompt # 7	Select dimension to be altered with cursor (else search for text)
	Alter another dimension or cancel dimension altering by pressing the Space Bar

27.21

Add Arrow ->

FUNCTION: The **Add Arrow** function is used to draw chained lines terminated by an arrow head.

To access the Add Arrow function, press Att S, A, >.

The arrow color, size of the head, and whether the arrow head is a blob or slash is determined in <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow <u>Set Arrow</u> **Defaults** (XA or Att S), (S), (W) - page 832).

These segments of the arrow are considered lines

Only this segment of the arrow is considered an arrow

Only the last line segment with the arrow head is considered an arrow. The preceding line segments are regarded as normal lines. This may lead to some confusion when using functions that discriminate between arrows and other elements. For example, if you use **Set Arrow Defaults** to change the color of an arrow, only the color of the last segment with the arrow head will be changed. You must use **Line Defaults** to change the color of the other arrow segments.

Enter arrow tail

Position the cursor where you want an arrow tail to be and click or press *-Enter*.

Enter next point of arrow (exit = [Space Bar] to enter arrow head)

Position the cursor where you want the arrow head or a bend in the arrow tail to be and click or press *Enter*.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter next point of arrow (exit = [Space Bar] to enter arrow head)




If you want the arrow head to be at the end of the line you have just drawn, press the Space Bar or click **Cancel**.

If you want to add another line to the arrow before adding the head, position the cursor where you want the arrow head or a bend in the arrow tail to be and click or press *returner*.

Enter arrow tail

Enter the position of another arrow tail or cancel arrow drawing by pressing Esc or the Space Bar, or by clicking on **Cancel**.



Enter first text for balloon	×
ОК	Cancel

Type the text for the balloon and click OK or press eterer. If you specified two lines of text in the <u>Start</u> → <u>Settings</u> → <u>Set Balloon</u> **Defaults** (AttS, S, O - page 834) function, the prompt will be repeated so you may enter the second text line.

Enter next point for arrow (press [Space Bar] to produce arrow head)



This question is only asked if you have specified arrows in the <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow <u>Set Balloon Defaults</u>.

Position the cursor where you want the arrow head or a bend in the arrow tail to be and click or press *Enter*.

This prompt will be repeated until you press the Space Bar, or click on **Cancel** to add an arrow head to the line you have just drawn.

Enter text position for balloon

Position the cursor where you want balloon text to appear and click or press <u>Finer</u>. Alternatively cancel balloon drawing by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u>Cancel</u>.

27.23

This is a

bubble

Add/Rem Text Bubble

FUNCTION: The Add/Rem Text Bubble function is used to add or remove a text bubble to or from existing text.



To access the Add/Rem Text Bubble function, press AttS, A, 7.

Select text that you want to add/remove balloon to

Position the cursor close to text that you want to add a balloon to or remove a balloon from. Click or press *etcher*.

The balloon becomes part of the text parameters. This means that if you use the **Take From** option in the **Start** \Rightarrow **Settings** \Rightarrow **Set Text Defaults** (AltS, S, E) - page 820) function to set text parameters and pick on the text with the balloon, subsequent text will also have a balloon.

Select text that you want to add/remove balloon to

Position the cursor close to other text that you want to add a balloon to or remove a balloon from and click or press <u>"Enter</u>. Cancel bubble drawing by pressing <u>Esc</u> or the <u>Space Bar</u>, or by clicking on <u><u>Cancel</u>.</u>

Enter Hatch/Solid Fill

FUNCTION: The **Enter Hatch/Solid Fill** function is used to hatch or solid fill an area.

To access the Enter Hatch/Solid Fill function, press AttS, A, F, or click the Hatch/Fill icon () in the Drawing window toolbar.



To hatch a polyline, see <u>Start</u> \Rightarrow <u>Settings</u> \Rightarrow Polyline Defaults (AttS, S, F - page 812).

In "Sight" Survey, you can either cross hatch an area (below left), or solid fill an area (below right).





When you select Enter Hatch/Solid Fill, the Hatch or Solid Fill dialog box appears on the screen in one of two versions: Hatch; or Solid Fill.

Hatch dialog box

27.24

This dialog box appears if the <u>Hatch</u> option is checked. If you want a solid fill, check the <u>Solid Fill</u> option.

Hatch or Solid Fill
◆ <u>H</u> atch ◇ <u>S</u> olid fill
No Hatch
angle
ansi31 ansi36 ▼
⊻iew
Scale: 1
<u>O</u> K <u>C</u> ancel

Perimeter Menu

Enter perimeter: <u>A</u> uto
Line
R <u>e</u> ctangle
A <u>r</u> c
<u>C</u> ircle
Intersections
0 <u>bj</u> ect
Do <u>n</u> e Perim
<u>S</u> how Perim
<u>D</u> el Previous
Dash T <u>o</u> ggle
<u>T</u> olerance
<u>Q</u> uit

The **Hatch** dialog box contains a list of hatch pattern names and a scale option. The scale option allows you to scale hatch patterns.

Hatches are stored in a file named **HATCH.PAT**, which is located in the program directory. You can edit hatches in this file, and even add your own hatches to the file. See **Section 32 - Hatch Patterns** for more information.

If you give a scale of 1, hatches are drawn at the size defined in the **HATCH.PAT** file. If you give a scale of 2, hatches are drawn at twice the size defined in the **HATCH.PAT** file, etc.

Click on the name of the hatch pattern you want to use, then click **OK**. If you are not sure what the hatch patterns look like, click

on the <u>Yiew</u> button. A sample of each hatch pattern will appear on the screen. Click on the one you want to use.

The **Perimeter Menu** appears. Choose one of the top five items for use in defining the hatch area. To select an item, press the underlined letter, or click the item.

Enter Perimeter: <u>Auto</u> If you select this option, you will be asked to click the cursor inside the desired perimeter. You will then be asked if you are satisfied with the perimeter. Click <u>Yes</u> and the hatch/fill is drawn.

Line If you select this option, the prompts that you get will be exactly the same as for <u>Start</u> \rightarrow <u>Draw</u> \rightarrow <u>Line</u> (Chained) (LI or AltS, D, H - page 585). When you have completed drawing the line, press <u>Esc</u> or <u>Space Bar</u> and "Sight" Survey will return you to the **Perimeter Menu**. Select <u>Done</u> Perim and the hatch/fill is drawn.

Rectangle If you select this option, the prompts that you get will be exactly the same as for **Start** [™] **Draw** [™] **Rectangle** (**DR** or **AttS**, **D**, **T** - page 588). When you have completed drawing the rectangle, press **Esc** or **Space Bar** and "Sight" Survey will return you to the **Perimeter Menu**. Select **Done Perim** and the hatch/fill is drawn.

Arc If you select this option, the prompts that you get will be exactly the same as for Start \bigcirc Draw \bigcirc Arc 3 Point (AC or Art), \square , \square - page 589). When you have completed drawing the arc,

press **Esc** or **Space Bar** and "Sight" Survey will return you to the **Perimeter Menu**. Select **Done Perim** and the hatch/fill is drawn.

<u>Circle</u> If you select this option, the prompts that you get will be exactly the same as for <u>Start</u> ² → <u>Draw</u> ² → <u>Circle</u> (DC or <u>Aft</u> S, D, C page 591). When you have completed drawing the circle, press <u>Esc</u> or <u>Space Bar</u> and "Sight" Survey will return you to the **Perimeter Menu**. Select <u>Done</u> **Perim** and the hatch/fill is drawn.

Hatches and solid fills can significantly slow down redraws. It is a good idea to go to <u>Start</u> <u>Settings</u> <u>View Settings</u> (AttS, S, \square - page 799) and to set the Hatch to Draw section of the dialog box to None. This means that hatches will not be drawn on redraws. If you then want to see your hatches, you can display them when you want to using <u>Start</u> <u>Annotate</u> <u>Draw All Hatch</u> (AttS, A, D - page 721).

Solid Fill dialog box

Hatch or Solid Fill	×
♦ <u>Hatch</u> ◆ <u>S</u> olid fill	
Set Color	
<u>O</u> K <u>C</u> ancel	

Solid Filling Areas with Islands

This dialog box appears if the **Solid Fill** option is checked. If you want a solid fill, check the **Hatch** option.

The **Solid Fill** dialog box contains a color palette that allows you to select a solid fill color.

The current solid fill color setting is displayed on the **Set Color** button. To change the color, click on the button and a palette will appear. Click on the color you want for solid fills. When you are satisfied with the color of the solid fill, click $\Box K$.

The **Perimeter Menu** appears (see page 717.) Use it to define the area to be filled. Once you have defined the perimeter, it is filled.

It is easy to cross hatch an area with an island in "Sight" Survey. However, if you try to solid fill an area with an island you can end up with fills that look quite ugly.





To prevent this happening, you can divide the area to be filled into sub-areas without islands. For example, this is the original area to be filled.



By extending the left hand vertical line of the D so it touches the top and the bottom of the box, the area can be divided into three sub-areas without islands: the area to the left of the D, the area to the right of the D, and the area in the middle.



These three areas can then be filled to achieve the desired effect.



You can also create solid fills with islands as follows: Solid fill an area, then solid fill another area on top of it in white, to make the island.



27.25

Adjust Existing Hatch

FUNCTION: The **Adjust Existing Hatch** function is used to adjust or alter an existing hatch.

To access the Adjust Existing Hatch function, press AltS, A, J.



This function allows you to alter the hatch pattern of a hatch, the hatch scale and/or the hatch perimeter. For example, Adjust Existing Hatch will allow you to alter a hatch such as this one ...



... in order to create a hatch such as this one.

周
A
<u> </u>

When you select **Adjust Existing Hatch**, a cross corresponding to each hatch appears.

Select hatch to change

Position the cursor on the cross corresponding to the hatch you want to alter and click or press File. The Hatch dialog box or the Solid Fill dialog box appears. See Start Annotate Charles Enter Hatch/Solid Fill (Alt) (Alt

If you do not want to change the hatch pattern or scale of the hatch but want to change the perimeter, for example by adding an island as in the diagram above, click $\Box K$.

Otherwise, select a new hatch pattern or scale from the Hatch or the Solid Fill dialog box, then click OK. The Perimeter Menu appears. (See page 717.) If you don't want to alter the hatch perimeter, click <u>Accept</u>.

If you do want to alter the perimeter, as in the example illustrated where a circle has been added to the perimeter, draw the additional perimeter. Then click on the **Done Perim** option of the **Perimeter Menu** and the updated hatch will be drawn.

<u>D</u>raw All Hatch

FUNCTION: The <u>Draw All Hatch</u> function is used to display hatches on screen.

To access the **Draw All Hatch** function, press AltS, A, D.

Since hatches can significantly slow down redraws, it is a good idea to "switch them off" and to display them only when you want to see them.

To "switch off" hatches, you must set to **None** the **Hatches to Draw** section of the <u>Start \Rightarrow Settings</u> \Rightarrow <u>View Settings</u> dialog box (AttS, $\$, \forall - page 799).

When you want to see the hatches, select <u>Draw All Hatch</u>. The hatches will be displayed on the screen. They will disappear next time you redraw the screen.

27.27

Draw Selected Hatch

Section 27

FUNCTION: The **Draw Selected Hatch** function is used to display selected hatches on screen.

To access the Draw Selected Hatch function, press AttS, E, O.

Since hatches can significantly slow down redraws, it is a good idea to "switch them off" and to display them only when you want to see them.

To "switch off" hatches, you must set to **None** the **Hatches to Draw** section of the <u>Start \Rightarrow Settings</u> \Rightarrow <u>View</u> Settings dialog box (Att)S, [S, V] - page 799).

You can display selected hatches on the screen when desired using **Draw Selected Hatch**. The hatches will disappear next time you redraw the screen.

Selected hatches are hatches that have been selected using the Hatch option in <u>Start</u> \Rightarrow <u>Edit</u> \Rightarrow <u>Selection Filters</u> (<u>Alt</u>S, E, F - page 560).

27.28

<u>H</u>atch -> Lines

FUNCTION: The <u>Hatch -> Lines</u> function is used to convert a hatch to lines.

To access the <u>Hatch -> Lines</u> function, press <u>Alts</u>, <u>A</u>, <u>H</u>.

To keep memory requirements for hatching minimal, "Sight" Survey stores only the hatch perimeter, not the lines that make up the hatch. These are recalculated each time the hatch is displayed. <u>Hatch -> Lines</u> converts a hatch to the lines which comprise it. After conversion the hatch will no longer respond to hatch functions. The lines will be like any other lines.

The disadvantage of converting hatches to lines is that the lines take up more memory than a hatch perimeter and, because each line must be drawn on each redraw, redraws take longer.

When you select <u>Hatch -> Lines</u>, a large crosshair appears on the screen. Each hatch is marked with a cross.

Enter box about hatch perimeters to be converted to lines

Draw a polygon around the white crosses marking the hatches to be converted to lines. The hatches are converted to lines.

Label <u>C</u>oordinates

FUNCTION: The Label <u>Coordinates</u> function is used to write coordinate values into your drawing.

To access the Label Coordinates function, press AttS, A, C.

This function writes the coordinates of a point either at the point or in a coordinate table. The appearance of the text is defined using Start 3 Set Text Defaults (AttS, S, E) - page 820).

When you access the Label <u>Coordinates</u> function, "Sight" Survey prompts:

Do you want a coordinate table, (else place each coordinate at point)

If you want the coordinates to appear in a coordinate table, click **Yes**. If you want each point to be labeled with its coordinate position, click **No**.

Enter point where coordinate table should start

This question is only asked if you answered **Yes** to the previous prompt.

Where the table appears relative to this position is dependent on the **Text Label Origin** you have defined in **Start** S **Settings** S **Set Text Defaults** (Att S), S), E) - page 820). For example, if the origin is 2, the table will appear on the right of this position. If the origin is 15, it will be centered around the position, etc.

Enter format for coordinate string	×
<mark>%11.2¶N%11.2f</mark>	
OK Cancel	

If the format for the coordinate string is **%11.1f%11.1f**, each coordinate is allotted eleven characters, of which one is set aside for a decimal place. Thus, the coordinate 25.6 -30 will appear as:

	2 5 .	6	- 3 0 . 0
$\overline{1}$ $\overline{2}$ $\overline{3}$ $\overline{4}$ $\overline{5}$ $\overline{6}$ $\overline{7}$	$\overline{8}$ $\overline{9}$ $\overline{1}$ 0	<i>11 1 2 3 4 5 6</i>	7 8 9 10 11
		mat of %9.3f%9.3f would a e and set aside three of these	
2 3 4 .	6 7 8	6.4.	3 2 7
$\overline{1}$ $\overline{2}$ $\overline{3}$ $\overline{4}$ $\overline{5}$ $\overline{6}$	$\overline{7}$ $\overline{8}$ $\overline{9}$	$\overline{1}$ $\overline{2}$ $\overline{3}$ $\overline{4}$ $\overline{5}$ $\overline{6}$	7 8 9
		n be left justified by typing %-9.3f%-9.3f will give the fo	
234.67	8	6 4 . 3 2	7
1 2 3 4 5 6	7 8 9	1 2 3 4 5	6 7 8 9
$\mathbf{N} = 4$ $ \frac{1}{I} \frac{1}{2}$	$\mathbf{N} = \%5$	can also be added into the f .2f, $E = \%5.2f$ will yield the , E – – – – – – – – – – – – – – – – – – –	e following: = 3 4 . 2 - $-\frac{1}{1}$ $\frac{1}{2}$ $\frac{1}{3}$ $\frac{1}{4}$

In the four examples shown above, the coordinates will be placed side-by-side. For example: N 345.25' E 512.33'

7

 $\overline{5}$


If you are placing coordinates at each point, instead of in a table, you can add a \N between the numbers to place the coordinates one atop the other. For example, entering a format string of N %5.2f\NE %5.2f would yield a printout of:

> N 345.25' E 512.33'

Enter point

Position the cursor onto the point that you want labeled and click or press *rener*.

To position the cursor accurately see **Accurate Placement** *on page* 497.



The coordinates are displayed in the prompt before they are placed on the drawing. At this stage they can be edited, for example to reflect a station name. To accept the coordinates, click OK or press $\overline{-Ener}$.

The coordinates will either be written into a table or onto the points, as specified.

3

ad

The order in which coordinates are displayed depends on the way you have set up Northings and Eastings in the **Surveyor Setup** *section of* **Start ⇒ Settings ⇒ Drawing Settings** (Att **S**, **S**, **D** - page 789).

Enter point

Position the cursor onto another point that you want labeled or cancel coordinate labeling by pressing Esc or the Space Bar, or by clicking on Cancel.



Jump to Grab All Cursor Jump <u>G</u>rid Jump Any Intersection Jump Point Jump Circle Center Jump Near Element Last Fixed Mid Point Jump <u>Ratio</u> Jump Move to Coordinates Polar Move Show Nodes Dump Data Grid <u>M</u>easure Polygon Area Query Entity (QE) Tidy Polygons E<u>x</u>pand

Section 28 <u>Start Menu - T</u>OOLS

The <u>T</u>OOLS menu accessed from the <u>Start</u> button in the **Drawing** window is where you'll find commands for various cursor operations, including jumps and moves.

28.01 Jump to Grab <u>All Cursor</u>

FUNCTION: The Jump to Grab <u>All Cursor</u> function is used to jumps to the closest point, intersection or grid point enclosed within the cursor box.

To access the Jump to Grab <u>All Cursor</u> function, press <u>Alt</u>S, T, A.

Jump to Grab <u>All Cursor</u> will only work if you are in the Grab All mode, i.e. if your cursor looks like this: .

Jump to Grab <u>All Cursor</u> searches for a point within the cursor box in the following order:

- 1. If a point (a point, the end of a line, the end of an arc, an arc or circle center) is found in the box, jump to the nearest one.
- 2. If a geometry intersection is found in the box, jump to the nearest one.
- 3. If any other intersection is found in the box, jump to the nearest one.
- 4. If a grid point is found in the box, jump to the nearest one.

Enter point to jump to

Move your cursor so that the cursor box surrounds the point, intersection or grid point you want to jump to, and click or press **Enter**. The cursor jumps exactly onto the point, intersection or grid point.

3 *If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press* **-***Enter to set the point as your starting point.*

28.02	Jump <u>G</u> rid
	FUNCTION: The Jump <u>G</u> rid function causes the cursor to snap to the nearest grid point of a grid created using <u>Start</u> <u>Tools</u> > <u>G</u> rid (AttS), 1 , G - page 747).
	To access the Jump Grid function, press AttS, T, U.
	Enter point to jump to
	Move your cursor close to the grid point you want to jump to and click or press with the cursor jumps exactly onto the grid point.
i	If Jump Grid does not appear to be working, it is probable that it is snapping to invisible grid points. In order to see these invisible points, zoom into your drawing or increase the maximum number of grid dots across screen. See Start Tools Grid (AttS, T, G - page 747).
3	If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press Fere to set the point as your starting point.



You can snap to a grid point anytime the **Drawing** window is prompting you to enter a point. Move the cursor close to the desired location and press G. Then press <u>were</u> to set the point.

28.03

Jump Any Intersection

FUNCTION: The **Jump Any Intersection** function causes the cursor to jump onto the nearest intersection. This intersection can be any combination of lines, arcs and geometry lines and circles.

To access the Jump Any Intersection function, press AltS, T, Y.

Enter point to jump to

Move your cursor close to the intersection you want to jump to and click or press *energy*. The cursor jumps exactly onto the intersection.



If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press Ferent to set the point as your starting point.

Section 28



You can snap to any intersection point anytime the **Drawing** window is prompting you to enter a point. Move the cursor close to the desired location and press \heartsuit . Then press \frown to set the point.

28.04	Jump Point
	FUNCTION: The <u>Jump Point</u> function causes the cursor to snap onto the nearest point. This may be a point, the end of a line or arc, an arc or circle center point, the label origin of an item of text, the label origin of an item of dimension text or an arrow end point.
	To access the Jump Point function, press ARS, T, J.
	Enter point to jump to
	Move your cursor close to the point you want to jump to and click or press <i>end</i> . The cursor jumps exactly onto the point.
	The search time increases as the number of elements increases.
	3 If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press First to set the point as your starting point.
	You can snap to point anytime the Drawing window is prompting you to enter a point. Move the cursor close to the desired location and press I . Then press File to set the point.

Jump Circle C<u>e</u>nter

FUNCTION: The Jump Circle Center function causes the cursor to jump onto the nearest arc or circle center.

To access the Jump Circle Center function, press AltS, T, E.

Enter point to jump to

Move the cursor close to the circle center you want to jump to and click or press — The cursor jumps exactly to the circle center.

3

If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press *enter* to set the point as your starting point.

 $\boldsymbol{\times}$

You can snap to a circle center point anytime the **Drawing** window is prompting you to enter a point. Move the cursor close to the desired location and press E. Then press with the point.

28.06

Jump <u>N</u>ear Element

FUNCTION: The Jump <u>Near Element</u> function causes the cursor to jump onto the nearest element. This element can be a solid, line or arc.

To access the Jump <u>Near Element</u> function, press AltS, T, N.

Enter point to jump to

Move your cursor close to the line or arc you want to jump to and click or press *eterer*. The cursor jumps exactly onto the line or arc.

3

If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press *enter* to set the point as your starting point.



You can snap to the nearest element anytime the **Drawing** window is prompting you to enter a point. Move the cursor close to the desired location and press N. Then press **-Enter** to set the point.

28.07

Last <u>F</u>ixed

FUNCTION: The Last Fixed function is used to jump to the location of the last selected point.

To access the Last Fixed function, press AltS, T, F.

The word "fixed" denotes the position of the last point you selected by pressing Fire or by clicking. This may be, for example, the end point of the last line you drew, and is always marked by a small cross: **x**. If the cursor is accidentally moved off this point, it can be returned to it using the Last Fixed jump.

3

If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press with the point as your starting point.



You can snap to the last fixed point anytime the **Drawing** window is prompting you to enter a point. Move the cursor close to the desired location and press X. Then press $\overline{-Enter}$ to set the point.

Mid Point Jump

FUNCTION: The Mid Point Jump function causes the cursor to jump onto the mid-point of the nearest line.

To access the Mid Point Jump function, press Alt S, T, 1.

Enter point to jump to

Move your cursor close to the line you want to jump to the mid point of and click or press <u>rener</u>. The cursor jumps exactly onto the mid point of the line.

3

If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press *enter* to set the point as your starting point.

You can snap to the mid-point of a line anytime the **Drawing** window is prompting you to enter a point. Move the cursor close to the desired location and press **T**. Then press **Enter** to set the point.

```
Section
28
```

28.09

<u>Ratio</u> Jump

FUNCTION: The <u>Ratio Jump</u> function causes the cursor to jump to a specified distance along a line or between two points.

To access the **<u>Ratio Jump</u>** function, press <u>Alt</u>S, T, R.

Enter point to jump to

Move your cursor close to the line or one of the points and click or press - It is important that you position your cursor carefully.

Enter division ratio for jump		×
.33		
ОК	Cancel	

Type a number here, for example if you type 0.5 or 1/2, the cursor will jump to half way along the line or between the two points. If you type 1/3, the cursor will jump to a third of the way along the line or between the two points, etc. Click **OK** or press **WENDE**.

Would you like to jump to ratio point on line (else between two points)

Jump to point on line	If you click <u>Yes</u> , the cursor will jump to the point along the nearest line specified by the ratio you entered in the previous prompt. The ratio distance will be measured from the point nearest to the cursor when the jump is made.
3	If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press Fine to set the point as your starting point.
Jump to point between points	If you click <u>No</u> , Sight Survey will prompt you for the first and second points.



To position the cursor accurately see **Accurate Placement** *on page* 497.

Enter first point

Move your cursor to the location of the first point and click or press *renter*.

Enter next point

Move your cursor to the location of the second point and click or press will jump to the point along the nearest line specified by the ratio you entered in the previous prompt. The ratio distance will be measured from the point nearest to the cursor when the jump is made.

3

If you intend to use the point you just jumped to as a starting point for a line, point, arc, etc., you must not move the mouse! After jumping to the point, use your keyboard to issue the drawing command. When "Sight" Survey prompts you for a point entry, press Ferent to set the point as your starting point.

28.10

Move to <u>C</u>oordinates

FUNCTION: The **Move to Coordinates** function causes the cursor to jump to a specific coordinate location.

To access the **Move to Coordinates** function, press Alt S, T, C, or right-click the **Polar Move** icon (\leq) on the **Drawing** window toolbar.



You can **Move to** <u>Coordinates</u> *anytime the* **Drawing** *window is prompting you to enter a point by pressing* **C**.

Enter coordinates cursor should move to (Northing Eas 🗵				
10000.820844 19985.921041				
ОК	Cancel			

Type the Northing and Easting coordinates that the cursor should move to, separated by a space, and click **OK** or press **Etter**.

(

Whether these coordinates are in the order Northing, Easting or Easting, Northing depends on how you have set this up in Start ⇒ Settings ⇒ Drawing Settings (Art S, S, D - page 789). The order or data entry is given in the prompt.

The origin point, (0, 0) is the center of the sheet of paper unless you have changed this using the Surveyor Setup in Start 3 Settings 2 Drawing Settings (AttS, S, D - page 789).

3

Unlike the other jumps in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in this section, you do not have to press in the press in this section, you do not have to press in the press in t

28.11

Polar Move

FUNCTION: The **Polar Move** function causes the cursor to move a particular distance in a particular direction.


To access the Polar Move function, press AltS, T, C, or click the Polar Move icon (\leq) on the Drawing window toolbar.



You can Polar Move anytime the Drawing window is prompting you to enter a point by pressing O.

ce to move		×
ОК	Cancel	

Type the distance you want the cursor to move then click OK or press -Enter.



Type the angle you want the cursor to move at then click $\bigcirc K$ or press \bigcirc The cursor moves the specified distance and angle.

The way in which the angle is measured depends upon how you have set up the Angular Format in Start ⇒ Settings ⇒ Drawing Settings (Att S, S, D - page 789). The order or data entry is given in the prompt.

Unlike the other jumps in this section, you do not have to press to accept the new cursor position after using Polar Move.

<u>S</u>how Nodes

i

3

28.12


FUNCTION: The <u>Show Nodes</u> function is used to show all the nodes (object control points) on the drawing.

To access the **Show Nodes** function, press Alt S, T, S.

When you select this function, all nodes on the drawing are marked:

- Points, the ends of lines and the ends of arcs are shown as **diamonds**.
- Arc and circle centers are shown as squares.
- Text and dimension text origins are shown as stars.





D<u>u</u>mp Data

FUNCTION: The **Dump Data** function is used to create a file of detailed data about the objects in your drawing.

To access the Dump Data function, press Att S, T, U.

Dump Data creates a file which gives the following information about each or specific objects in your drawing:

- Parent and object names.
- The coordinates of the object's snip box.
- The layer the object is on.
- The coordinates of the object's hook point.
- Whether the object is selected.
- Whether the object is a hatch perimeter.
- The coordinates, line type, pen and width of each primitive in the object, and whether this primitive is selected.

What layers do you want to dump data from (enter '*' for all layers)	×
*	
OK Cancel	
OK	

Type the name of the layer that you want to dump information from. To dump information from all layers, type * and click **OK** or press **--**Enter.



Type the name of the object or objects you want information about and click **OK** or press **Fine**. For example, if you type: **YELLOW CIRC1**, information about objects with the name **CIRC1** and with the parent name **YELLOW** will be dumped.

Wildcards may be used. For example, if you type: *** CIRC1**, information about all objects with the name **CIRC1** will be dumped, regardless of parent names. If you type: **YELLOW ***, information about all objects with the parent name **YELLOW** will be dumped, regardless of object names. If you type : *** ***, information about all the objects on the layer or layers you specified in the first prompt will be dumped.

Do you want data from all elements (else just object headers)

If you click <u>Yes</u>, the information that is dumped to the file will include both **Object Header** information and **Object Details**.

If you click <u>No</u>, only **Object Header** information will be dumped (see **Object Header** and **Object Details** later in this section).

A dialog box headed **Save Dump Data As** will then appear. This is a standard Windows **Save** dialog box. Type a name for the file. By default it has the name **UNTITLED.DMP**, but you can change this to any name by typing a new name in the **File Name** part of the dialog box.

After entering a filename, click $\square K$. The information is saved to file. You can look at it using any text editor such as the Windows Notebook. Sample data produced by $D\underline{u}mp$ Data is shown below.

	*****	****	*****	*****	****	
	parent YELLOW objectbox 39.962 objectlength 208 selected 0 clip 0 1 arc 88.891 radius 24.465	bjectbox 39.962 -15.016 88.891 33.914 objectscale 1.000 1.000 objectrot 0.000 bbjectlength 208 visibility 1 layer BEE object hook 88.891 9.449 elected 0 clip 0 hatch 0 type 0 patnumber 79 lib 0 key 0 rrc 88.891 9.449 64.426 9.449 88.891 9.449 adius 24.465 cw 0 line, pen, width 1 3 0 0 0 1 aspect 1 angle 0				•
	parent RED object RECT2 objectbox -90.770 -43.810 -36.365 7.158 objectscale 1.000 1.000 objectr objectlength 364 visibility 1 layer A object hook -90.770 -43.810 selected 0 clip 0 hatch 0 type 0 patnumber 75 lib 0 key 0 line -90.770 -43.810 -36.365 -43.810 1 1 0 0 0 0 line -36.365 -7.158 1 1 0 0					0 110000 110000
	*****	******	******	******	****	
	parent A objectbox -90.77 objectlength 364 selected 0 clip 0 1	visibility 1 lay	er BEE obj	ect hook -9	0.770 -43.8	310
		-43.810	-36.365		13000	
	line -36.365	-43.810	-36.365	7.158	13000	0
	line -36.365	7.158	-90.770	7.158	13000	0
	line -90.770	7.158	-90.770	-43.810	13000	0
ObjectHeader	Information a followed by O					
	parent YELLOWobject CIRC1objectbox 39.962 -15.016 88.891 33.914 objectscale 1.000 1.000 objectrot 0.000objectlength 208 visibility 1 layer BEE object hook 88.891 9.449selected 0 clip 0 hatch 0 type 0 patnumber 79 lib 0 key 0					
	It contains the following information.					
	parent object objectbox objectscale objectrot	parent nar object nar coordinate informatic	ne. es of recta on used b on used b	y TrueCA y TrueCA	AD. AD.	

objectlength

visibility

length of object data structure in bytes.

information used by TrueCAD.

layer object hook selected clip hatch type patnumber lib key	the layer the object is on. coordinates of the object's hook point. this figure is 1 if the object is selected. information used by TrueCAD. this is 0 if the object is not a hatch perimeter. information used by TrueCAD. information used by TrueCAD. information used by TrueCAD. information used by TrueCAD.
	t have been imported as DXF or DWG files are likel toCAD blocks. These will be represented in Dump he same way as TrueCAD objects, except that they
will have a ST	FARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOG STARTBLOCK purgedflag=0	FARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOG STARTBLOCK purgedflag=0	TARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOO STARTBLOCK purgedflag=0 ************************************	TARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOO STARTBLOCK purgedflag=0 ************************************	FARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOO STARTBLOCK purgedflag=0 ************************************	TARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOC STARTBLOCK purgedflag=0 ************************************	FARTBLOCK line above the object description and CK line beneath it: SOP [0.000000,0.000000] storescale=1.000000 flags=64 object P121 00 -10.000 10.000 10.000 objectscale 1.000 1.000 objectrot 0.000 8 visibility 0 layer 0 object hook 10.000 0.000 hatch 0 type 0 patnumber 121 lib 0 key 0
will have a ST an ENDBLOC STARTBLOCK purgedflag=0 ************************************	FARTBLOCK line above the object description and CK line beneath it:
will have a ST an ENDBLOC STARTBLOCK purgedflag=0 ************************************	FARTBLOCK line above the object description and CK line beneath it:


Object Details After the **Object Header**, details about each primitive in the object are given. These details vary depending on the nature of the primitive.

Section 28

Blocks



Pens (colors) are numbered downwards from 0 to 15 in the **Pen Selection Area** so that maroon is 0, red is 1, etc. A pen of 255 indicates that the pen is being set By Layer. **Line types** are numbered from 1 downwards in the **Line Type Menu** so that continuous is 1, dashed is 2, etc. A line type of 255 indicates that the line type is being set **By Layer**.




Points are represented in Dump Data files as lines whose start and end coordinates are the same.

polyline swid=		*	ed=0 selection= =0, key=0, SN		1	
vertex	-148.75	-3.4421 ty	pe=0 swidth=	0 ewidth=	0	
vertex	-119.73	35.404 ty	pe=0 swidth=	0 ewidth=	0	
vertex	-76.954	-16.719 ty	pe=0 swidth=	0 ewidth=	0	
vertex	-42.042	49.172 ty	pe=0 swidth=	0 ewidth=	0	
	A	ł	↑ ↑	▲		
Coordina	ates of polyli	ne's vertices				
Vertex type (straight line or arc)						
Start wid	lth and end w	vidth of vertex	ç			
lingt		lina tema				

ne type.
olor.
formation used by TrueCAD.
if polyline is selected, else 0.
umber of vertices in the polyline.
bline type: $0 = no$ spline, $1 = 3$ pt Bezier,
= 4 pt Bezier.
art width of polyline.
nd width of polyline.
if polyline is closed, else 0.

Points and Lines

Polylines



Text


balloon


this figure is 1 if a balloon has been placed around the text using **Start** \Rightarrow **Annotate** Add/Rem Text Bubble.

For further information on the above text properties, see Start ₹ Settings ₹ Set Text Defaults.

Horizontal, Vertical, Slope and **Ordinate Dimensions**

Angular Dimensions






pen 5 ar1 ar2 0 0 0 🖛 text posn 71.715 135.573 text :55.26°: color. pen


83.444


18.427

adim



	posn type link	coordinate position of data item. normally 0. Other types of data item are used internally by the program. information used by TrueCAD.
Bitmaps		e = "C:\MANDRAW\CCAD.BMP" pixel sition = 138.725166
	filename pixel size visible position For further infor ∛ <u>F</u>ile ∛ Import	the full path and filename of the bitmap. real world pixel size. this is "Y" if the bitmap is visible and "N" if it is displayed as a placeholder. the coordinates of the top left hand corner of the bitmap. mation on the above bitmap properties, see <u>Start</u> <u>Bitmap</u> .
Block Inserts	Drawings that have been imported as DXF or DWG files are likely to contain AutoCAD block inserts. These are represented as follows: Name of block being inserted Coordinates of inserted block's hook point INSERT "SOP" index=0 [240.307714,262.241572] xscl=3 yscl=3 ang=0	
	Number of block being 0 is the first block defi 1 is the next block etc.	ined in the drawing,





🖌 <u>G</u>rid On

Pen

spacing that should generate 80 rows and 80 columns of dots on the screen at a particular time, only 40 rows and 40 columns (i.e. every second dot) will be displayed if 40 has been typed as the maximum. The dots that are not displayed still exist and can be snapped to. You just can't see them.

Ç


If the Grid Snap mode or the Jump Grid Jump do not appear to be snapping to grid points, it is likely they are snapping to invisible grid points. To see these invisible points, zoom into your drawing or increase the Grid Display Density.

Grid On checkbox	When this box is checked, the grid is displayed. To hide the grid, uncheck this box.
Pen	The Pen button controls the color of the grid when it is displayed. To change the color, click the pen button and click on a new color.

28.15

<u>M</u>easure

FUNCTION: The <u>Measure</u> function is used to measure and display the distance and angle between two points. To place the dimension into your drawing, use dimensioning functions from the <u>Start</u> \Rightarrow <u>Annotate</u> menu.



To access the <u>Measure</u> function, press <u>Alt</u>S, T, M.

This function measures the slope distance, the x and the y distances and the angle between any two points.

Distances, arc lengths, angles, diameters and radii may also be measured using the various dimensioning functions in the **Start** ⇒ <u>Annotate</u> menu. If you use a dimensioning function to measure but do not want to add the dimension to the drawing, cancel the dimensioning function immediately after the measurement has been displayed.

•	The way that angles are measured depends on the way you have set up the Angular Format in Start ♣Settings ♣Drawing Settings (ArtS, S, D - page 789).
	Distance enter first point ([Space Bar] to exit)
]	Position the cursor at the first point and click or press <i>end</i> .
	Second point
]	Position the cursor at the second point and click or press <i>eterter</i> .
and	<i>To position the cursor accurately see</i> Accurate Placement <i>on page 497.</i>
,	The measurements are displayed. Click OK.
	Distance enter first point ([Space Bar] to exit)
•	

This routine repeats until you cancel measuring by pressing E_{SC} or the $S_{Pace Bar}$, or by clicking on C_{ancel} .

28.16

<u>P</u>olygon Area

FUNCTION: The <u>Polygon Area</u> function is used to measure the area of a polygon, then print the area inside the polygon.

To access the **Polygon Area** function, press **Att S**, **T**, **P**.

Enter point inside perimeter

Click your mouse somewhere inside the polygon you want to measure. "Sight" Survey will attempt to automatically identify a border, then highlight it so you can verify a correct perimeter border.



Select in what units the area should be reported by typing 1, 2, or 3 and clicking $\square K$. The prompt will reflect English or Metric choices depending upon the units you have set up in <u>Start</u> \implies <u>Settings</u> \implies <u>Unit Settings</u> (Alt) \subseteq , \subseteq , \square , page 797).

Enter placement for Area Text

Position the cursor where you want the middle of the text to be and click or press *-Enter*. If you selected option 1 or option 2 in the previous prompt, only a single line of text will be printed. If you selected option 3, two lines will be printed, one above the other.

Enter point inside perimeter

This routine repeats until you cancel it by pressing Esc or the Space Bar, or by clicking on **Cancel**.



"Sight" Survey may not be able to determine the correct perimeter, especially if you have a series of polygons, such as a group of lots. You may need to Select the lot, then use <u>Start</u> Modify Move (AttS, M, M - page 625) to move the lotaway from the others before using <u>Polygon Area</u>. Once thearea has been established, you can move the lot back intoplace.

An alternate method of measurement also exists. At any point prompt, type XX. In the TrueCAD Command window that opens, type QRYAREA and click OK. Use the Perimeter Menu (see page 597) that appears to select the method for marking the perimeter. When the perimeter is identified, press the space bar to reactivate the Perimeter Menu, then select Done Perim. The area and perimeter will be displayed but there is no way to place this information on your drawing.

Query Entity

FUNCTION: The **Query Entity** function is used to examine details of a drawing entity.

To access the Query Entity function, press Att S, T, Q.

Select element to query

Position the cursor on the entity you want to query and click or press *enter*. An entity information box will appear.



Pens (colors) are numbered downwards from 0 to 15 in the **Pen** Selection Area. A pen of 255 indicates that the pen is being set By Layer. Line types are numbered from 1 downwards in the Line Type Menu. A line type of 255 indicates that the line type is being set By Layer. Width is measured in tenths of a mm. Angles are measured counter-clockwise from the 3 o'clock position. The letter or name in single quotes after the word Layer is the layer name.

Depending upon the entity queried, the following information is displayed.

L	ine:	Parent and Object names.
L	ayer:	Layer containing the object.
L	ength:	Length in units set in <u>Start</u> [™] <u>Settings</u> [™] <u>Units</u> .
А	ingle:	Direction measured counter-clockwise from zero
		at 3 o'clock position.
L	inetype:	The style of the line.
P	en:	The pen (or color) used to draw the line.
W	Vidth:	The width of the line.
L	ine Coords:	The first pair of numbers are the X (Easting) and
		Y (Northing) coordinates of the beginning of the
		line. The second pair of numbers are the X and
		Y coordinates for the end of the line. If the first
		and second pair are identical, the entity is a
		point.

Points and Lines

Section 28

Polylines	NVertex Spline Key Snode Enode Vertex # Coordin	The number of vertices in the polyline. 0=polyline, 1=3 point Bezier curve, 2=4 point Bezier curve. ID field for GIS type applications. ID field for start point of polyline. ID field of end node. nates: Coordinates (X, Y) of the position of the first two vertices.
Arcs, Circles and Ellipses	Arc Length Radius CW Aspect Angle Arc Coordinates	In the units set in Start \Im Settings \Im Units. In the units set in Start \Im Settings \Im Units. 1 if the arc was drawn clockwise, else 0. Ellipse aspect ratio if ellipse. Ellipse angle if ellipse. The first pair (X, Y) mark the start of the arc. The second pair (X, Y) mark the center point. The third pair (X, Y) mark the other end of the arc.
Text	Height Width String Position Lorg	Text height is measured in tenths of a mm. Width is measured in tenths of a mm. 0 is the default width. Text content, i.e. what it says. Coordinate position (X, Y) of text. text label origin.
Horizontal, Vertical, Slope and Ordinate Dimensions		Arrow heads. The two figures following arrow1 and arrow2 are normally both 0. If an arrow head has been updated using Start \Rightarrow Annotate \Rightarrow Edit Dimension Properties it will be represented by the number 10. The contents of the dimension text, i.e. the measurement. Linates: The first pair (X, Y) mark one dimension point. The next pair (X, Y) mark the other dimension point. The third pair (X, Y) mark the position of the dimension text.

Angular Dimensions	Dimension Text	 These figures are not relevant to angular dimensions. The contents of the dimension text, i.e. the measurement. ons The first coordinate pair (X, Y) mark the intersection point if this is a dimensioned angle. If this is a dimensioned arc length, they mark the arc center point. The second pair (X, Y) mark the tip of the arrowhead that points in the counter-clockwise direction. The third pair (X, Y) mark the tip of the arrowhead that points in the clockwise direction.
Radial Dimensions	Arrow Text on Arrow Dimension Text Radial Dimensio	This figure is not relevant to radial dimensions. 1 if the dimension text is on the arrow, otherwise 0. The contents of the dimension text, i.e. the measurement. In The first coordinate pair (X, Y) are the coordinates of arc or circle center. The second pair (X, Y) are the coordinates of the point where the arrow head touches the arc or circle circumference. In the case of a circle, where two arrow heads touch the circumference, it is the arrow head nearest to the text. If the text is in between the two arrow heads, it is the arrow head nearest the position you specified in prompt 1 of Start ∿Annotate ∿ Radial Dimension . The third coordinate pair (X, Y) are the coordinates of the dimension text if this is not on the dimension arrow. If the text is on the dimension arrow, these coordinates are the same as the previous ones.
Arrows	Head Length Head Width Arrow Coords	Length of arrow head, in tenths of a mm. Width of arrow head in tenths of a mm. The first coordinate pair (X, Y) mark the arrow tail. The second pair (X, Y) mark the arrow tip.

Section 28

Data Items	String Position Type Link	Text content of the data item. Coordinate position of data item. Normally 0. Other types of data item are used internally by the program. Information used by TrueCAD.
Bitmaps	Pixel size Filename Upper left positi CX CY	Real world pixel size, measured in the units selected in <u>Start ⇒ Settings</u> ⇒ <u>Drawing Settings</u> . The full path and filename of the bitmap. on The coordinate position of the upper left corner of the bitmap Number of pixels in the X direction. Number of pixels in the Y direction.
Block Inserts	Drawings that have been imported as DXF or DWG files are likely to contain AutoCAD block inserts. When you query a block insert the following information appears:PositionCoordinates (X,Y) of the block's hook point. X ScaleY ScaleHorizontal scale of the block. Vertical scale of the block. AngleRotation angle of the block.	

<u>T</u>idy Polygons

FUNCTION: The <u>Tidy Polygons</u> function is used to clean up polygon segments entered from an "untidy" source such as a digitizer or raster to vector conversion program.

To access the **<u>Tidy Polygons</u>** function, press **AttS**, **T**, **T**.

<u>**Tidy Polygons**</u> has three functions to clean up polygons. When you enter the routine you must select one of these functions.

<u>A</u> dd nodes	
<u>T</u> idy up boundaries	
<u>D</u> rawingsnaptidy	
drawing <u>C</u> liptidy	
<u>Q</u> uit	


Select an option with your mouse or by pressing A, T, D, C, or Q.

1. Tidy Boundary Tidy Boundary removes redundant line segments. For example, when you sketch or digitize, you commonly enter many more line segments than are necessary. Tidy Boundary replaces these redundant segments with a single line.



Before

After



Segments made up of many small lines

Before you can use **Tidy Boundary**, you must add some nodes to the existing boundary. This **add nodes** function adds nodes at segment intersection points.

Enter node radius in mm on	paper	×
1		
ОК	Cance	

Enter the radius of the nodes to be added. A value of between one and two millimeters is reasonable. Press **______** or click **_____**.

Enter next node position



The cursor changes to **Point** mode $(\stackrel{\downarrow}{\downarrow}\stackrel{\downarrow}{}^{\downarrow})$ cursor. Position it close to the segment intersection you want to add a node to and click or press $\overline{}$ terms. A circle appears around the intersection, and this node is automatically added to the **__NODES__** layer so you can easily switch off or delete the nodes when you no longer need them.

Enter next node position

Add another node or cancel node addition by pressing the Space Bar or clicking Cancel.

Enter tolerance on each side o	of line for straightning (in mm on paper) 🗙
10	
ОК	Cancel
ОК	Cancel

Type a number and press <u>"Ener</u> or click **OK**. A number between .3 and .7 is usually appropriate. This number defines a "corridor" of a certain width, and line segments falling within this corridor will be replaced with a single line segment. The larger the number chosen, the more generalized (or smoother) the resulting boundary.

Select node for start of next boundary segment

Position the cursor on the node marking one end of the boundary segment to be tidied and click or press *etener*.

Show first line of segment (Pick first line at its mid point)

Position the cursor half way along the first line making up the boundary segment to be tidied, and click or press *etere*.



You may have to magnify into the drawing in order to identify this segment. At any time, you may click the **Zoom Window** icon (N) to magnify a portion of your drawing.

The program tracks along the segment until it reaches another node. You will see its progress as it tracks. If tracking is lost before another node is reached, or if there is ambiguity at a point, "Sight" Survey will be prompt:

Tracking lost .. enter next segment

Position the cursor on the next line in the boundary segment to be tracked and click or press *etenter*. Alternatively abandon tracking the boundary by pressing the *Space Bar* or clicking **Cancel**.

Select node for start of next boundary segment

Click on the first node of another boundary segment to tidy or cancel boundary tidying by pressing the Space Bar or clicking **Lancel**.

Tidy Snaps joins line end points to give a neat junction, deletes very short lines and removes duplicate lines.

Before

After


٤

If you are using this function in conjunction with Tidy Clips then you must Tidy Snaps first. Tidy Snaps might move line end points causing overshoots and undershoots already tidied by Tidy Clips to become untidy again.

Enter snap tolerance in current units	×
1.5 OK Cancel	

If two or more line end points lie within the snap tolerance, then **Tidy Snaps** will try to move these end points onto the intersection points of the lines.

2. Tidy Snaps



If you simply want to use **Tidy Snaps** for removing duplicate lines, set the tolerance to 0 (zero).

Enter minimum line length allowed (in current units)	×
0.5	
OK Cancel	

Tidy Snaps will delete all lines shorter than a given length. Type a minimum line length and press $\overline{\mbox{length}}$ or click $\overline{\mbox{OK}}$. If you do not want to delete any very short lines, enter a length of 0 (zero).

If you simply want to use **Tidy Snaps** for removing duplicate lines, set the length to 0 (zero).

Remove overlapping lines?

Click <u>Yes</u> to remove overlapping lines, otherwise click <u>No</u>. Overlapping lines will be removed as follows:

- Exactly overlapping one line will be deleted.
- Partially overlapping one line will be trimmed to meet the other.
- Long line completely overlapping short line short line will be deleted.

Enter polygon within which to Snaptidy


Draw a polygon around the area within which **Tidy Snaps** is to operate. This prompt repeats until you cancel by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.



In some cases, for example where there are three or more lines that do not intersect at the same point, **Tidy Snaps** may not be able to join the lines. In such cases you may have to use the **Trim**, **Divide/Extend** or **Move Point** functions in the <u>Start</u> *****<u>Modify Menu to join them</u>.


3. Tidy Clips

Tidy Clips cleans up line over and undershoots.



If you are using this function in conjunction with Tidy Clips then you must Tidy Snaps first. Tidy Snaps might move line end points causing overshoots and undershoots already tidied by Tidy Clips to become untidy again.

Tidy Clips will not tidy overshoots and undershoots where two line ends meet (circled in the diagram below). This is the function of Tidy Snaps.



Section 28

olerance in current	t units	×
ОК	Cancel	1
	Olerance in curren	Olerance in current units

Type in a tolerance for the maximum length of an over or undershoot to be tidied and press -Enter or click OK.

Enter polygon within which to Cliptidy

Draw a polygon around the area within which **Tidy Clips** is to operate. This prompt repeats until you cancel by pressing **Esc** or the **Space Bar**, or by clicking on **Cancel**.



In some cases **Tidy Clips** may not be able to resolve the over and undershoots. In such cases you may have to use the **Trim**, **Divide/Extend** or **Move Point** functions in the **Start SModify Menu** to join them.

28.19 E<u>x</u>pand


FUNCTION: The **Expand** function is used to automatically produce a detailed view.

To access the **Expand** function, press Att S, T, X.


Expand automatically produces a detailed view within a box or circle. It can also be used as a "*cut and paste*" function if magnification is set to **1**.



Expand lets you save a detailed view to a separate layer. This is a good practice to avoid accidentally changing the magnification of your drawing. You must create a layer to save the detailed view to before using Expand. Use Start ⇒ Settings ⇒ Layer Control (EL or AttS, S, Y) - page 839).



Click \underline{Yes} to have the detailed view to appear inside a box. To have the detailed view to appear inside a circle, click \underline{No} .



If you would like the box or circle to be drawn around the detailed view as in the previous examples, click \underline{Yes} . Otherwise, click \underline{No} .

Detailed View in a Box

Enter corner of expand box

Position the cursor at one corner of the expand box and click or press *rener*.

Enter another corner of box

Position the cursor at a diagonally opposite corner of the expand box and click or press *etcher*. Go to the **Enter magnification factor** prompt on the next page.

Detailed View in a Circle

Enter center point of expand circle

Position the cursor where the center of the expand circle is to be and click or press *Enter*.

Enter point on radius

Position the cursor at a point on the expand circle's circumference and click or press *energy*.

×
Cancel

Type the magnification of the detailed view and click $\bigcirc K$ or press \bigcirc fine.


Enter position of expanded detail

A box appears, representing the size of the detailed view. Move the box to a suitable screen location and click or press -Enter. The detailed view is drawn. Do you want an arrow joining the two circles



This question is only asked if you have chosen to draw an expand circle rather than a box, and if you have drawn a circle around the detailed view.

If you want to join the two circles with an arrow, click <u>Yes</u>. Otherwise, click <u>No</u>.



A Magnified Layer dialog box appears. Choose a layer for the detailed view to be copied onto by clicking on the layer name.

Enter new magnification for layer DETAILVIEW			
2 ОК	Cancel		

Anything that you subsequently draw onto the layer that the detailed view is on will have the magnification that you give here. For example, if the drawing scale is 1:1, and you enter a factor for magnification of **2**, anything else that you draw on this layer will be drawn at a scale of 1:0.5.

3

i

If you have placed the detailed view onto the same layer as the rest of your drawing, it is important that you type a magnification of **1** so that anything else you draw on the layer is not drawn at the wrong scale.

To add dimensions to the detailed view, accept the default magnification, which is the magnification of the detailed view. This will ensure that the dimensions are correctly sized. Accept the magnification you type by clicking **OK** or pressing **...**

If you had already dimensioned the drawing before creating the detailed view and the dimensions in the detailed view are now incorrect, you must do the following after you have completed the Expand function.

- 1. Select the detailed view using the <u>Select or Selection Filters</u> commands in the <u>Start</u> [⇒] Edit Menu.
- Then use the <u>Start</u> [™] <u>Modify</u> [™] <u>Scale</u> function to scale the detailed view by 0.5 0.5 then by 2 2. The dimensions will then read correctly.

Once you have changed the magnification of the layer, you will see that this magnification is reflected in the <u>Start</u> ⇒ <u>Settings</u> ⇒ Layer Control dialog box.



The **OBJECTS** menu contains commands relating to the creation Begin New Object and changing of objects. Objects are groups of drawing primitives Group into Object that have been given a name, and function as a single entity. Explode Object Show Objects List Objects 29.01 Begin New Object Make Symbol Change <u>N</u>ame FUNCTION: The Begin New Object function is used to Change Parent create an object by naming it, and then drawing it. Change Hook Point Update Objects To access the **Begin New Object** function, press AttS, O, B. Select Current Object There are three functions that may be used to create an object Blink Current Object manually: Begin New Object; Group Into Object; and Make Symbol. Using the **Begin New Object** involves naming the object first, then drawing it.

Section 29

Start Menu - OBJECTS

Giving the object a parent name

Follow one of these procedures to give an object a specific parent name:

- Before creating the object, use <u>Start</u> [∞] <u>Objects</u> [∞] <u>Change</u> <u>Parent</u> (<u>Att</u><u>S</u>), <u>O</u>, <u>P</u> - page 783). This function defines the default parent name, which will be given to all the objects you subsequently create until you use <u>Change Parent</u> again.
- After you have created the object, use <u>Start [™] Objects</u>
 [™] Change <u>Name</u> (<u>Atts</u>, O, N page 780).
- If you do not choose a parent name before creating the object, the object will be given the default parent name. This will be **A** unless you have already used the **Change Parent** option to change it.

Section 29



Objects with the parent name __LABEL__ (there are two underscores on either side of LABEL) are not displayed in the list of symbols that appears when you use the <u>Start</u> [¬]><u>D</u>raw [¬]><u>Symbol</u> function. If you are creating objects for use as symbols, use __LABEL__ as the parent name for anything which you do not want displayed, such as text descriptions.


When you enter the **Begin New Object** function, "Sight" Survey prompts:

	×
Cancel	
	Cancel

Type a name for the object and click **OK** or press **Fine**. You only need to type the object's name. **Do not type a parent name**. From this point on, all the primitives that you draw will be grouped into an object with this name until:

- You create another object using <u>Begin New Object</u>, <u>Group Into</u> Object, or <u>Make Symbol</u>.
- You use a function that automatically starts a new object, or you make the object too big (8000 bytes roughly 250 lines or 130 arcs). In either of these cases, "Sight" Survey will automatically start a new object.
- You change the current object (the object you are currently drawing) using the <u>Select Current Object</u> function.

If you are going to use the object as a symbol, you should draw it horizontally. For example, if you are drawing a fuse:



This is because of the way "Sight" Survey can automatically rotate and snip around symbols when they are inserted into drawings.

ad

"Sight" Survey will have positioned the object's hook point automatically. When you have finished creating the object, you may want to position its hook point manually. To do this, use <u>Start</u> **>**<u>O</u>bjects **>**<u>Change Hook</u> Point (AttS, O, K - page 784). If you are going to use the object as a symbol, you should position the hook point at the left hand end of the symbol because of the way that "Sight" Survey can automatically rotate and snip around symbols when they are inserted into drawings.

When you use **<u>Begin New Object</u>** to create an object, the object's snip box will fit exactly around the extreme edges of the object. No attributes will have been assigned to the object.

When you have created the object, you will be able to select the entire object at once by clicking on it with the **Select Cursor** (\triangleright). If you want to select a single primitive within the object, you must explode it first by using. Start \Rightarrow Objects \Rightarrow Explode Object (Att)S, \bigcirc , \boxtimes - page 770).

29.02

<u>Group Into Object</u>

FUNCTION: The <u>Group Into Object</u> function is used to create an object by selecting primitives you have already drawn, then grouping them.

Section 29

To access the <u>Group Into Object</u> function, press <u>Att</u>S, E, O.

There are three functions that may be used to create an object manually: <u>Begin New Object</u>; <u>Group Into Object</u>; and <u>Make Symbol</u>. The <u>Group Into Object</u> function involves drawing primitives, then grouping the primitives into objects later.

Before you use <u>Group Into Object</u>, first draw the primitives you want to group. You must then select them using the <u>Select</u> (<u>Att</u><u>S</u>),

E, S - page 552) or Selection Filters (AttS, E, F - page 560) commands.

If you are going to use the object as a symbol, you should draw it horizontally. For example, if you are drawing a fuse:



Draw it this way...

... not this way.

This is because of the way that "Sight" Survey can automatically rotate and snip around symbols when they are inserted into drawings.

Giving the object a parent name


Follow one of these procedures to give an object a specific parent name:

- Before creating the object, use <u>Start</u> → <u>Objects</u> → <u>Change</u> <u>Parent</u> (<u>Att</u>S), O, P - page 783). This function defines the default parent name, which will be given to all the objects you subsequently create until you use <u>Change Parent</u> again.
- After you have created the object, use <u>Start</u> [™] <u>Objects</u> [™] Change <u>Name</u> (<u>Alt</u>S), <u>O</u>, <u>N</u> page 780).
- If you do not choose a parent name before creating the object, the object will be given the default parent name. This will be **A** unless you have already used the **Change Parent** option to change it.



Objects with the parent name **__LABEL** (there are two underscores on either side of **LABEL**) are not displayed in the list of symbols that appears when you use the <u>Start</u> ⇒ <u>Draw</u> ⇒ <u>Symbol</u> function. If you are creating objects for use as symbols, use **__LABEL** as the parent name for anything which you do not want displayed, such as text descriptions.

When you enter the **<u>Begin New Object</u>** function, "Sight" Survey prompts:



Type a name for the object and click **OK** or press **.** You only need to type the object's name. **Do not type a parent name**. The selected primitives will be highlighted, and will be grouped under the name you have typed.

If you hadn't selected anything when you chose **Group Into Object**, you will now enter the **Select** function. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the primitives you want to group. When you have finished selecting primitives, press the **Space Bar** or click **Cancel**. The selected primitives will be grouped and highlighted.



"Sight" Survey will have positioned the object's hook point automatically. When you have finished creating the object, you may want to position its hook point manually. To do this, use <u>Start [®]Objects [®] Change Hook Point</u> (AttS, O, K - page 784). If you are going to use the object as a symbol, you should position the hook point at the *left* hand end of the symbol because of the way that "Sight" Survey can automatically rotate and snip around symbols when they are inserted into drawings.

When you use <u>Group Into Object</u> to create an object, the object's snip box will fit exactly around the extreme edges of the object. No attributes will have been assigned to the object.

When you have created the object, you will be able to select the entire object at once by clicking on it with the **Select Cursor** (\triangleright). If you want to select a single primitive within the object, you must explode it first by using. Start \Rightarrow Objects \Rightarrow Explode Object (Att)s, \bigcirc , \boxtimes - page 770).

29.03

Explode Object

FUNCTION: The Explode Object function is used to break apart objects and blocks so that individual primitives within them can be selected.

To access the **Explode Object** function, press \overline{AttS} , \overline{O} , \overline{X} .

Whenever you create an object manually using **Begin New Object**, Group Into Object, or Make Symbol in the Start >> Objects menu, the primitives in the object are grouped. This means that when you click on the object with the **Select Cursor** (\triangleright) all the primitives within it are selected at once, making selection quicker and easier.

Some "Sight" Survey functions that automatically create objects also group the primitives within these objects. For example, when you draw a rectangle using **Start** \Rightarrow **Draw** \Rightarrow **Rectangle**, the four lines making up the rectangle are grouped. When you create a polyline using **Start > Draw > Polyline**, all the lines making up the polyline are grouped. Similarly, symbols entered using Start Traw Symbol are grouped, and sketches produced using Start **Draw Sketch** are grouped.

All the lines, arcs etc. in a block that has been brought in from DXF or DWG are also grouped together. If you do not want to select the entire grouped object or block when you click on it, but want to select one primitive within it, you must first explode the object or block. To do this, select the object or block using Select (AltS, E, S - page 552) or Selection Filters (AltS, E, F - page 560).

If you haven't selected anything when you choose Explode Object, you will automatically enter the **Select** function as soon as you enter this routine. "Sight" Survey prompts:

Select Single Entity (Shift for multiple selection)

Select the object or block you want to ungroup. When you have finished selecting, press the Space Bar, or click Cancel

You will not see anything happening when you use **Explode Object**. Once you have used it, clear all selections using <u>Start</u> \Rightarrow <u>Edit</u> \Rightarrow <u>Clear Selection</u> (Att]S, E, L - page 567). You will now be able to select single primitives using <u>Select</u>.



Exploded polylines can be restored one at a time using Start $\underbrace{\mathbb{E}}_{\operatorname{Edit}} \underbrace{\mathbb{E}}_{\operatorname{Undo}} (00 \text{ or } \bigcirc \operatorname{Att}S, \boxdot, \bigcirc - \operatorname{page} 547).$

To regroup an object that you have exploded, use **Object** in <u>Start</u> \Rightarrow <u>Edit</u> \Rightarrow <u>Selection Filters</u> to select all the component primitives of the object, and then use <u>Start</u> \Rightarrow <u>Objects</u> \Rightarrow <u>Group Into Object</u> (<u>Att</u>S, \bigcirc , \bigcirc - page 767) to group them again.

29.04

Show Objects

FUNCTION: The **Show Objects** function is used to draw objects on the screen one by one.

To access the Show Objects function, press Alt S, O, H.

Suppose you have three objects in a drawing. When you select **Show Objects**, each object will be shown on the screen in turn. The object's *hook point* will be displayed as a *star*, and it will be surrounded by a box representing its *snip box*. Its *parent name*, *object name* and *layer* will be displayed in a prompt window. If the object is a hatch perimeter, the perimeter's reference point will be shown as a cross, and the hatch index used to hatch the perimeter will also be displayed in the prompt area.

When you select **Show Objects**, "Sight" Survey prompts:


What layer do you want to show objects from (enter '*' for all layers)	×
*	٦
OK Cancel	

Type the name of the layer you want to display the objects from and click OK or press -Enter. To show objects from all layers type ***** and click OK or press -Enter.

What object names do you want to show (* * for all objects)	×
* *	
OK Cancel	

You must type **both the parent name and the object name** of the objects you want to show. Names are **case-sensitive**. Wildcards may be used. For example, typing **SHAPES** * will select all objects with the parent name SHAPES, such as SHAPES CIRCLE, SHAPES TRIANGLE, SHAPES RECTANGLE etc. Typing: * **CIRCLE** will select all objects called CIRCLE, whatever their parent names are. Typing: * * will select all the objects in the drawing regardless of name.

Click OK or press — The objects are displayed, one by one, either until all the specified objects have been shown or until you press the Esc key.





1. When the current object is displayed, the words current object are shown.

2. When all your objects have been displayed, an extra object, comprising just a hook point at the screen center will appear. This is normal.

29.05

List Objects

FUNCTION: The List Objects function is used to list, count and measure objects.

To access the List Objects function, press Alt S, O, L.

List Objects creates an ASCII file which lists the objects in your drawing.

Below is a typical file created by List Objects, extracted from a drawing of a floor plan:

Parent name	object name	Quantity	Area	Perimeter
BUILDING	EXTWALLS	1	8.706215e+07	109939.5
BUILDING	INTWALLS	1	5647791	71410.93
fittings	door	8	8790306	27965.14
fittings	extdoor	1	3026734	3629.442
fittings	window	2	1.92039e+07	14844
furniture	chair	7	955833.1	8881.744
furniture	desk	7	4619122	23064.69
There are 27 of	pjects selected			

For each type of object on the drawing, List Objects shows:

- the parent name;
- the object name;
- the number of objects with that name;
- the total area taken up by objects with that name; and
- the total perimeter of objects with that name.

For example, in the listing shown above, there are seven desks in the drawing, grouped under the parent name furniture. The total area taken up by the seven desks is 4619122 sq. mm. The total perimeter of the desks is 23064.69mm.

The perimeters and areas are measured in the units you have selected in <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Drawing</u> Settings (AttS, S, D - page 789).

When you select List Objects, "Sight" Survey prompts:

Do you want data from all layers (else just displayed layers)

If you want to list all the objects in your drawing, click \underline{Yes} . If you only want to list the objects in the visible layers, click \underline{No} .

Do you want areas and perimeters calculated automatically

If you click Yes, "Sight" Survey will calculate areas and perimeters. Click No, and the perimeters and areas will not be calculated.

¥

Areas calculated by List Objects may be incorrect. For List Objects to produce correct results, the elements in each object must have been drawn sequentially.

You can select the units you want areas measured in, for example square feet, acres etc. These units can be different from the units you are drawing in. For example, you can draw in feet and measure areas in acres. See <u>Start \Rightarrow Settings \Rightarrow Drawing Settings (ArtS), S, D - page 789).</u>

A dialog box headed **Save Object Listing As** appears. This is a standard Windows **Save** dialog box. If you do not know how to use it, see the documentation that came with your copy of Windows.

Type a name for the file the object listing will be saved as, and click $\Box \kappa$. The information is saved to file. You can look at it using any text editor such as the Windows Notepad.

29.06

<u>M</u>ake Symbol

FUNCTION: The <u>Make Symbol</u> function is used to create an object from primitives you have already drawn by following a series of prompts.

To access the <u>Make Symbol</u> function, press <u>Alt</u>S, O, M.

There are three functions that may be used to create an object manually: <u>Begin New Object</u>; <u>Group Into Object</u>; and <u>Make Symbol</u>. The <u>Make Symbol</u> function involves drawing primitives, then grouping the primitives into objects later.

If you are going to use objects as symbols - that is, you are going to import them into other drawings - <u>Make Symbol</u> has three advantages over the other methods of object creation:

- It asks you a series of questions allowing you, for example, to place the object's hook point at a position of your choice. The position of the hook point is very important if you are going to import an object from one drawing into another as a symbol, because the object will appear in the second drawing with its hook point at the cursor position. If you were to use **Begin New Object** or **Group Into Object** to create the object, you would have to position the hook point separately using **Start** ³ **Objects** ³ **Change Hook Point** (Att S, O, K page 784).
- 2. It allows you to attach information (attributes) to objects. For example, if you draw a fuse, you might want to attach an attribute to it stating that its current rating is 2 amps.
- 3. It allows you to define your own snip box around the object. This will automatically delete any part of the drawing over which the symbol is placed.

Before using <u>M</u>ake Symbol

Before you use \underline{M} ake Symbol, you must draw the primitives you want to group.

If you are going to use the object as a symbol, you should draw it horizontally. For example, if you are drawing a fuse:



Draw it this way...

... not this way.

This is because of the way that "Sight" Survey can automatically rotate and snip around symbols when they are inserted into drawings.

Giving the object a parent name

Follow one of these procedures to give an object a specific parent name:

- Before creating the object, use <u>Start</u> [∞]Objects [∞]Change <u>Parent</u> (<u>Alt</u> <u>S</u>, <u>O</u>, <u>P</u> - page 783). This function defines the default parent name, which will be given to all the objects you subsequently create until you use Change <u>Parent</u> again.
- After you have created the object, use <u>Start</u> [™] <u>Objects</u>
 [™] Change <u>Name</u> (<u>Alt</u>S), <u>O</u>, <u>N</u> page 780).
- If you do not choose a parent name before creating the object, the object will be given the default parent name. This will be **A** unless you have already used the **Change Parent** option to change it.

Objects with the parent name **__LABEL_** (there are two underscores on either side of **LABEL**) are not displayed in the list of symbols that appears when you use the <u>Start</u> **>** <u>D</u>raw **>** <u>Symbol</u> function. If you are creating objects for use as symbols, use **__LABEL_** as the parent name for anything which you do not want displayed, such as text descriptions.

i

Using <u>Make Symbol</u>

When you select Make Symbol, "Sight" Survey prompts:

Enter name for new symbol (blank to stop making symbols)	×
OK	

Type the name of the object you are about to create and click **OK** or press **.** *Do not type a parent name*.

Enter symbol hook point

The hook point is the insertion (reference) point of the object which is used to position the object on the drawing. Choose the hook point carefully and position it accurately so that when you come to place the object into the drawing it will appear where you expect it to.

Because of the way that "Sight" Survey automatically rotates and snips around symbols when they are inserted into drawings, you should position the hook point on the left of the symbol.

This diagram shows two examples of objects - a window and a fuse. Position the cursor at the position to be used as the hook point and click or press *-Enter*.

To position the hook point accurately see Accurate Placement on page 497.

Enter lower left corner of snip box (for snipping out lines)



(ad)

ad

You can only define a linear, square or rectangular snip box.

Wall before symbol

Wall after symbol

When you insert the symbol into a drawing, the program will automatically snip out everything inside the box you define here, if you want it to. In the example to the left, a window symbol has been inserted into a wall and the wall has been snipped away to accommodate the window.

Position the cursor at the lower left corner of the snip box and click or press *rener*.

To position the cursor accurately see **Accurate Placement** *on page 497.*

Enter upper right corner of snip box (for snipping out lines)

Position the cursor at the upper right corner of the snip box and click or press *-*Enter.

Enclose everything that you want included in symbol

Draw a box or polygon around the primitives that you want to include in the object. Two diamonds marking the extents of the snip box will appear.

Ç

If you enclose any hatches within the polygon, these will be converted to lines. See Start Annotate Hatch->Lines (AltS, A, H - page 722).

If you want to attach information, called attributes, to an object, follow this section.

Enter prompt for symbol attribute 1 (Bla	ank for no attributes)	×
ОК	Cancel	

The attribute prompt is the name or description for information, for example RESISTANCE for a resistor, WEIGHT for a piece of steel, MATERIAL for what a window is to be manufactured from or CURRENT for the current rating of a fuse. Type in the name and click **OK** or press **.**

Enter attribute default value	×
ОК	Cancel

This will be the default value of the attribute named in the previous prompt. For example, you might type WOOD as the material a window is made out of, or 3 AMP for the current rating of a fuse. Type in the value and click OK or press Finer.

Attributes



When you come to enter the object into another drawing using <u>Start</u> \Rightarrow <u>Draw</u> \Rightarrow <u>Symbol</u>, you can either display attributes as text or extract them in a bill of materials. See <u>Start</u> \Rightarrow <u>File</u> \Rightarrow Load Symbol File (AttS, F, \oplus - page 525).

Enter attribute position

Position the cursor where you want the attribute to be positioned and click or press *eterer*. A diamond appears.

If you display the attribute as text when you load the object into another drawing, this is the position where the attribute will be displayed.

Enter prompt for symbol attribute 1 (Blank for no attributes)	×
OK Cancel	

Type a prompt for another attribute and click **OK** or press **Fine**. Attribute prompts will be repeated with reference to the new attribute.

Alternatively stop adding attributes by leaving the text entry area blank and clicking $\Box K$ or pressing $\blacksquare M$.

Enter name for new symbol (blank to stop making symbols)	×	ction
		Se
OK Cancel		

Type the name for a new object and click **OK** or press **returner**. To stop making objects, leave the text entry area blank and click **OK** or press **returner**.

No Attributes

If you don't want to attach information, called attributes, to an object, follow this section.

Enter prompt for symbol attribu	te 1 (Blank for no attributes) 🛛 🗙
ОК	Cancel

Leave the text entry area blank and click **OK** or press **Enter**.

Enter name for new symbol (blank to stop making symbols)	×
OK Cancel	

Type the name for a new object and click **OK** or press **Ener**. To stop making objects, leave the text entry area blank and click **OK** or press **Ener**.

When you have created the object, you will be able to select the entire object at once by clicking on it with the **Select Cursor** (\triangleright). If you want to select a single primitive within the object, you must explode it first by using. Start \Rightarrow Objects \Rightarrow Explode Object (Att)S, \bigcirc , \boxtimes - page 770).

Change <u>N</u>ame

FUNCTION: The **Change** <u>Name</u> function allows you to rename an object or objects. Both the object and parent names may be changed.

To access the Change Name function, press Alt S, O, N.

You can select the object whose name must be changed by one of two methods:

- 1. Clicking on it with your cursor (see Using the Cursor);
- 2. Specifying the name of those objects (see Specifying the Name).

29.07

Using the Cursor

Enter object name to be changed or	select object with cursor 🛛 🗙
Cursor	
ОК	Cancel

To select the object whose name must be changed by clicking on it with your cursor, click **OK** or press **-Enter** to accept the default answer to this question, **Cursor**.

Select object for name change

Type the new parent and/or object name for the object you have selected and click $\Box K$ or press \blacksquare



Objects with the parent name __LABEL__ (there are two underscores on either side of LABEL) are not displayed in the list of symbols that appears when you use the <u>Start</u> ⇒ <u>Draw</u> ⇒ <u>Symbol</u> function. If you are creating objects for use as symbols, use __LABEL__ as the parent name for anything which you do not want displayed, such as text descriptions.

Select object for name change

Position the cursor on the object whose name is to be changed and click or press *-Enter*, or cancel the function by pressing *Esc* or the *Space Bar*, or by clicking on *Lancel*.

Specifying the Name

Enter object name to be changed	or select object with cursor 🛛 🔀
Cursor	
ОК	Cancel

Type over the word **Cursor** with the name of the objects whose names you want to change. For example, suppose you have ten objects with the parent name **SHRUBS** and the object name **TREE_LG**. If you type **SHRUBS TREE_LG**, the names of all ten objects will be updated at once to the new name that you specify.

Wildcards may be used. For example, if you type SHRUBS *, all objects with the parent name SHRUBS will be updated to the new name that you specify, regardless of their object names. If you type *TREE_LG, all objects with the name TREE_LG will be updated to the new name that you specify, regardless of their parent names. If you type * *, all objects, regardless of their parent or object names, will be updated to the new name specified.

\checkmark

If "Sight" Survey can't find an object with the name you typed, the function will be terminated.

Enter new Parent and object name	s (separated by a space) 🛛 🗙
Shrubs Tree_(Large)	
ОК	Cancel

Type the new parent and object names and click **OK** or press <u>Enter</u>. Wildcards may not be used.



Objects with the parent name __LABEL__ (there are two underscores on either side of LABEL) are not displayed in the list of symbols that appears when you use the <u>Start</u> → <u>Draw</u> → <u>Symbol</u> function. If you are creating objects for use as symbols, use __LABEL__ as the parent name for anything which you do not want displayed, such as text descriptions.

29.08

Change <u>P</u>arent

FUNCTION: The **Change** <u>Parent</u> function is used to change the parent name of an object.

To access the Change Parent function, press AttS, O, P.

When you create a new object using **Begin New Object**, **Group Into Object** or **Make Symbol**, this object is given the default parent name. The **Change Parent** function changes the default parent name to whatever you specify. All subsequent objects that are created will be given this new name as their parent name until you change it again.

To change a parent name that has already been assigned to an object, use the **Change Name** function previously described.

Enter new parent name		×
PLANTS		ור
ОК	Cancel	

Type the new default parent name and click **OK** or press **Enter**.



If you are going to use the object as a symbol, note that objects with the parent name __LABEL__ (there are two underscores on either side of LABEL) are ignored by the <u>Start</u> ⇒ <u>Draw</u> ⇒ <u>Symbol</u> function. You can use __LABEL__ as the parent name for anything which you do not want displayed in the symbols list, such as text descriptions and annotations.

Section 29

Change Hook Point

FUNCTION: The Change Hook Point function is used to change the origin, or placement point of an object.

To access the Change Hook Point function, press AltS, O, K.

When an object is created it is automatically given a *hook point*, or placement point. However, this hook point may not be in a suitable position, especially if the object is to be used as a symbol. The **Change Hook Point** function allows you to change the hook point of an object.

When you select **Change Hook Point**, stars appear on the drawing. These stars represent the current positions of the hook points.

You may find that some objects do not appear to have a hook point. This occurs when hook points are positioned on top of each other. This is especially likely to be the case if one object was drawn originally and was later split into several objects.

Select object for hook change

Position the cursor near the object that needs a new hook point and click or press *enter*. The cursor jumps onto the object's current hook point.

Enter new hook point

Position the cursor where you want the object's new hook point to be and click or press *rener*.



If you are going to use the object as a symbol, you should position the hook point at the **left** hand end of the symbol because of the way "Sight" Survey automatically rotates and snips around symbols when they are inserted into drawings.

29.09



To position the cursor accurately see **Accurate Placement** *on page* 497.

A star appears at the new hook point position.

Select object for hook change

Position the cursor near another object that needs a new hook point and click or press *Enter*, or cancel the function by pressing *Esc* or the *Space Bar*, or by clicking on *Cancel*.

29.10

<u>U</u>pdate Objects

FUNCTION: The <u>Update Objects</u> function is used to replace all the examples of a particular object.

To access the Update Objects function, press AltS, O, U.

Update Objects allows all the examples of a particular object to be updated at once. A typical example would be the need to replace all the square columns shown on an existing floor plan with differently shaped columns. Without this function, each column would have to be updated individually.



Before using <u>Update Objects</u>, you must select *one* of the original objects (one of the square columns in this example) as the *current object* using the <u>Start [®] Objects [®] Select Current Object</u> (ARS, O, S) - page 787). You must then *edit* this one object to the desired shape and select the <u>Update Objects</u> command.

¥

It is a good idea to store your drawing before performing this operation, just in case things go wrong!

Update Objects assumes that Start → Modify → Repeat (ARS, M, P - page 631) or Start → Modify → Drop (AttS, M, D - page 634) were used to create the multiple copies of an object that now need replacing, as these two commands generate copies with the same parent and object names as the original. If Repeat or Drop were not used, use Start → Tools → Query Entity (AttS, T, Q - page 751) to ensure that all objects to be replaced have exactly the same parent and object names as the current object (the one that has been edited). If they do not, change them using Start → Objects → Change Name (AttS, O, N - page 780).

It is a good idea to establish the positions of the hook points of the objects you are going to replace before you select the Update Objects command. To do this, select Start Objects Change Hook Point (AltS, O, K - page 784). A star will appear on each object. Cancel the Change Hook Point function without changing any hook points by pressing so or the present function without changing on Cancel. The hook points will remain marked by green stars.

<u>Update Objects</u> will work on objects that have been scaled or rotated after being created using the <u>Start $\ Modify \ Repeat$ </u> or <u>Start $\ Modify \ Drop$ </u> commands. However it will not work if the current object (the one that has been edited) has been scaled or rotated.

Sure you want to update all objects with same name as current object

Click Yes if you are sure you want to update the objects, or if you want to cancel the function.

Enter point on current object where reference points on old objects must be

If you want the objects to retain their current positions, it is important that the point you choose here is *the hook point of the current object*. Otherwise, all the objects except the current object will be moved and the positions of their hook points will be altered. Once you have selected the point, click or press *-Enter*. The objects are replaced.

and

To position the cursor exactly at the hook point, see **Accurate Placement** *on page 497.*

Select Current Object

FUNCTION: The <u>Select Current Object</u> function is used to select an object to be the current object.

To access the Select Current Object function, press AttS, E, O.

All newly drawn primitives are added to the current object. If you want to add to an object which already exists, you should first choose that object as the current object.

Another use for <u>Select Current Object</u> is in the function Update Objects (discussed in the previous section) where the current object is used as the template for the other objects with the same name.

Select object to become current object

Position your cursor onto the object that must become the current object and click or press *enter*.

29.12

Blink Current Object

FUNCTION: The **Blink Current Object** function is used to highlight current object.

To access the Blink Current Object function, press Att S, O, 1.

29.11

When you select this function, the current object is highlighted. If the current object is already highlighted, selecting **Blink Current Object** un-highlights it. In this way the current pattern can be made to "*blink*."

Blinking the current object is a useful method of determining where the current object is located.



Drawing Settings Unit Settings View Settings Re-Center P<u>aper</u> Snap Mode Change Magnify Factor

Line Defaults (XL) Polyline De<u>f</u>aults Parallel Defaults

Set Text Defaults (XT) Dimension Defaults Surveying Dimensions Set Arrow Defaults (XA) Set Ballgon Defaults

D<u>X</u>F/DWG Conversion (XG) Virtual <u>M</u>emory Settings

Layer Control (EL) Set Current Layer (LV) Set Visi<u>b</u>le Layers Delete Layer Working Layers

Section 30 <u>Start Menu - SETTINGS</u>

The **SETTINGS** menu is where you will find all of the various routines needed to control drawing settings. From this menu you can change settings for: Drawings; Units; View; Dimensions; Text; Arrows; Layers; Memory; Lines; and Drawing Conversion.

30.01 Drawing Settings

FUNCTION: The <u>Drawing Settings</u> function is used to set or change paper size, scale, units, coordinate system, angular format and isometric grid, circles and dimensions.

When you select this option, a dialog box appears. The options in the box can be set before you start drawing or changed at any time during drawing.

Drawing defaults
Paper Size
A 8.5×11" A 8.5×11" A 9 Portrait Landscape
Scale Type Engineering 💌
1'' = 100'
Scale Ratio 1: 1200
Coordinate System Number of Decimals 4
♦ <u>C</u> artesian
• <u>Surveyor</u> <u>Surveyor Setup</u>
Angular Format
Nd'm's'₩
OK Cancel <u>H</u> elp

Section 30

	The default paper size, scale, units etc. that are loaded each time you enter "Sight" Survey or select Start ℃File ℃New Drawing (Att ⑤ , F), № - page 509) are stored in a drawing called STARTUP.DRG .
Paper Size	The currently selected paper size is displayed in a drop-down menu. To change paper size, click the down arrow (). Scroll the list of paper sizes until you see the size you want, then click it.
	On the drawing screen, the paper size is represented by a magenta box. The center of this box will always correspond to the coordinate 0 , 0 if you are using Cartesian coordinates, or to the coordinate you have specified for the screen center if you are using Surveyor coordinates (see Coordinate System).
	If you change to a larger paper size in mid-drawing (for example from A4 to A3), the objects you have drawn will take up a smaller proportion of the paper. You can see this if you do a <u>Start</u> $\sqrt[3]{View}$ $\sqrt[3]{Zoom Sheet}$ (ZS or AftS, V , S) - page 574), which displays your entire sheet of paper on the screen.
	Similarly, if you change to a smaller paper size in mid-drawing (for example from A3 to A4), the objects you have drawn will take up a larger proportion of the paper, and may even overlap the edges. If this is the case, do a Start View Zoom All (ZA or Atts, V), A - page 573) to see the whole drawing in relation to the paper size (represented by a purple box
	In either case, you may want to use Scale to rescale your drawing so that it fits the new paper size appropriately.
Orientation	Click on Portrait if you want your drawing to be oriented in portrait (i.e. tall), or on Landscape if you want it in landscape (i.e. wide). You can also toggle the orientation by clicking on the Paper Orientation icon () on "Sight" Survey's main toolbar.
Scale	The currently selected scale type is displayed in a drop-down menu. To change scale type, click the down arrow () and choose from three scale options: Architectural, Engineering and Metric/Custom. Click on the option you want.

Engineering

If you select the **Engineering** option, the scale part of the **Drawing Settings** dialog box looks like this:

Scale Ty	vpe Engineering			
	1'' = 10'			
Scale Ratio 1: 120				

You can select a standard scale from the list of scales that appears, for example 1'' = 10'. The first number (1'') is a length on paper. The second number (10') is the equivalent real length. When you select a standard scale from the list box, the **Scale Ratio** box automatically updates. For example, if you have chosen a standard scale of 1''=10', the scale ratio will automatically update to 1:120.

Alternatively you can type a scale ratio directly into the Scale Ratio box. For example, if you type 1, the scale will be 1:1. If you type 120, the scale will be 1:10, etc.

In the **Engineering** option, drawing units are automatically set to **feet**. However, you can change the units by selecting the **Metric/Custom** option, clicking on the **Drawing Units** button, and selecting the unit. Then reselect the **Engineering** option.

The **Architectural** option, the scale part of the **Drawing Settings** dialog box looks like this:

Scale	Туре	Architectural		
1/4" = 1'				
Scale Ratio 1: 48				

You can select a standard scale from the list of scales that appears, for example 1'' = 1'. The first number (1'') is a length on paper. The second number (1') is the equivalent real length. When you

Architectural

select a standard scale from the list box, the **Scale Ratio** box updates automatically. For example, if you have chosen a standard scale of **1**"=1', the scale ratio will automatically update to **1:12**.

Alternatively you can type a scale ratio directly into the Scale Ratio box. For example, if you type 1, the scale will be 1:1. If you type 12, the scale will be 1:12, etc.

In the Architectural option, drawing units are automatically set to **feet and inches**. However, you can determine the preferred denominator, or set the inches to decimal by selecting the Metric/Custom option, clicking on the Drawing Units button, selecting **feet inches** as the unit, selecting the denominator (see Drawing Units, below), then reselecting the Architectural option.

Metric/Custom

ī

Setting your drawing scale and units using the Metric/Custom option is best described using an examples

For details on the **Drawing Units** you can specify, see **Drawing Units** later in this chapter.

When specifying Drawing Units, ensure you also specify sensible Area Units. For example, if your drawing units are millimeters, you probably don't want to measure areas in square feet!

Suppose you want to produce a drawing at a scale of 1:50 in meters. To draw at this scale, set up the scale part of the **Drawing Settings** dialog box so that it looks like this:

Scale	Туре	Metric/Custom	•	
Paper Units		Drawing Units		
1	meter	→] = 50	meter	
Scale Ratio 1: 50				

You can do this in one of two ways:

- Set the Paper Units to 1 meter and the Drawing Units to 50 meters. The Scale Ratio box automatically updates to 1:50.
- Type 50 into the Scale Ratio box, which will then specify a scale of 1:50. Set the Drawing Units to meters.

If you change scale in mid-drawing, your drawing will be re-scaled about the coordinate 0, 0 if you are using **Cartesian** coordinates or about the coordinate you have specified for the screen center if you are using **Surveyor** coordinates (see **Coordinate System** later in this section).

Changing scale does not change dimensions. For example, if a line has a dimension of 100 feet, and the scale is changed, then that line will still have a dimension of 100 feet. It will merely look smaller or larger in relation to the paper size. If you change to a smaller scale (for example from 1:1 to 1:10), the objects you have drawn will take up a smaller proportion of the paper. Similarly, if you change to a larger scale (for example from 1:10 to 1:1), the objects you have drawn will take up a larger proportion of the paper, and may even overlap the edges. If this is the case, use Start \mathbb{V} View \mathbb{V} Zoom All (ZA or AttS, \mathbb{V} , A - page 573) to see the whole drawing in relation to the paper size. In either case, you may want to change the **Paper Size** (previously discussed) so that your drawing fits the paper appropriately. **Different Scales on One Drawing** You can have different scales on one drawing by creating layers with different magnifications. See Start >> Settings >> Layer **Control** (**EL** or **Att**S, **S**, \heartsuit - page 839) for more details. **Coordinate system** If you check **Cartesian**, the program will use the Cartesian coordinate system. Most professional designers, such as Mechanical Engineers and Architects, will use the Cartesian system. **Surveyor** coordinates are for use by surveyors. If you choose this option, the text on the button labeled Surveyor Setup... will become

Changing Scale

black. If you click on this button, the following dialog box appears.

Surveyor Settings	×
Surveyor Origin (screen center)	
0.000000 0.000000	
Set origin at known point	
• <u>N</u> orthing, Easting	
♦ Easting, Northing	
• No <u>r</u> thern Hemisphere	
\diamond So <u>u</u> thern Hemisphere	
OK Cancel	

If you are working in the <u>Surveyor</u> coordinate system, drawings that have been drawn using the same coordinate system will automatically be aligned with respect to each other if you use <u>Start</u> $\underbrace{View} \underbrace{Open Drawing}$ to load more than one drawing at once.

The **Surveyor Origin** section of the dialog box allows you to set up "Sight" Survey's coordinates to match the coordinates of your survey. Type the survey coordinates that should correspond to the screen center into the **Surveyor Origin** box.

If you want to type the coordinates of another point on the screen instead of the screen center, type these coordinates into the **Surveyor Origin** box and check **Set origin at known point**. When you exit **Drawing Settings**, this message will appear:

Message	×
Click on point with coordinates 50.00000	100.00000
[OK]	

Click **OK** to exit the message box. "Sight" Survey prompts:


Click on point with coordinates x y

Surveyor Origin

Place the cursor at the position on the screen corresponding to the coordinates you typed into the **Surveyor Origin** box and click or press <u>-Enter</u>.

Number of DecimalsThe number that you type here defines the number of decimal
places that "Sight" Survey's drawing is accurate to. The maximum
number is 15. This setting has nothing to do with "Sight"
Survey's double precision COGO accuracy.

Isometric Grids



If the **lsometric Grids** box is checked, certain functions will behave in a particular way.

<u>Start</u> Tools Grid will produce an **isometric grid**, where the grid points are angled at 30, -30 and 90 degrees to each other.

Start D **Draw** D **Ellipse** will draw ellipses that are the right shape for use as **circles on an isometric drawing**, and that are angled at 90 degrees to the angle at which the cursor is locked.

<u>Start</u> \mathbb{P} <u>Annotate</u> \mathbb{P} <u>S</u>lope Dimensions will allow you to angle witness lines to produce dimensions appropriate for isometrics.

Angular Format

When you click on the **Angular Format** button (labeled **dd.ddd** by default), a dialog box (shown on the next page) appears.

The selected **Angular Unit** is shown here (**dd.ddd** stands for decimal angles). To change units, click on the arrow, then click on the unit you want to use. You have a choice of grads (100 grads = 90 degrees), radians, decimal angles, and degrees, minutes and seconds.

Degrees, minutes and seconds can be displayed in one of three ways: degrees.minutes.seconds; degrees° minutes' seconds" or N degrees° minutes' seconds" W.

Section 30

Angular Format	×
Angular Units	Number decimals
d.mm.ss 💌	1
Zero Point	<u>1</u> 2 O'clock
<u>9</u> O'clock 🧄 ——	——
<	> <u>6</u> 0'clock
↔ Measure <u>C</u> lockWise	
♦ Measure CounterClo	ock <u>W</u> ise
ОК	Cancel

Number of Decimals

Zero Point and Clockwise/ Counter-clockwise Settings Type here the number of decimals that you want displayed.

The zero point option allows you to decide whether zero degrees will be in the 3, 6, 9, or 12 o'clock position. If the 3 o'clock position is checked, zero degrees will be at the 3 o'clock position and 180 degrees will be at the 9 o'clock position. If the 12 o'clock position is checked, zero degrees will be at the 12 o'clock position and 180 degrees will be at the 6 o'clock position, etc.

The zero point and clockwise/counter-clockwise settings you define in **Angular Format** apply only to **Polar Move** and to surveyor functions.

Other functions, such as <u>Start</u> \mathbb{P} <u>Modify</u> \mathbb{P} <u>Rotate</u>, are not affected by <u>Angular Format</u>. Angles are measured counter-clockwise from the 3 o'clock position.

The description of each individual function states whether that function is affected by **Angular Format** or whether angles are measured counter-clockwise from 3 o'clock.

If you check the **Measure Clockwise** diamond, angles will be measured in a clockwise direction. For example, if zero degrees is positioned at the 3 o'clock position, 90 degrees will be at the 6 o'clock position. if you check the **Measure Counter Clockwise** diamond, angles will be measured in a counter clockwise direction. For example, if zero degrees is positioned at the 3 o'clock position, 90 degrees will be at the 12 o'clock position.

Typing in degrees, minutes, seconds and quadrants

You can type in 12° 34' 56.78" as 12 34 56.78, as 12.34.56.78, or as 12.345678. Using the last method, the first two characters after the decimal point are taken as minutes, the next two as seconds, and anything after that as decimal seconds.

You can type in quadrants as N45 23 12E. Alternatively, you can use a quadrant number instead. Use the / or * characters to separate the angle from the quadrant number, which must come after the angle. For example, N12°34′56″E can be entered as 12.3456*1 or as 12.3456/1. As is the case in COGO, the four quadrants are: NE = 1; SE = 2; SW = 3; and NW = 4.

30.02

Unit Settings

FUNCTION: The Unit Settings function is used to change the drawing's linear and area units.

To access the Unit Settings function, press Alts, S, U.

To change units, set the Drawing Settings scale type to Metric/ **Custom**. The currently selected linear unit is displayed on the **Drawing Units** button. To change linear or area units, click on this button, and the **Change Units** dialog box appears. The Linear Units are shown along with the Unit Symbol and the Area Units.

You can change the linear units using the list box at the top of the Change Units dialog box. The choices are as follows:

- mm
- Meter •
- Inches. These are decimal inches, i.e. one and a half inches • would be represented as 1.5.
- User-defined. If you check this option, the prompt mm per • user unit will appear. Type the length of the user defined unit in mm.

Change Units	×
feet	•
Unit <u>S</u> ymbol	
<u>A</u> rea Units	
Square Feet	-
OK Canc	el

	 Feet inches. If you check this box, dimensions will be displayed in the format 5+7/12 (five inches and seven twelfths of an inch), 1'3+5/16 (one foot, three inches and five sixteenths of an inch), etc. When you check this option, another small dialog box appears. You must enter the largest denominator into this small dialog box. For example, if you type 12, the denominators used will be 2, 3, 4, 6 and 12. If you type 16, the denominators used will be 2, 4, 8 and 16, etc. Feet. These are decimal feet, i.e. one and a half feet would be represented as 1.5'. Yard Km Mile
Unit Symbol	Some units have a default symbol which appears in the Unit Symbol box. You can type any symbol to represent any unit here.
Area Units	These are the units that areas are measured in using <u>Start</u> → <u>Tools</u> → <u>Polygon Area</u> , and <u>Start</u> → <u>Objects</u> → <u>List Objects</u> . You can change the area units using the <u>Area Units</u> list box at the bottom of the <u>Change Units</u> dialog box. The choices are:
	User defined Square mm Square inches Square cm Square feet Square m Square yards Hectares Acres Square km Square miles
Changing Units	If you change linear units in the middle of a drawing, existing dimensions will not be updated to the new units automatically (see next paragraph). All subsequent dimensions, however, will be displayed in the new units. This is an advantage to some people who want or need to display both English and metric units on the same drawing .
	If you change units in the middle of a drawing and you want to update the dimensions you have already drawn to the new units, you must do the following once you have changed units. First select your entire drawing using Select All in Start ⇒ Edit ⇒ Selection Filters (AHS), E, F - page 560). Then use the Start ⇒ Modify ⇒ Scale (AHS), M, A - page 629) to scale the drawing

by 0.5 0.5. Finally, use the **Scale** function again to scale the drawing by 2 2. The dimensions will have been updated.

View Settings

FUNCTION: The <u>View Settings</u> function is used to control what is displayed in the **Drawing** window.

To access the <u>View Settings</u> function, press AHS, S, V.

When you select <u>View Settings</u>, a dialog box appears. The default view settings loaded each time you enter "Sight" Survey or select <u>Start $r = \underline{New Drawing}$ are stored in a drawing called STARTUP.DRG</u>.

View Settings	×
✓ Show coordinates ■ Polar coordinates	✓ Show a <u>r</u> c centers Control Bar Font
🗹 Show geometry	Background Color
Annotation to draw	Hatch to draw
All	All
Poi <u>n</u> t Style	Bit <u>m</u> aps to draw
	Normal 💌
_ Big C <u>u</u> rsor ∠ Ru <u>l</u> er	Sho <u>w</u> Data Items
V Rujer	Normal 💌
☑ Display <u>s</u> croll bars	
Set scroll interval to 2	0 % of screen
Text to <u>b</u> oxes at 1.5	% of screen
Text to <u>d</u> ots at 0.3	% of screen
Objects drawn at 1.5	% of screen
OK Canc	el <u>He</u> lp

Section 30

Show <u>C</u>oordinates and <u>P</u>olar Coordinates

The <u>Show Coordinates</u> and <u>Polar Coordinates</u> boxes are not used by "Sight" Survey. The Northing (Y) and Easting (X) coordinates at the cursor are always displayed at the bottom right of the screen.

Whether these coordinates are shown in the order Easting, Northing or Northing, Easting depends on the **Coordinate System** you have chosen in **Start ⇒ Settings ⇒ Drawing Settings** (ARS, S, D - page 789).

Show Geometry

Show Arc Centers

Control Bar Font

Background Color

Annotation to Draw



The **Show <u>G</u>eometry** box is not used by "Sight" Survey.

If the **Show A<u>r</u>c Centers** box is checked, dots marking arc or circle center points are displayed. (*Dot size shown is exaggerated.*)

You can jump to these dots using <u>Start</u> \textcircled{D}_{IOOS} <u>Jump Point</u> (AttS, T, J - page 730) and <u>Start</u> <u>Dools</u> <u>Jump Circle Center</u> (AttS, T, E - page 730).

If you uncheck the **Show A<u>r</u>c Centers** box, the dots will be "switched off". Even though you can't see them, you will still be able to jump to them.

The Control Bar Font button is not used by "Sight" Survey.

This option allows you to change the background color of the **Drawing** window. When you click on the button, a color palette appears.

Click on the color you want the **Drawing** window to be.

This setting allows you to determine which annotations will be displayed on the screen, and how. Your options are:

- None, all the annotations you have drawn will be "switched off". No annotations will be shown on the screen, although all will be printed or plotted out. This results in faster screen redraws.
- Text Only, dimensions will be "switched off".
- **Dimensions Only**, text, including text in balloons as well as entire text bubbles, will be "switched off".

- All Text as Boxes, all text, including balloon and dimension text, will be displayed as boxes.
- All, all annotations will be displayed.

Point Style ⇒ Draw ⇒ Point will be displayed.

×
Point Si <u>z</u> e (mm)
3
οκ
Cancel

This option controls point size and how points drawn using <u>Start</u>

Points can be "turned off," or displayed as follows:

- Point
- + Cross
- X Cross

Blip

By checking one or more of the boxes: Add <u>Circle</u>; Add box; Add biamond; you can choose to display points with circles, boxes and/or diamonds around them.

You may also set the size of the point to be drawn. Enter a value (mm). If you type a negative point size, it is interpreted as a percentage of the screen size. For example, a point size of -2 means that points will always be drawn at 2% of screen size regardless of magnification.

Big Cursor If you check this option, the cursor will be attached to a cross hair extending all the way across the drawing area in the horizontal and vertical directions.

	•	← Edge of the drawing area		If the Ruler box is checked, a ruler bar will be displayed of the Drawing window. If the Ruler box is not bar will not be displayed.
Hatch to	Draw		Displaying hatches	s slows down redraws. This setting gives you the

Displaying hatches slows down redraws. This setting gives you the option to display hatches on request only, to display all hatches or to display selected hatches. Your options are:

	 None, no hatches will be displayed when you redraw the screen. To display your hatches when None has been selected, use <u>Start ⇒ Annotate ⇒ Draw All Hatch</u> (Alt S, A, D - page 721). This will draw all your hatches onto the screen. The next time you do a redraw, the hatches be "switched off" again.
	• All, all your hatches will be displayed each time you redraw the screen.
	• Selected, only those hatch perimeters that have been selected using the Hatch option in <u>Start</u> ⇒ <u>Edit</u> ⇒ <u>Selection</u> <u>Filters</u> (AttS, E, F - page 560) will be hatched each time you redraw the screen.
Bit <u>m</u> aps to Draw	When you load a bitmap, you can either load it as a placeholder or in full detail. If you load a bitmap as a placeholder, it will be displayed as a cross-hatched rectangle. This speeds up redraws.
	The Bitmaps to Draw setting gives you the option to display all the bitmaps in your drawing as placeholders or in full detail, regardless of how you loaded them.
	• All, all bitmaps will be displayed in full detail.
	• None, all bitmaps will be displayed as placeholders.
	• Normal, the bitmaps will be displayed as you loaded them. Bitmaps that were loaded as placeholders will be displayed as placeholders. Bitmaps that were loaded in full detail will be displayed in full detail.
Sho <u>w</u> Data Items	This setting is not used by "Sight" Survey.
Display S <u>c</u> roll Bars	If the Display Scroll Bars box is checked, scroll bars will be displayed on the screen. The scroll interval determines how sensitive the scroll bar is. The smaller the interval, the smaller the distance you will be able to pan using the scroll bars.

Text to <u>B</u> oxes at _ % of Screen	There is no point in drawing text onto the screen in full detail if it is too small to read. The Text to Boxes option specifies a percentage of the screen size below which text is not drawn in full detail. For example, if the value is 1.5%, any text smaller than 1.5% of the screen size is drawn as a box, speeding up screen redraws.
Text to <u>D</u> ots at _ % of Screen	This is exactly the same as Text to <u>B</u>oxes , except that text is drawn as a dot instead of as a box.
<u>O</u> bjects Drawn at _ % of Screen	In concept, this option is the same as the Text to Boxes option. There is no point in drawing objects onto the screen in full detail if they are too small to see properly. This option specifies a percentage of the screen size below which objects are not drawn in full detail. For example, if the value is 1.5%, any object smaller than 1.5% of the screen size is drawn as a box, speeding up screen redraws.

Re-Center Paper

FUNCTION: The **Re-Center Paper** function is used to move the paper so it fits your drawing better.

To access the Re-Center Paper function, press AltS, S, A.



30.04

This function is especially useful for centering drawings that have been imported via DXF or DWG.

Section 30

The edges of your sheet of paper are marked by magenta dotted lines. Sometimes you may need to center your drawing on the paper.

When you select **Re-Center Paper**, "Sight" Survey prompts:

Enter new paper center

Position the cursor where you want the center of the paper to be and click or press *renter*.

If you are using **Cartesian** coordinates, this position will be at coordinate position 0, 0 after re-centering. If you are using **Surveyor** coordinates, it will retain its current coordinates, although it will be moved to the center of the paper.


30.05

<u>S</u>nap Mode

FUNCTION: The **Snap Mode** function is used to enter a snap mode.

To access the **Snap Mode** function, press **AttS**, **S**, **S**.

When you access **Snap Mode**, "Sight" Survey prompts:



To select a Snap Mode, click on the mode you want to use and then click $\Box K$.

Snap modes cause the cursor to behave in a particular way each time you click or press *Energy*. All of the snap modes except **Ereehand** cause the cursor to do two things:

1. To snap onto a specific point. For example, if you are in **<u>Grid</u>** mode, the cursor will snap onto the nearest grid point when you click or press **<u>-Enter</u>**.

2. To accept the point that is snapped onto. For example, suppose you are in **Grid** mode and "Sight" Survey is prompting you to enter the first point of line. When you click or press etemer, the cursor will snap onto the nearest grid point and this point will also be accepted as the first point of the line, causing "Sight" Survey to prompt for the next point of the line.

Ereehand mode is different from the other modes. Unlike the others, it does not cause the cursor to snap onto a particular point when you click or press Ferer. It just accepts the point on which the cursor is currently located. To accept a specific point accurately when using **Freehand** mode, move to that point first using the **Arrow Keys** or one of the **Jumps**, and then accept the point by pressing Ferer or clicking (see the various **Jumps** in the **Tools** menu beginning on page 727).

Freehand mode is the best mode to use for some functions. For example, if you use another mode for the **Fillet** function, the fillet may turn "inside-out". Similarly, if you are using a function like **Stretch**, this function may appear not to be working unless you are in **Freehand** mode. This is because the cursor may keep jumping back to the nearest point, usually the point you are trying to stretch. *If an inexplicable happening occurs, check your snap mode.*

There are two differences between Snap modes and Jumps:

- 1. Snap modes affect the cursor each time you click or press ender. Jumps cause a "one-off" movement of the cursor, i.e. each time you want to perform a jump you have to select the jump.
- 2. Snap modes both move the cursor onto a point and accept that point. Jumps merely move the cursor. To accept a point after you have jumped to it, you must click or press -Enter.

You can see from the cursor which mode you are in. For example, when you are in <u>Freehand</u> mode, the cursor looks like this: f° .

Unless you are using the **Grab** <u>All</u> mode (\bigcirc), the snap mode will not be operational when the **Select** or **Nodes** cursors are displayed (\triangleright or \rightarrow).

<u>F</u> reehand	You can also enter the Freehand mode by clicking on the Freehand icon () he Drawing window toolbar.
	When you are in Freehand mode, the cursor looks like this: f° .
	When you press Finer or click in Freehand mode, the point that the cursor is located on is accepted, for example as the first point of a line. To accept an accurate point in Freehandmode, position the cursor accurately before pressing Finer or clicking using the arrow keys, a jump, etc. See Accurate Placement on page 497.
Grab <u>A</u> ll	You can also enter the Grab <u>All</u> mode by clicking on the Grab <u>All</u> icon () in the Drawing window toolbar.
	When you are in Grab <u>All</u> mode, the cursor looks like this: \Box .
	When Ener is pressed or when you click when you are in Grab All mode, the cursor will automatically snap onto the closest point, intersection or grid point enclosed within the cursor box. Grab All searches within the box in the following order:
	1. If a point (for example a point, the end of a line, the end of an arc, an arc or circle center) is found, take the nearest one.
	2. If a geometry intersection is found, take the nearest one.
	3. If any other intersection is found, take the nearest one.
	4. If any grid point is found, take the nearest one.
	5. If none of the above are found, the Grab <u>All</u> mode will behave in the same way as the Freehand mode.
Į	Unless you need to snap onto points, intersections and grid points, the Freehand mode is a more efficient mode than the Grab All mode on a large drawing because of the searches that the Grab All mode must carry out.

When you are in **<u>G</u>rid** mode, the cursor looks like this: \pm

When you draw in this mode, the cursor will snap onto the nearest grid point when you click or press - If no grid has been drawn, Grid mode acts like the Freehand mode. See Start > Tools > Grid (AtS, T, D - page 747).

•	If the Grid mode does not appear to be working, it is probable that it is snapping to invisible grid points. In order to see these invisible points, zoom into your drawing or increase the maximum number of grid dots across screen. See Start Tools SGrid (ARS, T, D - page 747).
<u>P</u> oint	When you are in Point mode, the cursor looks like this: $\stackrel{*}{\leftrightarrow}$.
	When you draw in this mode, the cursor will snap onto the nearest point when you click or press $\overrightarrow{\text{rem}}$. This may be a point drawn with the Start $\overrightarrow{\text{Point}}$ Point function, the end of a line or arc, an arc or circle center point, the label origin of an item of text, the label origin of an item of dimension text or an arrow end point.
Geom Intersection	When you are in Geometric Intersection mode, the cursor looks like this: $\frac{1}{2}$
	When you press for click when you are in Geometric Intersection mode, the cursor will automatically snap onto the closest intersection or tangency point between geometry lines and circles. If no geometry has been drawn, the Geometric Intersection mode acts like the Freehand mode.
I <u>n</u> tersection	You can also enter the <u>Intersection</u> mode by clicking the <u>Intersection</u> ($\boxed{\mathbb{N}}$) icon in the Drawing window toolbar.
	When you are in Intersection mode, the cursor looks like this: $\sqrt{2}$.

<u>G</u>rid


	When you press Enter or click in Intersection mode, the cursor will snap to the nearest intersection. This intersection can be any combination of lines, arcs and geometry lines and circles.
Circle C <u>e</u> nter	When you are in Circle C<u>e</u>nter mode, the cursor looks like this: \bigcirc .
	When you draw in this mode, the cursor will snap onto the nearest arc or circle center when you click or press <i>-Ener</i> .
Nearest <u>L</u> ine/Arc	This mode will not snap to the centers of geometry circles. Use the Geom Intersection mode for this. You can also enter the Nearest Line/Arc mode by clicking on the Nearest Line/Arc icon (\searrow) in the Drawing window toolbar.
	When you are in Nearest Line/Arc mode, the cursor looks like this: $+$
	When you draw in this mode, the cursor will snap onto the nearest line or arc when you click or press <i>renter</i> . This line or arc can be solid or geometry.
Pe <u>r</u> p	You can also enter the Perpendicular mode by clicking on the Perpendicular icon (\downarrow) in the Drawing window toolbar.
	When you are in Perpendicular mode, the cursor looks like: $\frac{1}{4}$.
	The Perpendicular mode snaps the end of a line to another line or arc so that they are perpendicular to one another. The Perpendicular snap only works when you are drawing lines, including polylines. For example, if you have selected the <u>Start</u> Note: Start Note: Start Start Start Start Start Start
	Enter first point of line





Tan





Position the cursor where you want the start point of the line to be and click or press *Enter*.

Enter next point of line

Enter **Perpendicular** mode by clicking on the **Perpendicular** icon $(\square \square)$ in the **Drawing** window toolbar. The cursor changes to: $\square \square$. Position it close to the line or arc that the line you are drawing must be perpendicular to. Click or press \square .

The end of the line you are drawing snaps to the other line or arc so that they are perpendicular to each other.

You can also enter the <u>Tangent</u> mode by clicking on the <u>Tangent</u> icon (\bigcirc) in the <u>Drawing</u> window toolbar.

The <u>Tangent</u> mode snaps a line or arc to another line or arc so that they are tangential to one another. It only works when you are drawing lines or arcs, including polylines. For example, if you have selected the <u>Start</u> ⇒ <u>Draw</u> ⇒ Line (<u>Pt to Pt</u>) command, "Sight" Survey prompts:

Enter first point of line

Enter next point of line

Enter **Tan** mode by clicking on the **Tangent** icon (\bigcirc) in the **Drawing** window toolbar. The cursor changes shape. Position it close to the arc that the line you are drawing must be tangential to. Click or press **Fine**.

The end of the line you are drawing snaps to the arc so that they are tangential to each other.



30.06

Change Magnify Factor

FUNCTION: The <u>Change Magnify Factor</u> function is used to change the magnification factor.

To access the Change Magnify Factor function, press AttS, S, C.

When you use **<u>Start</u> <u>N</u><u>Uiew</u> <u>N</u><u>Agnify</u> or Demagnify**, the screen is magnified or demagnified by the factor you enter here.

Enter new magnification factor	
3	
ОК	Cancel

Type the magnification factor you want to use, then click **OK** or press <u>-Enter</u>.

30.07	Line Defaults
	FUNCTION: The Line Defaults function is used to determine or change the properties of lines and arcs drawn by "Sight" Survey.
	To access the Line Defaults function, press Ats , E , O , or by right-clicking on the Line icon (\nvdash) in the Drawing window toolbar.

The default line style that is loaded each time you enter "Sight" Survey or select <u>Start</u> \Rightarrow <u>File</u> \Rightarrow <u>New</u> Drawing is stored in a drawing called **STARTUP.DRG**.

When you edit the Line Defaults, the Polyline Defaults will automatically change to the same line type, pen and width you have selected.

You can also use **Line Defaults** to change the line style of lines and arcs as you are drawing them, or to change the line style of existing lines and arcs.

When you access the <u>Line Defaults</u> function, the Line Style dialog box appears.

	LineStyle Pen Width 0.25 points V OK Take From Apply Cancel
Line Style	Press the velocity button next to the line style shown. A drop-down scrollable selection list of several line styles will appear from which you can select the desired style.
Line Color	Press the Pen button next to the line style window. A color palette will appear from which you can select the desired color.
Line Width	Enter a new value into the Width entry box. If you need to change the line width measurement units, press the \checkmark button next to the units box shown. You may select from the following units: mm, inches, and points (a point is $1/72$ of an inch).
Take From	If you want to match the line style of an existing line or arc, select it using the <u>Select</u> (AttS, $[], [S]$ - page 552) or <u>Selection Filters</u> (AttS, $[], [F]$ - page 560) functions. Then go to the <u>Line Defaults</u> option and click <u>Take From</u> . The dialog box will automatically be updated so that the line style of subsequently drawn lines will match the line style of the existing line. Click <u>OK</u> .
Change Existing Lines	Use <u>Select</u> or <u>Selection Filters</u> to select the lines whose styles you want to change. Access the Line Defaults option. Edit the dialog box to your satisfaction, then click <u>Apply</u> and <u>OK</u> . The styles of the selected lines will be updated.

30.08

Polyline Defaults

FUNCTION: The **Polyline Defaults** function is used to determine or change the style of polylines and Bezier curves drawn by "Sight" Survey.

To access the **Polyline Defaults** function, press Att S, S, F, or right-click the **Polyline** icon (\bigcirc) in the **Drawing** window toolbar.

The default polyline style that is loaded each time you enter "Sight" Survey or select <u>Start</u> $\mathbb{P}_{Eile} \mathbb{P}_{New}$ Drawing is stored in a drawing called **STARTUP.DRG**.

When you edit the **Polyline Defaults**, the **Line Defaults** will automatically change to the same line type, pen and width you have selected.

The way polylines (and Bezier curves) look when you draw them depends on the way you have set up the **Polyline Defaults**. You can also use **Polyline Defaults** to change the style of existing polylines and Bezier curves.

When you access the **Polyline Defaults** function, the **Polyline Style** dialog box appears.

Poly LineStyle
Pen No Spline 💌
Width 0.25 points 🗾 Closed
◆ E <u>m</u> pty ◇ <u>H</u> atch ◇ <u>S</u> olid Fill
OK Take From Apply Cancel

In the same manner as Line Defaults, this box allows you to select Line Style of the polyline or Bezier curve (for example solid or dotted); its Line Color; and its Line Width in mm, inches or points. You can select an actual line color and line type, or can choose to set line color and line type By Layer (see <u>Start</u> Settings The set of the set of

The dialog box also allows you to determine whether a polyline will be a straightforward polyline with **No Spline**, a 3 pt **Bezier** curve, or a 4 pt **Bezier** curve, and whether it will be closed and contain a hatch or solid fill.

Polyline Defaults allows you to determine whether a polyline will be a straightforward polyline without a spline, a 3 point Bezier curve or a 4 point Bezier curve.

Polylines look exactly the same as lines drawn using <u>Start</u> [™]→<u>Draw</u> [™]→Line (Chained) (Aft S, D, H - page 585).

3 Point Bezier curves are drawn between every three polyline vertices.

4 Point Bezier curves are drawn through every four polyline vertices.


If you check the **Closed** option, the start point of the polyline will be joined with the end point.

Empty, Hatch and Solid Fill options allow you to hatch the polyline.

If you select **Empty**, the polyline will not be hatched.

Hatch lets you cross-hatch a polyline. If you select **Hatch**, a list box appears. Select the hatch pattern you want from the list box. Hatch patterns are the same as those used by **Enter Hatch/Solid Fill**, and are defined by the **HATCH.PAT** file. See **Start** \Rightarrow **Annotate** \Rightarrow **Enter Hatch/Solid Fill** (ArtS), \triangle , (\square) - page 716).

Solid Fill lets you solid fill a polyline. If you select **Solid Fill**, a colored button appears. Click on this button and a color palette appears. Select the color you want the polyline to be filled with.







Closed

Empty, Hatch and Solid Fill

Take From

If you want to match the style of an existing polyline or Bezier curve, select it using **Select** (Aft S, E, S - page 552) or **Selection Filters** (Aft S, E, F - page 560). Access the **Polyline Defaults** option and click **Take From**. The dialog box will automatically be updated so that the style of subsequently drawn polylines will match the style of the existing polyline. Click **OK**.

Change Existing PolylinesUse Select or Selection Filters to select the polylines or Bezier
curves whose styles you want to change. Access the Polyline
Defaults option. Edit the dialog box to your satisfaction, then click
Apply and OK. The styles of the selected polylines and Bezier
curves will be updated.

30.09

Parallel Defaults

FUNCTION: The <u>Parallel Defaults</u> function determines how parallel lines will be drawn, and what they will look like.

To access the Parallel Defaults function, press AttS, S, P.

When you select <u>Parallel Defaults</u>, a dialog box appears. The defaults selected here determine how parallel lines drawn using <u>Start</u> \rightarrow <u>Draw</u> \rightarrow <u>Parallel Line</u> are drawn, and what they look like.

The default parallel line settings that are loaded each time you enter "Sight" Survey or select **Start** \mathbb{P} **File** \mathbb{P} **New Drawing** are stored in a drawing called **STARTUP.DRG**.

Multiple Parallel Line defaults
◆ Draw <u>F</u> resh □ Line-arc-line ◇ Around <u>E</u> xisting Perimeter
Number of Parallel Lines 1
Defaults for line number 1
Type Width point Offset
Pen 0 -5
☐ <u>C</u> lose off ends ☐ Fillet corners
Starting angle 90
Ending angle 90
OK Cancel <u>H</u> elp

How Parallel Lines will be Drawn	Parallel lines may be drawn in one of three ways:
	1. Around an existing perimeter;
	As "fresh" parallel chained lines. "Fresh" means that there is no existing perimeter to draw around;
	3. As a "fresh" sequence of parallel lines and arcs.
Around an Existing Perimeter	If you want to draw parallel lines around an existing perimeter, check the Around Existing Perimeter box.
	If the Around Existing Perimeter box is checked, you will enter the Perimeter Menu (see page 597) when you select the Parallel Line (\searrow) function to draw the parallel lines. Using the Perimeter Menu , you will have to define the perimeter you want to draw parallel to. When you have defined the perimeter, the parallel lines and arcs will be drawn.
Fresh Parallel Chained Lines	Fresh parallel lines are parallel lines that are not drawn around an existing perimeter. When you draw fresh lines, only one line appears on the screen as you draw using the Parallel Line () function. This line is called the setting out line. The other parallel lines are drawn relative to it once it is complete.
	If you want to draw fresh parallel chained lines, for example the cavity walls of a house, check the Draw Fresh box.

Section 30

	If the Draw Fresh box is checked, you will enter the Line (Chained) function when you select the Parallel Line ($\boxed{\mathbb{N}}$) function. You will have to draw the line that other lines will be parallel to (the setting out line). When you have drawn the setting out line, the parallel lines will be drawn.
Parallel Line Arc LineSequence	If you want to draw a parallel line arc line sequence, check the Line Arc Line and Draw Fresh boxes.
	If the Line Arc Line box is checked, you will enter the Line Arc Line function when you select the Parallel Line (\nearrow) function. You will have to draw the line arc line sequence that other lines and arcs will be parallel to (the setting out line). When you have drawn the setting out line, the parallel lines and arcs will be drawn.
Defining the Parallel Lines	The number of parallel lines is the number of parallel lines excluding the setting out line or the perimeter. You can have a maximum of <i>ten</i> parallel lines.
	The line style of the setting out line is controlled by <u>Start</u> $\underbrace{Settings} \underbrace{Line Defaults}$. For each parallel line you must set up a default line style.
Defaults for Line Number	You may have a maximum of ten parallel lines. Suppose you have chosen 3 as the number of parallel lines. Ensure that the number 1 is displayed in the Defaults for Line Number box. Choose the Pen (color), Type (for example dotted, solid), Width and Offset for parallel line 1.
	Then click on the arrow to the right of the number 1. Because you have chosen 3 as the number of parallel lines, the numbers 1, 2 and 3 are shown. Click on the number 2, which will be displayed in the Defaults for Line Number box. Now choose the Pen, Type, Width and Offset for parallel line 2.
	Repeat for line 3 , or for however many lines you have chosen as the number of parallel lines.
	You can change the defaults of a particular parallel line at any time, so long as that line's number is the one shown in the Defaults for Line Number box.

Pen, Type & WidthThe methods for setting the Pen, Type and Width are identical to
the Start Settings Line Defaults. See page 810 for any needed
instructions.


When you draw fresh parallel lines, only one line will appear on the screen as you draw them. This line is called the **setting out** line, and the other parallel lines will be drawn relative to it. When you draw parallel lines around existing lines or a perimeter, the parallel lines are drawn relative to this perimeter.

The **Offset** is the distance between a parallel line and the setting out line, or a parallel line and the perimeter. It is measured in the units you specified in the <u>Start \Im Settings</u> \Im <u>Drawing Settings</u> (ARS, S, D) - page) dialog box.

Offsets for fresh parallel lines If you type a **positive** offset (for example: 5), the parallel line will appear on the **right** of the setting out line in the direction of drawing.




If you type a **negative** offset (for example: -5), the parallel line will appear on the **left** of the setting out line in the direction of drawing.



Offsets for parallel lines drawn around existing perimeters


Offset

If you type a **positive** offset (for example: 5), the parallel line will appear on the **right** of the perimeter in the direction in which you will define it using the **Perimeter Menu** options. (See page 597.)




Section 30


If you type a **negative** offset (for example: **-5**), the parallel line will appear on the **left** of the perimeter in the direction in which you define it using the **Perimeter Menu** options.



If you track the existing perimeter using the **Auto** option, parallel lines with a **positive** offset will appear on the **opposite side of the perimeter to the one you select** it on.




If you track the existing perimeter using the Auto option, parallel lines with a **negative** offset will appear on the **same side**.



Closing Off Ends

If you do not want to close off the ends of your parallel lines, do not check this box.

If you want to close off the ends of your parallel lines, check the **Close off Ends** box.




u	
<u> </u>	0
Š	0
Š	

Starting and Ending Angles


Start and end angles are measured counter-clockwise from the setting out line, in the direction of drawing or perimeter definition.

In this example, the starting and ending angles for the parallel lines were 135 degrees for the start angle and 45 degrees for the end angle.



If you check this box, "Sight" Survey will automatically fillet parallel lines on the **outside** of corners **less than 90 degrees**.

In this diagram, the solid line represents the setting out line or perimeter. The dashed lines represent the parallel lines.



New Geometry Color

"Sight" Survey does not use this setting.

Filleting Corners

Set Text Defaults

FUNCTION: The **Set Text Defaults** function is used to determine or change the style in which text is drawn.

To access the <u>Set</u> Text Defaults function, press Att, S, E, or right-click the Text icon (A) in the Drawing window toolbar.

The text defaults that are loaded each time you enter "Sight" Survey or select **Start** [™] **File** [™] **New Drawing** are stored in a drawing called **STARTUP.DRG**.

You can use **Set Text Defaults** to determine the style of text as you are writing it; of subsequently entered text; of text that you are importing; or to change the style of existing text. When you select **Set Text Defaults**, the following dialog box appears.

Set Text Defaults	×
Arial	10 points 💌
Character width	0 <u>Angle</u> 0
Linespacing	1 Pen
Text Alignment	◆ L <u>e</u> ft ◇ Center ◇ <u>R</u> ight
Text Label <u>o</u> rigi	in
	$\begin{array}{c c} & \diamond & 6 & \diamond & 9 \\ \hline \diamond & 13 & \diamond & 16 & \diamond & 19 \end{array}$
→ 2	\diamond 12 \diamond 15 \diamond 18 \diamond 8
	\diamond 11 \diamond 14 \diamond 17
♦ 1	⇒ 4 ⇒ 7
🔶 0 (decima	al point)
Take From Apply	
ОК	Cancel <u>H</u> elp

Take From and Apply

The Take From and Apply buttons lets you apply a captured text style or format to existing text. To capture text attributes, select the text, type XT, then click Take From OK.

To apply the captured attributes to other text, select the text, type **XT**, then click Apply to open the **Attributes to Apply** box, shown on the next page. From the **Attributes to Apply** box, select the attributes you want to apply to the selected text and click **OK**.


30.10





- 1. If you select more than one item, the Take From button is not available.
- 2. If you double-click an item instead of typing XT, neither the Take From or Apply buttons are available.
- 3. To change more than one item at a time, use the Selection Filter to select them, then type XT.

The name of the currently selected font is written on the button at the top left-hand corner of the **Set Text Defaults** dialog box. If you click on this button, the **Font Dialog Box** appears. This allows you to select the font you wish to use, embolden or italicize it, change its size, its color and to strike out or underline it.



Section 30

Font Style



Text height can either be determined in the Font Dialog Box (the Size option), where it is measured in points, or in the Set Text Defaults dialog box. Text height is described later in this section.

Windows contains with three types of fonts: **TrueType** fonts, **Screen** fonts and **Plotter** (or Stroke) fonts. If you are going to obtain output using a printer, you should use **TrueType** fonts, or **Printer** fonts that are native to your particular printer. If you are going to obtain output using a plotter, you should use **Plotter** fonts, such as the **Stroke Font** collection available from Simplicity Systems. *Call 1-800-777-7978 for details*.




If you are outputting to a vector (pen) plotter, you should use one of the plotter fonts, Modern, Roman, Script, or some type of stroke font for your text and dimensions. (HPGL Users - if you use any other font on your drawing it will be converted for the plotter but all your text will be plotted horizontally, regardless of its orientation on the drawing.)!

TrueType fonts are preceded by a **TT** or **T** icon in the list of fonts in the **Font Dialog Box**. They look the same on your screen as they do when they are output to your printer. TrueType fonts scale smoothly to any size on almost any Windows-supported screen and printer (but not daisy-wheel printers or plotters). Extra TrueType fonts can be purchased, and those supplied with other packages can be used.

Screen fonts (if they appear at all) are preceded by an icon representing a screen and usually have the suffix (WN) on the list of fonts in the **Font Dialog Box**. These are the fonts that Windows uses for the text that appears in dialog boxes on the screen, among other things. The font that you see on the screen will be approximated by your printer, so text written using screen fonts may look slightly different on the screen than when printed.

Plotter fonts are not preceded by an icon. They are vector fonts (i.e. they are made up of lines) and are the fonts you should choose if you are going to output to a plotter.

Printer fonts are usually preceded by a printer icon (**a**). These fonts are installed to Windows when you install a new printer.



Section 30

lines of text will be 19.8mm (3*6*1.1). The 1.1 factor is used because it creates an aesthetic line spacing for almost all fonts, whereas a factor of 1 causes some fonts to look squashed.

This determines the angle at which the text will be placed on the drawing. For example, an entry of 45 will result in the text being, placed on the drawing at an angle of 45 degrees.

Angles are measured in a counter-clockwise direction from the 3 o'clock position.

The **Pen** button is the color of the currently selected pen. To change pen colors, click on the **Pen** button and click on the color you want from the palette that appears.

The Text Alignment option is relevant if you have several lines of text. If the Left option is checked, the text will be left justified. If the Center option is checked, it will be centered. If the Right option is checked, it will be right justified.

This determines where text will be placed relative to the cursor position.

Label origins 1, 2, 3, 4, 6, 7, 8 and 9 are positioned around a character cell that is slightly larger than the character.

Label origins 11, 12, 13, 14, 16, 17, 18 and 19 are positioned around the character.


Label origin 15 is positioned at the center of the character.

Label origin 0 puts the text origin on the decimal point of the text. This is typically used for displaying elevations.



Text Angle

Text Label Origin



Angle

Pen

+ Text	If you choose origins 1, 2, 3, 11, 12 or 13, the text will appear on the right of the cursor position. For example, if you choose label origin 2, text will be placed relative to the cursor position as shown.
Text	If you choose origins 4, 6, 14, 15 or 16, text will appear centered about the cursor position. For example, if you choose label origin 15, text will be placed relative to the cursor position as shown.
Text +	If you choose origins 7, 8, 9, 17, 18 or 19, the text will appear on the left of the cursor position. For example, if you choose label origin 17, text will be placed relative to the cursor position as shown.
Take From	If you want to match the text style of an existing piece of text, select the existing text using Select (Art S, E, S - page 552) or Selection Filters (Art S, E, F - page 560). Go to Set Text Defaults and click Take From . The dialog box will automatically be updated so that the style of subsequently entered text will match the style of the existing text. Click OK .
Set or Change Text Style while Entering Text	Text is entered in the Text Edit dialog box (see <u>Start & Annotate</u> Text Line Entry - page 659). Click <u>Text Defaults</u> and the <u>Set</u> Text Defaults dialog box will appear. Edit the defaults until they are to your satisfaction. Then click <u>OK</u> . When you have finished typing the text and have exited the <u>Text Edit</u> dialog box, the text will appear on the screen in the style you have just defined.
Importing Text	Text can be imported either via the Start File Import ASCII Text option, or via the Start Edit Paste option. As text will be imported in the style currently selected in the Set Text Defaults dialog box, you should edit the dialog box to your satisfaction prior to importing the text.
Changing Existing Text	To change the style of existing text, double click the text. The Text Entry dialog box will appear. Click Text Defaults \rightarrow and the Set Text Defaults dialog box will appear. Edit the defaults until they are to your satisfaction. Then click OK . Click OK to exit.

30.11

Dimension Defaults

FUNCTION: The Dimension Defaults function is used to set default dimension parameters.

To access the Dimension Defaults function, press Att S, S, N., or right-click the Dimension icon (L) on the Drawing window toolbar.

Dimension Defaults determines how dimensions look. Dimension parameters are unlike text parameters in that if you change them, all the dimensions that you have drawn will be updated to the new parameters (the Witness Pen of existing dimensions is not updated).

The dimension defaults that are loaded each time you enter "Sight" Survey or select Start The File The New Drawing are stored in a drawing called **STARTUP.DRG**.

Dimension Settings
Witness & Arrow points Units (on paper)
Witness <u>G</u> ap 8 +
Witness Overshoot 8
Witness Pen
Arrowhead Length 15 $ ilde{Arrow}$ Blob
Arrowhead Width 5 Slash
• Mechanical style Number Decimals
Text Height 6 Linefeed 2.5
Text Pen Arial
OK Cancel H <u>e</u> lp

Witness Line and Arrow Style

Witness lines are the lines accompanying and indicating dimensions. Witness lines often print very faintly on modern high

	resolution inkjet printers. They can be thickened as follows. Set aside one color and draw all your witness lines in that color. Then map that color to the desired thickness when you print.
Witness and Arrow Units	The Witness Gap, Witness Overshoot, Arrow Head Length, Arrow Head Width and Text Height (see below) will be measured in the units you choose here.
	The currently selected units are displayed. To change units, click on the down arrow () on the right of the unit display, then click on the unit you want to use. You can choose between mm, inches and points.
	The sizes you type for the Witness Gap, Witness Overshoot, Arrow Head Length, and Arrow Head Width are the <i>sizes that will appear on the paper</i> when you come to plot or print the drawing, regardless of the drawing's scale.
Witness Gap	Witness Gap is the gap between the item being dimensioned and the start of the witness lines, as shown by the illustration in the dialog box. The Witness Gap does not affect angular or radial dimensions.
Witness Overshoot	Witness Overshoot is the extension of the witness lines beyond the dimension arrow head, as shown by the illustration in the dialog box. Witness Overshoot does not affect angular or radial dimensions.
Witness Pen	Witness Pen is the currently selected witness line and arrow color. If you click it, a color palette will appear. Click on the color you want the witness lines and arrows to be. To set pen By Layer, select the By Layer option. See <u>Start</u> Settings Layer Control on page 839.
	The color of existing witness lines and arrows will not be updated, but subsequently drawn witness lines and arrows will be in the new


color.

To change the pen of existing horizontal, vertical and slope dimensions, use <u>Start \Rightarrow Annotate \Rightarrow Edit Dimension Properties</u> (AttS, A, P - page 705). It is not possible to change the pen of an existing angular or radial dimension.




Set Arrow Defaults controls the arrows produced by the Start ⇒ Annotate ⇒ Add Arrow and Start ⇒ Annotate ⇒ Add Balloon. Dimension arrow defaults are set in Start ⇒ Settings ⇒ Dimension Defaults (Att S), (S), (N) - page 826).

Arrowheads







Number Decimals

You may choose one of three arrow styles: an <u>Arrow</u>; a <u>Blob</u>; or a <u>Slash</u>. Simply click on the desired arrow style.

Set the **Arrowhead Length** and **Arrowhead Width** measurements in the units shown.

All dimensions are **Mechanical Style** unless the **Architectural Style** box is checked.

If the Architectural Style box is checked, dimensions have constant witness line lengths and are always drawn in chained mode. See Start \Rightarrow Annotate \Rightarrow Horizontal Dimension on page 672.

The number that you type here determines the number of decimals that will be displayed on a dimension. The maximum number of decimals that can be displayed is 16.

If you set the number of decimals to **2**, then 12.3456 will be displayed as 12.35 (rounding to the nearest number). However, an exact number will be displayed without trailing decimals, for example, 12.000 will be displayed as 12.

You can also set the number of decimals to a negative number to get rounding to tens or hundreds. For example, if you set the number of decimals to -2, then 1234.45 will be displayed as 1200

(rounding to the nearest 100). If you set the number of decimals to **-1** then the number will be displayed as 1230.

Dimension Text HeightYou can either type the dimension text height into this box, or type
it into the Size box in the Font Dialog Box that appears when you
click on the button to the right of the Text Pen... button.

If you type the height into the **Text Height** box, it is measured in the witness and arrow units specified at the top of the **Dimension Settings** dialog box. If you use the **Size** box in the **Font Dialog Box**, it is measured in points.

As with text height in **Set Text Defaults**, **Text Height** does not represent the height of the actual characters. The actual height of the characters is two thirds of the text height. For example, if you set a text height of 6 points, the actual height of the characters will be 4 points. See <u>Start & Settings & Set Text Defaults</u> on page 820.

Linefeed controls the distance between subsequent dimension lines in running dimensions.


The figure you give for the **Linefeed** is multiplied by the **Text Height** to give the distance between subsequent dimension lines.

Example: If you have set a text height of 6 points, and a linefeed of 2, the distance between subsequent dimension lines will be 12 points (2x6).

Example: If you have set a text height of 6 points, and a linefeed of 4, the distance between subsequent dimension lines will be 24 points (4x6).

The **Text Pen...** button allows you to define the color of the dimension text. The button displays the currently selected color. To change the color, click on the button and a palette appears. Click on the color you want the dimension text to be. To set text color **By Layer**, select the **By Layer** option. See <u>Start</u> **Settings Layer Control** on page 839.

Linefeed





Text Style

The button to the right of the <u>Text Pen...</u> allows you to determine the style of the dimension text. If you click on it, the Font dialog box appears (see <u>Start ⇒ Settings ⇒ Set Text Defaults</u> on page 820). From the Font dialog box you can select the dimension text font and font parameters.

30.12

Surveying Dimension Setup

FUNCTION: The **Surveying Dimension Setup** function is used to determine or change the way Surveying dimensions are drawn.

To access the **Surveying Dimension Setup** function, press Att, S, S, G, or right-click the **Survey Dimension** icon ($\frac{MS}{MOT}$) in the **Drawing** window toolbar.



The Annotate Line icon in "Sight" Survey's main toolbar looks the same as the Survey Dimension icon in the Drawing window toolbar. However, the two icons function differently.


The surveying dimension defaults that are loaded each time you enter "Sight" Survey or select <u>Start r File r New Drawing are stored in a drawing called STARTUP.DRG.</u>

When you access the **Surveying Dimension Setup** function, "Sight" Survey displays the **Survey Dimension Setup** dialog box.

Survey Dimension Setup	×
Survey Dimension Orientation	
\diamond Text follows bearing direction	
 Text is always upright 	
Survey Dimension Format	
Bearing on top, Distance on bottom	
\diamond Distance on top, Bearing on bottom	
O Both Bearing and Distance on top	
 Distance only 	
Bearing direction is counter-clockwise	
Round to 0 Seconds.	
(O uses default angular decimals)	
<u>O</u> K <u>C</u> ancel	

Survey Dimension Orientation

Click the desired dimension orientation option. Most engineering drawings are read with the text always oriented right-reading or upright. To select this orientation (below left), click **Text is always upright**. If you select **Text follows bearing direction** (below right), your text can face any direction.



Section 30

Survey Dimension Format

Click the desired dimension orientation format. Your choices are:

- Bearing on top, Distance on bottom
- Distance on top, Bearing on bottom
- Both Bearing and Distance on top
- Distance Only

Bearing Direction isThis option is not used by "Sight" Survey. It should be leftCounter-Clockwiseunchecked.

Round to ... Seconds The survey dimension bearing is rounded to the number of seconds you use here. For example: enter 10 to round to the nearest 10 seconds; enter 1 to round to the nearest 1 second, etc.

If you enter 0, "Sight" Survey will use the number of decimal places set in the Angular Format section of <u>Start</u> ⇒ <u>Settings</u> ⇒ <u>Drawing Settings</u> (Att S, S, D - page 789).



Distances will always use the number of decimal places set in <u>Start [™]Settings [™]Dimension Defaults</u> (Alt S, S, N - page 826).

30.13

Set Arro<u>w</u> Defaults (XA)

FUNCTION: The **Set Arrow Defaults** function is used to determine or change the way in which arrows are drawn.

To access the **Set Arrow Defaults** function, type **XA** or press Att S, S, W.

The arrow defaults that are loaded each time you enter "Sight" Survey or select <u>Start \overline{P} File \overline{P} New Drawing are stored in a drawing called STARTUP.DRG.</u>



Set Arrow Defaults controls the arrows produced by the Start ⇒ Annotate ⇒ Add Arrow and Start ⇒ Annotate ⇒ Add Balloon. Dimension arrow defaults are set in Start ⇒ Settings ⇒ Dimension Defaults (Att S), (S), (N) - page 826).

When you select this function, the **Arrow Style** dialog box appears. You can use it for determining the style of subsequently drawn arrows, or for changing the style of existing arrows.

length length width	ArrowStyle	
Arrow Style	You may choose one of three arrow styles: an <u>Arrow</u> ; a <u>B</u> lob; or a <u>S</u> lash. Simply click on the desired arrow style.	
Length, Width & Units	Set the length and width measurements in the units shown. To change units, click on the down arrow and select from: mm ; inches ; or points (a point is ¹ /72 of an inch).	
Pen	The Pen button is the color of the currently selected pen. To change pen colors, click on the Pen button and click on the color you want from the palette that appears. You may also choose to place arrow colors By Layer .	
Take From	If you want to match the style of an existing arrow, select the existing arrow using Select (AttS, E, S) - page 552) or Selection Filters (AttS, E, F) - page 560). Go to Set Text Defaults and click Take From . The dialog box will automatically be updated so that the style of subsequently entered text will match the style of the existing text. Click OK .	
To Change Existing Arrows	Place your cursor on the arrow you want to change, then double click on it, or use <u>Select</u> or <u>Selection Filters</u> to select the arrows whose styles you want to change and select <u>Set Arrow Defaults</u> option. Edit the dialog box to your satisfaction, then click <u>Apply</u> . Click <u>OK</u> . The styles of the selected arrows will be updated. All subsequently drawn arrows will also be drawn using the newly	
	selected defaults.	

Set Balloon Defaults

FUNCTION: The **Set Balloon Defaults** function is used to set default balloon parameters.

To access the Set Balloon Defaults function, press AltS, S, O.

When you select **Set Balloon Defaults**, a dialog box appears. This box allows you to specify the default balloon size, the number of text lines, and whether an arrow is to be added or not. All balloons drawn subsequently using **Start Add Balloon** will adhere to these defaults.

The balloon defaults that are loaded each time you enter "Sight" Survey or select <u>Start \Rightarrow File \Rightarrow <u>New</u> Drawing are stored in a drawing called STARTUP.DRG.</u>

Balloon Defaults	×
 ✓ Add arrows to balloons □ Two rows of text on balloon 	
Balloon Fixed Size	
OK Cancel	

The style (color etc.) of the circle enclosing the balloon text is defined by **Start Stirings Stirings Line Defaults**.

The style (font etc.) of the text inside the balloon is determined by Start \Im Settings \Im Text Defaults.

Add Arrows to Balloons If this box is checked, arrows will be added to balloons. If the box is not checked, arrows will not be added to balloons. The way that the arrows look is determined by



dded to balloons. The way that the arrows look is determined by <u>Start [®]Settings [®]Set Arrow</u> Defaults (AttS, S, M - page 832).

30.14





F

G

Η

Ι

VARIABLE

Balloon Fixed Size

G1

H10

I100

If you want two rows of text in the balloon, check this box. If you select two rows, you will still be able to create balloons with one row of text by entering a blank instead of text for the second row. If you want one row of text in the balloon, don't check the box.

The number of characters that the balloon will accommodate is displayed here. If you want to change this, click on the arrow next to the display.

If you select 1, the balloon will accommodate 1 character in width.

If you select **2**, the balloon will accommodate 2 characters in width, even if you only type one character.

If you select **3**, the balloon will accommodate 3 characters in width, even if you only type 1 or 2 characters.

If you select **4**, the balloon will accommodate 4 characters in width, even if you only type 1, 2 or 3 characters.

If you type 0 the balloon will accommodate whatever you type in, to a maximum of 69 characters.

30.15

DXF/DWG Conversion Settings (XG)

FUNCTION: The **DXF/DWG Conversion Settings** function is used to define how AutoCAD DWG and DXF files will be converted to "Sight" Survey drawings, and vice versa.

To access the DXF/DWG Conversion Settings function, type XG or press AttS, S, X.

Section 30 When you select this item, the **To DXF/DWG Conversion Settings** dialog box or the **From DXF/DWG Conversion Settings** dialog box appears, depending upon which dialog box was last used.

To DXF/DWG Conversion	Settings 🛛 🗙	
For CADControl	Use DXF F <u>o</u> nt	
MODERN		
ROMAN	ROMANS	
ARIAL	- ROMAND -	
TIMES NEW ROMAN	ROMANC	
TIMES NEW ROMAN.		
For CADControl	Use DXF P <u>e</u> n	
0	▲ 0 ▲	
1		
23	2	
3	3	
4	<u> </u>	
Target DXF/DWG versi	ion	
	A 10	
$ \diamond 10 \diamond 11$	◆ 1 <u>2</u>	
-1		
From DXF Settings		
ок	Cancel Help	

To DXF Files	The To DXF/DWG Conversion Settings dialog box defines how CADControl fonts and pens will be converted to AutoCAD fonts and pens when you create a DWG or DXF file using Start ⇒ File ⇒ Save Drawing As . It also determines the version of AutoCAD the DWG or DXF file will be compatible with.
Font Conversion	Click on a CADControl font in the left side font selection box. Then click on the AutoCAD font it must be converted to in the right side box.
Pen Conversion	Click on a CADControl pen in the left side pen selection box. Then click on the AutoCAD pen it must be converted to in the right side box. (For best results, Import and Export pen settings should be reciprocal values.)
AutoCAD Version	Click the AutoCAD version you want the DXF or DWG file you create to be compatible with: version 10; version 11; or version 12.

To / From Button

From DXF Files

i

Click on this button to bring up the **From DXF/DWG Conversion Settings** dialog box.

CADControl pens are numbered from 0 to 15 in the Pen Selection Area. So maroon is 0, red is 1, etc. View the file named Linetype.mac (located in the "Macro" sub-directory of your "Program" directory) to determine how CAD line types will be converted to AutoCAD line types.

The From DXF/DWG Conversion Settings dialog box defines how AutoCAD fonts and pens will be converted to CADControl fonts and pens when you load a DWG or DXF file using File → Import → Drawing.

From DXF/DWG Conve	ersion Settings
For DXF <u>F</u> ont	Use CADControl
STANDARD	▲ MODERN ▲
TXT	ROMAN
MONOTXT	
ROMANS	ARIAL
SCRIPTS	▼ TIMES NEW ROMAN.E ▼
For DXF <u>P</u> en	Use CADControl
0	▲ 0 ▲
1	
2	2
3	
4	<u> </u>
To DXF Setting:	S
ОК	Cancel Help

Font ConversionClick on an AutoCAD font in the left side font selection box. Then
click on the CADControl font it must be converted to in the right
side box.Pen ConversionClick on an AutoCAD pen in the left side pen selection box. Then
click on the CADControl pen it must be converted to in the right
side box. (For best results, Import and Export pen settings should
be reciprocal values.)

To / From Button

Click on this button to bring up the **To DXF/DWG Conversion Settings** dialog box.

(

CADControl pens are numbered from 0 to 15 in the Pen Selection Area. So maroon is 0, red is 1, etc. To set up line type conversion between AutoCAD and "Sight" Survey, use the Linetype.mac file (located in the "Macro" sub-directory of your "Program" directory).

30.16

Virtual Memory Settings

FUNCTION: The Virtual <u>Memory Settings</u> function is used to specify at what point "Sight" Survey starts to use virtual memory.

To access the Virtual Memory Settings function, press AltS, S, M.

When you select Virtual <u>Memory Settings</u>, a dialog box appears.

CAD VMEM Preferences	×
Temp Path C:\WINDOWS\TEMP	
Allocate 10 Meg before spill to disk	
OK Cancel	

Sight" Survey will ask the operating system for as much memory as you type into the **Allocate** box. It will then start to spill temporary files to disk, at the location specified in the **Temp Path** box. This may be more efficient than the Windows swap file for large drawings.

If you experience a lot of disk thrashing, i.e. Sight" Survey seems to be accessing the hard disk continuously, lower the limit where the drawing will start to spill to the disk.

30.17

Layer Control (EL)

i

FUNCTION: The Layer Control function is used to add layers, edit layer names and magnifications, lock layers, and highlight layers.

To access the Layer Control function, type EL or press AHS, S, \heartsuit , or click the Layer Control icon (B) on the main "Sight" Survey toolbar

The layer names that are loaded each time you enter "Sight" Survey or select <u>Start ⇒ File ⇒ New Drawing</u> are stored in a drawing called **STARTUP.DRG**.

When you select Layer Control, the following dialog box appears.

Layer Editing Box		×
Name	Mag. V(isible) L(ocked) C(urrent)	
A	1.000 V	7
SYMBOLS	1.000 V	4
COORDINATES	1.000 V	4
COORDLIST	1.000 V	-
ELEVATIONS	1.000 V	4
ASCIITEXT	1.000 V	_
LINES	1.000 V C	
PTNAMES	1.000 V	-
<u>E</u> dit <u>A</u> dd	Delete Set Current Select All	
Visibility All Layers Visible Current Visible Only		
Layer Highlight 🔶 <u>N</u> o Hi	ighlight \diamond No. <u>8</u> Pen \diamond <u>R</u> ainbow	
Operate on 🔶 All Unlock	ed layers 🔷 Cu <u>r</u> rent Layer only	
ОК	Cancel <u>H</u> elp	

The Layer Editing Box shows the layer name, line style, line color (pen), and magnification factor for each defined layer. If the layer is visible, a V is displayed in the layer row. If the layer is locked, an L is displayed in the layer row. In addition, the layer designated as the Current Layer, contains a C in the layer row.

The following table lists each "Sight" Survey drawing entity and the corresponding layer onto which it is now placed:

Section 30

When this entity is placed into the Drawing Window	"Sight" Survey places it onto this Layer:
Dots & Crosses at Points	Points Layer
Symbols at End Points	Symbols Layer
Symbols within Custom Lines	Line Layer
Lines, Arcs, & Random Curves	Line Layer
Custom Lines	Line Layer
Circles & Rectangles	Line Layer
Parallel Lines	Line Layer
Leader Lines & Arrows	Current Layer
North Arrow & Scale Bar	Symbols Layer
Point Numbers	Pt. Number Layer
Northings & Eastings	Coords. Layer
Elevations	Elevations Layer
Point Descriptions/other Labels	Pt. Name Layer
Stations	Station Layer
Bearings & Distances	Line Annot Layer
Curve Length & Curve Labels	Line Annot Layer
Short Line Labels (L1, L2, etc.)	Line Annot Layer
Symbols Table	Symbols Layer
Text Placed w/Text Line (TL)	Current Layer
Text Placed on Custom Lines	Line Layer
Arc/Angle Labels (LA)	Current Layer
Surveying Dimensions	Current Layer
Dimensions	Current Layer
ASCII Text Files	ASCII File Layer
Coordinate Lists	Coord. List Layer
Curve & Line Tables	Sup. Table Layer
Imported BitMaps	Current Layer

Layer Name

The layer name will automatically appear in upper case. It can be up to 30 characters long. To change a layer's name, see Adding Layers later in this section.

Layer MagnificationNormally, layer magnification is 1. However, each layer can be
assigned a different magnification with respect to the scale of the
drawing.

To change a layer's magnification, see **Adding Layers** later in this section.

Visible Layers	Visible layers are the layers that are actually displayed on the screen. They are marked by the letter V. To change a layer's visibility, see Adding Layers and Setting Visible Layers later in this section.
Locked Layers	"Sight" Survey's functions will not work on locked layers. For example, you cannot select or accidentally move entities on a locked layer. Locked layers are marked by the letter L. To lock or unlock a layer, see Adding Layers later in this section.
Current Layer	Everything you draw is drawn onto the current layer. The current layer is marked by the letter C . To change the current layer, see Setting the Current Layer , later in this section.
Pen and Line Type	A horizontal line in the pen and line type assigned to the layer is drawn after the other details listed above. This is the pen and line type that will be used if you draw By Layer . See Pen By Layer and Line Type By Layer , later in this section.
Adding Layers	By default, "Sight" Survey has just one layer, 0 . You can add your own layers, up to a total of 65,000. To add a layer, click on the Add button. The Add New Layer dialog box appears. Fill in the dialog box as shown below, then click OK . The new layer will be added to the end of the Layer Editing Box , and will automatically become the new Current Layer .

<u>N</u>ame

The <u>Name</u> text entry box allows you to type in a new, or change an existing, layer name. Layer names can be up to 30 characters in

Cancel

0K

Section 30

	length. If you type a name that is longer than 30 characters, it will be truncated after the 30 th character. "Sight" Survey will replace any spaces and other invalid characters with an underscore to allow compatibility with other CAD programs. In addition, it will automatically convert any lowercase letters to UPPERCASE.
	The name that you enter in this box will appear in the Properties window when assigning layers to specific drawing elements.
La <u>v</u> er Linestyle	The Layer Linestyle list box allows you to select the line type that you would like assigned to this layer. This line type is only used when the Line Type property (in the Properties window) is set to By Layer .
Pen	The Pen button allows you to select the pen color that you would like assigned to this layer. This color is only used when the Object Color and/or Text Color properties (in the Properties window) are set to By Layer .
<u>V</u> isible	The <u>Visible</u> check box is used to toggle the visibility of the layer. When the box is checked, the layer is visible (i.e. you can see that layer's drawing entities). When the box is not checked, the layer is hidden (you cannot see that layer's drawing entities). To change the status of this item, click the check box with your mouse, or press $Ait[V]$, Space Bar.
	You cannot make editing changes to layers that are hidden. This prevents you from moving, changing, or deleting an entity which you didn't mean to edit. The only exception is the Clear Drawing Area (DX) routine which will always delete the entire drawing, regardless of layer settings.
(The Current Layer is ALWAYS visible regardless of the setting.
<u>L</u> ocked	The Locked check box is used to toggle the lock status of the layer. When the box is checked, the layer is locked. When the box is not checked, the layer is unlocked. To change the status of this item,

click the check box with your mouse, or press Alt L, Space Bar.

Layer locking is very helpful when you are trying to edit a cluttered area of your drawing. When a layer is locked, you cannot select, move, change or delete any entities on that layer, thus preventing you from editing something you didn't mean to edit. For example, by locking the Line Layer, you can easily select a bearing or distance without selecting a line by mistake. (The only exception is the **Clear Drawing Area** (DX) routine which will always delete the entire drawing, regardless of layer settings.)

The Mag. text entry box allows you to type in a number for the layer magnification. Normal layer magnification is 1. However, each layer can be assigned a different magnification with respect to the scale of the drawing. (The exception is layer **A**, whose magnification always remains at 1.0) For example, suppose the drawing is at a scale of 1:10. If you assign a magnification of 2 to a layer, anything drawn on that layer subsequently will be twice the size, i.e. at a scale of 1:5. If you assign a magnification of 0.5 to a layer, anything drawn on that layer subsequently will be half the size, i.e. at a scale of 1:20.

To edit or change an existing layer, double-click on the layer, or highlight the layer and click the <u>Edit.</u> button or press <u>Alt</u> E. This will display the **Edit one Layer** dialog box.

Edit one Layer	×
Name PTNUMBERS	Mag. ✓ Yisible 1.000 Locked
Layer Linestyle	Cancel

Whether you are editing or adding a layer, the items in the displayed dialog box are the same. Inside this box you can change the name, line type, color, magnification, visibility, and lock status of the layer.

Mag.

Editing One Layer

Editing Multiple Layers

You can edit the magnification, visibility and lock status for several layers at a time. To do this, highlight the desired layers and click the **Edit**. button or press **Att**. This will display the **Edit Multiple Layers** dialog box. Make any desired changes and click the **OK** button. All highlighted layers will be assigned the new settings.

Edit Multiple Layers	×
	Mag. <u>V</u> isible
ОК	Cancel

and

To edit ALL the defined layers, first click Select All (or press Alt], and then click Edit... (or press Alt].

Deleting Layers

To delete an existing layer, highlight the layer and click the **Delete** button or press **At D**. You will be prompted:

Warning	: Layer Delete 🛛 🗙
?	Warning: About to delete layer 'ASCIITEXT'. Are you sure?
	Yes <u>N</u> o Cancel

¥

"Sight" Survey allows you to delete layers that **DO** contain drawing information. **Before you delete a layer, make sure there is no drawing information that you need on that layer!** Once you save the drawing, you will not be able to recover the deleted layers. If you have not saved the drawing, simply reload the file, without saving the current changes. If you are absolutely sure that you want to delete this layer, select \underline{Yes} , otherwise select either \underline{No} or \underline{Cancel} .



To determine whether or not a layer has anything on it, click once on the desired layer in the Edit Layers dialog box and then click on Set Current . Next, click on the Current Visible Only button (or press Alt C) to hide all the layers except the current one. Then click the OK button to close the dialog box. Now, click on the to close the dialog box. Now, click on the to close the dialog box. If the Drawing window is empty, it is safe to delete the layer.



If you delete a layer which is set as the current value for any of the Layer... properties in the Properties window, that layer will be recreated when, or if, "Sight" Survey needs to place any drawing data on that layer. For example, if you delete the LINETEXT layer, but still have LINETEXT as the value for the Line Annotation Layer, the LINETEXT layer will be created as soon as any bearings or distances get placed on your drawing. If you want to delete a layer and not have it be recreated, you must change the value for the appropriate Layer... properties.

Setting the Current Layer To set a layer as the Current Layer, highlight the layer and click the Set Current button or press Alt S.

"Sight" Survey sends drawing entities to multiple layers based upon the layer setup specified in the **Properties** window. For example, before "Sight" Survey places a line, it sets the **Current Layer** to the specified **Line Layer**. However, when placing a **Leader Line & Arrow**, you must manually set the **Current Layer**.



I. These drawing entities are drawn on the Current Layer at the time of placement: Leader Lines & Arrows (AW), Text Lines (TL), and Angle Labels (LA).

2. When you add a new layer it automatically becomes the new *Current Layer*.

3. The **Current Layer** is ALWAYS visible regardless of the setting.

4. The name of the **Current Layer** is always shown in the of the **Drawing** window title bar.

 Setting Visible Layers
 Visible layers are the layers that are actually displayed on the screen. They are marked with the letter V to the right of the layer name in the Layer Editing Box. If you want ALL layers to be displayed on the screen, click on the All Layers Visible button (or press Alt](V). If you want only the Current Layer displayed, click on the Current Visible Only button (or press Alt](C).

To make one or more layers visible or hidden, highlight the desired layer(s) and click the <u>Edit.</u> button or press <u>Att</u>. Set the <u>Visible</u> check box to the desired setting. When the box is checked, the layer is visible. When the box is not checked, the layer is hidden. Since you cannot make editing changes to layers that are not visible, you are prevented from moving, changing, or deleting an entity which you didn't mean to edit. The only exception is the **Clear Drawing Area** (DX) routine which will always delete the entire drawing, regardless of layer settings.



1. The **Current Layer** is ALWAYS visible regardless of the setting.

- 2. To highlight a sequence of layers, highlight the first layer in the sequence, then press s while you click on the last layer in the sequence.
- 3. To highlight more than one individual layer, press Cm while you click on each layer.
- 4. To remove the highlight from a layer, press c while you click on the layer.

Layer Highlighting

You can choose to enable special layer highlighting for the **Drawing** window. If the selected option is the default, **No Highlight**, then no layer(s) will be highlighted. The drawing will appear as normal.

If the selected option is No. <u>8</u> Pen, all the layers except the **Current Layer** are drawn in a dotted line type with pen **08** - **Blue**. This option is useful when you want to keep all the layers visible yet distinguish which entities are on the **Current Layer**.

If the selected option is <u>Rainbow</u>, all layers except the current layer will be displayed using the default **Pen** color and **Line Type** for that layer. The default **Pen** color and **Line Type** for each layer is set up in the **Edit Layers** (**EL**) routine. **Rainbow** is useful for isolating items that have been drawn on an incorrect layer. For example, if all your lines are supposed to be on the same layer, then they should all be the same color. If any line appears in a different color, then it is located on the wrong layer.

Operate On (Which Layers?)

You may work with all unlocked layers or work with only the **Current Layer**. If the selected option is **All Unlocked Layers**, you will be able to select items on all drawing layers which have not been locked. If the selected option is **Current Layer Only**, you will only be able to select items which are on the **Current Layer**.

The **Current Layer Only** option is ideal for editing portions of your drawing that are cluttered. Since you cannot select items which are not on the **Current Layer**, it prevents you from moving, changing, or deleting an entity which you didn't mean to edit. The only exception is the **Clear Drawing Area** (DX) routine which will always delete the entire drawing, regardless of layer settings.

- 1. These settings control only the **selection** of entities. To control the **placement** of entities, use the **Layer**... properties within the **Properties** window, and the **Layer Override** (**LV**) routine.
- 2. To determine which layer a drawing entity is on, use the Query Entity (QE) command. See page 751 for more info.

Section 30



ad

When a drawing is imported which contains specific layers, those layers will automatically be created in the "Sight" Survey drawing. If the imported layers already exist in the current drawing, they will be merged onto the existing layer.

"BY LAYER" Layering	and Pen color to each	e allows you to assign a specific Linestyle layer. To instruct "Sight" Survey to use the ct the By Layer value for the desired
Pen By Layer	that you assign a parti Entities are automatic	t pens and line types By Layer . This means cular color and line type to each layer. ally drawn using the pen and line type yer you are drawing on.
	functions. A palette w	r , click the Pen button in the following vill appear. At the bottom of the palette is a ck this button to make "Sight" Survey draw by Layer:
	Line Defaults Parallel Defaults Polyline Defaults Set Arrow Defaults Set Text Defaults Set Dim Defaults	set line color by layer set parallel line color by layer set polyline color by layer set arrow color by layer set text color by layer set dimension witness line and text color by layer
Line Type By Layer		roperty is set to By Layer , "Sight" Survey he Linestyle associated with the layer that is he Line Layer .
Object Color By Layer	Survey draws all lines that is currently assign an exception to this ru- were created in, which symbol color after syn the steps in the Hands manual. If you prefer	r property is set to By Layer , "Sight" in the Pen color associated with the layer ned to the Line Layer . End point symbols are le – they are placed in the color that they is navy (or dark blue). You can change the mbols are placed on the drawing by following -On Instruction section on page 566 of this , you can permanently change the symbol esteps in the How to Permanently Change on page 474.
Text Color By Layer		property is set to By Layer , "Sight" Survey be Pen color associated with the layer that is

currently assigned to the layer for the type of text being placed. To explain this more clearly, the specific text entities and the layer that determines the pen color to use for the text (when **Text Color** is set to **By Layer**) are shown in the table on the following page.

When this Text is Placed into	"Sight" Survey uses the
Drawing Window "ByLayer"	Pen Color from Layer:
Point Numbers	Pt. Number Layer
Northings & Eastings	Coords. Layer
Elevations	Elevations Layer
Point Descriptions/other Labels	Pt. Name Layer
Stations	Station Layer
Bearings & Distances	Line Annot Layer
Curve Length & Curve Labels	Line Annot Layer
Short Line Labels (L1, L2, etc.)	Line Annot Layer
Symbols Table	Symbols Layer
Text Placed w/Text Line (TL)	Current Layer
Text Placed on a Custom Line	Line Layer
Arc/Angle Labels (LA)	Current Layer
ASCII Text Files	ASCII File Layer
Coordinate Lists	Coord. List Layer
Curve & Line Tables	Sup. Table Layer

30.18

Set Cu<u>r</u>rent Layer

FUNCTION: The **Set Current Layer** function is used to change the current layer.

To access the Set Current Layer function, press AHS, S, R, or type ΥC .



When you first start off with "Sight" Survey, only one layer, **0**, will appear in this dialog box. To add further layers or to rename layer **0**, see Layer Control. You can save default layers in **STARTUP.DRG**.

Section 30 Whatever you draw is placed on the **current layer**. When you select **Set Cu<u>r</u>rent Layer**, the following dialog box appears.

New current layer	X
Α	
SYMBOLS	
COORDINATES	
COORDLIST	
ELEVATIONS	
ASCIITEXT	
LINES PTNAMES	
PINAMES	
POINTS	
SUPTABLES	
LINETEXT	
STATIONS	
STATIONS	
ОК	Cancel

Click on the layer that must become the current layer. The new current layer will be highlighted. Click OK to exit.



The name of the **Current Layer** is always shown in the of the **Drawing** window title bar.

30.19

Set Visible Layers

FUNCTION: The **Set Visible Layers** function is used to select which layers should be displayed on the screen.

To access the Set Visible Layers function, press AttS, S, B.



When you first start off with "Sight" Survey, only one layer, **0**, will appear in this dialog box. To add further layers or to rename layer **0**, see Layer Control. You can save default layers in **STARTUP.DRG**.

When you select **Set Visible Layers**, the following dialog box appears.

Set Visible Layers 🛛 🗙	1
(Current layer is always ∨isible)	
Α	I
SYMBOLS	I
COORDINATES	l
COORDLIST	l
ELEVATIONS	l
ASCIITEXT	l
* LINES	l
PTNAMES	I
PTNUMBERS	I
POINTS	Į
SUPTABLES	I
LINETEXT	I
STATIONS	
	Į
<u>Current Only</u>	
Set Current Layer	
OK Cancel	

If you want all layers to be displayed on the screen, click

The **current layer** (the layer you are working on) is marked by an asterisk. If you only want to display the current layer, click Current Only

You can change the current layer while in the **Set Visible Layers** dialog box by clicking <u>Set Current Layer</u>. If you click on this button, a second dialog box appears. Click on the layer that must become the current layer, then click **OK**.

If you only want to display a few layers, ensure that the layers you want to display are highlighted. To highlight a layer, click on it. To highlight more than one layer, press Ctrl while you click on the layers you want to display. If a layer that you do not want to see on the screen is highlighted, press Ctrl and click on it. The highlight will disappear.



The current layer is always displayed, whether you highlight it or not.

30.20

Delete Layer

FUNCTION: The **Delete Layer** function is used to delete a layer and its contents.

To access the **Delete Layer** function, press AHS, S, T, or type **YX**.

When you access the **Delete Layer** function, "Sight" Survey displays a layer name dialog box:

Layer Name to Delete	×
Α	
SYMBOLS	
COORDINATES	
COORDLIST	
ELEVATIONS	
ASCIITEXT	
LINES	
PTNAMES	
PTNUMBERS	
POINTS	
SUPTABLES	
LINETEXT	
STATIONS	
L	
OK Cancel	

To delete a layer, select the layer by clicking on it in the list of layers. The layer will be highlighted. Click $\bigcirc K$. A warning will appear. If you are sure you want to delete the layer, click $\bigcirc K$ and the layer and all its contents will be deleted.



You cannot undo a layer delete!

٩

Use caution when deleting layers, since the layer may contain drawing information. Once you save the drawing, you cannot recover deleted layers. If you have not saved the drawing, simply reload the file without saving the current changes. To determine the contents of a drawing layer, type \mathbf{YC} to make the layer the current layer. Next, use **Start** \mathbf{VSE} **Set Visible Layers** and click **Current Only OK**. Now type **ZA** to view the entire current layer. If the layer is empty, it is safe to delete the layer.

30.21

Working Layers

FUNCTION: The **Working Layers** function is used to select which layers are operational at any given time.

To access the Working Layers function, press Att S, S, K.

When you access the **Working Layers** function, "Sight" Survey prompts:

Would you like to operate on current layer only (else all displayed layers)

If you click Yes, "Sight" Survey's functions will only operate on the current layer. If you click <u>No</u>, "Sight" Survey's functions will operate on all layers that have not been locked. To lock and unlock layers, see <u>Start Settings Layer Control</u> on page 839.



854 Start Menu - SETTINGS

This page intentionally left blank.



Section 31 Title Blocks

You can use "Sight" Survey to create and store commonly used title blocks and symbols (objects, notes, certificates, etc.) that can be saved for reuse at a later time.

In the following example, you will create a title block and border for a 24"x36" sheet in landscape orientation, with $1\frac{1}{2}$ " border on the left and $\frac{1}{2}$ " on the other 3 sides.



Landscape orientation means the paper is wider than it is tall. Portrait orientation means the paper is taller than it is wide.

Drawing the Lines

Type NJ, or press Att [F], N, or click the New Job icon () on the Top toolbar to select File New Job.

Paper Orientation

31.01

Press Att G to activate the **Config** menu, then click the command, **CAD Paper in Landscape Orientation**. Make sure there is a check mark in front of the menu item. You may also change the paper orientation by clicking the **Paper Orientation** icon () on the **Main** toolbar.



If you are constructing a portrait style title block and want to layout the border in portrait orientation, remove the checkmark by clicking on the CAD Paper in Landscape Orientation command again.

Section 31 Set up page information

Title block drawings have to be created in a special coordinate system. Type the two-letter command **TB** to set the drawing to the title block coordinate mode.

Convert	to Title Block Coordinate System 🛛 🛛
?	Your drawing is not currently in the correct coordinate mode to be used as a title block. This command will set your drawing in the format required to use it with the Import Title Block command. Are you sure you want to proceed?
	Yes No

Click Yes

Press Alt, R to select Config > Drawing Configuration Menu.

Configuration Screen		×
Iext Output Slope Entry	CA <u>D</u> <u>G</u> eneral	Angle Setup File Paths
Paper Size / Scale inch = inch inch Arch. D 24x36''	CAD Units C Eeet C Inches C Meters	Page Center North 0 East 0
Printed Prec Bng: 1 Crds: 5	 Dimensioning of Short Li Shrink te<u>x</u>t to fit along Create a short line table 	line
Dist: 3 V Elev: 1 V	Padding Option Pad with space	Custom Lines
Dist. Smbl. Text Offset	Label Offset 6.0 Reset 0	S Layers
<u> </u>	<u>C</u> ancel	Help

Under Paper Size / Scale, adjust the scale so that 1 foot = 1 foot, and set the paper size to Arch. D 24x36". Now set the Page Center to 0 North and 0 East, and set the CAD Units to Inches.

Changing the **CAD Units** will trigger an informational message about CAD database units. This message is shown at the top of the next page. Click **OK** to ignore the message and continue.



When everything on the **Configuration Screen** is correctly set, click **OK**

Type the two-letter **Zoom Sheet** command **ZS** to center the sheet of paper in the CAD window.

 Select line properties
 Before drawing any lines, set the color and line weight you want to use for your border. Click your mouse anywhere in the Drawing window, then press AttS, S, L to select Start → Settings → Line Defaults.

LineStyl	e	×	
Pen			
Width	2	points 💌	
ОК	Take From	Apply Cancel	

Set the **Pen** color to **Black** and the **Width** to 2 points, a nice bold line. Click OK.

Set the Border Starting Point

We will begin in the upper left corner of the border. Press AftS, □, H (or click →) to select Start → Draw → Lines (Chained). The Drawing window will prompt you for the first point of the line.

Enter first point of line

Press \boxdot to bring the **Freehand Cursor** ($_+^{\sim}$) cursor to the center of the of the paper, then press the left arrow key \boxdot . The following window appears:



858 Title Blocks

	×
Cancel	
	Cancel

It is 18" from the center of the page to the left edge. Since we want a $1\frac{1}{2}$ " margin, we want to move 18" - 1.5" = 16.5". Type **16.5** in the dialog box and press **.**

Press the up arrow key 1.

Move Up: How far ?		×
11.5		
ОК	Cancel	

It is 12" from the center of the page to the top edge. Since we want a $\frac{1}{2}$ " margin, we want to move 12" - 0.5" = 11.5". Type **11.5** in the dialog box and press Finer. Press Finer once again to accept this point as the start of the line.

Draw the top border	Press the right arrow key . As in the previous step, "Sight" Survey will prompt you for a distance to move, this time to the right.	
	The top border should be 36" - $1\frac{1}{2}$ " - $\frac{1}{2}$ " = 34". Type 34 in the dialog box and press <i>Fenter</i> . Press <i>Fenter</i> once again to accept this point as the end of the line segment.	
Create the rest of the border	In similar fashion, press the down arrow key []. Type 23 in the dialog box and press <i>renter</i> . Press <i>renter</i> once again to accept this point as the end of the line segment.	
	Press the left arrow key . Type 34 in the dialog box and press . Press . Press . once again to accept this point as the end of the line segment.	

Enter next point of line

Press the up arrow key 1. Type **23** in the dialog box and press --Enter. Press --Enter once again to accept this point as the end of the line segment.

Press Esc to cancel the line drawing routine. The border should now be completed.

Draw the title block lines Now you will create a title block area on the right hand side of the page. You'll begin by placing a vertical line 5.5 inches from the right border.

Press AttS, D, P (or click \nvdash) to select Start D are D to Pt). The Drawing window will prompt you for the first point of the line.

Enter first point of line

Move the **Freehand Cursor** $(+^{\sim})$ cursor so that the lower right corner of the border is very close the cursor. Press \Box to jump to the exact coordinates of the corner.

Press the left arrow key in to activate the prompt Move Left: How far? Type 5.5 and press Film. Press Film again to accept this point as the start of the line.

Enter next point of line

Press the up arrow key 1. Type 23 in the dialog box and press --Enter Once again to accept this point as the end of the line segment.

Now create some dividing lines within the title block. The first line will be located 1" up from the bottom border. The **Drawing** window will prompt you for the first point of the line.

Enter first point of line

Dividing lines



Move the **Freehand Cursor** $(+^{\circ})$ cursor so that the lower right corner of the border is very close the cursor. Press \Box to jump to the exact coordinates of the corner.

Press the up arrow key 1. Type 1 in the dialog box and press *Enter*. Press *Enter* once again to accept this point as the beginning of the line segment.

Enter next point of line

Press the left arrow key - to activate the prompt Move Left: How far? Type 5.5 and press - Press - Bress again to accept this point as the end of the line segment.

Repeat this procedure to create horizontal lines at 2.5", 6", 8.5", 14.5", 18.5", and 19" from the bottom.

Press Esc to exit the line drawing mode. This completes the line work needed for the border and title block.

31.02

Adding Text

Now we'll add some text to the title block. Select <u>Start</u> \Rightarrow <u>Annotate</u> \Rightarrow <u>Text Line Entry</u> by typing **TL**, or pressing <u>Att</u><u>S</u>, <u>A</u>, <u>Y</u>, or clicking the <u>Text</u> icon (<u>A</u>) in the <u>Drawing</u> window toolbar.

Enter text position

Click the cursor in the general area that you want to place text. Don't worry about the exact position. You'll probably want to reposition the text after you have completed text entry. The **Text Entry Dialog** box appears:

Text Entry Dialog		×			
<u>T</u> ext height : 10	points	Text <u>D</u> efaults >>			
I hereby certify that this survey was performed by me or under my direct supervision and that I am a duly registered Professional Land Surveyor under the laws of the State of Minnesota.					
John M. Smith		Reg. 99999			
₹		4			
<u>0</u> K	✓ Accept Ret Press Ent to move to ne	er Cancel			

Enter the text in the **Text Entry Dialog**.

Now click **Text Defaults** >>> to set the text properties. The **Set Text Defaults** dialog box appears:

Set Text Defaults		×	
<u>A</u> rial	10	points 💌	
Character <u>w</u> idth	0	Angle 0	
<u>L</u> inespacing	1	Pen	
Text Alignment 🔶 Left 🔷 Center 🔷 Right			
Text Label <u>o</u> rigi	n		
		\diamond 9 6 \diamond 19	
⇒ 2		$5 \diamond 18 \diamond 8$	
	\diamond 11 \diamond 14	4 💠 17	
♦ 1	◇ 4	⇒ 7	
🔷 0 (decimal point)			
<u>I</u> ake Fr	om	Appl <u>y</u>	
ОК	Cancel	<u>H</u> elp	

Select the font name and color, and enter the height of the text, as well as the units of the measurement. Click $\bigcirc K$ and return to the Text Entry Dialog box. Click $\bigcirc K$ again to exit the Text Entry Dialog box and place the text on your drawing.



Repositioning text

31.03

If the text is not positioned correctly you can adjust it now. Click on the text that is out of position. While holding the left mouse button down move the mouse until the text is in the proper position. Release the left mouse button. To place and additional text, repeat the steps in this section.

Grouping the Title Block

When you have completed drawing your title block, you'll want to group the elements into a single object. This will make it easier to move or delete the title block once it has been placed into your drawing.

Select <u>Start</u> [¬]→ <u>Edit</u> [¬]→ <u>Selection Filters</u> by typing SF, or pressing Alt S, E, F. The <u>Selection</u> dialog box will appear:

Selection	×		
Clear	Clos <u>e</u>		
<u>S</u> elect All			
Select by	Polygon		
0 <u>bj</u> ect	<u>N</u> ame		
<u>H</u> atch	Layer		
Filters	∠ All <u>o</u> w All		
 ∠ Lines ∠ Arrows ∠ Arcs ∠ Bitmaps ∠ Text ∠ PolyLines ∠ Points ∠ Data Items ∠ Dims ∠ BlockInserts Current Color Current linetype Current layer 			

Click **Select all**, then click **Close**. All the elements drawn in your title block should now be selected.

Select <u>Start</u> \bigcirc <u>Objects</u> \bigcirc <u>Group into Object</u> by pressing <u>Att</u> \bigcirc , \bigcirc , \bigcirc . The <u>TextInp</u> dialog box will appear but is not needed. Press <u>-Enter</u>.

Saving the Title Block

Select <u>Start</u> **File Save Drawing As** by pressing AttS, F, A, or clicking the Save Drawing icon () in the Drawing window toolbar. The File Save As dialog box will appear:

Filename to Write		? ×
File name: 24x36LS cadsplit.drg customlt.drg demo1.drg demo5.drg lesample.drg oakwoods.drg pentests.drg	Eolders: c:\sightsrv	OK Cancel
Save file as <u>type:</u> CADControl DRG	Dri <u>v</u> es:	Y

In the **File name** entry box, enter a descriptive name for your title block drawing. For example, since this is for a 24"x36" sheet in landscape orientation a good name might be 24x36LS. Verify that the drive and folder is set to your liking, then click **OK** to save your drawing.

3

The file type should always be CADControl DRG.

31.04

Using Your New Title Block

After you have completed a "Sight" Survey job and drawing, you may add a title block as follows:

Press AttS, F, K to access the <u>Start</u> > <u>File</u> > Load Title Block routine. The Title Block Drawing File dialog box appears:

Title Block Drawing File		? ×
File <u>n</u> ame: 24x36ls.drg cadsplit.drg customlt.drg	Folders: c:\sightsrv c:\ sightsrv program utility	OK Cancel
List files of <u>type:</u> *.DRG	Dri <u>v</u> es:	

Select the title block you want to load and click $\bigcirc K$. The drawing will be zoomed to show the whole page and the title block will be drawn on the screen.

31.05

"Sight" 3.0

Section 32 Hatches

This section shows you how hatch patterns are defined so that you can edit existing hatch patterns or create your own.

Hatch patterns are defined in a file called **HATCH.PAT** which resides in your Sight Survey program directory (usually c:\Sightsrv\program\.

You can look at, print out or edit the **HATCH.PAT** file in any text editor such as Windows Notepad. We suggest that before you edit the **HATCH.PAT** file, you make a **backup** of it.


Hatch Pattern Definitions

Below are shown the definitions of four sample hatches in the **HATCH.PAT** file: **line** (parallel horizontal lines), **dash** (dashed lines), **newbrick** (brick hatching), and **triang** (equilateral triangles).

*line,Parallel horizontal lines 10, 0 1, 0, 0, 0, 0, 0, 125 *dash,Dashed lines 10,0 1, 0, 0, 0,0, .125, .125, .125, -.125 *newbrick, Brick or masonry-type surface 10, 0 1, 0, 0, 0, 0, 0, .25 1, 0, 0, 0, .025, 0, .25 5, 1, 90, 0, 025, .25, .25, .225, .275 *triang,Equilateral triangles 10, 0 1, 0, 60, 0,0, .1875, .324759526, .1875, -.1875 1, 0, 120, 0,0, .1875, .324759526, .1875, -.1875 1, 0, 0, -.09375, 162379763, .1875, .324759526, .1875, -.1875




	 These definitions comprise the following information. *hatch name,hatch description scale, rotation pen, line width, angle, x origin, y origin, odd line offset, spacing, on distance, off distance for one line of hatch pen, line width, angle, x origin, y origin, odd line offset, spacing, on distance, off distance for another line of hatch, etc. The information in each description is summarized below, but is best understood by studying the line, dash, brick and triangle examples that follow on the next few pages (see Examples 1, 2, 3 and 4).
Scale	Scale is a scale factor which multiplies the x and y origins, off line offset, and on and off distance measurements to give the final size of the hatch.
Rotation	Rotation is applied to the entire hatch pattern and rotates it by the given angle. The angle is measured anti-clockwise from the 3 o'clock position.
Pen	Pen is the color of an individual line in the hatch pattern. The colors in the Pen Selection Area at the right of the screen are numbered downwards from 0 to 15, so maroon is 0, red is 1, olive is 2 etc.
Line width	Line width is the width of an individual line in the hatch pattern. It is measured in tenths of a millimeter and will be the width of the line on paper, regardless of drawing scale.
Angle	Angle is the angle of an individual line in the hatch pattern. The angle is measured anti-clockwise from the 3 o'clock position.
X origin and Y origin	X origin and Y origin allow individual lines in the hatch pattern to start in different places and therefore to be offset with respect to one another. X and Y origin are measured in millimeters on the final paper plot, regardless of drawing scale.
Odd line offset	Odd line offset allows alternate lines of a hatch to be offset, i.e. like this




It is measured in millimeters on the final paper plot, regardless of drawing scale.

Spacing is the distance between subsequent lines of the hatch. It is measured in millimeters on the final paper plot, regardless of drawing scale.



On distance & Off distance


On distance & Off distance are the lengths of each dash and gap in a dashed line. The off distance is always a negative number. On and off distances are measured in millimeters on the final paper plot, regardless of drawing scale.



Example 1 - Line

Spacing

The line hatch pattern comprises just one line at an **angle** of **0** degrees.









The line is repeated at a **spacing** of **0.125mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **1.25mm**.

No on distance or off distance have been included in the hatch pattern because the line in the hatch is solid, not dashed.

The **dash** hatch pattern comprises just **one** dashed line at an **angle** of **0** degrees.






The line is repeated at a **spacing** of **0.125mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **1.25mm**.




Example 2 - Dash




Each alternate line is **offset** by **0.125**mm. This offset is multiplied by a **scale** of **10**, so the offset is actually **1.25mm**.

Each dash is **0.125mm** long (**on distance**), and the gap between each dash is also **0.125mm** long (**off distance**). Note that the off distance is a negative number (-**0.125**). The on and off distances are multiplied by a **scale** of **10**, so the dashes and gaps are actually **1.25mm** long.

The **newbrick** hatch pattern comprises three lines: two solid lines at 0 degrees...




Example 3 - Newbrick





Line 1 is at an **angle** of **0** degrees.




The line is repeated at a **spacing** of **0.25mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **2.5mm**.

No on distance or off distance have been included in line 1 because it is solid, not dashed.


Line 2

Line 2 is at an **angle** of **0** degrees.




The line is repeated at a **spacing** of **0.25mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **2.5mm**.

Line 2 also has a **Y origin** of **0.025mm**. Multiplied by the **scale** of **10**, this gives an actual Y origin of **0.25mm**. The effect of this origin can be seen if you superimpose lines 1 and 2:



No on distance or off distance have been included in line 2 because it is solid, not dashed.

Line 3 Line 3 is at an **angle** of **90** degrees. It is a different color from lines 1 and 2 (it's **pen** is **5**), and slightly thicker (it's **line width** is **1** tenth of a millimeter).




The line is repeated at a **spacing** of **0.25mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **2.5mm**.



Each alternate line is **offset** by **0.25**mm. This offset is multiplied by a **scale** of **10**, so is actually **2.5mm**.

Each dash is **0.225mm** long (**on distance**), and the gap between each dash is also **0.275mm** long (**off distance**). Note that the off distance is a negative number (-**0.275**). The on and off distances are multiplied by a **scale** of **10**, so the dashes and gaps are actually **2.25** and **2.75mm** long respectively.

Line 3 also has a **Y origin** of **0.025mm**. Multiplied by the scale of **10**, this gives an actual Y origin of **0.25mm**. The effect of this origin can be seen if you superimpose lines 1, 2 and 3:



The **triang** hatch pattern comprises three lines: a dashed line at 60 degrees,

a dashed line at 120 degrees,




and a dashed line at 0 degrees.

_ _ -

Scale

- - $1,\,0,\,0,\,\text{-.09375},.162379763,\,.1875,.324759526,\,.1875,\text{-}$

Example 4 - Triangle



Section 32


Spacing=3.24759526mm On distance=1.875m > Odd line offset=1.875mm Off distance = -1.875 mm


The line is repeated at a **spacing** of **0.324759526mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **3.24759526mm**.

Each alternate line is **offset** by **0.1875mm**. This offset is multiplied by a **scale** of **10**, so the offset is actually **1.875mm**.

Each dash is **0.1875mm** long (**on distance**), and the gap between each dash is also **0.1875mm** long (**off distance**). Note that the off distance is a negative number (-**0.1875**).

The on and off distances are multiplied by a **scale** of **10**, so the dashes and gaps are actually **1.875mm** and **1.875mm** long respectively.






The line is repeated at a **spacing** of **0.324759526mm**. This spacing is multiplied by a **scale** of **10**, so the spacing between subsequent lines is actually **3.24759526mm**.

Each alternate line is **offset** by **0.1875mm**. This offset is multiplied by a **scale** of **10**, so the offset is actually **1.875mm**.

Each dash is **0.1875mm** long (**on distance**), and the gap between each dash is also **0.1875mm** long (**off distance**). Note that the off distance is a negative number (-**0.1875**). The on and off distances are multiplied by a **scale** of **10**, so the dashes and gaps are actually **1.875mm** and **1.875mm** long respectively.

Line 3 also has an X origin of -0.09375mm and a Y origin of 0.162379763mm. Multiplied by the scale of 10, this gives an actual X origin of -0.9375mm and an actual Y origin of 1.62379763mm. The effect of this origin can be seen if you superimpose lines 1, 2 and 3:



876 Hatches

This page intentionally left blank.



Section 33 Line Types

Every time you enter "Sight" Survey, a **LINETYPE.MAC** macro is automatically run. This macro controls the way that different line types appear on the screen and on paper. This chapter shows you how line types are defined so that you can edit existing line types or create your own.

You can define up to 30 line types.

LINETYPE.MAC is stored in the macro sub-directory of your \Sightsrv\Program\ directory. You can look at, print it out or edit it in any text editor such as Windows Notepad. We suggest that before you edit the LINETYPE.MAC file, you make a backup.



The **LINETYPE**. **MAC** file also determines whether **handles** are displayed when you select something.

Lines in the **LINETYPE.MAC** that start with the word **REM** are comments and will be ignored by "Sight" Survey.

Line Type Definitions

Each line in the **LINETYPE.MAC** file that defines a line type starts with the word **SETLINEDASH**. Below are shown the definitions of five sample line types in the **LINETYPE.MAC** file: 1 (Continuous), 2 (Dashed), 3 (Hidden), 4 (Center2) and 5 (Phantom2).

 SETLINEDASH 1 Continuous
 8
 32
 0
 100
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0

These definitions comprise the following information.

SETLINEDASH Line_number Description Plotrepeat Pixrepeat Percstart Perc_on Perc_off Perc_on Perc_off etc.

This information is summarized below, but is best understood by studying the diagrams at the end of this chapter.

- **Line number** Each line is numbered from 1 to 30.
- **Description** The description is matched to DXF or DWG line types when you load or save a DXF or DWG file. For example, when you load a DXF file, the DXF line type "Hidden" is displayed as line type 3.
- **Plotrepeat** This is the distance over which the line type pattern is repeated on your printer or plotter 8mm for line types 1, 2, 4 and 5 and 4mm for line 3.
- **Pixrepeat** This is the distance over which the line type pattern is repeated on the screen 32 pixels for line types 1, 4 and 5; 16 pixels for line type 2 and 8 pixels for line type 3. Pixrepeat must be a factor of 32, e.g. 4, 8, 16 or 32.



Pixels are the little squares that make up the display on your screen. Typically there are 640 pixels across the screen and 480 down it, or 800 pixels across the screen and 600 down it, or 1024 pixels across the screen and 768 down it, depending on screen resolution.

and

Some dashed/dotted line types appear continuous on the screen, although they plot or print correctly on paper. This problem can be overcome by increasing the Pixrepeat.


Percstart, Perc_on and Perc_off

Percstart, perc_on and perc_off show the percentage of **Plotrepeat** or **Pixrepeat** where a line is drawn and where a gap is left. Percstart is always 0. For example, in line type 4:


SETLINEDASH 4 Center2	8 32 0 50 70	80 100 0	0 0	0 0 0
	* * * *	≜ ≜ .		
Plotrepeat				Perc_off
Pixrepeat				$Perc_on$
Percstart				Perc_off
Perc_on				

On paper, a line is drawn between 0 and 50% of the 8mm

Plotrepeat. No line is drawn between 50 and 70%. A line is drawn between 70 and 80%. No line is drawn between 80 and 100%.



On the screen, a line is drawn between 0 and 50% of the 32 pixel **Pixrepeat**. No line is drawn between 50 and 70%. A line is drawn between 70 and 80%. No line is drawn between 80 and 100%.



880 Line Types

This page intentionally left blank.

1

1 Parallel Element · 599 by Spacing · 599 Through a Point · 600 Trimming · 600, 601

3

3 Point Bezier Curves · 813

4

4 Point Bezier Curves · 813

A

AA - Arc-Arc Intersection · 309 AB - Arc-Bearing Intersection · 311 ABACKUP1.DRG · 524 ABACKUP2.DRG · 524 Access Denied Error · 467 Accessing Menus · 25 Accuracy of CAD \cdot 795 Accuracy of Sight Survey · 795 Accurate cursor movement \cdot 497, 502 Activation Number · 38 AD - Arc-Distance Intersection · 313 Add Arrow \cdot 712 Add Balloon · 714 Add End Point Labels · 485 Add/Remove Text Bubble · 715 Adding Custom Lines · 397 Adding Layers · 841 Linestyle · 842 Locked · 842 Magnification · 843 Name · 841 Pen (color) · 842 Visibility · 842

Add-Ins Menu · 449 Collector Connector · 451 Contour It! · 449 LegalEase Write a Legal File · 453 Adjust Margins · 201 Adjust Screen Colors · 414 Adjust Traverse (AT) · 180 AL - Label an Angle · 383 Align · 671 Text · 671 Align Dialogue Box, Examples of Using · 669 Align icon \cdot 480 Alignment · 668 Aligning objects to a grid \cdot 669 Aligning objects with each other \cdot 669 Spacing objects evenly · 669 Alignment, Text · 824 All Colors to Black · 207, 534 Alphanumeric Point Numbers · 156 in Point Ranges · 163 Alter Dimension · 708 Alter Existing Hatch · 719 Angle Label · 383 Measure · 347 of Point Labels · 487 Slope · 175 Slash / or · 175 Text Angle · 824 Angle Code Sets · 164, 409 Hewlett Packard · 164, 409 Simplicity Systems · 164, 409 Angle Codes · 164 Angle Entry Combining Angle Entries and Codes · 165 D.MMSS Format · 163 Grads · 163, 164 Horizontal · 163 Vertical · 163 Angle measurement in CAD Zero point · 796 Angle Output · 408 Angle Setup Config Menu · 408 Angles How measured and displayed · 795 Standard Deviation of · 402

Pg. # < 155 – Quick Start

Pg. 155-474 – COGO Reference Manual

Vertical · 173, 174 Zenith · 173, 174 Angular Dimensions · 685 Extracting information about · 744 Angular Format · 795 Dialogue box · 795 Angular Units · 408 Angular Values Entering in CAD · 797 Annotate Menu · 659 Annotation Bearing · 490 Distance · 490 Annotation to Draw · 800 AO - Traverse Arc with Offsets · 305 AP - Edit Default Descriptions · 254 Application Error Message · 541 AR - Area Printout · 334 Arc Get from Drawing · 371 Arc 3 Point · 589 Arc Center Snap icon · 478 Arc Radius · 590 Arc Station and Offset · 332 Arc Text · 663 Arc-Arc Intersection · 309 Arc-Bearing Intersection · 311 Arc-Distance Intersection · 313 Arcs Deleting part of · 647, 650 Dividing · 647 Extending or shortening \cdot 647 Extracting information about · 743 Joining · 647 Line arc line sequences, parallel · 816 Querying · 752 Splitting · 647 Trimming \cdot 647, 650 Viewing centre points · 800 Area Point to Point · 336 Polygon · 749 Predetermined 2 Lines through a Point · 344 2 Sides Parallel · 339 Line through a Point \cdot 340 Radial Sides · 342 Area Print Out · 334

Area Units · 404 Cuerdas · 404 English · 404 Hectars · 404 Metric · 404 Around a Perimeter · 602 Arrow Add · 712 Arrow Defaults · 832 Length, Width & Units · 833 $Pen \cdot 833$ Style · 833 Arrow style · 826 Arrow units · 827 Arrowheads · 828 Editing · 833 Length, Width & Units · 833 $Pen \cdot 833$ Style · 833 Arrows Editing · 558 Extracting information about · 745 Part of arrow doesn't behave like an arrow · 712 Querying · 753 AS - Arc Station and Offset · 332 ASCII Custom Formats for Coordinate Files · 212 ASCII File Layer · 495 Assigned Elevations · 175, 176, 391 Assigning a name to a point · 233 Assigning a station to a point \cdot 234 Assigning an elevation to a point \cdot 232 Assigning coordinates to a point · 231 Associative Dimensions · 672, 679, 698, 699, 701 Asterisk (Preceding Lines) · 483 Attributes · 614, 778, 779 Displaying · 526 Auto Backup Drawing · 524 AutoCAD AutoCAD Release 13 or 14 · 511 Drawing origin · 512 Drawing scale · 512, 518 Exporting bitmaps to · 518 Exporting fonts to · 517 Exporting line types to \cdot 878 Imported drawings are very slow · 513 Importing attributes from · 513 Importing colors from · 511

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Importing dimensions from · 513 Importing fonts from · 511 Importing line types from \cdot 512, 878 Part of imported drawing is missing · 512 What AutoCAD supports · 511 AutoCAD DWG File · 473 AutoCAD DXF/DWG Conversion · 835 Automatic Point Numbering · 156, 404 Side Shots · 404 Automatic Routine Jumping · 156 Azimuth Direction · 409

B

BA - Bearing-Arc Intersection · 316 Background Color · 800 Backup Your Data · 155 Backups ABACKUP1.DRG · 524 ABACKUP2.DRG · 524 BAK files · 199, 518 BAK Extension · 182, 200, 492, 822 BAK Files · 199, 518 Balance Angles · 269 Balance Traverse · 180 Balloon Add · 714 Balloon Defaults · 834 Add Arrows · 834 Rows of text · 835 Size · 835 BB - Bearing-Bearing Intersection · 318 BC - Best Fit Curve · 308 BD - Bearing-Distance Intersection · 319 Bearing Annotation · 490 Enter Backsight Bearing · 168 Enter Backsight Point · 168 Laver · 495 Reference · 168 Select Using Draw Menu · 167, 370 Bearing-Arc Intersection · 316 Bearing-Bearing Intersection · 318 Bearing-Distance Intersection · 319 Bearings · 795 Combining Angle Entries and Codes · 165 Padding Options · 394

Printed Precision on Drawings · 394 Recalling · 165 Recalling Last Used · 167 Rounded to Nearest Degree · 394 Rounded to Nearest Minute · 394 Begin New Object · 765 Best Fit Curve · 308 Best Fit Line · 287 Bezier Curve · 610 3 Point · 610 4 Point · 610 BF - Best Fit Line · 287 Big Cursor · 801 Bitmaps Appear as hatched rectangles · 529, 802 Displaying · 529, 802 Editing parameters · 558 Exporting to AutoCAD · 518 Extracting information about · 746 Import · 528 Moving behind other elements · 530 Number of pixels · 530 Paste into drawing · 551 Placeholders · 529, 802 Querying · 754 Real world pixel size · 528 Resample mode · 529 saving drawings containing · 199 Saving drawings containing 518, 524, 530, 546 Viewing selected · 802 Bitmaps to Draw · 802 Blank Point Scan · 243 Blink Current Object · 787 Block Inserts Extracting information about · 746 Querying · 754 Block Statistics · 522 Blocks Extracting information about · 741 Bold Text · 494 BP - Blank Point Scan · 243 **Building Location** Draw · 617 Busy Printing · 208, 535 Button Responses · 25 By Layer Layering · 848 Line Type · 483, 848

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Object Color · 482, 848 Selection · 564 Text Color · 493, 849

C

CAD Drawing Scale · 393 Paper Size · 393 Printed Precision · 394 Units · 393 CAD Background Color · 394 CAD Configuration Menu · 392 CAD→COGO · 377 Calculations · 508 in Data Entry · 508 Calculator Pop-up · 360 Using calculated values · 365 Capacity, Point · 21 Cartesian Coordinates · 793 CB - Copy Block of Points · 245 CC - Clear Coordinates · 246 CE - Re-Center Paper · 393 Chained Dimensions · 674 Chamfer · 645 by Distance and Angle · 646 by Two Distances · 647 Change Drawing Background Color · 473 Drawing Entities · 560 Object Colors · 565 Symbol Colors · 474, 566 Change Existing Lines · 811 Change Hook Point · 784 Change Magnify Factor · 810 Change Name · 780 Change Parent · 783 Change Pens in Plotter · 209, 536 Change Text Parameters · 667 Changes from previous versions · 28 Character Width · 823 Check Boxes · 387 Check Registration · 38, 420 Circle · 591 Jump to Center · 730 Circle 2 Point · 593

Circle Center Snap Mode · 808 Circle Diameter · 592 Circles Isometric · 795 Circular Curve · 421 Circular Spline · 607 Clear Coordinates · 246 Clear Drawing Window · 584 Clear Point Names · 247 Clear Point Stations · 248 Clear Selection · 555 Clear Text Output window · 227 Clipboard · 549, 550, 552 Closing a Traverse · 268 CM - CAD Config Menu · 392 CN - Clear Point Names · 247 CO - Curve Offset · 306 COGO Config Menu Least Squares configuration · 402 COGO Configuration Menu · 401 COGO Font · 408 COGO.INI File · 469 Collate Copies · 210 Collector Connector · 451 Color Object (By Layer) · See By Layer Text (By Layer) · See By Layer Color, Background · 800 Colors Adjust Screen · 414 Comma Delimited · 213 Command Line · 476 Comment (for Figures) · 252 Compass Rule adjustment · 270 Component Table · 382 Component Table Layer · 494 Components · See Symbols Config Basic Colors · 414 Check Boxes · 387 Custom Colors · 414 Option Buttons · 387 Response Buttons · 388 Selection Lists · 387 Text Entry Boxes · 388 Text Output Menu · 388 Config Menu · 387 Adjust Screen Colors · 414

Pg. # < 155 – Quick Start

Pg. 155-474 – COGO Reference Manual

Pg. # > 474 - Drawing Window Reference Manual

4/4 = 0000 Kelefeliee

Angle Setup · 408 Angle Code · 409 Angle Output · 408 Angular Units · 408 Azimuth Direction · 409 Default Angle · 408 $CAD \cdot 392$ Background Color · 394 Bearings · 394 CAD Units · 393 Coordinates · 394 Create a Short Line Table · 394 Dimensioning of Short Lines · 394 Distance Symbol · 393, 394 Distances · 394 Drawing Scale · 393 Elevations · 394 Padding Options · 394 Page Center Coordinates · 393 Paper Size / Drawing Scale · 393 Printed Precision · 394 Shrink Text to Fit · 394 Text Output · 394 Check Registration · 38, 420 $COGO \cdot 401$ Area Units · 404 Automatic Point Numbering · 404 Change COGO Font · 408 Constant Factor · 406 Define Figures · 408 Least Squares configuration · 402 Old Style COGO Window · 404 Point Overwrite Protection · 404 Prompting for Point Descriptions · 404 Restore All Default settings · 408 Show Tool Tips · 405 Stations Format · 403 Customize Side Toolbar · 411 Customize Toolbar Button Command · 413 Changing a Button Caption · 412 Command Strings · 413 File Paths · 409 Form Color · 414 General Offsets · 405 Label Color · 414 Show Status Bar · 416

Show Tool Bar · 417 Slope Entry · 390 Assigned Elevations · 391 EDM · 391 EDM (Mining Option) · 391 Leveling · 391 Prompt for Slope Input · 390 Simple Slope Angles · 391 Stadia · 391 Total Stations · 391 Text Color · 414 Text Output Area · 389 Bearings · 389 Coordinates · 389 Elevations · 389 Print Elevations · 389 Print Input Data · 389 Print Point Descriptions · 390 Printed Precision · 389 Printing Options · 389 Configuration Conversion Settings from DXF/DWG · 836 to DXF/DWG · 836 Minimum System · 33 Optional Hardware · 33 Constant Factor · 406 Atmospheric Correction for EDM · 406 Correction for Steel Tape Measurements · 406 Contour It! · 449 Control Bar Font · 800 Conversion Settings from DXF/DWG · 836, 837 to DXF/DWG · 836 Coordinate Display Absolute or polar coordinates · 799, 800 Number of decimas shown in · 795 Coordinate List · 381 Coordinate System · 793 Coordinate Transformation Int'l Feet to Meters · 358 Int'l Feet to US Survey Feet · 359 Meters to Int'l Feet · 357 Meters to US Survey Feet · 356 Rotation Angle & Point Known · 349 Two Points in Each System Known · 352 US Survey Feet to Int'l Feet · 355

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

US Survey Feet to Meters · 354 Coordinate(s) Layer · 494 List Layer · 494 Coordinates Assigning to a point · 231 Cartesian · 793 Comma Delimited File · 213 Displaying · 799, 800 Edit · 159 Entering · 178 Export · 217 Import · 210 ASCII Custom Formats · 212 Merge · 214 Merge Coordinates · 212 Import File Format · 211 Label · 703, 723 Format · 724 Move to · 735 Northern and southern hemisphere · 794 Order in which read \cdot 794 Print · 209 Printed Precision on Drawings · 394 Setting origin · 794 Store · 155 Surveyor · 793 Copy · 224 Drawing command · 549 Copy Block of Points · 245 Copy Job · 220 Copy Selected to a New Layer · 657 Copy to the Clipboard \cdot 180, 229 Copying by Cursor · 557, 568 Copying to the Clipboard · 180 Correcting Entered Data · 179 Adding a Leg · 179, 180, 228 Deleting a Leg · 180, 229 Resizing the Data Presentation Grid · 180 Resizing the Grid · 180, 229 Crandall Rule adjustment · 270 Create a Short Line Table · 394 Cross-Hatches · 865 CS - Clear Point Stations · 248 CTE - Coordinate Transformation Meters to Int'l Feet · 357 CTI - Coordinate Transformation

Int'l Feet to Meters · 358 CTM - Coordinate Transformation Meters to US Survey Feet · 356 CTN - Coordinate Transformation Int'l Feet to US Survey Feet · 359 CTR - Coordinate Transformation Rotation Angle & Point Known · 349 CTS - Coordinate Transformation US Survey Feet to Int'l Feet · 355 CTT - Coordinate Transformation Two Points in Each System Known · 352 CTU - Coordinate Transformation US Survey Feet to Meters · 354 Cubic Spline · 608 Current Color · 561 Layer · 839 LineType · 566 Current Layer · 841, 845 Current Object Blink · 787 Select · 787 Cursor Select cursor (arrow-shaped) · 552 Cursor movement Accurate · 497, 502 Jumps and Snaps · 497 Curvature · 176, 392 Curve Bezier \cdot 610 3 Point · 610 4 Point · 610 Curve by Chord Offsets · 429 Curve by Deflections · 424 Curve by Tangent Offsets · 426 Curve Offset · 306 Curve Table · 379 Curve(s) In Point Strings · 251 Table Layer · 495 Curves Menu · 289 Best Fit Curve · 308 Curve Offset · 306 Inscribe Arc Non-Tangent from the PC · 297 Non-Tangent from the PI with Offsets · 301 Tangent from the PC \cdot 294 Tangent from the PC with Offsets · 298

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Tangent from the PI · 296 Tangent from the PI with Offsets · 300 Inverse Curve · 289 Obtuse Curve · 291 Three Point Curve · 292 Traverse Arc · 303 Traverse Arc with Offsets · 305 Custom Lines · 396, 483 Adding · 397 Deleting · 397 Editing · 397 Examples · 401 Font Name · 400 Font Size \cdot 400 Line Type · 399 Repeat Factor · 399 Rotation · 399 Scale Factor · 398 Trimming \cdot 399 Custom Symbols · 488 Customize Side Toolbar · 411 Customize Toolbar Button Caption · 412 Button Command · 413 Command Strings · 413 CustomLT.Drg File · 484 CustomLT.Mac File · 396 Cut · 224 Drawing command · 548 Cut and Rub · 650 Cut Dimension Line · 707 CW - Clear Text Output window · 227

D

D.MMSS Format · 163 DA - Distance-Arc Intersection · 321 Data Backup · 155 Correcting Entered Data · 180 Dump · 738 Data Entry Window · 185, 186 Data Entry Boxes · 187 Help · 187 Message Window · 187 Title Bar · 187 User Customizable Tool Bar · 187

Pg. # < 155 – Quick Start

rt Pg. 155-474 – COGO Reference Manual

Number to display · 796 Decimal Zero point for angle measurement in CAD · 796 Default Angle · 408 Default Layers Saving in Startup.DRG · 383 Default Settings Configuration · 408 Defaults Dimension · 826 Arrow style · 826 Arrow units · 827 Arrowheads · 828 Text Height · 829 Linefeed · 829 Pen · 829 Style · 830 Witness Gap · 827 Witness Line style · 826 Witness Line units · 827 Witness Overshoot · 827 Witness Pen · 827 Line · 810 Change Existing Lines · 811 Line Color · 811 Line Style · 811 Line Width · 811 Take From · 811 Parallel · 814 Around Existing Perimeter · 815 Close Ends · 818 Draw Fresh · 815 Filleting Corners · 819 Line Arc Line · 816

Data Items

Querying · 754

Viewing · 802

Decimal Places

Extracting information about · 745

DB - Distance-Bearing Intersection · 324

DD - Distance-Distance Intersection · 326

Number shown on dimensions · 828

Number that CAD is accurate to \cdot 795 Number that Sight Survey is accurate to \cdot 795

Decimal Label Placement · 486

Number of angular · 795

Pg. # > 474 – Drawing Window Reference Manual

Offset · 817

Starting/Ending Angles · 819 Polyline · 812, 813 3 Point Bezier Curves · 813 4 Point Bezier Curves · 813 Change Existing Polylines · 814 Closed · 813 Empty, Hatch, Solid Fill · 813 Take From · 814 Text · 820 Character Width · 823 Font Style · 821 Line Spacing · 823 $Pen \cdot 824$ Text Alignment · 824 Text Angle · 824 Text Height · 823 Text Label Origin · 824 Define Figures · 249, 408 Define Zoom View · 576, 577 Defined Figures · 163 Adding · 250 Deleting · 253 Editing · 253 Importing · 216 Naming · 250 Point String · 250 Printing · 253 Toolbar Button · 249 Using · 253 Deflection Inverse · 259 Degree Symbol · 687, 689, 691 Degrees, Minutes and Seconds · 795 Delete Drawing command · 551 Delete Job · 221 Delete Layer · 852 Delete Selected icon · 479 Deleting Part of a dimension witness line · 707 Part of a line or arc \cdot 647, 650 Part of an ellipse · 604 Redundant lines · 755 Trimming · 650, 757 Deleting Custom Lines · 397 Delimiter Character · 213 Demagnify · 580 $Demo \cdot 420$ Demo Version · 20

Description dialog box · 158 Description Layer · 495 Descriptions Prompting for Point · 404 Deselecting Individual primitives / objects · 555 DF - Define Figures Stations · 249 DI - Deflection Inverse · 259 Dimension Alter · 708 Angular · 685 Horizontal · 672 Ordinate · 698 Radial · 694 Slope · 679 at Fixed Angles · 683 Isometric · 683 Parallel Sloping · 681 Survey · 697 Vertical · 679 Dimension an Arc Between Three Points · 692 Dimension an Existing Arc · 690 Dimension Arc · 701 Dimension Defaults · 826 Arrow style · 826 Arrow units · 827 Arrowheads · 828 Surveying Dimensions · 830 Bearing Direction · 832 Format · 831 Orientation · 831 Rounding \cdot 832 Text Height · 829 Linefeed · 829 Pen · 829 Style · 830 Witness Gap · 827 Witness Line style · 826 Witness Line units · 827 Witness Overshoot · 827 Witness Pen · 827 Dimension icon · 480 Dimension Line Cut · 707 **Dimension Properties** Edit · 705 Dimensioning

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Short Lines · 394 Dimensioning Angles · 686 between Three Points · 688 between Two Existing Lines · 686 Dimensioning Arc Lengths · 690 Dimensioning of Short Lines · 493 Dimensions Adding notes to · 676, 681, 687, 689, 691, 693, 701, 705 Associative · 672, 679, 698, 699, 701 Chained · 674 Deleting parts of witness lines · 707 Editing · 558 Editing arrow heads · 705 Editing text and resizing object to fit · See Alter Dimension Editing text without affecting dimensioned object · 676, 681, 687, 689, 691, 693, 701, 705 Editing witness line color · 705 Extracting information about · 744 Free · 674 Isometric · 795 Mechanical style · 673, 677, 828 Number of decimal places shown · 828 Querying · 752 Running · 674 Switching off · 800 Text cramped message \cdot 676, 682 Text disappears · 800, 803 Text drawn as boxes \cdot 801, 803 Text drawn as dots · 803 Tolerances · 705 Directional Entries · 163 Display Resolution · 185 Display Scroll Bars · 802 Distance Annotation · 490 Measure \cdot 346 Recalling · 168 Recalling Last used · 169 Select Using Draw Menu · 170, 369 Distance Entry Horizontal · 168 Distance Symbol · 393, 394 Distance-Arc Intersection · 321 Distance-Bearing Intersection · 324 Distance-Distance Intersection · 326

Distances Printed Precision on Drawings · 394 Standard Deviation of · 402 Distances Layer · 495 Distribution · 669 Horizontal · 670 Vertical · 670 Divide/Extend · 647 Divide/Extend Lines · 647 Dividing Lines or Arcs · 647 DOM · See Drawing Office Manager Double Click Editing · 558 Drag Fields · 213 Dragging · 557, 568 Draw All Hatch · 721 Draw Circle icon · 479 Draw Commands Grids · 507 Jumps · 502 Diagonals · 503 Left, Right, Up, Down · 503 Precision Jumps · 503 to a Polar Location · 504 to a Ratio Distance · 505 to any Point in the Cursor Box \cdot 500 to Exact Coordinates · 504 to the Midpoint of a Line \cdot 500 to the Nearest Circle (or Arc) Center Point · 500 to the Nearest Intersection · 500 to the Nearest Line or Arc \cdot 500 to the Nearest Point · 500 Rotate Icon · 555 Snaps Ortho Snaps · 506 Placing Text · 507 Draw Fresh · 598 Draw Line (chained) icon · 478 Draw Line (pt to pt) icon · 478 Draw Menu · 367, 496, 585 1 Parallel Element · 599 by Spacing · 599 Through a Point · 600 Trimming \cdot 600, 601 Arc 3 Point · 589 Arc Radius · 590 Around a Perimeter · 602 CAD Paper in Landscape Orientation · 385

Pg. 155-474 - COGO Reference Manual

CAD to COGO Get a Line · 373 Get a Point · 375 Get a Point Series · 376 Get an Arc \cdot 371 Circle · 591 Circle 2 Point · 593 Circle Diameter · 592 Circular Spline · 607 Cubic Spline · 608 Draw a Building Location · 617 Ellipse · 603 Angle \cdot 604, 606 Aspect Ratio · 604, 606 Major Axis \cdot 603, 605 Label an Angle · 383 Layer Override · 382 Line (Chained) · 585 Line (Pt to Pt) \cdot 586 Line Arc Line · 595 Parallel Line · 597 Parallel Defaults Draw Fresh · 598 Perimeter Menu Arc · 598 Circle · 598 Line · 597 Rectangle · 597 Perimeter Menu · 597 Part Ellipse · 604 Point · 587 Polygon · 611 Polyline · 610 Quick Pick CAD to COGO · 377 Rectangle · 588 Select Bearing · 167, 370 Select Distance · 170, 369 Select Point · 156, 368 Show Paper Border \cdot 385 Sketch · 615 Snap Modes · 368 Supplemental Component Table · 382 Coordinate List · 381 Curve Table · 379 North Arrow · 381 Scale Bar · 380

Short Line Table · 379 Symbol · 613 Draw Parallel Lines icon · 479 Draw Polyline icon · 479 Draw Rectangle icon · 479 Draw Selected Hatch · 721 Drawing Auto Backup · 524 Background Color · 473 Codes · See Jump Codes Copy command · 549 Cut command · 548 Delete command · 551 Load · 513 $New \cdot 509$ Open · 510 Paste command \cdot 550 Plot Minimum and Maximum Pen · 533 X and Y Offset · 533 Redo a command · 548 Repair · 541 Save · 515 Save As · 515, 542 DWG/DXF conversion · 516, 517 Select command · 552 Undo a command · 547 Drawing Office Manager · 518, 521 Drawing Origin Defining · 794 Moving to bottom left of paper · 794 Drawing Reference Point · 513 Drawing Scale · 393. See Scale Drawing Settings · 789 Drawing Units Area · 798 Changing · 798 Imperial and metric on same drawing · 798 Drawing window · 475 Command Line · 476 Properties Menu button · 481 Scale Bar · 477 Scroll Bars · 476 Start Menu button · 480 Status Bar · 476 Toolbar · 477 Drawing Window · 185 Drawing won't Load · 541

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

DrawingMissing Bitmaps · 510 Drop · 634 Dump Data · 738 DWG Conversion Settings · 836 DWG File · 473 DXF Conversion Settings · 836 DXF File · 473 DXF/DWG Conversion · 835

E

EA - Enter and Assign · 231 Eastings · 794 EB - Enter Backsight Bearing · 238 EC - Edit Coordinates · 225 ED - Enter Diagonal · 272 Edit a Point Description · 159 Edit a Point Name · 159 Edit Coordinates · 159, 225 Edit Default Descriptions · 254 Edit Dimension Properties · 705 Edit Menu · 223, 547 Clear Text Output · 227 Copy · 224 Cut · 224 Edit Coordinates · 225 Edit Original Raw Data · 227 Paste · 225 Undo · 223 Edit Original Raw Data · 227 Edit Text · 664 Edit(ing) COGO.INI · 469 Object Colors · 565 Symbol Colors · 474, 566 Editing Custom Lines · 397 Editing Text · 188 Angle · 824 Character Width · 823 Line Spacing · 823 Pen · 824 Text Alignment · 824 Text Height · 823 Text Label Origin · 824 EDM · 391

EDM (Mining Option) · 391 EDM Reduction · 176 EDM Reduction (Mining Option) · 176 EDM Slope · 175 EDM Slope Distances - Mining Option · 175 EDM Slope Reduction · 431 Element Jump to nearest · 731 Elements · See Primitives Elevation Assigning to a point · 232 Elevations Layer · 495 Printed Precision on Drawings · 394 Ellipse · 603 Angle \cdot 604, 606 Aspect Ratio \cdot 604, 606 Convert to arcs for snipping \cdot 658 Extracting information about · 743 Hatching \cdot 604 Jumping and snapping to · 604 Major Axis · 603, 605 Part · 604 Querying · 752 Snipping part of · 604 Ellipse 2 Arcs · 658 End Point Symbols · See Symbols Enter and Assign · 178, 231 Enter Backsight Bearing · 168, 238 Enter Backsight Point · 168, 237 Enter Diagonal · 272 Enter Elevation · 232 Enter Hatch/Solid Fill · 716 Perimeter Menu · 717 Polyline · 716 Enter Station · 234 ENTER vs. PRESS · 23 Entering Angles in CAD · 797 Entering Coordinates · 178 Entities · See Primitives Entity Query · 751 Entity Statistics · 522 EP - Enter Backsight Point · 237 ER - Edit Original Raw Data · 227 Erasing · See Deleting ES - Enter Station · 234 Execute Macro · 545

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Exit "Sight" Survey \cdot 222 Exit Toolbar Button · 222 Expand · 760 Explode Object · 554 Explode Object · 770 Export Coordinates · 217 Text · 219, 530 Export Text from Text Output Window · 192 Extending Lines · 757 Extending Lines or Arcs · 647 EZ - Enter Elevation · 232

F

FI - Field Data Inverse · 256 Field Data Inverse · 256 FIG Extension · 216 Figures · See Defined Figures File Copy Job · 155 Save Job · 155 File Format Dialog Box · 211 File Menu · 197 Copies, Number of · 203 Copy Job · 220 Delete Job · 221 Drawing Window · 509 Exit "Sight"Survey · 222 Export Coordinates · 217 Text · 219 Export Coordinates File Format Dialog Box · 218 Import Coordinates · 197, 210 Merge Coordinates · 214 Text · 214 Import Coordinates ASCII Custom Formats · 212 Comma Delimited · 213 Delimiter Character · 213 Drag Fields · 213 File Format Dialog Box · 211 Header Lines · 213

Null Entry · 213 Last Used Job List \cdot 222 New Job · 197 Open Job · 197, 198 Plot Drawing Change Pens in Plotter · 209, 536 Fit to Page · 203 Make Arcs from Lines · 207, 534 Plot to Scale · 209 Scale Hatch · 207 Use Plotter Arcs · 207, 534 X and Y Offset · 206 Print Coordinates · 209 Print Dialog Box Collate Copies · 210 Print to File \cdot 210 Print Preview · 201 Print Range · 210 Print Setup · 203 Print Text · 202 Save As · 201 Save Job · 199 File Paths · 409 Fill · 716 Perimeter Menu · 717 Polyline · 716 Fill area with an Island · 718 Fillet · 641 Radius · 644 Single point · 643 Two points · 643 Filters · 561 Fix Drawing (FD) · 541 Floating point error · 474 Font Name in Custom Lines · 400 Font Selection in the Text Output Window · 192 Font Style · 821 Fonts Exporting to AutoCAD · 517 Importing from AutoCAD · 511 On the Control Bar · 800 Plotter · 204, 492, 822 Printer · 492, 822, 823 Screen · 492, 822 Size · 493 Size in Custom Lines · 400 Stroke · 492, 822

Pg. 155-474 - COGO Reference Manual

Text · 491 TrueType · 492, 822 Footers · 191 Form Color · 414 Format Paragraphs in Text Output Window Ruler: · 193 Tabs in Text Output Window · 193 FP Error Message · 541 Free Dimensions · 674 Freehand Cursor icon · 477 Freehand drawing · 616 Freehand Snap Mode · 805, 806

G

Geometric Intersection Snap Mode · 807 Get a Line · 373 Get a Point · 375 Get a Point Series · 376 Get an Arc · 371 Getting Support · 463 Go To · 236 Grab All Cursor Jump to · 727 Grab All Cursor icon · 478 Grab All Snap Mode · 806 Grads Format · 164 Graphic Screen · 467 Grid · 747 Can't jump or snap to · 748 Isometric · 747, 795 Jump · 728 Grid Display Density · 747 Grid Factor · 406 Grid Snap Mode · 807 Group into Object · 767 Grouping Drawing Entities · See Selection Filter Points · See Defined Figures GT - Go To · 236

Η

Handles · 553, 555, 556

Pg. # < 155 – Quick Start

Pg. 155-474 – COGO Reference Manual

Stretching and scaling with \cdot 556 Turning off as default · 555 Hanging Program · 470 Hatch · 564, 716 Alter existing · 719 Convert to lines · 722 Draw All · 721 Draw Selected · 721 Perimeter Menu · 717 Polyline · 716 Hatch area with an Island \cdot 718 Hatch or Solid Fill Dialogue Box · 718 Hatch to Draw · 801 Hatch to Lines · 722 HATCH.PAT · 865 Hatch/Fill icon · 480 Hatches · 865 Patterns Defining · 865 Angle · 866 Line width · 866 Odd line offset · 866 On & Off distance · 867 Pen (color) · 866 Rotation · 866 Scale · 866 Spacing \cdot 867 X & Y Origin · 866 Hatching Disappears · 718, 801 Ellipses · 604 Scaling · 717 Switching off · 801 Viewing selected · 801 Header Lines · 213 Headers · 191 Headers/Footers in Text Output Window · 191 Help Menu · 459 Contents · 459 Current Topic · 459 How to Use Help \cdot 460 Search for Help On · 460 System Information · 460 Serial Number · 461 Hiding Layers · See Layers, Visibility Hook Point · 776 Change · 784

Rotating with · 556

Horizontal Dimension · 672 Horizontal Distance Entry · 168 Horizontal Distribution · 670

Ι

IA - Inscribe Arc Non-Tangent from the PC · 297 Non-Tangent from the PI with Offsets · 301 Tangent from the PC with Offsets · 298 Tangent from the PI with Offsets · 300 IA – Inscribe Arc Tangent from the PC · 294 Tangent from the PI \cdot 296 IC - Inverse Curve · 289 Icon Align · 480 Arc Center Snap · 478 Delete Selected · 479 Dimension · 480 Draw Circle · 479 Draw Line (chained) · 478 Draw Line (pt to pt) \cdot 478 Draw Parallel Lines · 479 Draw Polyline · 479 Draw Rectangle · 479 Freehand Cursor · 477 Grab All Cursor · 478 Hatch/Fill · 480 Intersection Snap · 478 Nearest Element Snap · 478 Pan · 478 Perpendicular Snap · 478 Point Cursor · 477 Polar Move · 478 Refresh Drawing · 479 Save Drawing · 480 Select Cursor · 477 Select Nodes Cursor · 477 Survey Dimension · 480 Tangent Snap · 478 Text Line · 480 Trim · 479 Undo · 479 Zoom · 479 Zoom Window · 479 ID - Identify Point · 233

Identify Point · 158, 233 Illegal Operation Message · 541 Imperial Units On same drawing as metric · 798 Import ASCII File · 472 Bitmap \cdot 528 Coordinates · 197, 210 Defined Figures · 216 Merge Coordinates · 212, 214 Text · 214, 471, 527 Import Coordinates ASCII Custom Formats · 212 Comma Delimited · 213 Delimiter Character · 213 Drag Fields · 213 File Format Dialog Box · 211 Header Lines · 213 Null Entry · 213 Import Supplemental · 488 Importing Text into the drawing · 825 IN - Inverse · 255 In-Line Calculations · 508 In-Line Calculator · 166, 168, 170 Conversion Functions · 173 Logarithmic Functions · 173 Math Functions · 171 Trigonometric Functions · 172 Inscribe Arc Non-Tangent from the PC · 297 Non-Tangent from the PI with Offsets · 301 Tangent from the PC \cdot 294 Tangent from the PC with Offsets · 298 Tangent from the PI · 296 Tangent from the PI with Offsets · 300 Installation · 35 Intellimouse Problems Installing · 35 Internal Precision · 183 Intersection Arc Station and Offset · 332 Arc-Arc · 309 Arc-Bearing · 311 Arc-Distance · 313 Bearing-Arc · 316 Bearing-Bearing · 318 Bearing-Distance · 319 Distance-Arc · 321

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Distance-Bearing · 324 Distance-Distance · 326 Jump to any \cdot 729 Line Station and Offset · 331 Offset · 329 Perpendicular Offset · 328 Intersection Snap icon · 478 Intersection Snap Mode · 807 Invalid Backup Path Message · 525 Invalid Property Value · 469 Inverse · 255 Inverse Curve · 289 Inverse Obtuse Curve · 291 Inverse with Stations · 281 IS - Inverse with Stations · 281 Isometrics Circles · 795 Dimensions · 795 Grid · 747, 795 Italic Text · 494

J

Job Copy · 220 Delete · 221 List Last Used · 222 New · 197 Open · 197, 198 Save · 199 Save As · 201 Join (the Drawing) Window · 584 Join Lines · 648 Joining Lines · 757 Joining Lines or Arcs \cdot 647 Jump Any Intersection · 729 Jump Circle Center · 730 Jump Codes · 497 Jump Grid · 728 Jump Near Element · 731 Jump Point · 730 Jump to Grab All Cursor · 727 Jump to Last Fixed (point) · 732 Jump to Mid Point · 733 Jumps · 502 Diagonals · 503 Difference between jumps and snap modes · 805 Grids · 507 Jumping to ellipses · 604 Left, Right, Up, Down · 503 Precision Jumps · 503 Ratio · 733 to a Polar Location · 504 to a Ratio Distance · 505 to any Point in the Cursor Box · 500 to Exact Coordinates · 504 to the Midpoint of a Line · 500 to the Nearest Circle (or Arc) Center Point · 500 to the Nearest Intersection · 500 to the Nearest Line or Arc · 500 to the Nearest Point · 500 Jumps and Snaps · 497

K

Keyboard Shortcuts · 26 Keyboard, Using the · 24 Keycaps · 24

L

Label an Angle · 383 Label Color · 414 Label Coordinates · 703, 723 Format · 724 Label Type · 484 Coordinates · 485 Description · 485 Elevation · 485 Label, Point · 485 None · 485 Point Number · 485 Pt. # & Elevation · 485 Station · 486 Label(s) Angle for Points · 487 Layer · 495 Offset · 395 Placement (Decimal) · 486 LAN · 467 Landscape · 790 Last Fixed (point) · 732

Pg. # < 155 – Quick Start

Pg. 155-474 – COGO Reference Manual

Last Used Job List · 222 Laver Copy Selected to a New Layer · 657 for Annotation · 659 for Arc · 589, 590 for Building Location · 617 for Circle · 591, 592, 593 for Ellipse · 603, 605 for Line · 585, 586 for Line Arc Line \cdot 595 for Parallel Element · 599 for Parallel Line · 597, 602 for Point · 587 for Polygon · 612 for Polyline · 610 for Rectangle · 588 for Sketch · 615 for Spline \cdot 607, 608 for Symbol · 613 Move Selected to a New Layer · 655 Layer Control · 839 Layer Editing Dialogue Box · 839 Layer Magnification · 840 Layer Name · 840 Layer Override · 382 Layer(s) Add New \cdot 494 ASCII File · 495 Bearings & Distances · 495 Component Table · 494 Coordinate List · 494 Coordinates · 494 Current · 839 Curve & Line Tables · 495 Descriptions · 495 Elevations · 495 Hide/Show · See Layers (Visibility) Line Annotation · 495 Lines · 495 Locked · 839 Name · 470 North Arrow · 494 Point Labels · 495 Point Names · 495 Point Numbers · 495 Points · 495 Pt# & Elevations · 495 Scale Bar · 494

Selecting by · 564 Short Line Table · 495 Stations · 496 Supplemental Table · 495 Symbols · 494 Text Files · 495 To Operate On · 472 Visibility · 473, 839 Layers Adding · 841 Linestyle · 842 Locked · 842 Magnification · 843 Name · 841 Pen (color) \cdot 842 Visibility · 842 Angle Labels (LA) · 845 by Layer · 848 Changing · 843, 844 Copying and pasting between drawings · 551 Current · 841, 845 Default Saving in Startup.DRG · 383 Delete · 852 Deleting · 844 Editing Multiple · 844 Editing Single · 843 Highlighting · 846 Leader Lines & Arrows · 845 Locked · 841 Operating on all unlocked layers · 853 Operating on current layer only · 853 Parallel Lines · 845 Pen and Line Type · 841 Pen and line type by \cdot 841, 848 Set Current · 849 Set Visible · 850 Text Lines (TL) · 845 to Operate On · 847 Visable · 841 Visibility · 846 Working Layers · 853 LC - List Coordinates · 242 Leader Lines & Arrow Layer · 845 Least Squares adjustment · 271 Averaging · 274 Standard Deviations · 278

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Printing · 281 Stationary Points · 276 Traverse adjustment window · 277 Least Squares Adjustment Enter Diagonal · 272 Least Squares configuration · 402 LegalEase · 471 Write a Legal File · 453 Leveling · 177, 391 Levels · 175 LF - LegalEase Write a Legal File · 453 License Fees · 35 Multiple Office Installations · 34 Network Installations · 34 Site \cdot 33 Transportable · 34 Line Get from Drawing · 373 Line (Chained) · 585 Line (Pt to Pt) · 586 Line Arc Line · 595 Parallel · 816 Line Color · 811 Line Defaults · 810 Change Existing Lines · 811 Line Color · 811 Line Style · 811 Line Width · 811 Take From · 811 Line Spacing Text \cdot 823 Line Station and Offset · 331 Line Style · 484, 811 Line Type by Layer · 841, 848 Definitions · 877 Description · 878 Line number · 878 Percstart, perc on and perc off · 878 Pisrepeat \cdot 878 Plotrepeat · 878 Editing · 558 Importing from AutoCAD · 512 Line Type in Custom Lines · 399 Line Types Exporting to AutoCAD · 878

how displayed · 878 how printed \cdot 878 Importing from AutoCAD · 878 Line Width · 484, 811 by pen color · 534 By pen color · 207 Lines Annotation Layer · 495 Asterisk in front · 483 by Layer · 483, 848 Custom · 396, 483 Adding · 397 Deleting · 397 Editing · 397 Cut and Rub · 650 Deleting part of · 647, 650 Deleting redundant · 755 Divide/Extend · 647 Dividing \cdot 647 Extending or shortening \cdot 647, 757 Extracting information about · 742 Join · 648 Joining · 647, 757 Layer · 495 Line arc line sequences, parallel · 816 Querying · 751 Splitting · 647 Table Layer · 495 Text Layer · 495 Trimming · 647, 650, 757 Lines Menu · 255 Best Fit Line · 287 Deflection Inverse · 259 Enter Diagonal · 272 Field Data Inverse · 256 Inverse · 255 Inverse with Stations · 281 Offset · 264 Radial Inverse · 258 Radial Stake Out · 261 Side Shots · 262 Traverse · 265 Traverse Adjustment Balance Angles · 269 Compass Rule · 270 Crandall Rule · 270 Least Squares · 271 Transit Rule · 270

Pg. # < 155 – Quick Start

Pg. 155-474 – COGO Reference Manual

rence Manual Pg.

Traverse Close · 268 Traverse Right of Way · 285 Traverse with Offsets · 267 Traverse with Stations · 283 LINETYPE.MAC · 877 LINETYPE.MAC file · 555 Linetypes · 877 List Coordinates · 242 List Objects · 773 LO - Open Job · 198 Load Drawing · 513 Coordinate system · 513 Load Symbol File · 525 Load Title Block · 545 Loading Problems · 467 Locked Layers · 841 Lock-ups · 251, 470, 471 Long Pan · 581 LS - Line Station and Offset · 331 LV - Layer Override · 382

М

MA - Measure an Angle · 347 Macro Execute · 545 Magnify · 580 Magnify Factor Change · 810 Main Tool Bar · 417 MainCAD caused a General Protection Fault Message · 541 Make Symbol · 774 Mapping Colors to Line Widths · 207, 534 Maximizing a Window · 186 Maximum Pen · 206 MD - Measure a Distance · 346 Measure · 748 Measure a Distance · 346 Measure an Angle \cdot 347 Mechanical Style Dimensions · 673, 677, 828 Memory Virtual · 838 Menu Add-Ins · 449 Annotate · 659 Add Arrow · 712

Add Balloon · 714 Add/Remove Text Bubble · 715 Align \cdot 671 Text · 671 Alter Dimension · 708 Alter Existing Hatch · 719 Angular Dimension · 685 Arc Text · 663 Change Text Parameters · 667 Cut Dimension Line · 707 Dimension Arc · 701 Draw All Hatch · 721 Draw Selected Hatch · 721 Edit Dimension Properties · 705 Edit Text · 664 Enter Hatch/Solid Fill · 716 Perimeter Menu · 717 Polyline \cdot 716 Hatch to Lines · 722 Horizontal Dimension · 672 Label Coordinates · 703, 723 Format · 724 Move Text · 665 Ordinate Dimension · 698 Radial Dimension · 694 Select Text · 666 Set Alignment · 668 Slope Dimension · 679 at Fixed Angles · 683 Isometric · 683 Parallel Sloping · 681 Survey Dimension · 697 Text Line Entry · 659 Placing text at an angle · 662 Vertical Dimension · 679 Config · 387 Check Registration · 38 Curves · 289 Draw · 367, 496 Edit · 223 File · 197 Help · 459 Contents · 459 Current Topic · 459 How to Use Help \cdot 460 Search for Help On · 460 System Information · 460 Serial Number · 461

Pg. # < 155 – Quick Start

Pg. 155-474 – COGO Reference Manual

nce Manual Pg. # > 4/4 - L

Lines · 255 Misc · 309 Objects · 765 Begin New Object · 765 Blink Current Object · 787 Change Hook Point · 784 Change Name · 780 Change Parent · 783 Explode Object · 770 Group into Object · 767 List Objects · 773 Make Symbol · 774 Select Current Object · 787 Show Objects · 771 Update Objects · 785 Points · 231 Settings · 789 Change Magnify Factor · 810 Delete Layer · 852 Dimension Defaults · 826 Arrow style · 826 Arrow units · 827 Arrowheads · 828 Text Height · 829 Linefeed · 829 Pen · 829 Style · 830 Witness Gap · 827 Witness Line style · 826 Witness Line units · 827 Witness Overshoot · 827 Witness Pen · 827 Drawing Settings · 789 DXF/DWG Conversion · 835 Layer Control · 839 Adding Layers · 841 Linestyle · 842 Locked · 842 Magnification · 843 Name · 841 Pen (color) · 842 Visibility · 842 Current Layer · 841 Locked Layers · 841 $Magnification\cdot 840$ Name · 840 Pen and Line Type · 841

Visable Layers · 841 Line Defaults · 810 Change Existing Lines · 811 Line Color · 811 Line Style · 811 Line Width · 811 Take From · 811 Parallel Defaults · 814 Around Existing Perimeter · 815 Close Ends · 818 Draw Fresh · 815 Filleting Corners · 819 Line Arc Line · 816 Offset · 817 Starting/Ending Angles · 819 Polyline Defaults · 812, 813 3 Point Bezier Curves · 813 4 Point Bezier Curves · 813 Change Existing Polylines · 814 Closed · 813 Empty, Hatch, Solid Fill · 813 Take From · 814 Re-Center Paper · 803 Set Arrow Defaults · 832 Length, Width & Units · 833 Pen · 833 Style · 833 Set Balloon Defaults · 834 Add Arrows · 834 Rows of text · 835 Size · 835 Set Current Layer · 849 Set Visible Layer · 850 Snap Mode · 804 Circle Center · 808 Freehand · 805, 806 Geometric Intersection · 807 Grab All · 806 Grid · 807 Intersection · 807 Nearest Line/Arc · 808 Perpendicular · 808 Point · 807 Tangent · 809 Surveying Dimensions · 830 Bearing Direction · 832 Format · 831 Orientation · 831

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Rounding · 832 Text Defaults · 820 Character Width · 823 Font Style · 821 Line Spacing · 823 $Pen \cdot 824$ Text Alignment · 824 Text Angle · 824 Text Height · 823 Text Label Origin · 824 Unit Settings · 797 Area Units · 798 Unit Symbol · 798 View Settings · 799 Virtual Memory · 838 Working Layers · 853 Text Output Distances · 389 Tools · 727 Dump Data · 738 Expand \cdot 760 Grid \cdot 747 Jump Any Intersection · 729 Jump Circle Center · 730 Jump Grid · 728 Jump Near Element · 731 Jump Point · 730 Jump to Grab All Cursor · 727 Last Fixed (point) · 732 Measure · 748 Mid Point Jump · 733 Move to Coordinates · 735 Polar Move · 736 Polygon Area · 749 Query Entity · 751 Ratio Jump · 733 Show Nodes · 737 Tidy Polygons · 754 Utilities · 421 Windows · 455 Cascade · 456 Set User Arrangement · 455 Tile · 456 User Arrangement · 455 Menus Accessing · 25 Depicted in the Manual · 25 Metric Stationing · 403

Metric Units On same drawing as imperial · 798 Microsoft Intellimouse Problems Installing · 35 Mid Point Jump · 733 Minimizing a Window · 186 Minimum Pen \cdot 206 Minimum System Configuration · 33 Mirror Image · 627 Misc Menu · 309 Area Point to Point · 336 Area Print Out · 334 Coordinate Transformation Int'l Feet to Meters · 358 Int'l Feet to US Survey Feet · 359 Meters to Int'l Feet · 357 Meters to US Survey Feet · 356 Rotation Angle & Point Known · 349 Two Points in Each System Known · 352 US Survey Feet to Int'l Feet · 355 US Survey Feet to Meters · 354 Intersection Arc Station and Offset · 332 Arc-Arc · 309 Arc-Bearing · 311 Arc-Distance · 313 Bearing-Arc · 316 Bearing-Bearing · 318 Bearing-Distance · 319 Distance-Arc · 321 Distance-Bearing · 324 Distance-Distance · 326 Line Station and Offset · 331 Offset · 329 Perpendicular Offset · 328 Measure a Distance · 346 Measure an Angle · 347 Pop-up Calculator (PC) · 360 Predetermined Area 2 Lines through a Point · 344 2 Sides Parallel · 339 Line through a Point · 340 Radial Sides · 342 Missing Bitmaps in a drawing · 510 Missing Items on Drawing · 472, 473 Modify Menu · 623 Chamfer · 645

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

by Distance and Angle · 646 by Two Distances · 647 Copy Selected to a New Layer · 657 Cut and Rub · 650 Divide/Extend · 647 $Drop \cdot 634$ Ellipse 2 Arcs · 658 Fillet \cdot 641 Radius · 644 Single point · 643 Two points · 643 Join Lines · 648 Mirror Image · 627 Move · 625 Move Point · 626 Move Selected to a New Layer · 655 Repeat · 631 Polar · 633 Rectangular · 632 Rotate · 636 by Angle · 637 by Keyboard · 637 Scale · 629 by Cursor · 631 by Keyboard · 631 Snip · 653 Stretch · 623 $Trim \cdot 638$ Mouse Clicks · 24 Click · 24 Double-Click · 24 Right Click · 24 Move · 625 Polar · 736 Move Point · 626 Move Selected to a New Layer · 655 Move Text · 665 Move to Back · 570 Move to Coordinates · 735 Move to Front · 569 Moving Dragging with cursor · 557, 568 Nudging · 569 Moving Nodes accurately · 569 Multiple drawing windows \cdot 582 Multiple Parallel Line Defaults Dialogue Box · 814

N

Name Assigning to a point · 233 Change · 780 Names Output · 159 Nearest Element Snap icon · 478 Nearest Line/Arc Snap Mode · 808 Network · 34, 467 New Drawing · 509 New Job · 197 New Job Toolbar Button · 197 New Layer · 494 NJ - New Job · 197 Nodes · 568 Moving · 568 Select · 568 Selecting · 568 Show \cdot 737 Nodes Icon · 555 North Arrow · 381 North Arrow Layer · 494 Northern Hemisphere · 794 Northings · 794 NoTitle Switch · 468, 469 Nudge · 569 Null Entry · 213

0

Object Begin New · 765 Explode · 554, 770 Group into · 767 List · 773 Show · 771 Object Extends off Edge of World Message · 541 Object Too Long Message · 541 Objects Attributes · 526, 778, 779 Changing Color · 565 Color (By Layer) · 482, 848 Disappear · 803 Drawn as boxes · 803 Extracting details · 740 Hook point · 776

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Missing from Drawing · 472, 473 Parent name · 765, 768, 772, 776 Scale · 526 Selecting by Cursor · 554 Snip box \cdot 777 Spacing evenly · 669 Update \cdot 785 Obtuse Curve · 291 OC - Obtuse Curve · 291 Offset · 264 Offset Define Window · 405 Offset Description · 406 Offset Distance Dialog Box · 406 Offset Intersection · 329 Offset(s) Distance Routine (OD) Point Label · 395 Resetting · 395 Offsets · 405 Closing off ends · 818 Traverse with Offsets · 405 OI - Offset Intersection · 329 Old Style COGO Window · 404 Open Drawing · 510 Open Job · 197, 198 Opening Files · 198 Windows 3.1 · 198 Option Buttons · 387 Ordinate Dimension · 698 Orientation of paper · 790 Origin · See Drawing Origin Origin, Text Label · 824 OS - Offset · 264 Overwrite Protection · 157, 212, 404

Р

PA - Area Point to Point · 336 Padding Options · 394 Page Center Coordinates · 393 Pan · 581 Pan icon · 478 Paper Re-Center · 803 Paper Border · 385

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Landscape · 385 Portrait · 385 Paper Orientation Toolbar Button · 385 Paper Size · 393, 790 changing · 790 Changing · 790 Parallel Defaults · 814 Around Existing Perimeter · 815 Close Ends · 818 Draw Fresh · 598, 815 Filleting Corners · 819 Line Arc Line · 816 Offset · 817 Starting/Ending Angles · 819 Parallel Element · 599 by Spacing · 599 Through a Point · 600 Trimming · 600, 601 Parallel Lines · 597 Closing off ends · 818 Layer · 845 Parent Change · 783 Name · 765, 768, 772 Parents Name \cdot 776 Part Ellipse · 604 Paste · 225 Bitmaps · 551 Drawing command · 550 Paths File · 409 PC - Pop-up Calculator · 360 PD2 - Predetermined Area 2 Sides Parallel · 339 PDL - Predetermined Area Line through a Point \cdot 340 PDR - Predetermined Area Radial Sides · 342 PDT - Predetermined Area 2 Lines through a Point · 344 $Pen \cdot 824$ Pen Mapping · 207, 534 Pens by Layer · 841, 848 Editing pen of existing entities · 558 Importing from AutoCAD · 511

Paper Orientation · 385, 790

Mapping to line widths · 207, 534 Plotter Maximum Pen · 206 Minimum Pen · 206 Print all as black · 207, 534 Print very faintly · 207, 534 Perimeter Menu Arc · 598 Circle · 598 Enter Perimeter Auto · 597 Line · 597 Rectangle · 597 Perimeter Menu · 597 Perpendicular Offset Intersection · 328 Perpendicular Snap icon · 478 Perpendicular Snap Mode · 808 PI - Print Input Data · 389 Pixels · 528, 529 Placeholder for Bitmap · 529, 802 Placing text at an angle · 662 Plot · 531 Drawing Minimum and Maximum Pen · 533 X and Y Offset · 533 Plot Drawing Change Pens in Plotter · 209, 536 Fit to Page · 203 Make Arcs from Lines · 207, 534 Plot to Scale · 209 Scale Hatch · 207 Use Plotter Arcs · 207, 534 X and Y Offset \cdot 206 Plot to Fit · 536 Plotter Arcs · 207, 534 from Lines · 534 From Lines · 207 Plotter Fonts · 204, 492, 822 Plug Shameless · 822 PO - Perpendicular Offset Intersection · 328 Point · 587 Extracting information about · 742 Get a Series of Points from Drawing · 376 Get from Drawing · 375 Identify Point · 404 Jump · 730

Querying · 751 Searching for by Name · 160 Select Using Draw Menu · 156, 368 Strings · 163 Style · 801 Point Capacity · 21, 156 Point Cursor icon · 477 Point Description Edit · 159 Point Descriptions Prompting for · 404 Point Identifiers · 155 Point Information Window · 371 Point Name Edit · 159 Point Names · 158 Point Names dialog box · 158 Point Names Output · 159 Point Numbering · 156 Automatic · 156, 404 Side Shots · 404 Semi-Automatic · 156 Using + and - Keys \cdot 156 Using Function Keys · 156 Point Numbers Alphanumeric · 156 Point Overwrite Protection · 157, 212, 244, 404 Point Plot · 239 Point Ranges · 162 Using Alphanumeric Point Numbers · 163 Point Size, Font · 493 Point Snap Mode · 807 Point Style · 801 Points · 248 Alphanumeric · 156 Font Size · 823 Label Angle · 487 Label Offset Distance · 395 Labels Layer · 495 Layer for Dots & Crosses · 495 Name Layer · 495 Number Layer · 495 Ranges · 250 Selecting · 560 Strings · 250 Points Menu · 231 Blank Point Scan · 243 Clear Coordinates · 246

Pg. # < 155 – Quick Start

rt Pg. 155-474 – COGO Reference Manual

Clear Point Names · 247 Clear Point Stations · 248 Copy Block of Points · 245 Define Figures · 249 Edit Default Descriptions · 254 Enter and Assign · 231 Enter Backsight Bearing · 238 Enter Backsight Point · 237 Enter Elevation · 232 Enter Station \cdot 234 Go To · 236 Identify Point · 233 List Coordinates · 242 Point Plot · 239 Renumber Points · 243 Start At · 235 Polar Move · 736 Polar Move icon · 478 Polygon · 558, 611 Polygon Area · 749 Polygons Tidy · 754 Polyline · 610, 813 Change Existing · 814 Closed \cdot 813 Editing style of existing · 558 Empty, Hatch, Solid Fill · 813 Take From · 814 Polyline Defaults · 812, 813 3 Point Bezier Curves · 813 4 Point Bezier Curves · 813 Change Existing Polylines · 814 Closed \cdot 813 Empty, Hatch, Solid Fill · 813 Take From · 814 Polylines Editing style of existing · 811 Extracting information about · 742 Querying · 752 Pop-up Calculator · 360 Using calculated values · 365 Portrait · 790 PP - Point Plot · 239 Precision Area · 389 Bearings · 389 Coordinates · 389 Distances · 389

Elevations · 389 Printed on Drawings Bearings · 394 Bearings, Rounded Off · 394 Coordinates · 394 Data · 394 Distances · 394 Elevations · 394 Stations · 159 Precision Jumps · 503 Precision of internal calculations · 183 Predetermined Area 2 Lines through a Point · 344 2 Sides Parallel · 339 Line through a Point · 340 Radial Sides · 342 Preserve Black (bitmaps) · 529 Preserve White (bitmaps) · 529 Primitives Cannot select individual · 553 Selecting individual · 553 Print · 531 Drawing · 531 Minimum and Maximum Pen · 533 Setup · 540 X and Y Offset · 533 from Text Output Window · 192 Print Coordinates · 209 Print Dialog Box · 210 Collate Copies · 210 Print to File · 210 Print Elevations · 389 Print Input Data · 389 Print Point Descriptions · 390 Print Preview · 201 Print Quality · 203 Print Range · 203, 210 Print Setup · 203, 540, 823 Print Text · 202 Print to File · 210 Printed Precision · 389 Printer Fonts · 492, 822, 823 Printing All colors to black \cdot 207, 534 at a scale other than your drawing scale \cdot 536 Colors print very faintly · 207, 534 Line widths by color \cdot 207, 534 Part of a drawing · 536

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Text prints at wrong orientation · 532 to fit the paper \cdot 536 Printing Options · 389 Process LegalFile · 471 Product Registration · 38 Properties Text Size · 493 Properties Menu button · 481 Properties Window · 185, 481 End Point Symbol · 487 How to Use It \cdot 482 Label Angle · 487 Label Placement · 486 Label Type · 484 Layers · 494 Line Style · 484 Line Type · 483 Line Width · 484 Object Color · 482 Text Bold · 494 Text Color · 493 Text Font · 491 Text Italic · 494 Text Placement · 490 Pt# & Elevation Layer · 495 Purge Redundant Elements · 523, 544

Q

QP - Quick Pick · 377 Query Entity · 751 Quick Pick CAD to COGO · 377 Quick Pick Toolbar Button · 377 Quote Alphanumeric Point Numbers · 156

R

Radial Dimensions · 694 Extracting information about · 745 Radial Inverse · 258 Radial Stake Out · 261 Radius too small · 591 Raster to Vector Conversion Programs · 754 Ratio Jump · 733

Pg. # < 155 – Quick Start

rt Pg. 155-474 – COGO Reference Manual

Raw Data · 181, 182 Correcting · 179 Edit · 227 Read Me Files · 28 Real World Pixel Size · 528 Recall Bearing Window · 166 Recall Distance Window · 168 Recall the Last Used Bearing · 167 Recalling Bearings · 165 Recalling Distances · 168 Recalling Last Used Distance · 169 Re-Center Paper · 393, 803 Rectangle · 588 Redo Drawing command · 548 Redraw · 582 Redraws Very slow · 718 Reference Bearing · 168 Refraction · 176, 392 Refresh Drawing icon · 479 Registration · 420 Remove duplicate entries · 544 Remove unreferenced blocks · 544 Remove unreferenced layers · 544 Renumber Points · 243 Overwrite Protection · 244 Repair Drawing (FD) · 541 Repeat · 631 Polar · 633 Rectangular · 632 Repeat Factor in Custom Lines · 399 Resample Mode (bitmaps) · 529 Reset Offset Distances · 395 Response Buttons · 388 RI - Radial Inverse · 258 Rotate · 636 by Angle · 637 by Keyboard · 637 Rotate Icon · 553, 555 Rotating (Entities) by Cursor · 556 Rotating by Cursor · 556 Rotation Angle of Point Labels · 487 Rotation in Custom Lines · 399 Rounding Errors · 183 Routine Codes · 26 Routine Jumping · 156

RP - Renumber Points · 243 RS - Radial Stake Out · 261 Rubbing Out · See Deleting Ruler Bar Turning on and off \cdot 801 Running Dimensions · 674 RW - Traverse Right of Way · 285

S

SA - Slope Angle Prompting · 391 Save As \cdot 201 Save Drawing · 515 Save Drawing As · 515 DWG/DXF conversion · 516, 517 Save Drawing icon · 480 Save File Toolbar Button · 199 Save Job · 199 Save Job As · 200 Save Settings · 523 SC - Save Coordinates (Job) · 199 Scale · 629, 790 Architectural · 791 by Cursor · 631 by Keyboard · 631 Changing · 793 Different scales on one drawing · 793 Engineering · 791 Metric/Custom · 792 More than one on a drawing \cdot 840 Scale (Incorrect) · 473 Scale Bar · 380, 477 Scale Bar Layer · 494 Scale Factor in Custom Lines · 398 Scale Hatch · 207 Scaling (Entities) by Cursor · 556 Screen Colors Adjust · 414 Screen Fonts · 492, 822 Scroll Bars · 476 Switching on and off \cdot 802 Searching for a Point by Name · 160 Matching Points Window · 161 Wildcard Characters · 161 Select by Hatch Pattern · 564

by Layer · 564 by Name · 563 by Object Type · 563 by Polygon · 558 by Rectangle · 559 by Window · 559 Drawing command · 552 Drawing Entities · 560 Nodes \cdot 568 Using the Nodes cursor · 568 Select Bearing · 167, 168, 370 Select Current Object · 787 Select Cursor · 552 Select Cursor icon · 477 Select Distance · 170, 369 Select Nodes · 555, 568 Select Nodes Cursor icon · 477 Select Normal · 567 Select Point · 156, 368 Select Text · 666 Selecting Can't select individual primitive · 553 Drawing Entities Bearings · 378 Points · 377 Everything within a rectangle · 554 Individual primitives · 553 Objects by Cursor · 554 Selecting Drawing Entities Distances · 378 Selection Filter (SF) · 472 Selection Filter · 549, 560, 561 Selection Lists · 387 Selection set · 553 Selections Clear · 567 Serial Number · 461 Set Alignment · 668 Set Arrow Defaults · 832 Length, Width & Units · 833 Pen · 833 Style · 833 Set Balloon Defaults · 834 Add Arrows · 834 Rows of text · 835 Size · 835 Set Bitmap Parameters · 528

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Set Current Layer · 849 Set Text Defaults Dialogue Box · 820 Set Visible Layer · 850 Settings Drawing · 789 Save · 523 Unit · 797 Area Units · 798 Unit Symbol · 798 View · 799 Shameless Plug · 822 Short Line Table · 379, 493 Short Lines Dimensioning of · 394 Shrink Text to Fit · 394 Table · 394 Table Layer · 495 Shortcuts · 467 Shortening Lines · 757 Shortening Lines or Arcs · 647, 650 Show Arc Centres · 800 Show Coordinates · 799, 800 Show Data Items · 802 Show Nodes · 737 Show Objects · 771 Show Status Bar · 416 Shrink Text to Fit · 394 Side Shots · 262 Side Tool Bar Button Command · 413 Valid Command Strings · 413 Side Toolbar Change Button Caption · 412 Customize · 411 Sight Survey's Main Screen · 185 Simple Slope Angles · 175, 177, 391 Single Quote Alphanumeric Point Numbers · 156 Site License · 33 Sketch · 615 Slash / or · 175 Slash keys / or : To indicate slope distances · 391 Slope Angle \cdot 175 Slash / or · 175 Slope Angle Prompt · 175, 391 Slope Dimension · 679 at Fixed Angles · 683 Isometric · 683

Parallel Sloping · 681 Slope Distance Indicating with a slash keys · 391 Slope Entry · 175, 390 Assigned Elevations · 175, 176 EDM Reduction · 176 EDM Reduction (Mining Option) · 176 EDM Slope · 175 EDM Slope Distances - Mining Option · 175 Levels · 175, 177 Simple Slope Angles · 175, 177 Stadia · 175, 177 Total Station · 175, 178 Slope Input, Prompt for · 390 Slope Type · 175 Slow Drawings · 718 Snap Mode · 804 Circle Center · 808 Freehand · 805, 806 Geometric Intersection · 807 Grab All \cdot 806 Grid · 807 Intersection · 807 Nearest Line/Arc · 808 Perpendicular · 808 Point · 807 Tangent · 809 Snap Modes · 368, 497 Difference between jumps and snap modes · 805 Snapping to ellipses · 604 Snaps Grids · 507 Ortho Snaps · 506 Placing Text · 507 Snip · 653 Snip Box · 777 Software Upgrades & Updates · 466 Southern Hemisphere · 794 Spiral Curve · 436 Splash Screen · 467 Spline Circular · 607 Cubic \cdot 608 Split (the Drawing) Window · 582 Splitting Lines or Arcs · 647 SS - Side Shots · 262 ST - Start At · 235 Stadia · 175, 391

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Stadia Interval Constant · 178, 391, 435 Stadia Reduction · 177, 434 Standard Deviation · 402 of Angles \cdot 402 of Distances · 402 Start At · 235 Start Menu button · 480 Start ℜDraw Menu · 585 1 Parallel Element · 599 by Spacing · 599 Through a Point · 600 Trimming · 600, 601 Arc 3 Point · 589 Arc Radius · 590 Around a Perimeter · 602 Circle · 591 Circle 2 Point · 593 Circle Diameter · 592 Circular Spline · 607 Cubic Spline \cdot 608 Draw a Building Location · 617 Ellipse · 603 Angle · 604, 606 Aspect Ratio · 604, 606 Major Axis · 603, 605 Line (Chained) · 585 Line (Pt to Pt) · 586 Line Arc Line · 595 Parallel Line · 597 Parallel Defaults Draw Fresh · 598 Perimeter Menu Arc · 598 Circle · 598 Enter Perimeter Auto · 597 Line · 597 Rectangle · 597 Perimeter Menu · 597 Part Ellipse · 604 Point · 587 Polygon · 611 Polyline · 610 Rectangle · 588 Sketch · 615 Symbol · 613 Start ⇒Edit Menu · 547

Clear Selection · 555 Clear Selections · 567 Copy · 549 Cut · 548 Delete · 551 Move to Back · 570 Move to Front · 569 Paste · 550 Redo · 548 Select · 552 Select by Polygon · 558 Select Nodes · 555, 568 Select Normal · 567 Selection Filters · 560 Undo · 547 Start[®], File Menu · 509 Execute Macro · 545 Export Text · 530 Import Bitmap · 528 Text \cdot 527 Load Drawing · 513 Load Symbol File · 525 Load Title Block · 545 New Drawing · 509 Open Drawing · 510 Print · 531 Print Setup · 540 Purge Redundant Elements · 544 Repair Drawing File · 541 Save As \cdot 542 Save Drawing · 515 Save Drawing As · 515 DWG/DXF conversion · 516, 517 Save Settings · 523 Zoom Print · 536 Start Nodify Menu · 623 Add Arrow · 712 Add Balloon · 714 Add/Remove Text Bubble · 715 Align \cdot 671 Text · 671 Alter Dimension · 708 Alter Existing Hatch · 719 Angular Dimension · 685 Annotate · 659 Arc Text · 663

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Edit Text · 664 Text Line Entry · 659 Placing text at an angle \cdot 662 Chamfer · 645 by Distance and Angle · 646 by Two Distances · 647 Change Text Parameters · 667 Copy Selected to a New Layer · 657 Cut and Rub · 650 Cut Dimension Line · 707 Dimension Arc · 701 Divide/Extend · 647 Draw All Hatch · 721 Draw Selected Hatch · 721 Drop · 634 Edit Dimension Properties · 705 Ellipse 2 Arcs · 658 Enter Hatch/Solid Fill · 716 Perimeter Menu · 717 Polyline \cdot 716 Fillet · 641 Radius · 644 Single point · 643 Two points · 643 Hatch to Lines · 722 Horizontal Dimension · 672 Join Lines · 648 Label Coordinates · 703, 723 Format · 724 Mirror Image · 627 Move · 625 Move Point · 626 Move Selected to a New Layer · 655 Move Text · 665 Ordinate Dimension · 698 Radial Dimension · 694 Repeat · 631 Polar · 633 Rectangular \cdot 632 Rotate · 636 by Angle · 637 by Keyboard · 637 Scale · 629 by Cursor · 631 by Keyboard · 631 Select Text · 666 Set Alignment · 668 Slope Dimension · 679

at Fixed Angles · 683 Isometric · 683 Parallel Sloping · 681 Snip · 653 Stretch · 623 Survey Dimension · 697 Trim · 638 Vertical Dimension · 679 Start Nobjects Menu · 765 Begin New Object · 765 Blink Current Object · 787 Change Hook Point · 784 Change Name · 780 Change Parent · 783 Explode Object · 770 Explode Objects · 554 Group into Object · 767 List Objects · 773 Make Symbol · 774 Select Current Object · 787 Show Objects · 771 Update Objects · 785 Start ℜ Settings Menu · 789 Change Magnify Factor · 810 Delete Layer · 852 Dimension Defaults · 826 Arrow style · 826 Arrow units · 827 Arrowheads · 828 Text Height · 829 Linefeed · 829 Pen · 829 Style · 830 Witness Gap · 827 Witness Line style · 826 Witness Line units · 827 Witness Overshoot · 827 Witness Pen · 827 Drawing Settings · 789 DXF/DWG Conversion · 835 Layer Control · 839 Adding Layers · 841 Linestyle \cdot 842 Locked · 842 Magnification · 843 Name · 841 Pen (color) · 842

Pg. # < 155 – Quick Start

Pg. 155-474 - COGO Reference Manual

Visibility · 842 Current Layer · 841 Locked Layers · 841 Magnification · 840 Name · 840 Pen and Line Type \cdot 841 Visable Layers · 841 Line Defaults · 810 Change Existing Lines · 811 Line Color · 811 Line Style · 811 Line Width · 811 Take From · 811 Parallel Defaults · 814 Around Existing Perimeter · 815 Close Ends · 818 Draw Fresh · 815 Filleting Corners · 819 Line Arc Line · 816 Offset · 817 Starting/Ending Angles · 819 Polyline Defaults · 812, 813 3 Point Bezier Curves · 813 4 Point Bezier Curves · 813 Change Existing Polylines · 814 $Closed\cdot 813$ Empty, Hatch, Solid Fill · 813 Take From · 814 Re-Center Paper · 803 Set Arrow Defaults · 832 Length, Width & Units · 833 Pen · 833 Style · 833 Set Balloon Defaults · 834 Add Arrows · 834 Rows of text · 835 Size · 835 Set Current Layer · 849 Set Visible Layer · 850 Snap Mode · 804 Circle Center · 808 Freehand \cdot 805, 806 Geometric Intersection · 807 Grab All · 806 Grid · 807 Intersection · 807 Nearest Line/Arc · 808 Perpendicular · 808

Point · 807 Tangent · 809 Surveying Dimensions · 830 Bearing Direction · 832 Format · 831 Orientation · 831 Rounding \cdot 832 Text Defaults · 820 Character Width \cdot 823 Font Style · 821 Line Spacing · 823 Pen · 824 Text Alignment · 824 Text Angle · 824 Text Height · 823 Text Label Origin · 824 Unit Settings · 797 Area Units · 798 Unit Symbol · 798 View Settings · 799 Virtual Memory · 838 Working Layers · 853 Start Tools Menu · 727 Dump Data · 738 Expand · 760 Grid \cdot 747 Jump Any Intersection · 729 Jump Circle Center · 730 Jump Grid \cdot 728 Jump Near Element · 731 Jump Point · 730 Jump to Grab All Cursor · 727 Last Fixed (point) · 732 Measure \cdot 748 Mid Point Jump · 733 Move to Coordinates · 735 Polar Move · 736 Polygon Area · 749 Query Entity · 751 Ratio Jump · 733 Show Nodes · 737 Tidy Polygons · 754 Start [®]View Menu · 571 Clear Drawing Window · 584 Demagnify · 580 Join Window · 584 Long Pan · 581 Magnify · 580

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Pan · 581 Redraw · 582 Split Window · 582 Zoom All · 573 Zoom Last · 572 Zoom Next · 573 Zoom Scaled · 574 Zoom Selected · 575 Zoom Sheet · 574 Zoom View · 576 Define · 576, 577 Zoom Window · 571 Starting "Sight" Survey Windows 3.1 · 36 Windows 95/98/NT · 37 Starting "Sight" Survey · 36 Startup Problems · 467 Startup Tips · 404 Station Assigning to a point · 234 Numbers · 155 Station Layer · 496 Stationing Metric Format · 403 US Format · 403 Stations · 159, 248 English Units · 160 Format of · 403 Metric Units · 160 Precision · 159 Statistics Block · 522 Entity · 522 Status Bar · 416, 476 Store Coordinates · 155 Stretch · 623 Stretching by Cursor · 556 Stroke Fonts · 492, 822 Supplemental Table Layer · 495 Support · 463 Plans · 464 Survey Dimension · 697 Survey Dimension icon · 480 Surveying Dimensions · 830 Bearing Direction · 832 Format · 831 Orientation · 831 Rounding · 832

Surveyor Coordinates · 793 Surveyor Settings Dialogue Box · 794 SY - Exit "Sight"Survey · 222 Symbol · 613 Symbol File Load · 525 Symbols Add Symbols Icon · 487 Attributes · 614 Changing Color · 474, 566 Custom · 488 Layer · 494 Make · 774 Placing · 487 Rotation · 614 Scale · 526, 614 Selecting \cdot 562 Snip around · 614 Trimming · 490 System Information · 188 System Resources · 416, 476 SYSTEM.INI File · 469

T

TA - Traverse Arc · 303 Table Curve · 379 Short Line · 379, 493 Tables Layer · 495 Tabs in Text Output Window · 193 Take From · 811 Tangent Snap icon · 478 Tangent Snap Mode · 809 TC - Traverse Close · 268 Technical Support · 463 Plans · 464 Text Align \cdot 671 ASCII File Layer · 495 at top of screen is too big or small · 800 Bold · 494 Changing style of existing text · 825 Color (By Layer) · 493, 849 Color (in Custom Lines) · 400 Disappears · 800, 803

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Displayed as Boxes · 473 Drawn as boxes · 801, 803 Drawn as dots · 803 Editing · 558, 662 Export · 219 Export File · 530 Extracting information about · 743 Import File · 214, 527 Importing into the drawing · 825 Italic · 494 Matching the style of existing text · 825, 833 Offset Distance · 394 Placed in Custom Lines · 397 Placing text using Ortho snaps · 507 Prints at wrong orientation · 532 Querying · 752 Switching off · 800 Text Alignment · 824 Text Angle · 824 Text Balloon · 714 Text Bubble Add/Remove · 715 Text Color · 414 Text Cramped Message · 676, 682 Text Defaults · 820 Character Width · 823 Font Style · 821 Line Spacing · 823 Pen · 824 Text Alignment · 824 Text Angle · 824 Text Height · 823 Text Label Origin · 824 Text Entry Boxes · 388 Text Entry Dialogue Box · 661 Text Font · 491 Text Height · 823 Dimensions · 829 Points · 823 Text Label Origin · 824 Text Line Entry · 659 Placing text at an angle \cdot 662 Text Line icon · 480 Text Linefeed Dimensions · 829 Text Output Config Menu · 388 Text Output Window · 185, 188 Editing Menu · 189

Copy · 190 Cut · 190 Delete Selected · 190 Field Markers · 191 Headers/ Footers Field Markers · 191 Insert Page Break · 190 Paste · 190 Select All · 190 Undo · 190 View Headers/Footers · 191 Editing Text · 188 Export Text · 192 Help · 196 Icon Bar · 194 Font Name · 194 Font Size · 194 Formatting Characters · 195 Justification · 194 Line Spacing · 195 Subscript · 195 Superscript · 195 Tab Selection · 195 Text Attribute · 195 Text Color Button \cdot 195 Moving the Cursor · 188 Paragraph Dialog Box · 193 Print · 192 Print Preview · 192 Ruler · 193 Format Paragraphs · 193 Set Tabs · 193 Select a Line · 189 Select a Paragraph · 189 Select a Word · 189 Select Everything · 189 Select everything from the Cursor Point · 189 Select Font for Selected · 192 Select Global Font · 192 Status Line · 191, 195 **Text Parameters** Change · 667 Text Pen Dimensions · 829 Text Placement · 490 Text Size · 493 Text Style Dimensions · 830

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Thin Pixels (bitmaps) · 529 Three Point Curve · 292 Tidy Boundary · 755 Tidy Clips · 759 Tidy Polygons · 754, 765 Tidy Snaps · 757 Tip of the Day \cdot 404 Tips · 467 Title Blocks · 855 Drawing internal title block lines · 859 Drawing Lines · 855 Drawing the border \cdot 857 Grouping elements · 862 Line properties · 857 $Load \cdot 545$ Paper Orientation · 855 Paper Size · 856 Saving the title block \cdot 863 Scale · 856 Set up page information \cdot 856 Text Adding · 860 Repositioning · 862 Using the title block \cdot 864 TO - Traverse with Offsets · 267 Tolerances · 705 Tool Bar · 417 Main · 417 Side Button Command · 413 Valid Command Strings · 413 Tool Tips · 405 Toolbar Side Change Button Caption · 412 Toolbar Button Exit · 222 New Job · 197 Paper Orientation · 385 Quick Pick · 377 Save File · 199 Tools Menu · 727 Topo Plots · 486 Total Station · 175, 178 Total Stations · 391 TP - Three Point Curve · 292 TR - Traverse · 265 Transformation

Coordinates Int'l Feet to Meters · 358 Int'l Feet to US Survey Feet · 359 Meters to Int'l Feet · 357 Meters to US Survey Feet · 356 Rotation Angle & Point Known · 349 Two Points in Each System Known · 352 US Survey Feet to Int'l Feet · 355 US Survey Feet to Meters · 354 Transit Rule adjustment · 270 Traverse · 265 Adjustment (AT) · 180 Traverse Adjustment Balance Angles · 269 Compass Rule · 270 Crandall Rule · 270 Least Squares · 271 Transit Rule · 270 Traverse Arc · 303 Traverse Arc with Offsets · 305 Traverse Close · 268 Traverse Right of Way · 285 Traverse with Offsets · 267 Traverse with Stations · 283 $Trim \cdot 638$ Trim icon · 479 Trimming · 650, 757 Trimming in Custom Lines · 399 Trimming Under Symbols · 490 Troubleshooting · 467 TrueType Fonts · 492, 822 TS - Traverse with Stations · 283 Two Letter Routine Codes · 26

U

Undo · 223 Drawing command · 547 Undo icon · 479 Unhiding Layers · See Layers, Visibility Un-Installing "Sight" Survey · 39 Unit Settings · 797 Area Units · 798 Unit Symbol · 798 Units of Measure Area · 798 Changing · 798

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Imperial and metric on same drawing \cdot 798 Universal Triangle · 446 Update Objects · 785 Updates Program · 466 Upgrade Activation Number · 38 Upgrades Program · 466 Upgrading · 420 Utilities Menu · 421 Circular Curve · 421 Curve by Chord Offsets \cdot 429 Curve by Deflections · 424 Curve by Tangent Offsets · 426 EDM Slope Reduction · 431 Spiral Curve · 436 Stadia Reduction · 434 Universal Triangle · 446 Vertical Alignment · 440

V

Version Demo · 20, 38 Upgrade Activation Number · 38 Fully Functional · 20 How to Upgrade · 21 Vertical Alignment · 440 Vertical Angles · 173, 174 Vertical Dimension · 679 Vertical Distribution · 670 View Menu · 571 Clear Drawing Window · 584 Define Zoom View · 577 Demagnify · 580 Join Window · 584 Long Pan · 581 Magnify · 580 Pan · 581 $Redraw\cdot 582$ Split Window · 582 Zoom All · 573 Zoom Last · 572 Zoom Next · 573 Zoom Scaled · 574 Zoom Selected · 575 Zoom Sheet · 574

X

X and Y Offset, Plotting Drawing · 206

Y

YES or NO Responses · 24

Ζ

ZAK Extension · 201

Pg. # < 155 -Quick Start

Pg. 155-474 - COGO Reference Manual

Pg. # > 474 – Drawing Window Reference Manual

Zoom View · 576 Zoom Window · 571 View Settings · 799 Virtual Memory · 838 Visable Layers · 841 VShare Device · 469

W

Wildcard Characters, in Point Name Search · 161 Window Data Entry · 185, 186 Drawing · 185 Maximizing · 186 Minimizing · 186 Properties · 185 Text Output · 185 Windows Control Panel · 823 Windows Font Dialog Box · 491 Windows Menu · 455 Cascade · 456 Set User Arrangement · 455 Tile · 456 User Arrangement · 455 Witness Gap · 827 Witness Line style · 826 Witness Line units · 827 Witness Overshoot · 827 Witness Pen · 827 Working Layers · 853

ZBK Extension · 201 Zenith Angles · 173, 174 Zoom All · 573 Zoom icon · 479 Zoom Last \cdot 572 Zoom Next · 573 Zoom Print · 536

Zoom Scaled \cdot 574 Zoom Selected \cdot 575 Zoom Sheet \cdot 574 Zoom View · 576 Define · 576, 577 Zoom Window · 571 Zoom Window icon · 479

Pg. # < 155 – Quick Start Pg. 155-474 – COGO Reference Manual